AIRWORTHINESS DIRECTIVE SUMMARY SUBJECT INDEX

SMALL AIRCRAFT

JANUARY 2007

(Also see applicable rotorcraft, engine, propeller and appliance notes)

* * * * * * * * * *

We will no longer include the Book number or Biweekly number in the index.

The indexes, which are published twice a year, are intended to be used as a guide only and should not be relied upon as conclusive evidence of AD applicability. Aircraft operators, inspectors, and persons performing maintenance are reminded of their responsibility under Sections 39.3, 43.11, and 43.13 of the Federal Aviation Regulations, respectively, to assure compliance with all applicable AD's.

* * * * * * * * * *

SMALL AIRCRAFT MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AERMACCHI S.P.A						
(Formerly AGUSTA S.p.A., SIAI MARCHETTI S.p.A.)						
(For ADs in Bk 1 See SIAI Marchetti and Agusta S.P.A. for AD's in Book 2)						
(For Models F260, SF260 in Bk 2 see SIAI)						
S.205 Series	A9EU	66-29-03		Rear spar web	Bk	1
		72-03-02		Wing front spar attachment	Bk	1
		72-14-02		Fuel or fumes in wings or cabin	Bk	1
		73-11-07		Frayed aileron control cables	Bk	1
		73-11-08		Landing gear link pins and bolts	Bk	1
		76-09-06		Aileron control	Bk	1
		84-16-02		MLG long arm cross-member insp	Bk	2
S.205-18/F	A9EU	71-17-04	R1	Cracks in main gear axle	Bk	1
		75-17-23	R2	Landing gear operating mech.	Bk	1
		75-22-18		Nose landing gear	Bk	1
		83-08-07		Propeller control	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3
S.205-18/R	A9EU	71-17-04	R1	Cracks in main gear axle	Bk	1
		72-16-04		Cracks in nose gear drag link	Bk	1
		73-11-04		Main landing gear eye bolt seizure	Bk	1
		75-17-23	R2	Landing gear operating mech.	Bk	1
		75-17-24		Landing gear actuator brackets	Bk	1
		75-22-20		Landing gear	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		83-08-07		Propeller control	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3
S.205-20/F	A9EU	71-17-04	R1	Cracks in main gear axle	Bk	1
		75-17-23	R2	Landing gear operating mech.	Bk	1
		75-22-18		Nose landing gear	Bk	1
		83-07-10		Butterfly valve attachment	Bk	2
		83-08-07		Propeller control	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S.205-20/R	A9EU	71-17-04	R1	Cracks in main gear axle	Bk	1
		72-16-04		Cracks in nose gear drag link	Bk	1
		73-11-04		Main landing gear eye bolt seizure	Bk	1
		75-17-23	R2	Landing gear operating mech.	Bk	1
		75-17-24		Landing gear actuator brackets	Bk	1
		75-22-20		Landing gear	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		83-07-10		Butterfly valve attachment	Bk	2
		83-08-07		Propeller control	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3
S.205/22R	A9EU	68-08-06		Nose gear brace	Bk	1
		68-12-01		Sealant at firewall and nose wheel	Bk	1
		68-16-02		Gear position indicator switch	Bk	1
		68-19-01		Suction gage markings	Bk	1
		68-19-02		Cracks in lower fuselage	Bk	1
		69-19-07		Engine and elevator controls	Bk	1
		70-20-01		Flap locking mechanism	Bk	1
		71-17-04	R1	Cracks in main gear axle	Bk	1
		72-16-04		Cracks in nose gear drag link	Bk	1
		73-11-04		Main landing gear eye bolt seizure	Bk	1
		75-17-23	R2	Landing gear operating mech.	Bk	1
		75-17-24		Landing gear actuator brackets	Bk	1
		75-22-20		Landing gear	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		83-07-20		Exhaust system	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3
S.208 Series	A9EU	72-03-02		Wing front spar attachment	Bk	1
		72-14-02		Fuel or fumes in wings or cabin	Bk	1
		73-11-07		Frayed aileron control cables	Bk	1
		75-17-24		Landing gear actuator brackets	Bk	1
		75-22-20		Landing gear	Bk	1
		76-09-06		Aileron control	Bk	1
		84-16-02		MLG longarm cross-member insp	Bk	2
S.208	A9EU	71-17-04	R1	Cracks in main gear axle	Bk	1
		75-17-23	R2	Landing gear operating mechanism	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		83-08-07		Propeller control	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-04		Landing gear rod springs	Bk	3
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3
S.208A Series	A9EU	84-16-02		MLG longarm cross-member insp.	Bk	2
S.208A	A9EU	71-17-04	R1	Cracks in main gear axle	Bk	1
		75-17-23	R2	Landing gear operating mech.	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		83-08-07		Propeller control	Bk	2
		83-23-02	R1	Flap hinges attach brackets	Bk	2
		98-08-04		Landing gear rod springs	Bk	3
		98-08-06		Flight control cables	Bk	3
		98-12-14		Inspect flap cable pulley bracket	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
F.260	A10EU	75-17-06		Emergency landing gear control	Bk	1
		75-17-19		Landing gear	Bk	1
		75-21-01		Landing gear	Bk	1
		75-22-19		Main landing gear	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		77-14-18		Airplane control	Bk	1
		83-06-05	R1	Nose-gear barrel	Bk	2
		83-06-10		Prop. governor relief valve	Bk	2
		83-08-07		Propeller control	Bk	2
		98-13-09		Airspeed indicator	Bk	3
F.260B	A10EU	75-17-06		Emergency landing gear control	Bk	1
		75-21-01		Landing gear	Bk	1
		75-22-19		Main landing gear	Bk	1
		76-23-01		Landing gear control switch	Bk	1
		77-14-18		Airplane control	Bk	1
		83-06-05	R1	Nose-gear barrel	Bk	2
		83-06-10		Prop. governor relief valve	Bk	2
		83-08-07		Propeller control	Bk	2
		98-13-09		Airspeed indicator	Bk	3
F.260C	A10EU	83-06-05	R1	Nose-gear barrel	Bk	2
		83-06-10		Prop. governor relief valve	Bk	2
		98-13-09		Airspeed indicator	Bk	3
F.260D	A10EU	98-13-09		Airspeed indicator	Bk	3
SF260	A10EU	83-06-05	R1	Nose-gear barrel	Bk	2

AERO COMMANDER (North American Rockwell Corp.)
(See AIRPLANE SERVICES, AYRES, AIRCRAFT PARTS & DEVELOPMENT CORP., GULFSTREAM AMERICAN)

AERONAUTICA MACCHI, S.P.A.

AL60	7A12	63-07-02		Engine exhaust manifold	Bk	1
		64-04-04		Fuel selector valve	Bk	1
		65-28-03		Elevator center hinge eyebolt	Bk	1
		76-07-14		Engine mounting plates	Bk	1
		83-07-13		Engine mount structure	Bk	2
AL60-B	7A12	63-07-02		Engine exhaust manifold	Bk	1
		64-04-04		Fuel selector valve	Bk	1
		65-28-03		Elevator center hinge eyebolt	Bk	1
		76-07-14		Engine mounting plates	Bk	1
		83-07-13		Engine mount structure	Bk	2

AERONCA INCORPORATED
(See BELLANCA (MN), F.R.A. ENTERPRISES)

65-CA, S-65-CA (Aeronca)	A-675	47-30-08		Seat modification	Bk	1
65-LA (Aeronca)	A-702	47-30-08		Seat modification	Bk	1
15AC	A-802	48-38-01		Oil cooler installation	Bk	1
		48-43-02		Continental C-145-2 engines	Bk	1
		61-16-01		Lift strut fittings	Bk	1
		68-20-05		Fuel tank inspection	Bk	1
S15AC	A-802	48-38-01		Oil cooler installation	Bk	1
		61-16-01		Lift strut fittings	Bk	1
		68-20-05		Fuel tank inspection	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AEROSPACE TECHNOLOGIES OF AUSTRALIA PTY LTD (Formerly Government Aircraft Factories)						
N22 Series	A7PC	81-11-01		Emergency exit door	Bk	2
		97-10-10		Upper fin/horizontal stabilizer fittings	Bk	3
N22B	A7PC	80-11-10		Hot air check valve	Bk	2
		80-12-06		Replace structural rivets	Bk	2
		80-12-09		Rudder trim tab control	Bk	2
		80-12-12		Trim tab hinge	Bk	2
		80-13-07		Aileron control	Bk	2
		80-17-01		Rudder control torque shaft	Bk	2
		81-01-02	R1	Fuel valves	Bk	2
		81-07-01	R1	Horizontal stabilizer mod	Bk	2
		81-08-03		Horizontal stabilizer structure	Bk	2
		82-16-11		Instln of horizontal stabilizer	Bk	2
		85-21-05		Emergency exit door trim	Bk	2
		86-16-01		Sidewall structure & rudder pedals mod.	Bk	2
		91-02-08		Airplane electrical system	Bk	3
		96-23-18		Fuselage stub fin plate	Bk	3
		96-24-04		Inspect tailplane stabilizer	Bk	3
		96-24-05		Inspect flap and aileron control rod fork ends	Bk	3
		97-09-08		Pilot/co-pilot control wheels	Bk	3
		97-11-11		Horizontal stabilizer	Bk	3
		97-11-12		Front spar	Bk	3
		97-24-05		Inspect aft wing break connectors	Bk	3
		98-04-18		AFM - Limitations Section - icing	Bk	3
		2000-02-28		AFM – Ice protection systems	Bk	4
		2003-14-20		Rudder control system	Bk	4
		2003-22-13		Ailerons	Bk	4
		2004-05-02		Wing strut fittings and stub wing spar assy	Bk	4
		2004-06-10		Rivet heads on rear bulkhead frame	Bk	4
		2005-10-24		Rudder control lever shafts	BW 05-11	
		2006-21-12				
N24 Series	A7PC	81-11-01		Emergency exit door	Bk	2
		97-10-10		Upper fin/horizontal stabilizer fittings	Bk	3
N24A	A7PC	80-11-10		Hot air check valve	Bk	2
		80-12-06		Replace structural rivets	Bk	2
		80-12-09		Rudder trim tab control	Bk	2
		80-12-12		Trim tab hinge	Bk	2
		80-13-07		Aileron control	Bk	2
		80-17-01		Rudder control torque shaft	Bk	2
		81-01-02	R1	Fuel valves	Bk	2
		81-07-01	R1	Horizontal stabilizer mod	Bk	2
		81-08-03		Horizontal stabilizer structure	Bk	2
		83-09-01		Placard on instrument panel	Bk	2
		85-21-05		Emergency exit door trim	Bk	2
		86-16-01		Sidewall structure & rudder pedals mod.	Bk	2
		91-02-08		Airplane electrical system	Bk	3
		96-23-18		Fuselage stub fin plate	Bk	3
		96-24-04		Inspect tailplane stabilizer	Bk	3
		96-24-05		Inspect flap and aileron control rod fork ends	Bk	3
		97-09-08		Pilot/co-pilot control wheels	Bk	3
		97-11-11		Horizontal stabilizer	Bk	3
		97-11-12		Front spar	Bk	3
		97-24-05		Inspect aft wing break connectors	Bk	3
		98-04-18		AFM - Limitations Section - icing	Bk	3
		2000-02-28		AFM – Ice protection systems	Bk	4
		2003-14-20		Rudder control system	Bk	4
		2003-22-13		Ailerons	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
N24A continued						
		2004-05-02		Wing strut fittings and stub wing spar assy	Bk	4
		2004-06-10		Rivet heads on rear bulkhead frame	Bk	4
		2005-10-24		Rudder control lever shafts	BW 05-11	
		2006-21-12				
N22S	A7PC	91-02-08		Airplane electrical system	Bk	3
		96-23-18		Fuselage stub fin plate	Bk	3
		96-24-04		Inspect tailplane stabilizer	Bk	3
		96-24-05		Inspect flap and aileron control rod fork ends	Bk	3
		97-09-08		Pilot/co-pilot control wheels	Bk	3
		97-11-11		Horizontal stabilizer	Bk	3
		97-11-12		Front spar	Bk	3
		97-24-05		Inspect aft wing break connectors	Bk	3
		2004-05-02		Wing strut fittings and stub wing spar assy	Bk	4
		2004-06-10		Rivet heads on rear bulkhead frame	Bk	4
		2005-10-24		Rudder control lever shafts	BW 05-11	
		2006-21-12		Inspect ailerons		

AEROSTAR AIRCRAFT CORP.
(See MOONEY AIRCRAFT CORP., SMITH AEROSTAR)

AEROSTAR AIRCRAFT CORPORATION
(Formerly PIPER, TED SMITH)
(See Piper for AD's in Book 1)

PA-60 Series	A17WE	88-21-05		Exhaust systems (STC SA980NM)	Bk	2
		89-03-04		Cabin door	Bk	2
PA-60-600	A17WE	70-23-04		Wing flap tracks	Bk	1
(Aerostar 600)		70-23-05		Fuel pressure indicators	Bk	1
		70-25-09		Microphone jack connection	Bk	1
		71-02-05		Main cabin door lock pins	Bk	1
		71-05-06		Main landing gear	Bk	1
		71-10-02		Over voltage relay ground	Bk	1
		71-17-07		Wing flap attachment rib	Bk	1
		74-25-02		Electrical attitude/directional gyros	Bk	1
		78-18-05		LH and RH fuel quantity indicator	Bk	1
		79-01-05		Fuel starvation	Bk	1
		79-08-05		Engine nacelles	Bk	1
		79-18-10		Cabin door latching mechanism	Bk	1
		80-12-14		Engine fire	Bk	2
		80-19-14		Horizontal/vertical stabilizer	Bk	2
		83-14-07	R3	Rev. to Limitations Section of AFM	Bk	2
		87-07-09		Exhaust system components	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		90-01-02		SB 920 - fire prevention	Bk	3
		93-13-08		Torque links	Bk	3
		94-15-13		NLG Corrosion check	Bk	3
		95-23-11		Inspect upper and lower horizontal flanges	Bk	3
		98-04-23		AFM - Limitations Section - icing	Bk	3
		98-24-29		Wing upper spar cap	Bk	3
		2001-08-10		Main landing gear lower side brace	Bk	4
		2003-22-01		Auxiliary fuel transfer pumps	Bk	4
PA-60-601	A17WE	70-23-04		Wing flap tracks	Bk	1
(Aerostar 601)		70-23-05		Fuel pressure indicators	Bk	1
		70-25-09		Microphone jack connection	Bk	1
		71-02-05		Main cabin door lock pins	Bk	1
		71-05-06		Main landing gear	Bk	1
		71-10-02		Over voltage relay ground	Bk	1
		71-17-07		Wing flap attachment rib	Bk	1
		74-25-02		Electrical attitude/directional gyros	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-60-601 continued		78-18-05		LH and RH fuel quantity indicator	Bk	1
(Aerostar 601)		79-01-05		Fuel starvation	Bk	1
		79-08-05		Engine nacelles	Bk	1
		79-18-10		Cabin door latching mechanism	Bk	1
		80-12-14		Engine fire	Bk	2
		80-18-03		Fuel pressure system	Bk	2
		80-19-14		Horizontal/vertical stabilizer	Bk	2
		83-14-07	R3	Rev. to Limitations Section of AFM	Bk	2
		87-07-09		Exhaust system components	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		88-25-02		Engine fluid-carrying hoses	Bk	2
		90-01-02		SB 920 - fire prevention	Bk	3
		93-13-08		Torque links	Bk	3
		94-15-13		NLG Corrosion check	Bk	3
		95-23-11		Inspect upper and lower horizontal flanges	Bk	3
		98-04-23		AFM - Limitations Section - icing	Bk	3
		98-24-29		Wing upper spar cap	Bk	3
		2001-08-10		Main landing gear lower side brace	Bk	4
		2002-24-07		Oil scavenge pumps	Bk	4
		2003-22-01		Auxiliary fuel transfer pumps	Bk	4
PA-60-601P	A17WE	74-25-02		Electrical attitude/directional gyros	Bk	1
(Aerostar 601P)		78-18-05		LH and RH fuel quantity indicator	Bk	1
		79-01-05		Fuel starvation	Bk	1
		79-08-05		Engine nacelles	Bk	1
		80-12-14		Engine fire	Bk	2
		80-18-03		Fuel pressure system	Bk	2
		80-19-14		Horizontal/vertical stabilizer	Bk	2
		83-14-07	R3	Rev. to Limitations Section of AFM	Bk	2
		87-07-09		Exhaust system components	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		88-25-02		Engine fluid-carrying hoses	Bk	2
		90-01-02		SB 920 - fire prevention	Bk	3
		93-13-08		Torque links	Bk	3
		94-15-13		NLG Corrosion check	Bk	3
		95-23-11		Inspect upper and lower horizontal flanges	Bk	3
		98-04-23		AFM - Limitations Section - icing	Bk	3
		98-24-29		Wing upper spar cap	Bk	3
		2001-08-10		Main landing gear lower side brace	Bk	4
		2002-24-07		Oil scavenge pumps	Bk	4
		2003-22-01		Auxiliary fuel transfer pumps	Bk	4
PA-60-602P	A17WE	83-14-07	R3	Rev. to Limitations Section of AFM	Bk	2
(Aerostar 602P)		87-07-09		Exhaust system components	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		88-25-02		Engine fluid-carrying hoses	Bk	2
		90-01-02		SB 920 - fire prevention	Bk	3
		93-13-08		Torque links	Bk	3
		94-15-13		NLG Corrosion check	Bk	3
		95-23-11		Inspect upper and lower horizontal flanges	Bk	3
		98-04-23		AFM - Limitations Section - icing	Bk	3
		98-24-29		Wing upper spar cap	Bk	3
		2001-08-10		Main landing gear lower side brace	Bk	4
		2002-24-07		Oil scavenge pumps	Bk	4
		2003-22-01		Auxiliary fuel transfer pumps	Bk	4
PA-60-700P	A17WE	87-07-09		Exhaust system components	Bk	2
(Aerostar 700P)		87-21-01		Fuel filler openings	Bk	2
		88-25-02		Engine fluid-carrying hoses	Bk	2
		90-01-02		SB 920 - fire prevention	Bk	3
		91-23-16		Manifold pressure operations	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		93-13-08	Torque links	Bk	3
		94-15-13	NLG Corrosion check	Bk	3
		98-04-23	AFM - Limitations Section - icing	Bk	3
		98-24-29	Wing upper spar cap	Bk	3
		2001-08-10	Main landing gear lower side brace	Bk	4
		2002-24-07	Oil scavenge pumps	Bk	4
		2003-22-01	Auxiliary fuel transfer pumps	Bk	4
AEROTEK II, INC.					
(Formerly Airplane Services, Inc.)					
(For ADs in Book 1 see Airplane Services)					
B-1	A7WE,	72-21-01	Landing gear shock strut	Bk	1
	A8WE	74-02-02	Front wing spar failure	Bk	1
		79-16-04	Wing rear spars	Bk	1
B-1A	A7WE,	72-21-01	Landing gear shock strut	Bk	1
	A8WE	74-02-02	Front wing spar failure	Bk	1
		79-16-04	Wing rear spars	Bk	1
AG CAT CORPORATION					
(Formerly SCHWEIZER)					
(For ADs in Book 1 and 2 see Schweizer)					
(See Allied Ag Cat Productions, Inc)					
AGUSTA S.P.A.					
(Formerly SIAI MARCHETTI, S.P.A., AGUSTA, COSTRUZIONI AERONAUTICHE GIOVANNI)					
(*See Aermacchi S.P.A, SIAI Marchetti.)*					
AIR TRACTOR, INC.					
AT-250	A9SW	96-24-08	Parking brake valve	Bk	3
		2002-25-09	Overturn skid plate	Bk	4
AT-300	A9SW	82-06-12	Main landing gear struts	Bk	2
		83-18-01	Fuselage attach fittings	Bk	2
		92-07-14	Wing Structure	Bk	3
		96-24-08	Parking brake valve	Bk	3
		98-25-01	Flap actuator overtravel stop	Bk	3
		2002-25-09	Overturn skid plate	Bk	4
		2003-06-01	Wing centerline splice joint	Bk	4
		2003-07-04	Vertical fin front spar fittings	Bk	4
		2005-13-12	Front and rear spar of the horizontal stabilizer	BW 05-13	
AT-301	A9SW	82-06-12	Main landing gear struts	Bk	2
		83-18-01	Fuselage attach fittings	Bk	2
		92-07-14	Wing Structure	Bk	3
		96-24-08	Parking brake valve	Bk	3
		97-14-05	Inspect front spar attachment lugs	Bk	3
		98-25-01	Flap actuator overtravel stop	Bk	3
		2000-11-05	Detect and correct cracks in spar plates	Bk	4
		2002-25-09	Overturn skid plate	Bk	4
		2003-06-01	Wing centerline splice joint	Bk	4
		2005-13-12	Front and rear spar of the horizontal stabilizer	BW 05-13	
AT-302	A9SW	82-06-12	Main landing gear struts	Bk	2
		83-18-01	Fuselage attach fittings	Bk	2
		92-07-14	Wing Structure	Bk	3
		96-24-08	Parking brake valve	Bk	3
		97-14-05	Inspect front spar attachment lugs	Bk	3
		98-25-01	Flap actuator overtravel stop	Bk	3
		2002-25-09	Overturn skid plate	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2003-06-01		Wing centerline splice joint	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
AT-400	A9SW	82-06-12		Main landing gear struts	Bk	2
		92-07-14		Wing Structure	Bk	3
		96-24-08		Parking brake valve	Bk	3
AT-400 continued		97-14-05		Inspect front spar attachment lugs	Bk	3
		98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4
		2003-06-01		Wing centerline splice joint	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
		2006-08-08		Wing lower spar cap	BW 06-10	
AT-400A	A9SW	82-06-12		Main landing gear struts	Bk	2
		92-07-14		Wing Structure	Bk	3
		96-24-08		Parking brake valve	Bk	3
		97-14-05		Inspect front spar attachment lugs	Bk	3
		98-25-01		Flap actuator overtravel stop	Bk	3
		2002-25-09		Overturn skid plate	Bk	4
		2003-06-01		Wing centerline splice joint	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
AT-401	A17SW	96-24-08		Parking brake valve	Bk	3
		97-14-05		Inspect front spar attachment lugs	Bk	3
		98-25-01		Flap actuator overtravel stop	Bk	3
		2000-11-05		Detect and correct cracks in spar plates	Bk	4
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
		2006-08-08		Wing lower spar cap	BW 06-10	
AT-401A, AT-401B	A17SW	98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2006-08-08		Wing lower spar cap	BW 06-10	
AT-402	A17SW	96-24-08		Parking brake valve	Bk	3
		97-14-05		Inspect front spar attachment lugs	Bk	3
		98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
		2006-08-08		Wing lower spar cap	BW 06-10	
AT-402A, AT-402B	A17SW	98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2006-08-08		Wing lower spar cap	BW 06-10	
AT-501	A17SW	96-24-08		Parking brake valve	Bk	3
		97-14-05		Inspect front spar attachment lugs	Bk	3
		98-25-01		Flap actuator overtravel stop	Bk	3
		2000-11-05		Detect and correct cracks in spar plates	Bk	4
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05	R1	Wing lower spar cap	BW 06-10	
		2002-25-09		Overturn skid plate	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2006-24-10		Wing spar lower cap		
AT-502	A17SW	96-24-08		Parking brake valve	Bk	3
		97-14-05		Inspect front spar attachment lugs	Bk	3
		98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4
		2002-26-05		Fatigue cracks in wing lower spar cap	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2006-23-14		Rudder and vertical fin hinge attaching structure		
		2006-24-10		Wing spar lower cap		
AT-502A, AT-502B	A17SW	98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-25-09		Overturn skid plate	Bk	4
		2002-26-05		Fatigue cracks in wing lower spar cap	Bk	4
		2003-07-04		Vertical fin front spar fittings	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2006-23-14		Rudder and vertical fin hinge attaching structure		
		2006-24-10		Wing spar lower cap		
AT-503A	A17SW	98-25-01		Flap actuator overtravel stop	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-26-05		Fatigue cracks in wing lower spar cap	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2006-24-10		Wing spar lower cap		
AT-602	A19SW	2004-15-15		Upper longeron and diagonal tube	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
		2006-22-08		Inspect engine mount		
		2006-23-09		Wing main spar lower caps		
		2006-23-14		Rudder and vertical fin hinge attaching structure		
AT-802	A19SW	96-04-08		Main landing gear legs	Bk	3
		97-04-11		Tail landing gear spring	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-15-06		Rudder control cables and fairlead	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
		2006-08-09		Main spar lower caps	BW 06-10	
		2006-20-10		Angles on the firewall		
		2006-22-08		Inspect engine mount		
		2006-23-14		Rudder and vertical fin hinge attaching structure		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AT-802A	A19SW	96-04-08		Main landing gear legs	Bk	3
		97-04-11		Tail landing gear spring	Bk	3
		2001-10-04	R1	Cracks in the wing lower spar cap	Bk	4
		2002-11-05		Fatigue cracks in wing lower spar cap	Bk	4
		2002-15-06		Rudder control cables and fairlead	Bk	4
		2004-15-15		Upper longeron and diagonal tube	Bk	4
		2005-13-12		Front and rear spar of the horizontal stabilizer	BW 05-13	
		2006-08-09		Main spar lower caps	BW 06-10	
		2006-20-10		Angles on the firewall		
		2006-22-08		Inspect engine mount		
		2006-23-14		Rudder and vertical fin hinge attaching structure		

AIR TRADING CORPORATION
(Formerly Grumman American Avn)
(For ADs in Bk 1 see Grumman)

TBF Series	LTC 8	58-19-01		Fire resistant hose	Bk	1
		64-26-03		Elevator push rod assembly	Bk	1
TBM Series	LTC 8	58-19-01		Fire resistant hose	Bk	1
		64-26-03		Elevator push rod assembly	Bk	1

AIRCRAFT ACQUISITION CORPORATION
(Formerly HELIO AIRCRAFT LIMITED, TAYLORCRAFT, INC.)
(See HELIO AIRCRAFT LTD and
TAYLORCRAFT, INC. for AD's prior to 1980)
(See HELIO ENTERPRISES INC.)

AIRCRAFT PARTS & DEVELOPMENT CORP.
(Formerly AERO COMMANDER, CALLAIR, INTERMOUNTAIN)

A-4	A-758	60-07-03		Engine mount brace	Bk	1
A-5	A-758	60-07-03		Engine mount brace	Bk	1
		64-02-03		Horizontal stabilizers	Bk	1
A-6	A-758	60-07-03		Engine mount brace	Bk	1
		64-02-03		Horizontal stabilizers	Bk	1
A-9	A-758	73-22-02		Water in wing lift struts	Bk	1
		78-20-06		Hopper's carry through tube	Bk	1
A-9A	A-758	73-22-02		Water in wing lift struts	Bk	1
		78-20-06		Hopper's carry through tube	Bk	1
A-9B	A4WE	73-22-02		Water in wing lift struts	Bk	1
		78-20-06		Hopper's carry through tube	Bk	1

AIRPLANE SERVICES, INC.
(Formerly S.L. INDUSTRIES)
(See Aerotek II, Inc.)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
ALEXANDRIA AIRCRAFT LLC						
(Formerly Bellanca Inc., Minnesota)						
(See Bellanca Inc, Minnesota for ADs in Book 1, 2, 3)						
All models		47-50-13		Propellers -See Bellanca, DE	Bk	1
14-19 Series	1A3	47-50-13		Propellers -See Bellanca, DE	Bk	1
		51-16-02		Trim tab modification	Bk	1
		53-16-01		Elevator trim tab looseness	Bk	1
14-19	1A3	63-06-02		Rudder bellcrank	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
14-19-2	1A3	63-06-02		Rudder bellcrank	Bk	1
		72-01-01		Engine flex hose assys	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
14-19-3	1A3	72-01-01		Engine flex hose assys	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		77-22-02		Nose landing gear engine mount	Bk	1
		90-02-17		Landing gear fitting assemblies	Bk	3
14-19-3A	1A3	68-23-08		Horizontal tail surface	Bk	1
		69-12-04		Stabilizer strut clevis	Bk	1
		72-01-01		Engine flex hose assys	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		77-22-02		Nose landing gear engine mount	Bk	1
		90-02-17		Landing gear fitting assemblies	Bk	3
17-30	1A3	68-23-08		Horizontal tail surface	Bk	1
		69-12-04		Stabilizer strut clevis	Bk	1
		71-10-01		Fuel leakage	Bk	1
		72-01-01		Engine flex hose assys	Bk	1
		72-13-03		Fuel boost pump circuit	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		76-23-03	R1	Exhaust system	Bk	1
		77-22-02		Nose landing gear engine mount	Bk	1
		86-25-06		Wing main and auxiliary fuel tanks	Bk	2
		87-11-01	R1	Fuel caps & drains	Bk	2
		90-02-17		Landing gear fitting assemblies	Bk	3
		96-18-07		NLG drag strut brackets	Bk	3
17-31	1A3	75-11-06		Check valve	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		76-23-03	R1	Exhaust system	Bk	1
		86-25-06		Wing main and auxiliary fuel tanks	Bk	2
		87-11-01	R1	Fuel caps & drains	Bk	2
		90-02-17		Landing gear fitting assemblies	Bk	3
		96-18-07		NLG drag strut brackets	Bk	3
17-31TC	1A3	75-11-06		Check valve	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		86-25-06		Wing main and auxiliary fuel tanks	Bk	2
		87-11-01	R1	Fuel caps & drains	Bk	2
		90-02-17		Landing gear fitting assemblies	Bk	3
		96-18-07		NLG drag strut brackets	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
17-30A	A18CE	72-01-03		Engine fuel hose		1
		73-03-03		Engine induction box bolts	Bk	1
		73-05-02		Rudder control system	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		76-23-03	R1	Exhaust system	Bk	1
		77-22-02		Nose landing gear engine mount	Bk	1
		86-25-06		Wing main and auxiliary fuel tanks	Bk	2
		87-11-01	R1	Fuel caps & drains	Bk	2
		90-02-17		Landing gear fitting assemblies	Bk	3
		96-18-07		NLG drag strut brackets	Bk	3
17-31A	A18CE	72-01-03		Engine fuel hose	Bk	1
		73-05-02		Rudder control system	Bk	1
		75-11-06		Check valve	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		76-23-03	R1	Exhaust system	Bk	1
		86-25-06		Wing main and auxiliary fuel tanks	Bk	2
		87-11-01	R1	Fuel caps & drains	Bk	2
		90-02-17		Landing gear fitting assemblies	Bk	3
		96-18-07		NLG drag strut brackets	Bk	3
17-31ATC	A18CE	72-01-03		Engine fuel hose	Bk	1
		73-05-02		Rudder control system	Bk	1
		75-11-06		Check valve	Bk	1
		75-20-06		Vertical tubes	Bk	1
		76-08-04	R1	Wood deterioration	Bk	1
		86-25-06		Wing main and auxiliary fuel tanks	Bk	2
		87-11-01	R1	Fuel caps & drains	Bk	2
		90-02-17		Landing gear fitting assemblies	Bk	3
		96-18-07		NLG drag strut brackets	Bk	3
DW-1	A4NW	82-22-03		Aft elevator push tube	Bk	2

ALLIANCE AIRCRAFT GROUP, LLC
(Formerly Helio Enterprises, Inc., Helio Aircraft)
(See Helio Aircraft Ltd for Book 1, Helio Enterprises for Book 2)

H250	1A8	82-16-08		L and R main spar carry-thru assy	Bk	2
H295 (U-10D)	1A8	82-16-08		L and R main spar carry-thru assy	Bk	2
HT-295	1A8	82-16-08		L and R main spar carry-thru assy	Bk	2
H-391B	1A8	56-22-02		Wing attachment washers	Bk	1
		57-25-02		Fin spar inspection	Bk	1
		58-01-04		Aileron bellcrank inspection	Bk	1
		58-25-04		Fin hinge attachment	Bk	1
		59-17-05		Horizontal tail spar fitting	Bk	1
		59-17-06		Pulley guards	Bk	1
		63-18-02		Engine breather	Bk	1
		82-16-08		L and R main spar carry-thru assy	Bk	2
H-395 (L-28A)	1A8	58-25-04		Fin hinge attachment	Bk	1
		59-17-05		Horizontal tail spar fitting	Bk	1
		59-17-06		Pulley guards	Bk	1
		63-18-02		Engine breather	Bk	1
		82-16-08		L and R main spar carry-thru assy	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
H-395A	1A8	59-17-06		Pulley guards	Bk	1
		63-18-02		Engine breather	Bk	1
		82-16-08		L and R main spar carry-thru assy	Bk	2
H-391 (YL-24)	1A8	82-16-08		L and R main spar carry-thru assy	Bk	2
H-700	1A8	87-04-09		Landing gear legs	Bk	2
H-800	1A8	87-04-09		Landing gear legs	Bk	2
ALLIED AG CAT PRODUCTIONS						
(Formerly Ag Cat Corp)						
(See Ag Cat for Book 1, Book 2)						
G-164 Series	1A16	63-22-02		Throttle control pivot bolt	Bk	1
		66-01-02		Propeller cone and spacer sets	Bk	1
		89-18-02	R1	Elevator push-pull rods	Bk	2
G-164	1A16	62-08-07		Aileron control cable modification	Bk	1
		63-01-01		Engine mount washers	Bk	1
		63-22-01		Spray pump fan blades	Bk	1
		66-27-06		Right-hand elevator torque tubes	Bk	1
		67-09-04		Control surface lock	Bk	1
		67-29-04		Elevator forward pushrod	Bk	1
		75-14-04		Rudder cables	Bk	1
		76-13-10		Landing gear strut	Bk	1
		76-21-03		Main landing gear struts	Bk	1
		78-08-09		Rudder assembly	Bk	1
		78-23-11		Aileron balance cables	Bk	1
		78-26-03		Wing fittings corrosion detection	Bk	1
G-164A	1A16	66-27-06		Right-hand elevator torque tubes	Bk	1
		67-09-04		Control surface lock	Bk	1
		72-02-02		Fuel line fitting leakage	Bk	1
		73-19-10		Elevator control horn	Bk	1
		75-14-04		Rudder cables	Bk	1
		76-13-10		Landing gear strut	Bk	1
		77-13-04		Placard-brake warning	Bk	1
		77-19-05		Flying wire terminals	Bk	1
		78-08-09		Rudder assembly	Bk	1
		78-23-11		Aileron balance cables	Bk	1
		78-26-03		Wing fittings corrosion detection	Bk	1
		82-07-04		Fuel shutoff valve modification	Bk	2
G-164B	1A16	73-19-10		Elevator control horn	Bk	1
		75-14-04		Rudder cables	Bk	1
		77-13-04		Placard-brake warning	Bk	1
		77-19-05		Flying wire terminals	Bk	1
		78-08-09		Rudder assembly	Bk	1
		78-23-11		Aileron balance cables	Bk	1
		78-26-03		Wing fittings corrosion detection	Bk	1
		82-07-04		Fuel shutoff valve modification	Bk	2
		82-13-06		Aileron bellcrank inspection	Bk	2
G-164C	1A16	78-23-11		Aileron balance cables	Bk	1
		82-07-04		Fuel shutoff valve modification	Bk	2
		82-13-06		Aileron bellcrank inspection	Bk	2
G164D	1A16	82-07-04		Fuel shutoff valve modification	Bk	2
		82-13-06		Aileron bellcrank inspection	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.

AMERICAN AVIATION CORP.
(See GULFSTREAM AMERICAN AVIATION CORP.)

AMERICAN CHAMPION AIRCRAFT CORP.
(Formerly F.R.A. ENTERPRISES)
(See F.R.A. Enterprises for AD's in Bk 1)

All Models		47-50-13		Koppers aeromatic propellers	Bk	1
7 Series	A-759	48-08-02		Cleveland wheels	Bk	1
		48-39-01		Control stick rework	Bk	1
7AC	A-759	47-20-01		Gascolator bowl cleaning	Bk	1
		47-20-02		Oleo piston	Bk	1
		47-30-01		Lift strut wing attach fittings	Bk	1
		47-30-05		Exhaust stack inspection	Bk	1
		48-04-02		Wing rib rework	Bk	1
		49-11-02		Wing attach fitting	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7ACA	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
S7AC	A-759	49-11-02		Wing attach fitting	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7BCM	A-759	47-20-01		Gascolator bowl cleaning	Bk	1
		49-11-02		Wing attach fitting	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7CCM (L-16B)	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7DC	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7EC	A-759	56-04-01		Control stick socket castings	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7ECA	A-759	67-03-02		Fuel shutoff valve bracket	Bk	1
		71-20-04		Lower fuselage longeron	Bk	1
		72-20-06		Aerobatic flight placard	Bk	1
		75-17-16		Engine power loss	Bk	1
		76-22-01		Adjustable front seat	Bk	1
		77-22-05		Operating limitations	Bk	1
		79-22-01		Exhaust system	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		81-16-04		Competition harness installation	Bk	2
		89-18-06		Front folding seats	Bk	2
		96-18-02		Inspect wing front strut attach fittings	Bk	3
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7FC	A-759	57-20-01		Fireproof steering link boot	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW	06-02
7GC Series	A-759	64-04-03		Air door hinge	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
7GC	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7GCA	A-759	64-04-03		Air door hinge	Bk	1
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7GCAA	A-759	67-03-02		Fuel shutoff valve bracket	Bk	1
		71-20-04		Lower fuselage longeron	Bk	1
		72-18-03		Corrosion of rudder & elevator cables	Bk	1
		72-20-06		Aerobatic flight placard	Bk	1
		75-17-16		Engine power loss	Bk	1
		76-22-01		Adjustable front seat	Bk	1
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		81-16-04		Competition harness installation	Bk	2
		89-18-06		Front folding seats	Bk	2
		96-18-02		Inspect wing front strut attach fittings	Bk	3
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7GCB	A-759	64-04-03		Air door hinge	Bk	1
		67-03-02		Fuel shutoff valve bracket	Bk	1
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7GCBA	A-759	64-04-03		Air door hinge	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7GCBC	A-759	67-03-02		Fuel shutoff valve bracket	Bk	1
		71-20-04		Lower fuselage longeron	Bk	1
		72-18-03		Corrosion of rudder & elevator cables	Bk	1
		72-20-06		Aerobatic flight placard	Bk	1
		75-17-16		Engine power loss	Bk	1
		76-22-01		Adjustable front seat	Bk	1
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		81-16-04		Competition harness installation	Bk	2
		89-18-06		Front folding seats	Bk	2
		96-18-02		Inspect wing front strut attach fittings	Bk	3
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7HC Series	A-759	64-04-03		Air door hinge	Bk	1
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7JC	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
7KC Series	A-759	64-04-03		Air door hinge	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
7KCAB	A-759	71-20-04		Lower fuselage longeron	Bk	1
		72-18-03		Corrosion of rudder & elevator cables	Bk	1
		72-20-06		Aerobatic flight placard	Bk	1
		75-17-16		Engine power loss	Bk	1
		76-22-01		Adjustable front seat	Bk	1
		77-22-05		Operating limitations	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		81-16-04		Competition harness installation	Bk	2
		89-18-06		Front folding seats	Bk	2
		96-18-02		Inspect wing front strut attach fittings	Bk	3
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
S7CCM	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
S7DC	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
S7EC	A-759	2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
8KCAB	A21CE	72-18-03		Corrosion of rudder & elevator cables	Bk	1
		72-20-06		Aerobatic flight placard	Bk	1
		74-23-04		Rib flanges	Bk	1
		75-17-16		Engine power loss	Bk	1
		76-22-01		Adjustable front seat	Bk	1
		79-22-01		Exhaust system	Bk	1
		80-21-06		Muffler core and body assys	Bk	2
		81-16-04		Competition harness installation	Bk	2
		89-18-06		Front folding seats	Bk	2
		90-15-15	R1	Front spar strut fittings	Bk	3
		96-18-02		Inspect wing front strut attach fittings	Bk	3
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
8GCBC	A21CE	74-15-07		Propeller mounting	Bk	1
		75-04-12		Markings on tachometer	Bk	1
		75-17-16		Engine power loss	Bk	1
		76-22-01		Adjustable front seat	Bk	1
		79-22-01		Exhaust system	Bk	1
		89-18-06		Front folding seats	Bk	2
		96-18-02		Inspect wing front strut attach fittings	Bk	3
		2000-25-02	R1	Wood wing spar	Bk	4
		2005-24-10		Pilot's Operating Handbook (POH) limitation	BW 06-02	
11 Series	A-761	48-08-02		Cleveland wheels	Bk	1
11AC	A-761	47-20-01		Gascolator bowl cleaning	Bk	1
		47-20-02		Oleo piston	Bk	1
		47-30-01		Lift strut wing attach fittings	Bk	1
		47-30-05		Exhaust stack inspection	Bk	1
		48-04-02		Wing rib rework	Bk	1
		48-13-07		Turnbuckle fork replacement	Bk	1
		49-11-02		Wing attach fitting	Bk	1
		49-15-01		Seat anchorage rework	Bk	1
		52-28-01		Fuel transfer placard	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2000-25-02	R1	Wood wing spar	Bk	4
S11AC	A-761	48-13-07		Turnbuckle fork replacement	Bk	1
		49-11-02		Wing attach fitting	Bk	1
		49-15-01		Seat anchorage rework	Bk	1
		52-28-01		Fuel transfer placard	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
11BC	A-761	48-04-02		Wing rib rework	Bk	1
		49-11-02		Wing attach fitting	Bk	1
		49-15-01		Seat anchorage rework	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
11CC	A-761	49-11-02		Wing attach fitting	Bk	1
		2000-25-02	R1	Wood wing spar	Bk	4
S11CC	A-761	2000-25-02	R1	Wood wing spar	Bk	4
402	A3CE	64-17-04		Exhaust systems	Bk	1

AMERICAN GENERAL AIRCRAFT HOLDING CO., INC.
(Formerly GULFSTREAM)
(For ADs in Bk 1 See Gulfstream Aerospace)
(See Tiger Aircraft LLC)

APEX AIRCRAFT
(Formerly Avions Mudry et Cie and Avions Pierre Robin)
(See Avions Mudry for TC A36EU and Avions Pierre for TCs A48EU, A66EU for ADs in Book 2, 3)

CAP 10 B Series	A36EU	91-23-03		Fuel system	Bk	3
		2003-04-02		Wing spar	Bk	4
R2160	A48EU	87-08-01		Rudder	Bk	2
		97-06-05		Strut and lower plate of NLG leg	Bk	3
		99-01-04		Rudder bars	Bk	3
		99-02-15		Engine bearer	Bk	3
		99-07-20		Vertical stabilizer spar	Bk	3
		99-09-08		Aileron/flap common support bracket	Bk	3
		99-10-01		Wing attachment bolts	Bk	3
		99-10-02		Fuel venting system parts	Bk	3
R3000	A66EU	97-23-05		Attachment bolts	Bk	3
		97-23-08		Yaw damper control cables	Bk	3
R3000/160	A66EU	98-08-28		Nose landing gear bolts	Bk	3
		98-09-08		Inspect flap control shaft and welds	Bk	3

ARCTIC AIRCRAFT CO., INC.
(See Interstate Engineering & Type Design Company, Inc.)

AUGUSTAIR
(Formerly MONTANAIR, VARGA)
(See MONTANAIR for AD's in Bk 1)

2150	4A19	65-12-04		Elevator horn	Bk	1
		65-28-05		Main landing gear oleos	Bk	1
		80-02-08		Rudder balance attach bolts	Bk	2
		80-13-08		Throttle movement	Bk	2
2150A	4A19	65-12-04		Elevator horn	Bk	1
		65-28-05		Main landing gear oleos	Bk	1
		80-02-08		Rudder balance attach bolts	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		80-13-08		Throttle movement	Bk	2
		81-20-02		Vent tube assembly	Bk	2
		82-08-04		Elevator horn assembly	Bk	2
2180	4A19	82-08-04		Elevator horn assembly	Bk	2
AUTAIR LTD.						
Harvard (Army AT-16)		2005-12-51		Upper and lower wing attach angle	BW 05-12	
AVIAT, INC.						
(Formerly Christen Industries, Inc.)						
(See Sky International, Inc.)						
AVIONS MUDRY et CIE						
(See Apex)						
AVIONS PIERRE ROBIN						
(See Apex)						
AYRES CORPORATION						
(See Quality Aerospace, Inc.)						
BEAGLE AIRCRAFT						
(See BRITISH AEROSPACE CORP.)						
BEECH AIRCRAFT CORP.						
(See RAYTHEON AIRCRAFT CO.)						
D18C-T	TC 770	47-33-06		Stabilizer spar replacement	Bk	1
		47-33-07		Alternate static source	Bk	1
		47-34-02		Tail cone drain holes	Bk	1
		47-51-10		Birdproof windshield	Bk	1
		48-34-01		Stabilizer attachment fitting	Bk	1
		49-29-02		Rudder spring bushings	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
BELLANCA AIRCRAFT CORPORATION, DELAWARE						
(See AERONCA, F.R.A. ENTERPRISES)						
All Models		47-50-13		Kopper aeromatic props	Bk	1
		48-21-01		Accelerator pump linkage	Bk	1
CH	ATC 47	76-20-07		Wood decayed wing spars	Bk	1
CH-300 Pacemaker	ATC 129	76-20-07		Wood decayed wing spars	Bk	1
300-W Pacemaker	ATC 328	76-20-07		Wood decayed wing spars	Bk	1
CH-400 Skyrocket	ATC 319	76-20-07		Wood decayed wing spars	Bk	1
E Pacemaker	ATC 476	76-20-07		Wood decayed wing spars	Bk	1
F Skyrocket	TC 2-475	76-20-07		Wood decayed wing spars	Bk	1
14-9, -9L	TC 716	76-20-07		Wood decayed wing spars	Bk	1
14-12F-3	TC 745	76-20-07		Wood decayed wing spars	Bk	1
14-13	A-773	46-41-01		Rudder bellcrank replacement	Bk	1
		46-41-02		Aileron control bushing	Bk	1
		46-41-03		Control wheel universal joints	Bk	1
		47-07-01		Fuel selector valve indexing	Bk	1
		47-14-01		Flap hinge bracket	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		47-25-09	Fin and stabilizer fittings	Bk	1
		47-32-17	Landing gear inspection covers	Bk	1
		47-32-18	Sprocket cotter pin	Bk	1
		47-51-13	Cabin heat control valve	Bk	1
		48-05-03	Trim tab bracket bolts	Bk	1
		48-13-06	Engine cowl brackets	Bk	1
		49-13-02	Landing gear drag strut	Bk	1
		51-16-01	Trim tab modification	Bk	1
		52-17-01	Landing gear chain guard	Bk	1
		52-28-02	Fuel pump relief valve	Bk	1
		63-06-02	Rudder bellcrank	Bk	1
		63-17-01	Main landing gear	Bk	1
		63-20-01	Brake cylinder support bracket	Bk	1
		76-20-07	Wood decayed wing spars	Bk	1
		79-19-05	Aileron control system	Bk	1
14-13-2	A-773	46-41-01	Rudder bellcrank replacement	Bk	1
		46-41-02	Aileron control bushing	Bk	1
		46-41-03	Control wheel universal joints	Bk	1
		47-07-01	Fuel selector valve indexing	Bk	1
		47-14-01	Flap hinge bracket	Bk	1
		47-25-09	Fin and stabilizer fittings	Bk	1
		47-32-17	Landing gear inspection covers	Bk	1
		47-32-18	Sprocket cotter pin	Bk	1
		48-05-03	Trim tab bracket bolts	Bk	1
		48-13-06	Engine cowl brackets	Bk	1
		49-13-02	Landing gear drag strut	Bk	1
		51-16-01	Trim tab modification	Bk	1
		52-17-01	Landing gear chain guard	Bk	1
		52-28-02	Fuel pump relief valve	Bk	1
		63-06-02	Rudder bellcrank	Bk	1
		63-17-01	Main landing gear	Bk	1
		63-20-01	Brake cylinder support bracket	Bk	1
		76-20-07	Wood decayed wing spars	Bk	1
		79-19-05	Aileron control system	Bk	1
14-13-3	A-773	49-13-02	Landing gear drag strut	Bk	1
		52-17-01	Landing gear chain guard	Bk	1
		52-28-02	Fuel pump relief valve	Bk	1
		63-06-02	Rudder bellcrank	Bk	1
		63-17-01	Main landing gear	Bk	1
		63-20-01	Brake cylinder support bracket	Bk	1
		76-20-07	Wood decayed wing spars	Bk	1
		79-19-05	Aileron control system	Bk	1
14-13-3W	A-773	52-17-01	Landing gear chain guard	Bk	1
		63-06-02	Rudder bellcrank	Bk	1
		63-17-01	Main landing gear	Bk	1
		63-20-01	Brake cylinder support bracket	Bk	1
		76-20-07	Wood decayed wing spars	Bk	1
		79-19-05	Aileron control system	Bk	1
31-42 Pacemaker	TC 2-509 TC 578	76-20-07	Wood decayed wing spars	Bk	1

BELLANCA INC., MINNESOTA
(See AERONCA, F.R.A. ENTERPRISES)
(See Alexandria Aircraft LLC)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B-N GROUP LTD						
(Formerly Pilatus Britten-Norman and Britten-Norman)						
(See Pilatus Britten-Norman (A17EU) and Britten-Norman (A29EU) for AD's in Book 1 thru 3)						
BN-2	A17EU	69-13-01		Nose wheel steering	Bk	1
		69-13-08		Fuel line leak	Bk	1
		70-02-06		Elevator trim tab attach	Bk	1
		70-03-06		Rudder bar assembly	Bk	1
		70-06-04		Fuselage attach spindles	Bk	1
		70-06-05		Elevator trim system drive	Bk	1
		70-07-04		Tail plane front spar	Bk	1
		70-07-05		Carburetor air box	Bk	1
		70-12-11		Flap actuating system	Bk	1
		71-05-05		Elevator trim tab system	Bk	1
		76-13-12		Flap retraction	Bk	1
		82-24-06	R1	Carburetor air box shutter	Bk	2
		83-07-12	R1	Fuel transmitter floats	Bk	2
		83-10-06	R1	Elevator trim tabs	Bk	2
		83-23-01		Wing tank fuel system mod.	Bk	2
		86-23-02		Modification NB/M/990	Bk	2
		96-18-21		Aileron mass balance clamp unit	Bk	3
		97-22-01		MLG torque link assembly area	Bk	3
		97-22-02		Engine mounting brackets, bolts, and bushes	Bk	3
		98-04-17		Diodes on terminal switches	Bk	3
		98-16-14		MLG fitting attachment bolts, nuts, & washers	Bk	3
		98-18-07		Inspect generator system	Bk	3
		2002-01-11		Throttle friction-shaft	Bk	4
		2002-02-10		Inboard brackets of elevator outboard hinge	Bk	4
		2002-02-11		Oleo attachment brackets	Bk	4
		2002-03-04		Emergency exit window sealant	Bk	4
		2002-22-02		Engine mount bracket	Bk	4
		2002-25-05		Universal joint shafts	Bk	4
		2006-16-19		Elevator final drive control rods		
		2006-23-03		Horizontal stabilizer attachment bolts		
BN-2A Series	A17EU	71-05-05		Elevator trim tab systems	Bk	1
		75-26-01		Rudder control	Bk	1
		76-02-04		Engine mounting frame	Bk	1
		76-13-12		Flap retraction	Bk	1
		76-21-07		Engine mounting	Bk	1
		77-07-10		Aileron mass balance support arm	Bk	1
		78-11-08		Elevator and flap control rods	Bk	1
		82-24-06	R1	Carburetor air box shutter	Bk	2
		83-07-12	R1	Fuel transmitter floats	Bk	2
		83-10-06	R1	Elevator trim tabs	Bk	2
		83-23-01		Wing tank fuel system mod.	Bk	2
		84-23-06	R1	Engine mounting brackets *(see Book 3 for paper copy)*	Bk	2
		86-07-02	R1	Inspect MLG torque link lug & upper case *(see Book 3 for paper copy)*	Bk	2
		95-04-09		Nose wheel steering system	Bk	3
		96-18-21		Aileron mass balance clamp unit	Bk	3
		97-22-01		MLG torque link assembly area	Bk	3
		98-04-17		Diodes on terminal switches	Bk	3
		98-16-14		MLG fitting attachment bolts, nuts, & washers	Bk	3
		98-18-07		Inspect generator system	Bk	3
		2002-01-11		Throttle friction-shaft	Bk	4
		2002-02-10		Inboard brackets of elevator outboard hinge	Bk	4
		2002-02-11		Oleo attachment brackets	Bk	4
		2002-03-04		Emergency exit window sealant	Bk	4
		2002-25-03		Rudder bar assemblies	Bk	4
		2002-25-05		Universal joint shafts	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
BN-2A	A17EU	69-13-01		Nose wheel steering	Bk	1
		69-13-08		Fuel line leak	Bk	1
		70-02-06		Elevator trim tab attach	Bk	1
		70-03-06		Rudder bar assembly	Bk	1
		70-06-04		Fuselage attach spindles	Bk	1
		70-06-05		Elevator trim system drive	Bk	1
		70-07-04		Tail plane front spar	Bk	1
		70-07-05		Carburetor air box	Bk	1
		70-12-11		Flap actuating system	Bk	1
		76-06-05		Pilot's seat	Bk	1
		83-05-02		Teleflex swivel assembly insp.	Bk	2
		86-23-02		Modification NB/M/990	Bk	2
		97-22-02		Engine mounting brackets, bolts, and bushes	Bk	3
		98-04-21		AFM - Limitations Section - icing	Bk	3
		98-16-14		MLG fitting attachment bolts, nuts, & washers	Bk	3
		2002-01-11		Throttle friction-shaft	Bk	4
		2002-02-10		Inboard brackets of elevator outboard hinge	Bk	4
		2002-02-11		Oleo attachment brackets	Bk	4
BN-2A continued		2002-03-04		Emergency exit window sealant	Bk	4
		2002-22-02		Engine mount bracket	Bk	4
		2006-16-19		Elevator final drive control rods.		
		2006-23-03		Horizontal stabilizer attachment bolts		
BN-2B Series	A17EU	83-07-12	R1	Fuel transmitter floats	Bk	2
		83-10-06	R1	Elevator trim tabs	Bk	2
		83-23-01		Wing tank fuel system mod.	Bk	2
		95-04-09		Nose wheel steering system	Bk	3
		97-22-01		MLG torque link assembly area	Bk	3
		97-22-02		Engine mounting brackets, bolts, and bushes	Bk	3
		98-04-17		Diodes on terminal switches	Bk	3
		98-04-21		AFM - Limitations Section - icing	Bk	3
		98-16-14		MLG fitting attachment bolts, nuts, & washers	Bk	3
		98-18-07		Inspect generator system	Bk	3
		2002-01-11		Throttle friction-shaft	Bk	4
		2002-02-10		Inboard brackets of elevator outboard hinge	Bk	4
		2002-02-11		Oleo attachment brackets	Bk	4
		2002-03-04		Emergency exit window sealant	Bk	4
		2002-22-02		Engine mount bracket	Bk	4
		2002-25-05		Universal joint shafts	Bk	4
		2006-16-19		Elevator final drive control rods.		
		2006-23-03		Horizontal stabilizer attachment bolts		
BN-2T	A17EU	87-04-11		Isolator mounting brackets/elastomer cores	Bk	2
		91-05-07		Electrical system	Bk	3
		91-05-09		Engine ignition system	Bk	3
		95-04-09		Nose wheel steering system	Bk	3
		97-22-01		MLG torque link assembly area	Bk	3
		97-22-02		Engine mounting brackets, bolts, and bushes	Bk	3
		98-04-21		AFM - Limitations Section - icing	Bk	3
		98-16-14		MLG fitting attachment bolts, nuts, & washers	Bk	3
		2002-01-11		Throttle friction-shaft	Bk	4
		2002-02-10		Inboard brackets of elevator outboard hinge	Bk	4
		2002-02-11		Oleo attachment brackets	Bk	4
		2002-03-04		Emergency exit window sealant	Bk	4
		2002-22-02		Engine mount bracket	Bk	4
		2002-24-09		Turbine engine-mounting frame	Bk	4
		2002-25-05		Universal joint shafts	Bk	4
		2006-16-19		Elevator final drive control rods.		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2006-23-03		Horizontal stabilizer attachment bolts		
BN2T-4R	A17EU	2002-24-09		Turbine engine-mounting frame	Bk	4
		2002-25-05		Universal joint shafts	Bk	4
		2006-16-19		Elevator final drive control rods.		
		2006-23-03		Horizontal stabilizer attachment bolts		
BN-2A Mark III	A29EU	75-22-17		Rudder trim control	Bk	1
		76-02-04		Engine mounting frame	Bk	1
		76-06-05		Pilot's seat	Bk	1
		76-21-07		Engine mounting	Bk	1
		77-07-10		Aileron mass balance support arm	Bk	1
		78-11-08		Elevator and flap control rods	Bk	1
		79-03-05		Main landing gear	Bk	1
		79-21-03		Elevator trim tab cable	Bk	1
		80-14-10		Rudder balance arm brackets	Bk	2
		82-24-06	R1	Carburetor air box shutter	Bk	2
		83-03-05		Undercarriage shock absorber	Bk	2
		83-05-02		Teleflex swivel assembly insp.	Bk	2
		83-07-12	R1	Fuel transmitter float insp.	Bk	2
		83-12-02		Rudder drive lever support assy.	Bk	2
		83-14-02		Wing-to-fuselage attach	Bk	2
		84-23-06	R1	Engine mounting brackets	Bk	2
				(see Book 3 for paper copy)		
		86-07-02	R1	Inspect MLG torque link lug & upper case	Bk	2
BN-2A Mark III continued				*(see Book 3 for paper copy)*		
		87-13-02		Elevator trim tab assemblies	Bk	2
		95-04-09		Nose wheel steering system	Bk	3
		96-18-21		Aileron mass balance clamp unit	Bk	3
		98-18-07		Inspect generator system	Bk	3
		2002-01-11		Throttle friction-shaft	Bk	4
		2002-02-11		Oleo attachment brackets	Bk	4
		2002-03-04		Emergency exit window sealant	Bk	4
		2002-22-02		Engine mount bracket	Bk	4
		2002-24-01		Rear engine-mounting frame	Bk	4
		2002-25-03		Rudder bar assemblies	Bk	4
		2002-25-05		Universal joint shafts	Bk	4
BOEING AIRPLANE CO., WICHITA DIVISION						
A75L3, 75, A-75, B-75,	A-743	46-24-01		Wing drain holes	Bk	1
E-75, A75J-1, D75N1,		49-23-01		Fuselage truss	Bk	1
A75N1, B75N1,		50-06-02		Wing spar inspection	Bk	1
A75L300 Series		60-08-02		Longeron cracks	Bk	1
		63-13-01		Inspection of propellers	Bk	1
BOEING OF CANADA						
(See DEHAVILLAND)						
BOMBARDIER, INC.						
(Formerly deHavilland)						
(For AD's in Bk 1 and 2 see DeHavilland)						
DHC-3 (U-1A)	A-815	56-17-02		Flap control restriction	Bk	1
(Otter)		76-08-05		Various modifications	Bk	1
		83-02-01		Wing strut tie-bar	Bk	2
		83-04-05		Control column lower assy.	Bk	2
		86-16-12		Inspect elevator pushrod	Bk	2
		88-15-08		Utility seat forward leg	Bk	2
		92-08-08		Fuel condition lever lock	Bk	3
		96-09-04		Tailplane main rib forward & lower flanges	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		98-18-08		Voltage regulator, voltage-ammeter gauge, and auxiliary bus systems	Bk	3
		2004-05-01	R1	Elevator servo trim tab system	Bk	4
		2004-21-06		Lockwire security	Bk	4
		2004-24-01		Elevator servo tab balance assembly	Bk	4
		2004-24-10		Electrical wiring to engine heating blankets	Bk	4\
DHC-6 Series (Twin Otter)	A9EA	67-28-03		Horizontal stabilizer	Bk	1
		67-33-01		Anti-collision light	Bk	1
		67-33-02		Left elevator trim tab	Bk	1
		68-26-02		Wing strut inspection	Bk	1
		69-05-01	R2	Control column sub-assy cracks	Bk	1
		69-08-12		Flight controls	Bk	1
		71-11-01		Protection for circuit wires	Bk	1
		71-14-05		Possible explosion in bays 9 and 2	Bk	1
		71-16-01		Fuel cell flapper valves	Bk	1
		71-21-07		Loss of AC power system	Bk	1
		73-20-05		Float to fuselage bolts	Bk	1
		74-08-11		Side seat rail attachment	Bk	1
		74-22-06		Horizontal stabilizer	Bk	1
		75-08-02		Aileron control cable	Bk	1
		75-24-15		A.C. power	Bk	1
		75-26-07		Electrical fire hazards	Bk	1
		76-07-08		Water leakage-float models	Bk	1
		76-13-06		Lightning protection	Bk	1
		78-01-05		Electrical failure	Bk	1
		79-14-01		Elevator control system	Bk	1
		80-03-08		Flap control rod tubes	Bk	2
		80-13-10		Y-joint MLG legs	Bk	2
		80-13-11	R2	Rod assemblies	Bk	2
		80-13-12	R1	Longerons	Bk	2
		80-13-13		Struts	Bk	2
		81-22-03		Elevator torque tube	Bk	2
		82-26-06		Windscreen washer/deicing system	Bk	2
		93-10-08		Controls in overhead control console	Bk	3
DHC-6-1	A9EA	83-02-02		Structural components	Bk	2
		87-03-12		Utility seat-forward legs	Bk	2
		87-04-23		Wing support strut	Bk	2
		89-24-06	R1	Elevator quadrant	Bk	2
		90-11-01		Elevator pushrod assembly	Bk	3
		93-02-04		Elevator support assembly	Bk	3
		93-10-08		Controls in overhead control console	Bk	3
		94-04-01		Wing attachment fittings	Bk	3
		94-08-10		Wing main spar	Bk	3
		94-14-22		Elevator control support	Bk	3
		95-18-10		Elevator root rib	Bk	3
		95-18-11		Wing rear spar attachment caps	Bk	3
		95-21-14		Tailplane outboard hinge arm assy.	Bk	3
		95-22-07		Horizontal stabilizer attachment fittings	Bk	3
		96-09-11		AFM - Icing	Bk	3
		97-07-10	R1	Inspect wing struts	Bk	3
		97-23-09		Inspect fuselage side frames for cracks	Bk	3
		99-18-13		AFM - Limitation Section - power levers	Bk	3
		2000-06-03		AFM – Limitation section – ice protection sys	Bk	4
DHC-6-100	A9EA	73-19-01		Prop auto-feathering system	Bk	1
		83-02-02		Structural components	Bk	2
		87-03-12		Utility seat-forward legs	Bk	2
		87-04-23		Wing support strut	Bk	2
		89-24-06	R1	Elevator quadrant	Bk	2
		90-11-01		Elevator pushrod assembly	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		93-02-04		Elevator support assembly	Bk	3
		93-10-08		Controls in overhead control console	Bk	3
		94-04-01		Wing attachment fittings	Bk	3
		94-08-10		Wing main spar	Bk	3
		94-14-22		Elevator control support	Bk	3
		95-18-10		Elevator root rib	Bk	3
		95-18-11		Wing rear spar attachment caps	Bk	3
		95-21-14		Tailplane outboard hinge arm assy.	Bk	3
		95-22-07		Horizontal stabilizer attachment fittings	Bk	3
		96-09-11		AFM - Icing	Bk	3
		97-07-10	R1	Inspect wing struts	Bk	3
		97-23-09		Inspect fuselage side frames for cracks	Bk	3
		99-18-13		AFM - Limitation Section - power levers	Bk	3
		2000-06-03		AFM – Limitation section – ice protection sys	Bk	4
DHC-6-200	A9EA	73-19-01		Prop auto-feathering system	Bk	1
		83-02-02		Structural components	Bk	2
		87-03-12		Utility seat-forward legs	Bk	2
		87-04-23		Wing support strut	Bk	2
		89-24-06	R1	Elevator quadrant	Bk	2
		90-11-01		Elevator pushrod assembly	Bk	3
		93-02-04		Elevator support assembly	Bk	3
		93-10-08		Controls in overhead control console	Bk	3
		94-04-01		Wing attachment fittings	Bk	3
		94-08-10		Wing main spar	Bk	3
		94-14-22		Elevator control support	Bk	3
		95-18-10		Elevator root rib	Bk	3
		95-18-11		Wing rear spar attachment caps	Bk	3
		95-21-14		Tailplane outboard hinge arm assy.	Bk	3
		95-22-07		Horizontal stabilizer attachment fittings	Bk	3
		96-09-11		AFM - Icing	Bk	3
		97-07-10	R1	Inspect wing struts	Bk	3
		97-23-09		Inspect fuselage side frames for cracks	Bk	3
		99-18-13		AFM - Limitation Section - power levers	Bk	3
		2000-06-03		AFM – Limitation section – ice protection sys	Bk	4
DHC-6-300	A9EA	83-02-02		Structural components	Bk	2
		87-03-12		Utility seat-forward legs	Bk	2
		87-04-23		Wing support strut	Bk	2
		89-24-06	R1	Elevator quadrant	Bk	2
		90-11-01		Elevator pushrod assembly	Bk	3
		93-02-04		Elevator support assembly	Bk	3
		93-10-08		Controls in overhead control console	Bk	3
		94-04-01		Wing attachment fittings	Bk	3
		94-08-10		Wing main spar	Bk	3
		94-14-22		Elevator control support	Bk	3
		95-18-10		Elevator root rib	Bk	3
		95-18-11		Wing rear spar attachment caps	Bk	3
		95-21-14		Tailplane outboard hinge arm assy.	Bk	3
		95-22-07		Horizontal stabilizer attachment fittings	Bk	3
		96-09-11		AFM - Icing	Bk	3
		97-07-10	R1	Inspect wing struts	Bk	3
		97-23-09		Inspect fuselage side frames for cracks	Bk	3
		99-18-13		AFM - Limitation Section - power levers	Bk	3
		2000-06-03		AFM – Limitation section – ice protection sys	Bk	4

BOOTH, LEE F. (dba Taylorcraft Aerospace)
(See Taylorcraft 2000, LLC)
(Formerly Taylorcraft Aircraft Co.)
(See TAYLORCRAFT, INC. for BF, BL & DC Series)
(See Taylorcraft Aircraft for Book 1 and 2)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
BRITISH AEROSPACE (Aircraft Group)						
(Formerly SCOTTISH AVIATION)						
(Formerly JETSTREAM)						
B.206 Series 1	A11EU	77-23-05		Wing or empennage assemblies	Bk	1
B.206 Series 2	A11EU	77-23-05		Wing or empennage assemblies	Bk	1
		78-12-02		Exhaust system bellows assembly	Bk	1
B.121 Series 1, 2, 3	A22EU	76-08-03		Flap actuating lever	Bk	1
		83-04-06		Engine mounting structure	Bk	2
		83-06-06		Rudder control lever assembly	Bk	2
		86-23-07		Vertical fin/fuselage structure	Bk	2
		91-10-06		Flight control column handgrips	Bk	3
		92-07-06		Wing/fuselage joint plate	Bk	3
		98-16-15		Fuselage main-spar attachment fittings	Bk	3
		98-26-05		Brake torque tube assemblies	Bk	3
HP 137 MK.1, Series 200	A21EU	70-15-04		Relocating fuel and hydraulic valves	Bk	1
(TC A21EU - See Jetstream for		72-23-01		Nacelle fire prevention	Bk	1
ADs in Bk 2)		73-12-10		DC power control box	Bk	1
		75-17-03		Wing fuselage fittings	Bk	1
		76-26-04		Flap separation	Bk	1
		83-05-08	R1	Fuel filter bleed pipe inspection	Bk	2
		83-07-07		Rudder jamming	Bk	2
		83-07-15		Cabin differential pressure gauge	Bk	2
		84-11-05		Placard -Max. flap ext. speed	Bk	2
		86-24-06		Aileron-stud and nut	Bk	2
		87-02-04		Inspect main landing gear	Bk	2
		87-13-06		Main landing gear legs	Bk	2
		89-03-07		SB 57-A-JA880144	Bk	2
		91-14-01		MLG wheel bearings	Bk	3
		91-15-08		Engine power lever control cables	Bk	3
		92-07-04		Emergency gear & flap exten. sys.	Bk	3
		93-01-02		Tailplane de-icing system	Bk	3
		94-24-01		Flap torque shaft assembly	Bk	3
		95-01-08		Rudder control	Bk	3
		95-02-05		Passenger/crew door internal handle	Bk	3
		95-02-19		Inspect left & right windscreens	Bk	3
		95-15-12		Limitations - flaps	Bk	3
		95-16-06		Lower wing skins inspection	Bk	3
		95-24-13		Inspect mounting spigots for cracks	Bk	3
		96-11-02		Inspect spigot housing plate	Bk	3
		96-17-12		Nose landing gear securing bolts	Bk	3
		97-07-11		NLG actuator support structure	Bk	3
		97-10-05		Main landing gear	Bk	3
		98-12-23		Windshield wiper arm, NLG toggle, and axle bracket lugs	Bk	3
		99-06-11		Elevator bias spring assembly	Bk	3
		99-06-12		Nose landing gear steering	Bk	3
		99-15-11		NLG steering selector valve	Bk	3
		2000-16-13		Nose wheel steering system	Bk	4
		2000-20-13		Rudder quadrant structure	Bk	4
		2000-23-33		Inspect vertical stabilizer	Bk	4
		2001-01-02		Steering jack piston rods	Bk	4
		2001-01-03		Nose landing gear steering actuator	Bk	4
		2001-03-11		MLG radius rods	Bk	4
		2002-01-05		Main landing gear (MLG) radius rods	Bk	4
		2002-03-02		MLG hinge fitting & attachment bolts	Bk	4
		2003-04-07		Horizontal & vertical stabilizer attach. fittings	Bk	4
		2003-07-06		Steering jack piston rod	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
Jetstream 3101	A21EU	83-22-07		AFM-icing	Bk	2
		84-11-05		Placard max. flap ext. speed	Bk	2
		85-06-06		Emergency lighting system	Bk	2
		85-10-01		Rear turbine bearing inspection	Bk	2
		85-19-08		Spigot flange	Bk	2
		86-16-04	R1	Inspect flap torque shaft	Bk	2
		86-21-09		Hydraulic pressure pipe	Bk	2
		86-24-06		Aileron -stud and nut	Bk	2
		86-24-08		Electrical supply source mod.	Bk	2
		86-24-10		POH/AFM appendix-icing	Bk	2
		87-02-04		Inspect main landing gear	Bk	2
		87-03-03		Valves	Bk	2
		87-13-06		Main landing gear legs	Bk	2
		88-13-02		Propeller RPM levers	Bk	2
		88-18-07		Cable terminal ends	Bk	2
		89-03-07		SB 57-A-JA880144	Bk	2
		89-07-06		Engine fire extinguisher systems	Bk	2
		89-15-09		Electrical system	Bk	2
		89-16-04		Autopilot elevator trim cable	Bk	2
		89-16-06		SB 11-A-JA880140	Bk	2
		90-15-16		Cabin door structure	Bk	3
		91-14-01		MLG wheel bearings	Bk	3
		91-15-08		Engine power lever control cables	Bk	3
		92-07-04		Emergency gear & flap exten. sys.	Bk	3
		93-01-02		Tailplane de-icing system	Bk	3
		93-08-10		AFM preflight main cabin door checks	Bk	3
		94-24-01		Flap torque shaft assembly	Bk	3
		95-02-05		Passenger/crew door internal handle	Bk	3
		95-02-06		AFM limitations - flaps	Bk	3
		95-02-19		Inspect left & right windscreen	Bk	3
		95-11-17		Electrical system	Bk	3
		95-12-06		Shear fitting of right-hand escape hatch	Bk	3
		95-15-13		Passenger/crew door	Bk	3
		95-17-10		Central annunicator panel test button circuit	Bk	3
		95-24-13		Inspect mounting spigots for cracks	Bk	3
		96-09-17		AFM - Icing	Bk	3
		96-11-01		Automatic airframe de-ice system	Bk	3
		96-11-02		Inspect spigot housing plate	Bk	3
		96-17-12		Nose landing gear securing bolts	Bk	3
		97-07-11		NLG actuator support structure	Bk	3
		97-10-05		Main landing gear	Bk	3
		97-24-07		Magnetically latching relays	Bk	3
		98-11-31		Autopilot elevator electric system	Bk	3
		98-12-11		Emergency hydraulic hand-pump	Bk	3
		98-12-23		Windshield wiper arm and NLG toggle and axle bracket lugs	Bk	3
		98-12-31		Fuel cross feed pipes	Bk	3
		98-21-13		Elevator trim servo motor	Bk	3
		98-21-14		Navigation system	Bk	3
		98-21-25		Ground inhibit relay	Bk	3
		98-21-28		Propeller de-icing system	Bk	3
		99-01-06		Bonding socket at fueling points	Bk	3
		99-01-07		Lower fuselage skin panels	Bk	3
		99-04-21		MLG brakes units	Bk	3
		99-06-11		Elevator bias spring assembly	Bk	3
		99-06-12		Nose landing gear steering	Bk	3
		99-15-11		NLG steering selector valve	Bk	3
		2000-16-13		Nose wheel steering system	Bk	4
		2000-20-13		Rudder quadrant structure	Bk	4
		2001-01-02		Steering jack piston rods	Bk	4
		2001-01-03		Nose landing gear steering actuator	Bk	4
		2001-03-11		MLG radius rods	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		2002-01-05	Main landing gear (MLG) radius rods	Bk	4
		2002-03-02	MLG hinge fitting & attachment bolts	Bk	4
		2003-04-07	Horizontal & vertical stabilizer attach. fittings	Bk	4
		2003-07-06	Steering jack piston rod	Bk	4
Jetstream Model 3201	A56EU	90-15-16	Cabin door structure	Bk	3
		91-14-01	Main landing gear bearings	Bk	3
		91-15-08	Engine power control cables	Bk	3
		92-03-04	Wing main spar webs	Bk	3
		92-07-04	Emergency gear & flap exten. sys.	Bk	3
		93-01-02	Tailplane de-icing system	Bk	3
		93-08-10	AFM changes-main cabin door checks	Bk	3
		94-24-01	Flap torque shaft assembly	Bk	3
		95-02-05	Passenger/crew door internal handle	Bk	3
		95-02-19	Inspect left & right windscreens	Bk	3
		95-11-17	Electrical system	Bk	3
		95-12-06	Shear fitting of right hand escape hatch	Bk	3
		95-15-13	Passenger/crew door	Bk	3
		95-17-10	Central annunciator panel test button circuit	Bk	3
		95-24-12	MLG bay forward lower edge wing skin	Bk	3
		95-24-13	Inspect mounting spigots	Bk	3
		96-09-17	AFM - Icing	Bk	3
		96-11-01	Automatic airframe de-ice system	Bk	3
		96-13-02	Inspect spigot housing plate	Bk	3
		96-17-12	Nose landing gear bolts	Bk	3
		97-07-11	NLG actuator support structure	Bk	3
		97-10-05	Main landing gear	Bk	3
		97-24-07	Magnetically ltching relays	Bk	3
		98-12-23	Windshield wiper arm and NLG toggle and axle bracket lugs	Bk	3
		98-21-25	Ground inhibit relay	Bk	3
		98-26-17	MLG bay auxiliary spar booms	Bk	3
		99-04-21	MLG brakes units	Bk	3
		99-06-11	Elevator bias spring assembly	Bk	3
		99-06-12	Nose landing gear steering	Bk	3
		99-07-09	Hydraulic components	Bk	3
		99-15-11	NLG steering selector valve	Bk	3
		2000-16-13	Nose wheel steering system	Bk	4
		2000-20-13	Rudder quadrant structure	Bk	4
		2001-01-02	Steering jack piston rods	Bk	4
		2001-01-03	Nose landing gear steering actuator	Bk	4
		2001-03-11	MLG radius rods	Bk	4
		2002-01-05	Main landing gear (MLG) radius rods	Bk	4
		2002-20-08	Insulation wiring within the fuel tanks	Bk	4
		2003-04-07	Horizontal & vertical stabilizer attach. fittings	Bk	4
		2003-07-06	Steering jack piston rod	Bk	4

BRITTEN-NORMAN, LTD
(See also PILATUS BRITTEN-NORMAN)
(See B-N Group LTD)

BURKHART GROB LUFT-UND RAUMFAHRT
(See Grob-Werke)

CAMAIR AIRCRAFT CORP. - FRED GARCIA

480	2A2	63-21-05	Main and nose retraction links	Bk	1

CESSNA AIRCRAFT CORP.

T-50	A-722	46-01-01	Flap chain	Bk	1
(AT-17, UC-78, JRC-1)		46-01-02	Wing covering	Bk	1
		46-12-01	Fabric inspection	Bk	1
		46-46-03	Aileron and flap hinge brackets	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		47-05-01	Fuel shutoff valve handle	Bk	1
		47-30-02	Brake pedal links	Bk	1
		47-30-03	Wing inspection for I.D.	Bk	1
		47-30-04	Landing gear chains	Bk	1
		51-18-01	Rudder torque tube	Bk	1
		51-25-01	Horizontal stabilizer	Bk	1
		53-06-01	Landing light motor circuit	Bk	1
		53-18-01	Goodrich wheel bearing	Bk	1
		56-21-02	Spar deterioration	Bk	1
120	A-768	46-44-01	Rudder stop bolts	Bk	1
		46-44-02	Safety belt bracket reinforcement	Bk	1
		46-44-03	Windshield retaining channel	Bk	1
		46-44-04	Carburetor hot air ducts	Bk	1
		46-44-05	Engine mounting bolts	Bk	1
		47-06-10	Aileron carry-through bar	Bk	1
		47-06-11	Forward doorpost cracks	Bk	1
		47-26-02	Wing leading edge rework	Bk	1
		47-43-01	Primer line relocation	Bk	1
		47-43-02	Fuel selector valve handle	Bk	1
		47-43-03	Seaplane spreader struts	Bk	1
		47-43-04	Rudder control cable horns	Bk	1
		47-43-05	Elevator spar web reinforcement	Bk	1
		47-43-06	Aileron support ribs	Bk	1
		47-43-08	Beech R003-201 propeller blades	Bk	1
		47-50-02	Fuselage bulkhead	Bk	1
		48 05-04	Operator limitations placard	Bk	1
		48-07-01	Stabilizer attaching bolts	Bk	1
		48-25-02	Welded exhaust muffler	Bk	1
		48-25-03	Wing drag wire system	Bk	1
		50-31-01	Fin spar reinforcement	Bk	1
		51-21-01	Rudder rib flanges	Bk	1
		61-25-01	Met-Co-Aire landing gear	Bk	1
		62-24-03	Cabin heat system	Bk	1
		79-08-03	Electrical system	Bk	1
		2004-19-01	Shoulder harness adjuster	Bk	4
140	A-768	46-44-01	Rudder stop bolts	Bk	1
		46-44-02	Safety belt bracket reinforcement	Bk	1
		46-44-03	Windshield retaining channel	Bk	1
		46-44-04	Carburetor hot air ducts	Bk	1
		46-44-05	Engine mounting bolts	Bk	1
		47-06-10	Aileron carry-through bar	Bk	1
		47-06-11	Forward doorpost cracks	Bk	1
		47-26-02	Wing leading edge rework	Bk	1
		47-43-01	Primer line relocation	Bk	1
		47-43-02	Fuel selector valve handle	Bk	1
		47-43-03	Seaplane spreader struts	Bk	1
		47-43-04	Rudder control cable horns	Bk	1
		47-43-05	Elevator spar web reinforcement	Bk	1
		47-43-06	Aileron support ribs	Bk	1
		47-43-08	Beech R003-201 propeller blades	Bk	1
		47-50-02	Fuselage bulkhead	Bk	1
		48-05-04	Operator limitations placard	Bk	1
		48-07-01	Stabilizer attaching bolts	Bk	1
		48-25-02	Welded exhaust muffler	Bk	1
		48-25-03	Wing drag wire system	Bk	1
		50-31-01	Fin spar reinforcement	Bk	1
		51-21-01	Rudder rib flanges	Bk	1
		61-25-01	Met-Co-Aire landing gear	Bk	1
		62-24-03	Cabin heat system	Bk	1
		79-08-03	Electrical system	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2004-19-01		Shoulder harness adjuster	Bk	4
140A	5A2	61-25-01		Met-Co-Aire landing gear	Bk	1
		62-24-03		Cabin heat system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		2004-19-01		Shoulder harness adjuster	Bk	4
150 Series	3A19	62-22-01		Vacuum pump modification	Bk	1
		67-03-01		Exhaust gas heat exchangers	Bk	1
		68-17-04		Stall warning system	Bk	1
		71-22-02		Cracks in nose gear fork	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
150	3A19	Refer to the following AD's for the applicable serial numbers.				
		73-23-07		Defective spar attach fittings	Bk	1
		74-06-02		AVCON mufflers	Bk	1
		75-15-08		Engine lubrication	Bk	1
		77-02-09		Wing flap system	Bk	1
		86-15-07		Modification-larger engine	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
150A	3A19	75-15-08		Engine lubrication	Bk	1
		86-15-07		Modification-larger engine	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
150B	3A19	75-15-08		Engine lubrication	Bk	1
		86-15-07		Modification-larger engine	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
150C	3A19	75-15-08		Engine lubrication	Bk	1
		86-15-07		Modification-larger engine	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
150D	3A19	75-15-08		Engine lubrication	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2004-19-01		Shoulder harness adjuster	Bk	4
150E	3A19	75-15-08		Engine lubrication	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
150F	3A19	72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
150G	3A19	67-31-04		Removal of glove compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
150H	3A19	67-31-04		Removal of glove compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
150J	3A19	72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
150K	3A19	72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
150L	3A19	72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
150M	3A19	80-06-03		Wing flap cable clamp	Bk	2
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A150 Series	3A19	79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
A150	3A19	Refer to the following AD's for the applicable serial numbers.				
		73-23-07		Defective spar attach fittings	Bk	1
		77-02-09		Wing flap system	Bk	1
A150K	3A19	72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-01-01		High speed flutter	Bk	1
		79-08-03		Electrical system	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A150L	3A19	72-03-03	R3	Wing flap jack screw	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-01-01		High speed flutter	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A150M	3A19	78-25-07		Vertical fin attach brackets	Bk	1
		80-06-03		Wing flap cable clamp	Bk	2
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		88-15-06		Battery location	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
152	3A19	79-02-06		Exhaust system	Bk	1
		80-01-06		Flap actuator assembly	Bk	2
		80-06-03		Wing flap cable clamp	Bk	2
		80-11-04		Cracked nutplates	Bk	2
		81-05-01		Fuel tank capacity	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A152	3A19	78-25-07		Vertical fin attach brackets	Bk	1
		79-02-06		Exhaust system	Bk	1
		80-01-06		Flap actuator assembly	Bk	2
		80-06-03		Wing flap cable clamp	Bk	2
		80-11-04		Cracked nutplates	Bk	2
		81-05-01		Fuel tank capacity	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-05		Placard-spins	Bk	2
		96-12-23		Wing stall fence height	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F150	A13EU	68-17-04		Stall warning system	Bk	1
F150F (Reims)	- -	72-03-03	R3	Wing flap jack screw	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F150G (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		80-11-04		Cracked nutplates	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F150H (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F150J (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F150K (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F150L (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F150M (Reims)	A13EU	80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FA150K (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		76-01-01		High speed flutter	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
FA150L (Reims)	A13EU	72-03-03	R3	Wing flap jack screw	Bk	1
		76-01-01		High speed flutter	Bk	1
		80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FA150M		2000-06-01		Fuel strainer assembly	Bk	4
FRA150L	A13EU	80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FRA150M	A13EU	80-11-04		Cracked nutplates	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-15-06		Battery location	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F152 (Reims)	A13EU	80-01-06		Flap actuator assembly	Bk	2
		80-11-04		Cracked nutplates	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FA152 (Reims)	A13EU	80-01-06		Flap actuator assembly	Bk	2
		80-11-04		Cracked nutplates	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
170 Series	A-799	48-43-02		Continental C-145-2 engines	Bk	1
		69-15-03		Muffler assembly	Bk	1
		73-17-01		Fuel transfer pump placard	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
170	A-799	Refer to the following AD's for the applicable serial numbers.				
		74-06-02		AVCON mufflers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		2004-19-01		Shoulder harness adjuster	Bk	4
170A	A-799	82-07-02		Engine crankcase breather	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		2004-19-01		Shoulder harness adjuster	Bk	4
170B	A-799	82-07-02		Engine crankcase breather	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
172 Series	3A12	69-15-03		Muffler assembly	Bk	1
		71-18-01		Fuel selector valve placard	Bk	1
		71-22-02		Cracks in nose gear fork	Bk	1
		73-17-01		Fuel transfer pump placard	Bk	1
		74-04-01		Aft fuselage bulkhead assy	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
172	3A12	Refer to the following AD's for the applicable serial numbers.				
		59-10-03		Flasher switch	Bk	1
		68-17-04		Stall warning system	Bk	1
		72-07-02		Selector valve placard	Bk	1
		73-23-07		Defective spar attach fittings	Bk	1
		74-06-02		AVCON mufflers	Bk	1
		77-02-09		Wing flap system	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		90-06-03	R1	Exhaust heater/muffler assembly	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
172A	3A12	72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
172B	3A12	68-19-05		Utility category placard	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
172C	3A12	68-19-05		Utility category placard	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
172D	3A12	68-19-05		Utility category placard	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
				(see Bk 4 for paper copy)		
		2004-19-01		Shoulder harness adjuster	Bk	4
172E	3A12	68-19-05		Utility category placard	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves	Bk	3
				(see Bk 4 for paper copy)		
		2004-19-01		Shoulder harness adjuster	Bk	4
172F	3A12	68-19-05		Utility category placard	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves	Bk	3
				(see Bk 4 for paper copy)		
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
172G	3A12	68-19-05		Utility category placard	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves	Bk	3
				(see Bk 4 for paper copy)		
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
172H	3A12	68-17-04		Stall warning system	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves	Bk	3
				(see Bk 4 for paper copy)		
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
172I	3A12	68-17-04		Stall warning system	Bk	1
		70-10-06		Oil pressure instrument line	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
172K	3A12	70-10-06		Oil pressure instrument line	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-02		Selector valve placard	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
172L	3A12	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
172M	3A12	76-04-03		ARC PA-500A actuators	Bk	1
		76-21-06		Loss of engine oil	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		83-10-03		Control wheel yoke guide mod.	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
172N	3A12	76-21-06		Loss of engine oil	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		80-06-03		Wing flap cable clamp	Bk	2
		81-05-01		Fuel tank capacity	Bk	2
		81-16-09		Elevator control system	Bk	2
		82-07-02		Engine crankcase breather	Bk	2
		83-10-03		Control wheel yoke guide mod.	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
172P	3A12	81-05-01		Fuel tank capacity	Bk	2
		81-16-09		Elevator control system	Bk	2
		82-07-02		Engine crankcase breather	Bk	2
		83-10-03		Control wheel yoke guide mod.	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pins	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
172Q	3A12	83-22-06		Aileron hinge pin	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
172R	3A12	97-12-06		Check clearance between cowling and gascolator and cowling and tailpipe	Bk	3
		98-01-01		Placard in cockpit	Bk	3
		98-02-05		Engine exhaust muffler	Bk	3
		98-13-41		Aileron control cables	Bk	3
		98-14-07		Lower forward doorpost	Bk	3
		98-25-03		Aileron control cable	Bk	3
		99-18-14		Control yoke pivot bolt	Bk	3
		2000-04-01		Engine oil pressure switch diaphragm	Bk	4
		2001-06-17		Rough engine operation or engine stoppage	Bk	4
		2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
		2005-05-53	R1	Flight control system	BW 05-07	
		2005-13-10		Main electrical power junction box circuit breakers	BW 05-13	
		2006-17-04		Flexible fuel hoses		
172S	3A12	2000-04-01		Engine oil pressure switch diaphragm	Bk	4
		2001-06-17		Rough engine operation or engine stoppage	Bk	4
		2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
		2005-05-53	R1	Flight control system	BW 05-07	
		2005-13-10		Main electrical power junction box circuit breakers	BW 05-13	
		2006-17-04		Flexible fuel hoses		
F172 (Reims)	A4EU	81-16-09		Elevator control system	Bk	2
		83-10-03		Control wheel yoke guide mod.	Bk	2
F172D (Reims)	A4EU	86-24-07		Engine controls installation	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
F172E (Reims)	A4EU	86-24-07		Engine controls installation	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
F172F (Reims)	A4EU	72-03-03	R3	Wing flap jack screw	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F172G (Reims)	A4EU	72-03-03	R3	Wing flap jack screw	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F172H (Reims)	A4EU	68-17-04		Stall warning system	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
F172K (Reims)	A4EU	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F172L (Reims)	A4EU	76-04-03		ARC PA-500A actuators	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F172M (Reims)	A4EU	76-04-03		ARC PA-500A actuators	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F172N (Reims)	A4EU	83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
F172P (Reims)	A4EU	83-22-06		Aileron hinge pin	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
FP172 (Reims)	--	86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
FR172 (Reims)	A18EU	81-16-09		Elevator control system	Bk	2
		83-10-03		Control wheel yoke guide mod.	Bk	2
FR172E (Reims)	A18EU	72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
FR172F (Reims)	A18EU	72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
FR172G (Reims)	A18EU	72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
FR172H (Reims)	A18EU	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FR172J (Reims)	A18EU	76-04-03		ARC PA-500A actuators	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
FR172K (Reims)	A18EU	83-22-06		Aileron hinge pin	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
172RG	3A17	80-01-06		Flap actuator assembly	Bk	2
		80-19-08		Fuel/air mixture	Bk	2
		81-05-01		Fuel tank capacity	Bk	2
		81-14-06		Rudder trim/nose gear steering bungee	Bk	2
		81-16-09		Elevator control system	Bk	2
		83-14-04		Cabin heater shroud mod.	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		85-20-01		Cabin heat deactivated	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-06-06		Cracks on the design landing gear pivots	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
P172, P172E		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
P172D	3A17	79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
R172 Series	3A17	79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
R172	3A17	Refer to the following AD's for the applicable serial numbers.				
		77-02-09		Wing flap system	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		86-19-11		Contaminated fuel	Bk	2
R172E (T-41B, -41C, -41D)	3A17	72-03-03	R3	Wing flap jack screw	Bk	1
		73-20-04		Fuel boost electrical circuit	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
R172F (T-41D, -41C)	3A17	72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
R172G (T-41D)	3A17	72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
R172H (T-41D)	3A17	72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
R172J	3A17	86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
R172K	3A17	77-12-08		External elec. ground power recep	Bk	1
		80-06-03		Wing flap cable clamp	Bk	2
		80-07-03		Oil pressure	Bk	2
		81-05-01		Fuel tank capacity	Bk	2
		81-16-09		Elevator control system	Bk	2
		83-10-03		Control wheel yoke guide mod.	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2001-23-03		Doorpost map light switch insulator	Bk	4
175 Series	3A17	69-15-03		Muffler assembly	Bk	1
		71-22-02		Cracks in nose gear fork	Bk	1
		73-17-01		Fuel transfer pump placard	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
175	3A17	Refer to the following AD's for the applicable serial numbers.				
		62-22-01		Vacuum pump modification	Bk	1
		74-06-02		AVCON mufflers	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2004-19-01		Shoulder harness adjuster	Bk	4
175A	3A17	62-22-01		Vacuum pump modification	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
175B	3A17	62-22-01		Vacuum pump modification	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
175C	3A17	62-22-01		Vacuum pump modification	Bk	1
		82-07-02		Engine crankcase breather	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
177 Series	A13CE	70-24-04		Fuel shut-off valve	Bk	1
		71-01-03		Cracks in stabilizer attachment angles	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
177	A13CE	Refer to the following AD's for the applicable serial numbers.				
		68-07-09		Longitudinal control system	Bk	1
		68-17-04		Stall warning system	Bk	1
		68-18-02		Oil pressure line	Bk	1
		70-01-02		Fuel quantity transmitter float	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		74-16-06		Oil Pressure gage line	Bk	1
		75-07-02		Air filter seal	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
177A	A13CE	70-01-02		Fuel quantity transmitter float	Bk	1
		71-01-03		Cracks in stabilizer attachment angles	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
177B	A13CE	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-14-08		Trim tab actuator	Bk	1
		76-21-06		Loss of engine oil	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		99-27-02		Fuel selector valve cams or valves *(see Bk 4 for paper copy)*	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
177RG	A20CE	72-03-03	R3	Wing flap jack screw	Bk	1
		74-16-06		Oil pressure gage line	Bk	1
		75-07-02		Air filter seal	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-14-08		Trim tab actuator	Bk	1
		76-21-06		Loss of engine oil	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		79-08-03		Electrical system	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-12-12		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F177RG (Reims)	A26EU	72-03-03	R3	Wing flap jack screw	Bk	1
		74-16-06		Oil pressure gage line	Bk	1
		75-07-02		Air filter seal	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-12-12		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
180 Series	5A6	68-17-04		Stall warning system	Bk	1
		73-17-01		Fuel transfer pump placard	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-04-05		Carburetor air intake	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14		Fuel tank venting	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
180	5A6	Refer to the following AD's for the applicable serial numbers.				
		59-10-03		Flasher switch	Bk	1
		73-23-07		Defective spar attach fittings	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		90-21-08		Fuel tank bladder	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
180A	5A6	59-10-03		Flasher switch	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180B	5A6	83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180C	5A6	83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180D	5A6	83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180E	5A6	83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180F	5A6	83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180G	5A6	83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
180H	5A6	76-04-03		ARC PA-500A actuators	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
180J	5A6	73-23-07		Defective spar attachment fitting	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
180K	5A6	77-12-08		External elec. ground power recep	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
182 Series	3A13	71-22-02		Cracks in nose gear fork	Bk	1
		72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		73-17-01		Fuel transfer pump placard	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-04-05		Carburetor air intake	Bk	1
		77-23-11		ELT installation	Bk	1
		78-01-14		ELT installation	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
182	3A13	Refer to the following AD's for the applicable serial numbers.				
		59-10-03		Flasher switch	Bk	1
		73-23-07		Defective spar attachment fitting	Bk	1
		75-05-02		Engine oil	Bk	1
		77-02-09		Wing flap system	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182A	3A13	59-10-03		Flasher switch	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182B	3A13	75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
182C	3A13	75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182D	3A13	75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182E	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182F	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182G	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
182H	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
182J	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
182J continued		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
182K	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
182L	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
182M	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
182N	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		75-05-02		Engine oil	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
182P	3A13	75-05-02		Engine oil	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		77-14-09		Aircraft controllability	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
182Q	3A13	77-12-08		External elec. ground power recep	Bk	1
		77-14-09		Aircraft controllability	Bk	1
		83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
182R	3A13	83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
182S	3A13	98-01-01		Placard in cockpit	Bk	3
		98-01-14		Engine exhaust muffler	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-02-14		Placard - Engine backfire	Bk	4
		2000-04-01		Engine oil pressure switch diaphragm	Bk	4
		2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
182T	3A13	2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
		2005-05-53	R1	Flight control system	BW	05-07
		2005-13-10		Main electrical power junction box circuit breakers	BW	05-13
		2006-17-04		Flexible fuel hoses		
R182	3A13	83-13-01		Placard -improper fuel cap sealing	Bk	2
		83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		84-10-01	R1	Bladder fuel cells	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
T182	3A13	83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
T182T	3A13	2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
		2005-05-53	R1	Flight control system	BW	05-07
		2005-13-10		Main electrical power junction box circuit breakers	BW	05-13
		2006-17-04		Flexible fuel hoses		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
TR182	3A13	83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A182 Series	3A13	84-10-01	R1	Bladder fuel cells	Bk	1
A182J	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		2000-06-01		Fuel strainer assembly	Bk	4
A182K	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		2000-06-01		Fuel strainer assembly	Bk	4
A182L	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		2000-06-01		Fuel strainer assembly	Bk	4
A182M	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
A182N	3A13	72-03-03	R3	Wing flap jack screw	Bk	1
		2000-06-01		Fuel strainer assembly	Bk	4
F182 Series (Reims)	A42EU	84-10-01	R1	Bladder fuel cells	Bk	2
F182 (Reims)	A42EU	79-25-07		Alternator ground	Bk	1
F182P (Reims)	A42EU	86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F182Q (Reims)	A42EU	83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FR182 Series (Reims)	A42EU	84-10-01	R1	Bladder fuel cells	Bk	2
FR182 (Reims)	A42EU	83-22-06		Aileron hinge pin	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
185 Series	3A24	75-16-01		Wing fuel tanks	Bk	1
		77-04-05		Carburetor air intake	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
185	3A24	Refer to the following AD's for the applicable serial numbers.				
		68-17-04		Stall warning system	Bk	1
		73-23-07		Defective spar attach fittings	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
185 continued		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
185A	3A24	83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
185B	3A24	83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
185C	3A24	83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
185D	3A24	83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
185E	3A24	83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		93-24-15		Replace instrument panel light rheostat	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
185F	3A24	93-24-15		Replace instrument panel light rheostat	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A185 Series	3A24	75-09-06		Engine induction air duct	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-25-07		Alternator ground	Bk	1
A185E	3A24	68-17-04		Stall warning system	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
A185F	3A24	76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		83-17-06		Aileron balance weights	Bk	2
		83-22-06		Aileron hinge pin	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-20-04		Fuel system	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-16-04		Inspect angle stiffener along lower spar cap	Bk	3
		98-23-02		Airglas Engrg. ski installation	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
188 Series	A9CE	73-16-02		Strands on control cables	Bk	1
		77-04-05		Carburetor air intake	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
188	A9CE	Refer to the following AD's for the applicable serial numbers.				
		68-07-07		Rudder pedal assembly	Bk	1
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
188A	A9CE	87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
188B	A9CE	86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A188 Series	A9CE	75-09-06		Engine induction air duct	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-04-05		Carburetor air intake	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-25-07		Alternator ground	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A188	A9CE	68-07-07		Rudder pedal assembly	Bk	1
		69-04-02		Throttle bellcrank bracket	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A188A	A9CE	86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
A188B	A9CE	74-23-07		Air inlet duct	Bk	1
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
T188 Series	A9CE	84-10-01	R1	Bladder fuel cells	Bk	2
T188C	A9CE	86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
190 Series	A-790	50-39-01		Rudder cable inspection	Bk	1
		51-10-04		Cowl mounting channels	Bk	1
		51-11-02		Elevator spar	Bk	1
		63-20-02		Wing spar inspection	Bk	1
		79-08-03		Electrical system	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
190	A-790	87-20-03	R2	Seat tracks	Bk	2
		2004-19-01		Shoulder harness adjuster	Bk	4
		2004-21-08		Magnesium aileron hinge brackets	Bk	4
195 Series	A-790	50-39-01		Rudder cable inspection	Bk	1
		51-11-02		Elevator spar	Bk	1
		63-20-02		Wing spar inspection	Bk	1
		79-08-03		Electrical system	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
195	A-790	87-20-03	R2	Seat tracks	Bk	2
		2004-19-01		Shoulder harness adjuster	Bk	4
		2004-21-08		Magnesium aileron hinge brackets	Bk	4
195A	A-790	87-20-03	R2	Seat tracks	Bk	2
		2004-21-08		Magnesium aileron hinge brackets	Bk	4
195B	A-790	87-20-03	R2	Seat tracks	Bk	2
		2004-21-08		Magnesium aileron hinge brackets	Bk	4
206 Series	A4CE	72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
206	A4CE	Refer to the following AD's for the applicable serial numbers.				
		69-08-11		Fuel boost pump	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		77-02-09		Wing flap system	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
P206 Series	A4CE	72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
P206	A4CE	69-08-11		Fuel boost pump	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
P206A	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
P206B	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
P206C	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
P206D	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
P206E	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
U206 Series	A4CE	72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
U206	A4CE	Refer to the following AD's for the applicable serial numbers.				
		69-08-11		Fuel boost pump	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
U206A	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
U206B	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
U206C	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
U206D	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
U206E	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
U206F	A4CE	76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
U206G	A4CE	77-12-08		External elec. ground power recep	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-11-07		STC SA2353NM - voltage regulator & elec. system	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
TP206 Series	A4CE	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		78-07-01		Engine oil pump	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		80-07-01		Oil pressure	Bk	2
		84-10-01	R1	Bladder fuel cells	Bk	2
		88-22-07		Hose assemblies	Bk	2
TP206	A4CE	97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
TP206A	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TP206B	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
TP206C	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TP206D	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TP206E	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TU206 Series	A4CE	71-09-07	R1	Exhaust gases entering cabin	Bk	1
		72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		78-07-01		Engine oil pump	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14		Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		80-07-01		Oil pressure	Bk	2
		84-10-01	R1	Bladder fuel cells	Bk	2
		88-22-07		Hose assemblies	Bk	2
TU206A	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
TU206B	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TU206C	A4CE	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TU206D	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
TU206E	A4CE	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
TU206F	A4CE	76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
TU206G	A4CE	77-12-08		External elec. ground power recep	Bk	1
		79-03-03		Engine oil pressure	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-11-07		STC SA2353NM - voltage regulator & elec. system	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
206H	A4CE	99-13-04		Aileron control bellcrank stop bolts & lock nuts	Bk	3
		2000-04-01		Engine oil pressure switch diaphragm	Bk	4
		2001-09-06		Horizontal stabilizer attachment brackets	Bk	4
		2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
		2005-13-10		Main electrical power junction box circuit breakers	BW 05-13	
T206H	A4CE	99-13-04		Aileron control bellcrank stop bolts & lock nuts	Bk	3
		2000-04-01		Engine oil pressure switch diaphragm	Bk	4
		2001-09-06		Horizontal stabilizer attachment brackets	Bk	4
		2003-24-13		Autopilot computer system	Bk	4
		2004-15-18		Autopilot system	Bk	4
		2005-13-10		Main electrical power junction box circuit breakers	BW 05-13	
207 Series	A16CE	72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-02-09		Wing flap system	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
207	A16CE	Refer to the following AD's for the applicable serial numbers.				
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
207A	A16CE	77-12-08		External elec. ground power recep	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
T207 Series	A16CE	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		75-16-01		Wing fuel tanks	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		78-07-01		Engine oil pump	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		80-07-01		Oil pressure	Bk	2
		84-10-01	R1	Bladder fuel cells	Bk	2
		88-22-07		Hose assemblies	Bk	2
T207	A16CE	Refer to the following AD's for the applicable serial numbers.				
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T207A	A16CE	77-12-08		External elec. ground power recep	Bk	1
		79-03-03		Engine oil pressure	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-17-07		Wing rear spar	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
208	A37CE	86-22-06		Cessna Bulletins CAB86-8 and CAB86-26	Bk	2
		90-05-01		Bellcrank assembly	Bk	3
		90-05-04		Engine mount ring	Bk	3
		96-09-15		AFM - Icing	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		97-25-04		AFM - Limitations - Power levers	Bk	3
		2004-08-17		Nuts on wing struts upper attachment bolts	Bk	4
		2004-17-01		Inboard forward flap bellcranks	Bk	4
		2006-01-11	R1	Cargo pod and landing gear fairings	BW	06-11
		2006-06-06		Airplane Flight Manual (AFM)	BW	06-11

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
208A	A37CE	86-22-06		Cessna Bulletins CAB86-8 and CAB86-26	Bk	2
		90-05-01		Bellcrank assembly	Bk	3
		90-05-04		Engine mount ring	Bk	3
		97-25-04		AFM - Limitations - Power levers	Bk	3
208B	A37CE	88-19-06		Elevators	Bk	2
		90-05-01		Bellcrank assembly	Bk	3
		90-05-04		Engine mount ring	Bk	3
		96-09-15		AFM - Icing	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		97-25-04		AFM - Limitations - Power levers	Bk	3
		2004-08-17		Nuts on wing struts upper attachment bolts	Bk	4
		2004-17-01		Inboard forward flap bellcranks	Bk	4
		2006-01-11	R1	Cargo pod and landing gear fairings	BW 06-11	
		2006-06-06		Airplane Flight Manual (AFM)	BW 06-11	
210 Series	3A21	72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
210	3A21	Refer to the following AD's for the applicable serial numbers.				
		66-19-02		Fuel system	Bk	1
		69-08-11		Fuel boost pump	Bk	1
		76-04-01		Main gear extension	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		91-22-01		Electrical wires	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
210A	3A21	66-19-02		Fuel system	Bk	1
		76-04-01		Main gear extension	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
210B	3A21	76-04-01		Main gear extension	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
210C	3A21	76-04-01		Main gear extension	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
210D	3A21	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-01		Main gear extension	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
210E	3A21	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
210F	3A21	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T210 Series	3A21	72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		78-07-01		Engine oil pump	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		79-25-07		Alternator ground	Bk	1
		80-07-01		Oil pressure	Bk	2
		84-10-01	R1	Bladder fuel cells	Bk	2
		88-22-07		Hose assemblies	Bk	2
T210	3A21	Refer to the following AD's for the applicable serial numbers.				
		69-08-11		Fuel boost pump	Bk	1
		71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
T210F	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		85-03-01		Throttle and engine mixture	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
T210F continued		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
210G	3A21	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T210G	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
210H	3A21	71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T210H	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		71-24-04		Flexible hoses in engine compartment	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
T210H continued		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
210J	3A21	72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T210J	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		76-14-07	R2	Landing gear saddles	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle and mixture controls	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
210K	3A21	72-03-03	R3	Wing flap jack screw	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
210L	3A21	76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		79-19-06		Fuel flow system per STC SA3835WE	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
(205) 210-5	3A21	69-08-11		Fuel boost pump	Bk	1
		72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-09		Cracks and loose bolts in fin & rudder	Bk	1
		77-16-05		Fuel selector valve	Bk	1
		79-08-03		Electrical system	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		84-10-01	R1	Bladder fuel cells	Bk	2
		85-02-07		Fuel selector	Bk	2
		85-03-01		Throttle induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
(205A) 210-5A	3A21	72-03-03	R3	Wing flap jack screw	Bk	1
		72-07-09		Cracks & loose bolts in fin & rudder	Bk	1
		79-08-03		Electrical system	Bk	1
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
T210K	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		93-13-09		Air induction hose	Bk	3
		94-12-08		Flight manual revision	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T210L	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		79-19-06		Fuel flow system per STC SA3835WE	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-25-04		AFM/POH changes-magneto	Bk	2
		93-13-09		Air induction hose	Bk	3
		94-12-08		Flight manual revision	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
210M	3A21	78-11-05		Autopilot actuator	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		79-19-06		Fuel flow system per STC SA3835WE	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
T210M	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		79-03-03		Engine oil pressure	Bk	1
		79-19-06		Fuel flow system per STC SA3835WE	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-25-04		AFM/POH changes-magneto	Bk	2
		93-13-09		Air induction hose	Bk	3
		94-12-08		Flight manual revision	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
210N	3A21	78-26-12		Fuel quantity system	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		85-10-02		Engine induction airbox	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
P210 Series	3A21	78-11-05		Autopilot actuator	Bk	1
		79-15-01		Fuel flow distribution	Bk	1
		88-22-07		Hose assemblies	Bk	2
P210N	3A21	78-26-12		Fuel quantity system	Bk	1
		79-19-06		Fuel flow system per STC SA3835WE	Bk	1
		79-25-07		Alternator ground	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		81-15-05		Engine and airplane modifications	Bk	2
		81-23-03	R2	Engine exhaust system	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		85-11-07	R1	Turbocharger oil reservoir	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		86-24-07		Engine controls installation	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-25-04		AFM/POH changes-magneto	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
P210N continued		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-05-14	R1	AFM - Limitations Section - icing	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
210R	3A21	86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
P210R	3A21	85-11-07	R1	Turbocharger oil reservoir	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-05-14	R1	AFM - Limitations Section - icing	Bk	3
T210N	3A21	71-09-07	R1	Exhaust manifold heat exchanger	Bk	1
		78-26-12		Fuel quantity system	Bk	1
		80-21-03		Roll axis flight control	Bk	2
		82-06-10		Vacuum-driven-attitude instruments	Bk	2
		85-02-07		Fuel selector	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		88-25-04		AFM/POH changes-magneto	Bk	2
		93-13-09		Air induction hose	Bk	3
		94-12-08		Flight manual revision	Bk	3
		98-05-14	R1	AFM - Limitations Section - icing	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2002-07-01		Horizontal stabilizer attachment brackets	Bk	4
T210R	3A21	85-11-07	R1	Turbocharger oil reservoir	Bk	2
		86-19-11		Contaminated fuel	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		94-12-08		Flight manual revision	Bk	3
		98-20-33		AFM - Limitation Section - icing	Bk	3
T303	A34CE	85-11-05	R1	AFM placard - icing condition		2
		85-23-06		Fuel metering units insp.	Bk	2
		86-01-01	R2	Placard -icing condition	Bk	2
		87-20-03	R2	Seat tracks	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		88-25-04		AFM/POH changes-magneto	Bk	2
		91-11-09		Nose gear actuator fitting	Bk	3
		95-09-13		Fuel inlet float valve	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
305A	5A5	75-04-04		Oil line system	Bk	1
310 Model or Series	3A10	Refer to the AD for the applicable serial numbers.				
		57-04-01		Aileron hinge	Bk	1
		69-12-03		Fuel crossfeed line	Bk	1
		69-15-09		Fuel starvation	Bk	1
		72-03-07		Landing gear failure	Bk	1
		72-14-08	R1	Flexible hose assemblies	Bk	1
		73-07-07		Fuel hoses & electrical wiring chafing	Bk	1
		74-20-08		Fire procedures checklist	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		90-02-13		Main landing gear	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
310A	3A10	69-12-03		Fuel crossfeed line	Bk	1
(U-3A)		69-15-09		Fuel starvation	Bk	1
		74-20-08		Fire procedures checklist	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
310B	3A10	69-12-03		Fuel crossfeed line	Bk	1
		69-15-09		Fuel starvation	Bk	1
		74-20-08		Fire procedures checklist	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
310C	3A10	69-12-03		Fuel crossfeed line	Bk	1
		69-15-09		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
310D	3A10	69-12-03		Fuel crossfeed line	Bk	1
		69-15-09		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310E	3A10	69-12-03		Fuel crossfeed line	Bk	1
(U-3B)		69-15-09		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310F	3A10	69-12-03		Fuel crossfeed line	Bk	1
		69-15-09		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310G	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310H	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
E310H	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
310I	3A10	69-14-01		Fuel starvation	Bk	1
		73-25-01		Heater fuel pump relay relocation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310J	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310J-1	3A10	76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310K	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310L	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
310N	3A10	69-14-01		Fuel starvation	Bk	1
		73-01-02		Alternate air system	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
310P	3A10	69-14-01		Fuel starvation	Bk	1
		73-01-02		Alternate air system	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
310Q	3A10	73-01-02		Alternate air system	Bk	1
		74-20-01		Main landing gear trunnion	Bk	1
		75-23-07		Emergency exit window	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
310R	3A10	75-23-07		Emergency exit window	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		80-13-14		Fuel flow transducer	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
T310P	3A10	69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
T310Q	3A10	70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		75-23-07		Emergency exit window	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
T310R	3A10	75-23-07		Emergency exit window	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		87-21-02	R1	Fuel filler opening	Bk	2
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
E310J	3A10	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
320 Model or Series	3A25	Refer to the AD for the applicable serial numbers.				
		69-15-09		Fuel starvation	Bk	1
		71-09-01		Nacelle electrical failures	Bk	1
		72-14-08	R1	Flexible fuel hose assemblies	Bk	1
		73-07-07		Fuel hoses & electrical wiring chaffing	Bk	1
		75-11-01		Fuel lines	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		90-02-13		Main landing gear	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
320A	3A25	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
320B	3A25	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
320C	3A25	69-14-01		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
320D	3A25	69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
320E	3A25	69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
320F	3A25	69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		2000-01-16		Inspect exhaust system	Bk	4
320-1	3A25	69-15-09		Fuel starvation	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		2000-01-16		Inspect exhaust system	Bk	4
335	3A25	80-13-14		Fuel flow transducer	Bk	2
		80-19-10		Deicer systems in adverse weather	Bk	2
		81-07-11	R1	Balance weight support structure	Bk	2
		82-26-05		Rudder balance weight rib	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
340 Model or Series	3A25	Refer to the AD for the applicable serial numbers.				
		72-03-07		Landing gear failure	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		74-20-01		Main landing gear trunnion	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		78-14-01		Optional storage/refreshment	Bk	1
		81-07-11	R1	Balance weight support structure	Bk	2
		82-26-05		Rudder balance weight rib	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		88-03-07		Insp. fuel lines	Bk	2
		90-02-13		Main landing gear	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
340A	3A25	77-06-05		Fire hazard in oxygen system	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		78-14-01		Optional storage/refreshment	Bk	1
		80-13-14		Fuel flow transducer	Bk	2
		80-19-10		Deicer systems in adverse weather	Bk	2
		81-07-11	R1	Balance weight support structure	Bk	2
		82-26-05		Rudder balance weight rib	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		88-03-07		Insp. fuel lines	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		98-24-14		Exhaust system components	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
321 (Navy OE-2)	3A11	2000-01-16		Inspect exhaust system	Bk	4
336	A2CE	70-15-02		Fuel quantity indicators	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		72-23-03		Wing flap actuator	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		78-16-04		Weight and balance data	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2004-19-01		Shoulder harness adjuster	Bk	4
337 Model or Series	A6CE	Refer to the AD for the applicable serial numbers.				
		70-15-02		Fuel quantity indicators	Bk	1
		71-17-08		Rear engine stoppage on take off	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		72-23-03		Wing flaps	Bk	1
		75-09-05		Pitot system	Bk	1
		77-08-05		Single engine takeoffs	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
337A	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
337B	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
337C	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
337D	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
337E	A6CE	76-04-03		ARC PA-500A actuators	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
337F	A6CE	76-04-03		ARC PA-500A actuators	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
337G	A6CE	76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
337H	A6CE	78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
M337 Series	A6CE	77-08-05		Single engine takeoffs	Bk	1
M337B	A6CE	78-09-05		Wing spar caps and web doublers	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
T337 Model or Series	A6CE	Refer to the AD for the applicable serial numbers.				
		77-08-05		Single engine takeoffs	Bk	1
		79-10-14	R1	Fuel tank venting	Bk	1
T337B	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T337C	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		71-24-04		Flexible hose in engine compartment	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T337D	A6CE	70-15-02		Fuel quantity indicators	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T337E	A6CE	76-04-03		ARC PA-500A actuators	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
		2004-19-01		Shoulder harness adjuster	Bk	4
T337F	A6CE	76-04-03		ARC PA-500A actuators	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
T337G	A6CE	76-04-03		ARC PA-500A actuators	Bk	1
		77-12-08		External elec. ground power recep	Bk	1
		78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
T337H	A6CE	78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
P337H	A6CE	78-09-05		Wing spar caps and web doublers	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
T33H-SP	A6CE	87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
F337E (Reims)	A23EU	76-04-03		ARC PA-500A actuators	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F337F (Reims)	A23EU	76-04-03		ARC PA-500A actuators	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F337G (Reims)	A23EU	76-04-03		ARC PA-500A actuators	Bk	1
		87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F337H (Reims)	A23EU	87-20-03	R2	Seat tracks	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
F337GP (Reims)	A23EU	76-04-03		ARC PA-500A actuators	Bk	1
FP337	- -	87-20-03	R2	Seat tracks	Bk	2
FT337E	A23EU	97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FT337F	A23EU	97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FT337GP	A23EU	97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FT337HP	A23EU	97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
FTB337		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-06-01		Fuel strainer assembly	Bk	4
401 Model or Series	A7CE	Refer to the AD for the applicable serial numbers.				
		69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		71-07-04		Emergency exit window	Bk	1
		72-03-07		Landing gear failure	Bk	1
		72-12-04		Support of fuel lines	Bk	1
		72-14-08	R1	Flexible fuel hose assemblies	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		76-13-07		Fork bolts	Bk	1
		76-16-07		Engine attachment tangs	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		90-02-13		Main landing gear	Bk	3
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW	05-14
		2005-20-25		Avionics bus circuit breaker switches	BW	05-21

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
401A	A7CE	69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		71-07-04		Emergency exit window	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
401B	A7CE	70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		71-07-04		Emergency exit window	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
402 Model or Series	A7CE	Refer to the AD for the applicable serial numbers.				
		69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		71-07-04		Emergency exit window	Bk	1
		72-03-07		Landing gear failure	Bk	1
		72-12-04		Support of fuel lines	Bk	1
		72-14-08	R1	Flexible fuel hose assemblies	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		76-13-07		Fork bolts	Bk	1
		76-16-07		Engine attachment tangs	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		90-02-13		Main landing gear	Bk	3
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
402A	A7CE	69-14-01		Fuel starvation	Bk	1
		70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		71-07-04		Emergency exit window	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
402B	A7CE	70-03-04	R1	Turbosupercharger turbine housing	Bk	1
		71-07-04		Emergency exit window	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		74-20-01		Main landing gear trunnion	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-12-13		Forward wing spars	BW 05-13	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
402C	A7CE	80-13-14		Fuel flow transducer	Bk	2
		84-20-02		Nose landing gear	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		92-16-18		Passenger seat reinforcement	Bk	3
		95-09-13		Fuel inlet float valve	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		97-26-16		Engine mount beams	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2000-23-01		Inspect auxiliary wing spars	Bk	4
		2005-05-52		Spar strap modification	BW 05-07	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
411 Model or Series	A7CE	Refer to the AD for the applicable serial numbers.				
		69-14-01		Fuel starvation	Bk	1
		71-07-04		Emergency exit window	Bk	1
		72-02-01		Propeller attachment nuts	Bk	1
		72-11-05		Auxiliary fuel cell leaks	Bk	1
		72-14-08	R1	Flexible fuel hose assemblies	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		76-13-07		Fork bolts	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		90-02-13		Main landing gear	Bk	3
		91-02-07		AFM - Pilot's checklist	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
411A	A7CE	69-14-01		Fuel starvation	Bk	1
		71-07-04		Emergency exit window	Bk	1
		72-02-01		Propeller attachment nuts	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		79-10-15		Cracks in wing structure	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		91-02-07		AFM - Pilot's checklist	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-12-12		Right and left wing spar lower cap	BW 05-14	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
414 Model or Series	A7CE	Refer to the AD for the applicable serial numbers.				
		72-03-07		Landing gear failure	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		74-20-01		Main landing gear trunnion	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		76-13-07		Fork bolts	Bk	1
		76-16-07		Engine attachment tangs	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		88-03-07		Insp. fuel lines	Bk	2
		90-02-13		Main landing gear	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
414A	A7CE	78-11-05		Autopilot actuator	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		80-13-14		Fuel flow transducer	Bk	2
		84-03-04		Windshield instln. insp.	Bk	2
		84-20-02		Nose landing gear	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		95-09-13		Fuel inlet float valve	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		97-26-16		Engine mount beams	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		98-24-14		Exhaust system components	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-05-52		Spar strap modification	BW 05-07	
		2005-12-13		Forward wing spars	BW 05-13	
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
421 Model or Series	A7CE	Refer to the AD for the applicable serial numbers.				
		69-14-01		Fuel starvation	Bk	1
		72-02-01		Propeller attachment nuts	Bk	1
		72-03-07		Landing gear failure	Bk	1
		72-11-05		Auxiliary fuel cell leaks	Bk	1
		72-14-08	R1	Flexible fuel hose assemblies	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		76-13-07		Fork bolts	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		90-02-13		Main landing gear	Bk	3
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
421A	A7CE	69-14-01		Fuel starvation	Bk	1
		72-02-01		Propeller attachment nuts	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
421B	A7CE	72-02-01		Propeller attachment nuts	Bk	1
		72-03-04		Crankcase vent line ice	Bk	1
		73-13-08		Turbochargers	Bk	1
		73-22-01		Fuel in wing leading edge	Bk	1
		74-20-01		Main landing gear trunnion	Bk	1
		76-04-03		ARC PA-500A actuators	Bk	1
		76-08-02	R2	Wing tip nose cap	Bk	1
		77-09-02		Windshield inspection and repair	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		87-21-02	R1	Fuel filler openings	Bk	2
		92-16-18		Passenger seat reinforcement	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
421C	A7CE	76-07-07		Fuel leakage	Bk	1
		77-09-02		Windshield inspection and repair	Bk	1
		78-11-05		Autopilot actuator	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		80-13-14		Fuel flow transducer	Bk	2
		80-20-06		KFC-200 FCS mod. under STC SA1246CE	Bk	2
		84-03-04		Windshield instln. insp.	Bk	2
		84-20-02		Nose landing gear	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		91-25-08	R1	Wing front spar upper caps	Bk	3
		92-16-18		Passenger seat reinforcement	Bk	2
		95-09-13		Fuel inlet float valve	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
425	A7CE	84-03-04		Windshield instln. insp.	Bk	2
		84-20-02		Nose landing gear	Bk	2
		85-25-11		Nuts - Cessna P/N NAS1291-8	Bk	2
		91-25-08	R1	Wing front spar upper caps	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		97-25-04		AFM - Limitations - Power levers	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
404	A25CE	78-11-05		Autopilot actuator	Bk	1
		78-13-05		Improperly installed seats	Bk	1
		80-13-14		Fuel flow transducer	Bk	2
		80-15-06		Elevator trim tab assy	Bk	2
		84-20-02		Nose landing gear	Bk	2
		86-20-12		Engine mount beams	Bk	2
		87-21-02	R1	Fuel filler openings	Bk	2
		92-16-18		Passenger seat reinforcement	Bk	3
		95-09-13		Fuel inlet float valve	Bk	3
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2000-01-16		Inspect exhaust system	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
F406 (Reims)	A54EU	92-16-18		Passenger seat reinforcement	Bk	2
		97-01-13		Check fuel, oil and hydraulic hoses	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2001-23-07		Canted rib upper cap	Bk	4
		2003-09-09	R1	Fuel boost pump wiring	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
441	A28CE	79-08-07		Anti-icing propeller wiring	Bk	1
		79-09-02		Aileron control surfaces drainage	Bk	1
		79-19-12		Engine stoppage	Bk	1
		79-19-13		Elevator trim tab	Bk	1
		80-02-17		Flight manual performance data	Bk	2
		83-12-03		Battery switch wiring	Bk	2
		84-20-02		Nose landing gear	Bk	2
		85-25-11		Nuts - Cessna P/N NAS1291-8	Bk	2
		86-24-13		POH/AFM appendix-icing	Bk	2
		92-16-07		Horizontal stabilizer front spar	Bk	3
		92-16-18		Passenger seat reinforcement	Bk	3
		95-25-10		Replace outflow/safety valve	Bk	3
		97-25-04		AFM - Limitations - Power levers	Bk	3
		98-04-28		AFM - Limitations Section - icing	Bk	3
		2003-09-09	R1	Fuel boost pump wiring	Bk	4
		2005-20-25		Avionics bus circuit breaker switches	BW 05-21	
500	A22CE	73-26-09		Cracks in flt. compt. side windows	Bk	1
		79-12-06		Upper & lower spar cap stems	Bk	1
		80-09-09		Dual flight director installation	Bk	2
		93-05-15		Thrust reverser throttle load limiter	Bk	3
		95-25-10		Replace outflow/safety valve	Bk	3
		98-04-38		AFM - Limitations Section - icing	Bk	3
		2004-09-05		Stator disks on brake assembly	Bk	4
550 Model or Series	A22CE	Refer to the AD for the applicable serial numbers.				
		79-12-06		Upper & lower spar cap stems	Bk	1
		80-09-09		Dual flight director installation	Bk	2
		88-06-02		Indirect lighting system	Bk	2
		89-16-10		Fuel flow transmitter	Bk	2
		90-07-10	R1	Air conditioning system	Bk	3
		93-05-15		Thrust reverser throttle load limiter	Bk	3
		95-25-10		Replace outflow/safety valve	Bk	3
		98-04-38		AFM - Limitations Section - icing	Bk	3
		2004-09-05		Stator disks on brake assembly	Bk	4
S550 Model or Series	A22CE	Refer to the following AD's for the applicable serial numbers.				
		85-24-04		AFM Rev. Placard-icing	Bk	2
		85-25-10		Placard -icing conditions	Bk	2
		88-06-02		Indirect lighting system	Bk	2
		88-11-07		Flap panels	Bk	2
		88-24-16		Cabin electrical power	Bk	2
		88-13-03	R1	Cotter pins-main landing gear	Bk	2
		90-07-10	R1	Air conditioning system	Bk	3
		93-05-15		Thrust reverser throttle load limiter	Bk	3
552	A22CE	85-03-51		Aircraft battery inspection	Bk	2
		85-25-10		Placard -icing conditions	Bk	2
		88-11-07		Flap panels	Bk	2
560 Series	A22CE	93-05-15		Thrust reverser throttle load limiter	Bk	3
		95-25-10		Replace outflow/safety valve	Bk	3
		96-24-06		AFM - Limitations Section	Bk	3
		98-04-38		AFM - Limitations Section - icing	Bk	3
		2000-03-09		AFM – Limitations Section – icing	Bk	4
		2003-23-02		Trim system	Bk	4
560XL		2001-14-09		Prevent shorting to ground of electrical power	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
501	A27CE	79-12-06		Upper & lower spar cap stems	Bk	1
		80-09-09		Dual flight director installation	Bk	2
		93-05-15		Thrust reverser throttle load limiter	Bk	3
		98-04-38		AFM - Limitations Section - icing	Bk	3
		2004-09-05		Stator disks on brake assembly	Bk	4
551 Model or Series	A27CE	Refer to the AD for the applicable serial numbers.				
		79-12-06		Upper & lower spar cap stems	Bk	1
		80-09-09		Dual flight director installation	Bk	2
		89-16-10		Fuel flow transmitters	Bk	2
		90-07-10	R1	Air conditioning system	Bk	3
		93-05-15		Thrust reverser throttle load limiter	Bk	3
		98-04-38		AFM - Limitations Section - icing	Bk	3
		2004-09-05		Stator disks on brake assembly	Bk	4
525 (Citation Jet)	A1WI	97-01-02		MLG trunnion pins	Bk	3
		2001-02-13		Prevent this battery switch from failing	Bk	4
		2004-14-20		Trim printed circuit board (PCB) assembly	Bk	4
		2005-17-11		Fire extinguisher bottles	BW 05-18	
525A	A1WI	2005-17-11		Fire extinguisher bottles	BW 05-18	
525B	A1WI	2005-17-11		Fire extinguisher bottles	BW 05-18	

CHAMPION AIRCRAFT CORP.
(See F.R.A. ENTERPRISES and AIRCRAFT ACQUISITION CORP.)

CHAPARRAL MOTORS
(Formerly Great Lakes Aircraft)
(See Great Lakes Aircraft)

CHILD, DOYLE F.
(See CHRISTEN INDUSTRIES)

CHRISTEN INDUSTRIES, INC.
(See Sky International, Inc..)

CIRRUS DESIGN

SR20 and SR22	A00009CH	2001-25-03		Understrength rivets in the elevator and rudder	Bk	4
		2002-05-05		AFM - Limitation Section -	Bk	4
		2002-21-02		Retaining nut on roll and yaw trim cartridge	Bk	4
		2002-24-08		Parachute system (CAPS) activation system	Bk	4
		2005-17-19		Crew seat recline locks	BW 05-18	
		2006-07-06		Wire harness	BW 06-07	
		2006-19-10		Adjust crew seat break-over bolts		
		2006-21-03		Brake caliper piston O-ring seals		

COLONIAL
(See CONSOLIDATED AERONAUTICS, INC.)

COLUMBIA AIRCRAFT
(Formerly Lancair Company)

LC40-500FG	A00003SE	2004-06-09		Fuel pressure transducer	Bk	4
		2005-02-01		Takeoff chart distance values	BW 05-02	
LC41-550FG	A00003SE	2005-12-20		Elevator torque tube assembly	BW 05-14	
		2006-25-08		Deice system		
LC42-550FG	A00003SE	2004-06-09		Fuel pressure transducer	Bk	4
		2005-02-01		Takeoff chart distance values	BW 05-02	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2006-25-08		Deice system		
COMMANDER AIRCRAFT						
(Formerly GULFSTREAM)						
(For ADs in Bk 1 See Gulfstream Aerospace)						
112	A12SO	73-14-04		Engine and prop controls	Bk	1
		73-14-06		Cracks in prop spinner bulkhead	Bk	1
		73-24-01		Control surface hinge failure	Bk	1
		75-22-09		Ailerons	Bk	1
		77-01-08		Engine failure	Bk	1
		85-03-04	R2	Front seat and belt attach.	Bk	2
		88-05-06		Inspect for cracks	Bk	2
		90-04-07		Wing spars	Bk	3
112B	A12SO	88-05-06		Inspect for cracks	Bk	2
		90-04-07		Wing spars	Bk	3
112TC	A12SO	85-03-04	R2	Front seat and belt attach.	Bk	2
		88-05-06		Inspect for cracks	Bk	2
		90-04-07		Wing spars	Bk	3
112TCA	A12SO	88-05-06		Inspect for cracks	Bk	2
		90-04-07		Wing spars	Bk	3
114	A12SO	76-23-02		Cabin vents and air ducts	Bk	1
		85-03-04	R2	Front seat and belt attach.	Bk	2
		88-05-06		Inspect for cracks	Bk	2
		90-04-07		Wing spars	Bk	3
114A	A12SO	85-03-04	R2	Front seat and belt attach.	Bk	2
		88-05-06		Inspect for cracks	Bk	2
		90-04-07		Wing spars	Bk	3
114TC	A12SO	2000-11-04		V-band exhaust clamp	Bk	4
COMMONWEALTH AIRCRAFT, INC.						
Rearwin 175, 180, 185, 180F, 190F	A-729	48-06-02		Jury struts	Bk	1
CONSOLIDATED AERONAUTICS, INC.						
(See REVO, INC.)						
CONVAIR						
(See GENERAL DYNAMICS CORP.)						
COSTRUZIONI AERONAUTICHE GIOVANNI AGUSTA						
(See AGUSTA)						
CULVER						
(See SUPERIOR AIRCRAFT CO.)						
DAIMLERCHRYSLER AEROSPACE AG						
(Formerly Bolkow-Apparatebau Gmbh (Messerschmitt))						
(See Bolkow-Apparatebau GmbH, in Book 1 for AD)						
(Formerly Messerschmitt-Bolkow-Blohm Gmbh)						
(See Messererschmitt-Bolkow-Blohm Gmbh, for Ads in Books 1, 2 or 3)						
Bolkow Jr.	A1EU	69-23-05		Lower engine mount bolts	Bk	1
BO-209 Series	A27EU	75-21-02		Fuselage	Bk	1
		76-04-08		Engine mount	Bk	1
BO-209-150 FV, RV. FF	A27EU	87-09-01		Wing spar carry-through	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		91-08-08		Elevator spar	Bk	3
BO-209-160 FV, RV	A27EU	87-09-01		Wing spar carry-through	Bk	2
		91-08-08		Elevator spar	Bk	3
DEHAVILLAND AIRCRAFT CO. & BOEING OF CANADA *(See Bombardier,Inc.)*						
DeHavilland Series prior to S/N 04503		61-11-04		Wing spar boom corrosion	Bk	1
DH.104 Dove Series	A-807	55-25-02		Front fin attachment brackets	Bk	1
		55-25-03		Earth post corrosion	Bk	1
		56-11-01		Oil pressure & temperature gage mod.	Bk	1
		56-15-04		Nose gear brackets	Bk	1
		56-19-01		Aileron pulley locking pin	Bk	1
		58-20-02		Fire extinguisher electrical circuit	Bk	1
		59-01-02		Landing gear locking lever	Bk	1
		59-05-02		Oil dipstick modification	Bk	1
		59-12-08		Fire extinguisher spray pipe	Bk	1
		63-19-01		Control brackets	Bk	1
		64-13-01		Main ground assembly	Bk	1
		66-02-03		Main and nose landing gear assys	Bk	1
		66-05-02		Rudder & elevator trim tab rod end assys	Bk	1
		66-20-02		Engine fire extinguishing system	Bk	1
		69-25-06		Aileron lever	Bk	1
		70-03-01		Nose landing gear locking lever	Bk	1
		70-07-01		Engine mount structure	Bk	1
		70-07-06		X-Ray tailplane rear spar	Bk	1
		70-15-07		Wing flap datum hinge links	Bk	1
		70-21-02		Wing flap datum hinge assys	Bk	1
		70-23-02		Wing lower main spar cap	Bk	1
		71-13-02		Dunlop air bottle	Bk	1
		71-19-06		Escape hatch lock check	Bk	1
		72-10-01		Cracks in control pedal reversal lever	Bk	1
		72-10-03		Fatigue failure wing spar fitting	Bk	1
		72-12-03		Failure of air bottles	Bk	1
		72-16-07		Wing main spar pick up fittings	Bk	1
		75-24-06		Main spar joint	Bk	1
		75-27-01		Nose and main gear screws	Bk	1
		76-02-05		Engine mounting frame	Bk	1
		76-06-04		Engine mounting brackets	Bk	1
		76-06-10		Nose landing gear casing	Bk	1
		76-10-03		Drag brace fittings	Bk	1
		77-14-04		Electrical system	Bk	1
		77-14-15		Corrosion of engine mount stay strut	Bk	1
		77-16-04		Wing structure	Bk	1
		78-09-04		Main spar bottom boom lugs	Bk	1
		79-02-07		Wing to fuselage attachment	Bk	1
DH.114 Heron	A-816	61-23-03		Wing rear spar	Bk	1
		63-15-02		Bolt attaching flap jack to wing	Bk	1
		64-19-02		Trim tab rod assembly	Bk	1
		65-08-01		Main ground assembly	Bk	1
		66-20-03		Engine fire extinguishing system	Bk	1
		69-25-07		Aileron lever	Bk	1
		69-26-02		Engine mount wing straps	Bk	1
		70-07-06		X-ray tailplane rear spar	Bk	1
		70-10-07		Nose gear locking lever	Bk	1
		70-15-08		Wing flap datum hinge links	Bk	1
		70-21-04		Fin to fuselage attachment	Bk	1
		70-21-05		Flap datum hinge assemblies	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		71-13-03	Dunlop air bottles	Bk	1
DH.114 Heron continued		71-20-02	Emergency escape hatches	Bk	1
		72-06-03	Corrosion in engine mount	Bk	1
		72-06-04	Main undercarriage down lock lever	Bk	1
		72-07-03	Failure of air bottles	Bk	1
		72-08-02	Main and damper jack bolts	Bk	1
		72-08-03	Cracks in rudder control pedal	Bk	1
		72-09-04	Fuselage keel frame	Bk	1
		72-12-05	Landing gear jack assemblies	Bk	1
		72-15-01	Wing to fuselage attach bolts	Bk	1
		72-20-01	Failure of airplane structure	Bk	1
		73-13-06	Aileron and rudder trim	Bk	1
		73-17-03	Flap hinge-to-wing attachments	Bk	1
		75-16-22	Counterweight bushings	Bk	1
		75-24-10	Wing structure	Bk	1
		75-27-03	Nose gear screws	Bk	1
		76-07-04	Nose landing gear	Bk	1
		76-16-03	Wing to fuselage attach	Bk	1
		77-12-03	Engine mount stay struts	Bk	1
		77-13-14	Drag brace fittings	Bk	1
		77-14-04	Electrical system	Bk	1
		77-15-13	Main landing gear damper ram	Bk	1
		81-21-03	Wing leading edge access doors	Bk	2
		84-20-04	Eyebolt holes modification	Bk	2
DHC-2 Series (L-20A) (Beaver)	A-806, AR-33	53-07-01	Elevator hinge attachment	Bk	1
		53-09-02	Fuselage skin cracks	Bk	1
		53-10-02	Wing skin cracks	Bk	1
		53-11-02	Engine oil sump chafing	Bk	1
		53-12-02	Hydraulic hand pump seals	Bk	1
		53-21-01	Wing rear spar attachment bolt	Bk	1
		53-23-02	Fuel tank filler neck	Bk	1
		54-15-01	Control cable turnbuckle threads	Bk	1
		64-09-03	Aileron mass balance weight arm	Bk	1
		64-14-02	Elevator trim tab end blocks	Bk	1
		66-17-02	Front and rear spars	Bk	1
		73-25-05	Float support structure	Bk	1
		74-17-03	Cabin heater inspection	Bk	1
		76-14-02	Various modifications	Bk	1
		80-24-02	Aileron mount structures	Bk	2
		81-13-01	Elevator butt ribs	Bk	2
		84-07-05	L/R Aileron hinge bracket	Bk	2
		84-09-06	Control column sub-assembly	Bk	2
		84-20-07	Wing lift strut assembly	Bk	2
		88-08-02	Wing strut assemblies	Bk	2
		90-02-22	Fuselage attachment brackets	Bk	3
		92-24-02	Horizontal front anter spar	Bk	3
		99-15-07	Inspect rear fuselage bulkhead for cracks	Bk	3
		2002-13-08	Mass balance weights at elevator tip ribs	Bk	4
		2002-14-28	Front fuselage strut	Bk	4
		2004-21-06	Lockwire security	Bk	4
DIAMOND AIRCRAFT INDUSTRIES					
Canada					
DA 20-A1	TA4CH	96-09-05	Inspect aft wing cavities	Bk	3
		97-13-02	Placard - Spins Prohibited	Bk	3
DA 40					
		2006-23-04			

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
DORNIER-WERKE GmbH & DORNIER LUFTFAHRT GmbH						
Do 27 Q-6	A8IN	64-14-04		Control flap lever	Bk	1
		77-14-17	R1	Dornier fuel & oil hose insp.	Bk	1
		98-24-06		Inspect forward stabilizer attach fittings	Bk	3
		2003-06-08		Fuel lines	Bk	4
Do 28 Series	7A13 &	64-14-03		Electrical installation	Bk	
	A16EU	77-14-17	R1	Dornier fuel & oil hose insp.	Bk	1
Do 28 A-1	7A13	64-14-03		Electrical installation	Bk	1
		64-14-04		Control flap lever	Bk	1
Do 28 B-1	7A13	64-14-03		Electrical installation	Bk	1
		66-30-03		Stabilizer hinge bracket	Bk	1
Do 28D	A16EU	64-14-03		Electrical installation	Bk	1
		76-10-08		Elevator trim control	Bk	1
		89-03-15		Horizontal tail rivets	Bk	2
		90-21-06		Engine mount	Bk	3
Do 28D-1	A16EU	64-14-03		Electrical installation	Bk	1
		69-19-05		Elevator control	Bk	1
		70-12-10		Elevator trim tab system	Bk	1
		70-19-03		Jumper wire installation	Bk	1
		70-21-01		Cabin door structure	Bk	1
		71-13-05		Cracks in landing gear wheel forks	Bk	1
		76-10-08		Elevator trim control	Bk	1
		76-11-04		Electrical cable insulation	Bk	1
		82-26-04		Autopilot actuators	Bk	2
		89-03-15		Horizontal tail rivets	Bk	2
		89-04-04		SB-1121-1703	Bk	2
		90-21-06		Engine mount failure	Bk	3
Do 28D-2	--	79-13-06		Engine fire system	Bk	1
Do 228-100	A16EU	87-15-05		See Hartzell Propellers	Bk	2
		91-05-03		Bonding straps	Bk	3
		91-12-13		Electric trim system	Bk	3
		91-12-14		AC power supply	Bk	3
		96-09-14		AFM - Icing	Bk	3
		97-22-09		Pilot’s Operating Handbook - Power levers	Bk	3
		98-06-13		MLG axle housing assembly	Bk	3
		98-11-16		Landing gear warning system	Bk	3
		2000-06-02		AFM – Limitation section – ice protection sys	Bk	4
		2001-04-04		Windshield spray nozzle heating system	Bk	4
		2001-21-01		Cracks in horizontal stabilizer skin and ribs	Bk	4
		2003-16-17		Cockpit and cabin auxiliary cabin heater	Bk	4
		2006-11-19		Flight deck overhead panels (locations 5VE and 6VE)	BW	06-12
Do 228-101	A16EU	91-05-03		Bonding straps	Bk	3
		91-12-13		Electric trim system	Bk	3
		91-12-14		AC power supply	Bk	3
		96-09-14		AFM - Icing	Bk	3
		97-22-09		Pilot’s Operating Handbook - Power levers	Bk	3
		98-06-13		MLG axle housing assembly	Bk	3
		98-11-16		Landing gear warning system	Bk	3
		2000-06-02		AFM – Limitation section – ice protection sys	Bk	4
		2001-04-04		Windshield spray nozzle heating system	Bk	4
		2001-21-01		Cracks in horizontal stabilizer skin and ribs	Bk	4
		2003-16-17		Cockpit and cabin auxiliary cabin heater	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		2006-11-19	Flight deck overhead panels (locations 5VE and 6VE)	BW 06-12	
Do 228-200	A16EU	87-15-05	See Hartzell Propellers	Bk	2
		91-05-03	Bonding straps	Bk	3
		91-12-13	Electric trim system	Bk	3
		91-12-14	AC power supply	Bk	3
		96-09-14	AFM - Icing	Bk	3
		97-22-09	Pilot's Operating Handbook - Power levers	Bk	3
		98-06-13	MLG axle housing assembly	Bk	3
		98-11-16	Landing gear warning system	Bk	3
		2000-06-02	AFM – Limitation section – ice protection sys	Bk	4
		2001-04-04	Windshield spray nozzle heating system	Bk	4
		2001-21-01	Cracks in horizontal stabilizer skin and ribs	Bk	4
		2003-16-17	Cockpit and cabin auxiliary cabin heater	Bk	4
		2006-11-19	Flight deck overhead panels (locations 5VE and 6VE)	BW 06-12	
Do 228-201	A16EU	91-05-03	Bonding straps	Bk	3
		91-12-13	Electric trim system	Bk	3
		91-12-14	AC power supply	Bk	3
		96-09-14	AFM - Icing	Bk	3
		97-22-09	Pilot's Operating Handbook - Power levers	Bk	3
		98-06-13	MLG axle housing assembly	Bk	3
		98-11-16	Landing gear warning system	Bk	3
		2000-06-02	AFM – Limitation section – ice protection sys	Bk	4
		2001-04-04	Windshield spray nozzle heating system	Bk	4
		2001-21-01	Cracks in horizontal stabilizer skin and ribs	Bk	4
		2003-16-17	Cockpit and cabin auxiliary cabin heater	Bk	4
		2006-11-19	Flight deck overhead panels (locations 5VE and 6VE)	BW 06-12	
Do 228-202	A16EU	91-05-03	Bonding straps	Bk	3
		91-12-13	Electric trim system	Bk	3
		91-12-14	AC power supply	Bk	3
		96-09-14	AFM - Icing	Bk	3
		97-22-09	Pilot's Operating Handbook - Power levers	Bk	3
		98-11-16	Landing gear warning system	Bk	3
		2000-06-02	AFM – Limitation section – ice protection sys	Bk	4
		2001-04-04	Windshield spray nozzle heating system	Bk	4
		2001-21-01	Cracks in horizontal stabilizer skin and ribs	Bk	4
		2003-16-17	Cockpit and cabin auxiliary cabin heater	Bk	4
		2006-11-19	Flight deck overhead panels (locations 5VE and 6VE)	BW 06-12	
Do 228-212	A16EU	91-05-03	Bonding straps	Bk	3
		91-12-13	Electric trim system	Bk	3
		96-09-14	AFM - Icing	Bk	3
		97-22-09	Pilot's Operating Handbook - Power levers	Bk	3
		98-11-16	Landing gear warning system	Bk	3
		2000-06-02	AFM – Limitation section – ice protection sys	Bk	4
		2001-04-04	Windshield spray nozzle heating system	Bk	4
		2001-21-01	Cracks in horizontal stabilizer skin and ribs	Bk	4
		2001-25-09	Brake housing assembly	Bk	4
		2003-16-17	Cockpit and cabin auxiliary cabin heater	Bk	4
		2006-11-19	Flight deck overhead panels (locations 5VE and 6VE)	BW 06-12	

DYNAC AEROSPACE CORP.
(Formerly AERO COMMANDER, NORTH AMERICAN ROCKWELL,
CALLAIR, VOLAIRE, INTERMOUNTAIN, S. L. INDUSTRIES)

10	1A21	68-12-05	Rudder control system	Bk	1
10A	1A21	68-12-05	Rudder control system	Bk	1
100	1A21	68-12-05	Rudder control system	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		68-21-02		Aileron cable assembly	Bk	1
		68-23-03		Fuel octane placard	Bk	1
		73-01-01		Exhaust outlet blockage	Bk	1
100A	1A21	68-12-05		Rudder control system	Bk	1
100-180	1A21	68-21-02		Aileron cable assembly	Bk	1
		68-23-03		Fuel octane placard	Bk	1
		73-01-01		Exhaust outlet blockage	Bk	1
EADS-PZL WARSZAWA-OKECIE S.A.						
(Formerly Panstwowe Zakiady Lotnicze)						
PZL-104 Wilga 80	A55EU	2000-16-51		Tailplane to fuselage joint connector	Bk	4
EADS SOCATA						
TBM 700		2006-22-11		Initial elevator trim actuator greasing		
EAGLE AIRCRAFT COMPANY						
(See BELLANCA, MN)						
EMBRAER - EMPRESA BRASILEIRA de AERONAUTICA, S.A.						
EMB-110 Series	A21SO	91-25-09		Elevator trim tab actuator support	Bk	3
		91-25-11		Rudder trim tab system	Bk	3
		92-17-02		Rudder trim tab actuating system	Bk	3
EMB-110P1	A21SO	79-04-03	R2	Landing gear	Bk	1
		79-10-11		Flight control rods	Bk	1
		79-24-05		Wing flap supports	Bk	1
		81-14-01		Rudder upper hinge support	Bk	2
		82-05-01	R2	Wing flap actuators	Bk	2
		82-18-01		Water in fuel tank	Bk	2
		82-20-02		Temporary revision to POH/AFM	Bk	2
		82-27-09		Primary flight control cables	Bk	2
		83-04-03	R1	Control wheel failure	Bk	2
		83-14-09		Rivet attachments	Bk	2
		83-15-10		Control surface balance	Bk	2
		84-24-53	R1	Empennage assembly	Bk	2
		85-01-51		Empennage assembly	Bk	2
		85-17-04		Elevator control rod tube	Bk	2
		87-01-05		Bearings-flight control systems	Bk	2
		87-13-08		AFM/POH changes	Bk	2
		88-25-10		Flap control switch	Bk	2
		89-20-11		AFM change -emergency exit	Bk	2
		90-12-01		Elevator balance weight arms	Bk	3
		96-09-12		AFM - Icing	Bk	3
		97-26-13		AFM - Limitation Section - Power levers	Bk	3
		98-01-10		MLG wheel axle/piston tube	Bk	3
		2000-02-27		AFM – Ice protection systems	Bk	4
EMB-110P2	A21SO	79-04-03	R2	Landing gear	Bk	1
		79-10-11		Flight control rods	Bk	1
		79-24-05		Wing flap supports	Bk	1
		81-14-01		Rudder upper hinge support	Bk	2
		82-05-01	R2	Wing flap actuators	Bk	2
		82-18-01		Water in fuel tank	Bk	2
		82-20-02		Temporary revision to POH/AFM	Bk	2
		82-27-09		Primary flight control cables	Bk	2
		83-04-03	R1	Control wheel failure	Bk	2
		83-14-09		Rivet attachments	Bk	2
		83-15-10		Control surface balance	Bk	2
		84-24-53	R1	Empennage assembly	Bk	2
		85-01-51		Empennage assembly	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		85-17-04		Elevator control rod tube	Bk	2
		87-01-05		Bearings-flight control systems	Bk	2
		87-13-08		AFM/POH changes	Bk	2
		88-25-10		Flap control switch	Bk	2
		89-20-11		AFM change -emergency exit	Bk	2
		90-12-01		Elevator balance weight arms	Bk	3
		96-09-12		AFM - Icing	Bk	3
		97-26-13		AFM - Limitation Section - Power levers	Bk	3
		98-01-10		MLG wheel axle/piston tube	Bk	3
		2000-02-27		AFM – Ice protection systems	Bk	4
EMERALD ENTERPRISES, LTD						
(Formerly Wing Aircraft Co)						
(See Wing Aircraft for ADs in Bk 2)						
D-1	A9WE	82-08-05	R1	Placard -cabin heater	Bk	2
EMIGH AIRCRAFT CORP.						
(See GARCIA, HENRY S)						
ERCOUPE, INC.						
(See UNIVAIR AIRCRAFT CORP.)						
EXTRA FLUGZEUGBAU GmbH						
(See Extra Flugzeugproduktions-Und Vertriebs - GmbH)						
EXTRA FLUGZEUGPRODUKTIONS-UND VERTRIEBS - GMBH						
(Formerly Extra Flugzeugbau GmbH)						
(See Extra Flugzeugbau GmbH for Book 3 paper copies)						
EA-300	A67EU	98-03-14		Inspect upper longeron cutout bridge	Bk	3
		98-04-01		Canopy latches	Bk	3
		98-06-03		Elevator mass balance assemblies	Bk	3
		98-09-10		Inspect rudder control cables	Bk	3
		98-24-07		Rudder pedal footrest	Bk	3
		2005-01-17		Upper longeron cutout-bridge	BW 05-02	
		2005-11-07		Bottom fuselage cover (belly fairing) and the firewall	BW 05-12	
EA-300L	A67EU	98-24-07		Rudder pedal footrest	Bk	3
		2003-17-02		Fuel selector valve	Bk	4
		2005-11-07		Bottom fuselage cover (belly fairing) and the firewall	BW 05-12	
EA-300S	A67EU	98-03-14		Inspect upper longeron cutout bridge	Bk	3
		98-04-01		Canopy latches	Bk	3
		98-09-10		Inspect rudder control cables	Bk	3
		98-24-07		Rudder pedal footrest	Bk	3
		2002-21-11		Horizontal stabilizer attachment	Bk	4
		2003-17-02		Fuel selector valve	Bk	4
		2005-01-17		Upper longeron cutout-bridge	BW 05-02	
		2005-11-07		Bottom fuselage cover (belly fairing) and the firewall	BW 05-12	
EA-300/200	A67EU	97-22-03		Seat belt safety cover	Bk	3
		2003-17-02		Fuel selector valve	Bk	4
		2005-11-07		Bottom fuselage cover (belly fairing) and the firewall	BW 05-12	
FAIRCHILD AIRCRAFT CORPORATION						
(See M7 Aerospace LP)						
FAIRCHILD INDUSTRIES						
22 Series	ATC 517, ATC 564	46-40-02		Oleo tube reinforcement	Bk	1
24 Series	A-535,	46-21-01		Landing gear universal joints	Bk	1
	ATC 600,	46-40-01		Fuel tank selector valve placard	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
	ATC 633, TC 667, A-706, A-707	46-40-02	Oleo tube reinforcement	Bk	1
24R Series	A-706	47-50-09	Landing gear fittings	Bk	1
24R-46	A-706	47-21-01	Starter relay terminal wire	Bk	1
		47-21-02	20-ampere landing light fuse	Bk	1
		47-21-03	Rudder cable turnbuckles	Bk	1
24R-46S	A-706	47-21-01	Starter relay terminal wire	Bk	1
		47-21-02	20-ampere landing light fuse	Bk	1
		47-21-03	Rudder cable turnbuckles	Bk	1
24R-46A	A-706	47-21-03	Rudder cable turnbuckles	Bk	1
24W Series	A-707	47-50-09	Landing gear fittings	Bk	1
24W-41A	A-707	47-21-03	Rudder cable turnbuckles	Bk	1
24W-46	A-707	47-21-01	Starter relay terminal wire	Bk	1
		47-21-02	20-ampere landing light fuse	Bk	1
		47-21-03	Rudder cable turnbuckles	Bk	1
24W-46S	A-707	47-21-01	Starter relay terminal wire	Bk	1
		47-21-02	20-ampere landing light fuse	Bk	1
		47-21-03	Rudder cable turnbuckles	Bk	1
M-62 Series	A-724	43-07-01	Wing center section spars	Bk	1
		47-07-02	Elevator hinge attachments	Bk	1
		47-07-03	Wing inspection	Bk	1
		47-07-04	Control stick safetying	Bk	1
		47-07-05	Torque tube cover	Bk	1
		47-07-06	Vertical fin attachment	Bk	1
		48-45-01	Wing spar inspection	Bk	1
M-62A-3	A-724	46-14-02	Cockpit heat control valve	Bk	1
M-62A-4	A-724	46-14-02	Cockpit heat control valve	Bk	1
M-62C	A-724	46-14-01	Propeller indexing	Bk	1
FLS AEROSPACE					
OA7 Optica Series 300	A64EU	96-26-02	Fan shaft extension flange	Bk	3
FORNEY					
(See UNIVAIR AIRCRAFT CORP.)					
FOUND BROTHERS AVIATION LTD.					
FBA-2C	A7EA	68-01-04	Forward wing-to-fuselage attachment	Bk	1
F.R.A. ENTERPRISES					
(Formerly CHAMPION AIRCRAFT CORP.)					
FUJI HEAVY IND.					
FA-200	A4PC	90-20-01 2006-20-13	Gust lock pin holes	Bk	3
FUNK AIRCRAFT CO.					
C	TC 2-564	75-12-05	Support struts and longerons	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
GARCIA, HENRY S.						
(Formerly EMIGH AIRCRAFT)						
(See KEARNS, EDWARD SCOTT)						
GATES LEARJET CORPORATION						
(See LEARJET)						
GENERAL DYNAMICS CORP.						
L-13 (Convair)	AR-10	65-22-01		Wing channels	Bk	1
BT-13, -13A, SNV-1,	A-2-571	46-06-04		Propeller spinner attaching lugs	Bk	1
BT-13B, SNV-2, BT-15		47-25-10		Elevator tab failure	Bk	1
		49-07-03		Fuel system placard	Bk	1
		49-27-01		Fuel line rework	Bk	1
		52-02-01		Bronze rear spar fittings	Bk	1
GLOBAL AMPHIBIANS, LLC						
(Formerly Revo, Inc.)						
(See Revo for ADs in Book 1, 2,and 3)						
(See Revo, Inc.)						
GLOBE						
(See UNIVERSAL AIRCRAFT INDUSTRIES)						
GOVERNMENT AIRCRAFT FACTORIES						
(See AEROSPACE TECHNOLOGIES of AUSTRALIA PTY LTD)						
GREAT LAKES AIRCRAFT CO., GA						
(See CHAPARRAL MOTORS)						
(Formerly Chaparral Motors)						
2T-1A-1	A18EA	78-26-10	R1	Cockpit heater system	Bk	1
		80-21-12	R1	Engine oil system	Bk	2
		2004-25-22		Induction system	Bk	4
2T-1A-2	A18EA	78-26-10	R1	Cockpit heater system	Bk	1
		80-21-12	R1	Engine oil system	Bk	2
		2004-25-22		Induction system	Bk	4
GROB-WERKE						
(Formerly Burkhart Grob Luft-Und Raumfahrt)						
(See Burkhart Grob Luft-Und Raumfahrt for AD's in Book 3)						
G115, G115A, G115B, G115C,	A57EU	98-10-06		Airspeed placard	Bk	3
G115C2, G115D, G115D2		98-24-08		Trim tab hinges	Bk	3
GRUMMAN AMERICAN AVIATION CORP.						
(GULFSTREAM AMERICAN CORP.)						
(See Air Trading Corporataion)						
G-21	TC 654	46-38-01		Vacuum system tubing	Bk	1
		63-27-02		Rudder control push rod end fittings	Bk	1
		72-11-03		Engine fuel starvation	Bk	1
		73-12-06		Elevator & rudder torque tube failure	Bk	1
G-21A	TC 654	46-38-01		Vacuum system tubing	Bk	1
(AO-9, JRF)		49-16-01		Fuel tank baffles	Bk	1
		50-15-01		Mixture control rework	Bk	1
		53-21-02		Horizontal stabilizer strut	Bk	1
		53-24-01		Stabilizer strut terminals	Bk	1
		63-27-02		Rudder control push rod end fittings	Bk	1
		71-12-03		Flex drive elevator tab control	Bk	1
		72-11-03		Engine fuel starvation	Bk	1
		73-12-06		Elevator & rudder torque tube failure	Bk	1
		79-02-03		Engine restart	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
GULFSTREAM AEROSPACE CORP. AND GULFSTREAM AMERICAN CORP.					
(See GRUMMAN, SCHWEIZER, FRAKES, FLYING BOAT, COMMADER AIRCRAFT, TWIN COMMANDER, AMERICAN GENERAL AIRCRAFT HOLDING CO., INC)					
G-44 (OA-14, J4F-2)	A-734	48-31-01	Stabilizer strut	Bk	1
		54-26-01	Landing gear valve placard	Bk	1
G-44A (Scan Type 30)	A-734	48-31-01	Stabilizer strut	Bk	1
		54-26-01	Landing gear valve placard	Bk	1
HANDLEY PAGE					
(See BRITISH AEROSPACE CORP.)					
HARBIN AIRCRAFT MANUFACTURING CORP.					
Y12 IV	A00006WI	98-04-19	AFM - Limitations Section - icing	Bk	3
		2000-02-26	AFM – Ice protection systems	Bk	4
HAWKER SIDDELEY AVIATION					
(See DEHAVILLAND)					
HELIO AIRCRAFT LIMITED					
(See AIRCRAFT ACQUISITION)					
HELIO ENTERPRISES, INC.					
(Formerly AIRCRAFT ACQUISITION CORP.)					
(See Alliance Aircraft Group, LLC)					
HOAC AUSTRIA					
DV-20 Katana	A74EU	96-24-07	Exhaust system end pipe and muffler	Bk	3
		98-04-02	NLG nose wheel tappet	Bk	3
		98-24-05	EMI on engine electronic module	Bk	3
INDUSTRIE AERONAUTICHE E MECCANICHE					
(See PIAGGIO & C)					
(See Piaggio Aero Industries S.p.A)					
P.166	7A4	62-16-04	Frame angle bar	Bk	1
		63-15-05	Steel control guides	Bk	1
		63-15-06	Elevator trim tab levers	Bk	1
		63-22-04	Main landing gear shock absorber	Bk	1
		64-03-04	Nose landing gear steering control unit	Bk	1
INIZIATIVE INDUSTRIALI ITALIANE S.P.A.					
Sky Arrow 650 TC, 650 TCN	A41CE	2003-13-05	Engine mount	Bk	4
		2003-13-06	Nose gear support bulkhead (STA 600)	Bk	4
INTERCEPTOR CORP.					
(Formerly MEYERS, AERO COMMANDER, ROCKWELL INTERNATIONAL)					
(See PROP JETS, INC.)					
INTERMOUNTAIN					
(See S.L. INDUSTRIES, AIRCRAFT PARTS & DEVELOPMENT CORP.)					
INTERSTATE ENGINEERING & TYPE DESIGN COMPANY, INC.					
(Formerly ARCTIC AIRCRAFT CO., INC.)					
(See Arctic Aircraft Co., Inc., for ADs in Book 2)					
S-1B2	A-754	86-20-04	Placard-airspeed indicator	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
JETSTREAM AIRCRAFT LTD						
(Formerly BRITISH AEROSPACE)						
(See British Aerospace)						
KAISER FLEETWINGS, INC.						
F5	ATC 680	49-32-01		Engine support struts	Bk	1
F-401	TC 2-540	49-32-01		Engine support struts	Bk	1
KEARNS, EDWARD SCOTT						
(Formerly GARCIA, HENRY S.)						
(For ADs in Bk 1 see Garcia, Henry)						
Trojan A-2	A-801	52-11-01		Elevator tube socket	Bk	1
KWAD COMPANY						
(Formerly PINE AIR)						
Super V	A5IN 4A29	76-05-04		Stabilizer attach fitting	Bk	1
LAKE AIRCRAFT CORP.						
(See CONSOLIDATED AERONAUTICS)						
LATINO AMERICANA DE AVIACION						
(Formerly Piper)						
(See Piper for AD's in Book 1, Book 2, and Book 3)						
PA-25 Series	2A8 &	80-21-08		Forward wing spars	Bk	2
	2A10	99-01-05		Wing lift struts or forks	Bk	3
		99-26-05		Induction air filter	Bk	3
PA-25	2A8 &	62-02-06		Wing spar hinge fitting	Bk	1
	2A10	65-15-05		Elevator control system	Bk	1
		72-24-02		Throttle movement placard	Bk	1
		73-26-01		Forward wing spars	Bk	1
		77-21-06		Fuselage steel tubing cluster	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		90-02-06		Inspect for cracks	Bk	3
		95-12-01		Forward wing spars	Bk	3
PA-25-235	2A8 &	63-17-05		Landing gear shock struts	Bk	1
	2A10	64-24-05		Fuselage landing gear fitting seals	Bk	1
		65-15-05		Elevator control system	Bk	1
		67-14-07		Engine exhaust system	Bk	1
		73-15-05		Cracks in hopper bay longerons	Bk	1
		73-26-01		Forward wing spars	Bk	1
		74-18-02		Fuel lines	Bk	1
		77-21-06		Fuselage steel tubing cluster	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		90-02-06		Inspect for cracks	Bk	3
		95-12-01		Forward wing spars	Bk	3
		99-26-05		Induction air filter	Bk	3
PA-25-260	2A8 &	73-26-01		Forward wing spars	Bk	1
	2A10	74-18-02		Fuel lines	Bk	1
		77-21-06		Fuselage steel tubing cluster	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		90-02-06		Inspect for cracks	Bk	3
		95-12-01		Forward wing spars	Bk	3
		99-26-05		Induction air filter	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
LANCAIR COMPANY, THE						
(see Columbia Aircraft)						
LEARJET CORPORATION						
23 Model/Series	A5CE	65-26-02		Electrical wiring	Bk	1
		65-26-03		Ducting in the cabin air system	Bk	1
		66-13-04		Pressure control static air system	Bk	1
		66-14-02		Windshield deicing systems	Bk	1
		69-15-06		Engine throttle cable	Bk	1
		71-16-04		Battery change or modification of comb	Bk	1
		72-05-01		Flap actuator rod end	Bk	1
		74-23-01		External power receptacle	Bk	1
		75-15-06		Landing gear struts	Bk	1
		77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		80-07-09		Main cabin entrance door	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		80-26-02		AFCS/AFC-SS pitch function	Bk	2
		81-13-07		Change to AFM	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-25-03		Deterioration of flapper valves of tip tank	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
24 Series	A10CE	75-15-06		Landing gear struts	Bk	1
		76-18-07		Inverter input power	Bk	1
		80-07-09		Main cabin entrance door	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-26-02		AFCS/AFC-SS pitch function	Bk	2
		81-13-07		Change to AFM	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		84-19-06		Tab control system	Bk	2
		89-12-01		Drag chute riser	Bk	2
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
24	A10CE	66-13-04		Pressure control static air system	Bk	1
		66-14-02		Windshield deicing systems	Bk	1
		69-15-06		Engine throttle cable	Bk	1
		71-16-04		Battery change or modification of comb	Bk	1
		72-15-03		Spoiler actuator pivot bolts	Bk	1
		74-23-01		External power receptacle	Bk	1
		75-15-06		Landing gear struts	Bk	1
		76-18-07		Inverter input power	Bk	1
		77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		84-19-06		Tab control system	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		95-25-03		Deterioration of flapper valves of tip tank	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
24A	A10CE	75-24-03		Crew emergency exit	Bk	1
		77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24B	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24B-A	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24C	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24D	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24D-A	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24E	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		81-16-08	R3	AFM changes - operation altitudes	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
24E continued		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24F	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		81-16-08	R3	AFM changes - operation altitudes	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
24F-A	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-17-02		Hor. stab. trim actuator	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
25 Series	A10CE	71-16-04		Battery inspection	Bk	1
		72-15-03		Spoiler actuator bolts	Bk	1
		75-15-06		Landing gear struts	Bk	1
		76-18-07		Inverter input power	Bk	1
		80-07-09		Main cab entrance door	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-26-02		AFCS/AFC-SS pitch function	Bk	2
		81-13-07		Changes to AFM	Bk	2
		84-19-06		Tab control system	Bk	2
		89-12-01		Drag chute riser	Bk	2
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
25	A10CE	69-15-06		Engine throttle cable	Bk	1
		71-16-04		Battery change or modification of comb	Bk	1
		72-15-03		Spoiler actuator pivot bolts	Bk	1
		75-15-06		Landing gear struts	Bk	1
		76-18-07		Inverter input power	Bk	1
		77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		80-26-02		AFCS/AFC-SS pitch function	Bk	2
		82-01-04	R2	Horizontal stabilizer trim actuator *(See Book 3 for paper copy)*	Bk	2
		84-19-06		Tab control system	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		95-25-03		Deterioration of flapper valves of tip tank	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
25A	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-04	R2	Horizontal stabilizer trim actuator	Bk	2
				(See Book 3 for paper copy)		
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
25B	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-04	R2	Horizontal stabilizer trim actuator	Bk	2
				(See Book 3 for paper copy)		
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
25C	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-04	R2	Horizontal stabilizer trim actuator	Bk	2
				(See Book 3 for paper copy)		
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
25D	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		81-16-08	R3	AFM changes - operating altitude	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
25F	A10CE	77-19-02		Cabin door locking mechanism	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-12-05		Stall warning systems	Bk	1
		80-19-11	R1	Flight manual revisions	Bk	2
		81-16-08	R3	AFM changes - operating altitude	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
28	A10CE	80-07-09		Main cab entrance door	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		80-26-02		AFCS/AFC-SS pitch function	Bk	2
		81-13-07		Changes to AFM	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-19-06		Tab control system	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		89-12-01		Drag chute riser	Bk	2
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
29	A10CE	80-07-09		Main cab entrance door	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		80-26-02		AFCS/AFC-SS pitch function	Bk	2
		81-13-07		Changes to AFM	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		84-19-06		Tab control system	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		89-12-01		Drag chute riser	Bk	2
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
31 Series	A10CE	91-03-08		Fluorescent lighting systems	Bk	3
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		98-06-28		Auxiliary cabin heater relay box AWG wire	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
		99-23-19		Spoiler actuator	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
		2004-03-08		Shear webs of forward engine beams	Bk	4
31A	A10CE	95-21-03		Engine fire pull switch assembly	Bk	3
		99-23-19		Spoiler actuator	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
		2004-03-08		Shear webs of forward engine beams	Bk	4
35 Series	A10CE	76-18-07		Inverter input power	Bk	1
		78-25-02		Door mechanism	Bk	1
		80-07-09		Main cab entrance door	Bk	2
		80-17-11		Airspeed warning placard	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		81-13-07		Changes to AFM	Bk	2
		84-19-06		Tab control system	Bk	2
		85-16-04		Raisbeck STC SA766NW	Bk	2
		87-02-06		Inspect engine mounts	Bk	2
		89-12-01		Drag chute riser	Bk	2
		91-03-08		Fluorescent lighting systems	Bk	3
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		96-19-13		Operating Mach limit	Bk	3
		2000-24-19		Revise Emergency Procedures of AFM	Bk	4
35	A10CE	76-18-07		Inverter input power	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-08-01	R1	Thrust reversers	Bk	1
		80-06-02		Electrical systems	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		83-08-03		Hydraulic pressure line	Bk	2
		84-19-06		Tab control system	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		87-02-06		Inspect engine mounts	Bk	2
		87-04-06		Autopilot/flight director	Bk	2
		95-25-03		Deterioration of flapper valves of tip tank	Bk	3
		99-23-19		Spoiler actuator	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
		2004-03-08		Shear webs of forward engine beams	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
35A Series	A10CE	91-03-08		Fluorescent lighting systems	Bk	3
		96-19-13		Operating Mach limit	Bk	3
		2000-24-19		Revise Emergency Procedures of AFM	Bk	4
35A (C-21A)	A10CE	78-16-03		Refrigeration condenser fan	Bk	1
		79-08-01	R1	Thrust reversers	Bk	1
		80-06-02		Electrical systems	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		85-16-04		Raisbeck STC SA766NW	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		87-04-06		Autopilot/flight director	Bk	2
		98-06-28		Auxiliary cabin heater relay box AWG wire	Bk	3
		99-23-19		Spoiler actuator	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
		2004-03-08		Shear webs of forward engine beams	Bk	4
36 Series	A10CE	76-18-07		Inverter input power	Bk	1
		78-25-02		Door mechanism	Bk	1
		80-07-09		Main cabin entrance door	Bk	2
		80-17-11		Airspeed warning placard	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		81-13-07		Changes in AFM	Bk	2
		84-19-06		Tab control system	Bk	2
		85-16-04		Raisbeck STC SA766NW	Bk	2
		87-02-06		Inspect engine mounts	Bk	2
		89-12-01		Drag chute riser	Bk	2
		91-03-08		Fluorescent lighting systems	Bk	3
		92-19-12		Oxygen plumbing & map light wires	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		96-19-13		Operating Mach limit	Bk	3
		2000-24-19		Revise Emergency Procedures of AFM	Bk	4
36	A10CE	76-18-07		Inverter input power	Bk	1
		78-16-03		Refrigeration condenser fan	Bk	1
		79-08-01	R1	Thrust reversers	Bk	1
		80-06-02		Electrical systems	Bk	2
		80-19-09	R1	Jet pumps	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		83-08-03		Hydraulic pressure	Bk	2
		84-19-06		Tab control system	Bk	2
		86-05-05	R1	Battery vent system	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		87-02-06		Inspect engine mounts	Bk	2
		87-04-06		Autopilot/flight director	Bk	2
		95-25-03		Deterioration of flapper valves of tip tank	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
		2004-03-08		Shear webs of forward engine beams	Bk	4
36A Series	A10CE	91-03-08		Fluorescent lighting systems	Bk	3
		96-19-13		Operating Mach limit	Bk	3
		2000-24-19		Revise Emergency Procedures of AFM	Bk	4
36A	A10CE	78-16-03		Refrigeration condenser fan	Bk	1
		79-08-01	R1	Thrust reversers	Bk	1
		80-06-02		Electrical systems	Bk	2
		80-19-11	R1	Flight manual revisions	Bk	2
		82-01-05	R2	Stall warning accelerometer unit	Bk	2
		85-16-04		Raisbeck STC SA766NW	Bk	2
		86-05-05	R1	Battery vent system	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
36A continued		87-04-06		Autopilot/flight director	Bk	2
		2001-07-11		Separation of tread of MLG tires	Bk	4
		2004-03-08		Shear webs of forward engine beams	Bk	4
55 Series	A10CE	87-02-06		Inspect engine mounts	Bk	2
		91-03-08		Fluorescent lighting systems	Bk	3
		95-20-03		AFM - altitude limitations	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
		2001-12-02		Prevent bottoming of the valve components	Bk	4
55	A10CE	84-19-06		Tab control system	Bk	2
		85-22-08	R2	AFM changes - spoilers/autospoilers	Bk	2
		86-22-05		Flap sector mounting brackets insp.	Bk	2
		87-02-06		Inspect engine mounts	Bk	2
		89-12-01		Drag chute riser	Bk	2
		93-24-10		Generator wiring	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
55B Series	A10CE	91-03-08		Fluorescent lighting systems	Bk	3
		93-24-10		Generator wiring	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
55C Series	A10CE	91-03-08		Fluorescent lighting systems	Bk	3
		93-24-10		Generator wiring	Bk	3
		2001-07-11		Separation of tread of MLG tires	Bk	4
60 Series	A10CE	93-23-12		Heating systems	Bk	3
		95-21-03		Engine fire pull switch assembly	Bk	3
		96-18-01		Aft core cowl nozzle of engine nacelles	Bk	3
		98-16-18		Brake wear dimension	Bk	3
		99-16-03		Horizontal stabilizer anti-ice system	Bk	3
		99-23-19		Spoiler actuator	Bk	3
		2000-23-18		Inspect oxygen tubing	Bk	4
		2001-12-02		Prevent bottoming of the valve components	Bk	4
		2003-19-11		Fuel crossflow tube	Bk	4
LOCKHEED AIRCRAFT CORP., LOCKHEED-GEORGIA COMPANY, and LOCKHEED-CALIFORNIA COMPANY						
L-14	ATC 657,	98-04-32		AFM - Limitations Section - icing	Bk	3
	ATC 683	99-19-08		AFM - Deicing	Bk	3
LUSCOMBE AVIATION HISTORY FOUNDATION, INC., THE DON						
(Formerly Luscombe Aircraft Corp.)						
(See Luscombe Aircraft for ADs in Bk 1 and Bk 2)						
8 Series	A-694	47-10-40		Rudder control arm reinforcement	Bk	1
		47-22-01		Bulkhead reinforcement for seaplanes	Bk	1
		48-08-02		Cleveland wheels	Bk	1
		48-09-03		Kollsman airspeed baffle	Bk	1
		48-49-01		Vertical stabilizer spar fitting	Bk	1
		49-43-02		Stabilizer spar inspection	Bk	1
		51-10-02		Control cable inspection	Bk	1
		55-24-01		Corrosion inspection	Bk	1
		61-03-05		Fuel line interference	Bk	1
		94-16-02		Stabilizer forward attach fitting	Bk	3
		96-24-17	R1	Wing inspection holes	Bk	3
8A	A-694	46-30-01		Control stick horn adjustment screw	Bk	1
8C	A-694	50-37-01		Fuel system modifications	Bk	1
8E, 8F, T-8F	A-694	62-24-03		Cabin heat system	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
LUSCOMBE AIRCRAFT CORP. (LARSEN)						
(See TEMCO for Model 11 Series in Bk 1)						
(See Luscombe Aviation History Foundation, Inc., The Don)						
Luscombe 11A	A-804	49-40-01		Trim tab horn attachment	Bk	1
		49-45-01		Landing gear bulkhead reinforcement	Bk	1
		51-21-03		Rudder bellcrank	Bk	1
M7 AEROSPACE LP						
(Formerly Fairchild Aircraft)						
SA26 Series	A5SW	90-24-03		Rudder trim link assemblies	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
SA26-T	A5SW	69-11-01		Cockpit side window	Bk	1
		77-04-08		Spar brackets	Bk	1
		81-26-05	R1	Wing station 99	Bk	2
		87-13-11		Landing gear selector	Bk	2
		96-20-08		Replace side cockpit window	Bk	3
SA26-AT	A5SW	69-11-01		Cockpit side window	Bk	1
		77-04-08		Spar brackets	Bk	1
		81-26-05	R1	Wing station 99	Bk	2
		87-13-11		Landing gear selector	Bk	2
		96-20-08		Replace side cockpit window	Bk	3
		2002-01-16		POH/AFM appendix-icing	Bk	4
SA226 Series	A5SW,	90-24-03		Rudder trim link assemblies	Bk	3
	A8SW	97-02-02		Control column pitch bearing attaching nuts	Bk	3
		2000-03-17		Pitch trim actuator	Bk	4
SA226-T	A5SW	73-08-02		Operation in icing conditions	Bk	1
		76-20-04		Wheel wells	Bk	1
		77-18-05		Variable authority steering system	Bk	1
		79-13-07		Baggage compartment	Bk	1
		79-25-04		Models incorporating Rosemount servos	Bk	1
		81-15-01		Structural wear or damage	Bk	2
		81-24-04		Change to AFM "icing conditions"	Bk	2
		81-26-04		Cable guard & retainer installation	Bk	2
		82-23-06		MLG door installation	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		85-04-01	R1	Hydraulic and oxygen lines insp.	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		87-13-11		Landing gear selector	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3
		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-07		MLG doors	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		95-25-07		MLG actuator tang and hardware	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA226-T continued		97-11-13		Generator fault transformer wiring	Bk	3
		98-04-05		Inspect wing trailing edge ribs	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		99-21-05		Landing gear actuator rod ends	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4
		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW 05-07	
SA226-AT	A5SW	73-08-02		Operation in icing conditions	Bk	1
		76-20-04		Wheel wells	Bk	1
		77-18-05		Variable authority steering system	Bk	1
		79-13-07		Baggage compartment	Bk	1
		79-25-04		Models incorporating Rosemount servos	Bk	1
		80-09-08	R2	Door latching mechanism	Bk	2
		81-15-01		Structural wear or damage	Bk	2
		81-24-04		Change to AFM "icing conditions"	Bk	2
		81-26-04		Cable guard & retainer installation	Bk	2
		82-23-06		MLG door installation	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		85-04-01	R1	Hydraulic and oxygen lines insp.	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		87-13-11		Landing gear selector	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		90-14-01		Passenger seat	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3
		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-09-05		Inspect elevator controls	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-07		MLG doors	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-18-05		Aluminum cargo door receptacles	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		95-25-07		MLG actuator tang and hardware	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		97-11-13		Generator fault transformer wiring	Bk	3
		98-04-05		Inspect wing trailing edge ribs	Bk	3
		98-06-25		Inspect cargo door lower belt frames	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		99-21-05		Landing gear actuator rod ends	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA226-AT continued		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW 05-07	
SA226-T(B)	A5SW	79-13-07		Baggage compartment	Bk	1
		81-24-04		Change to AFM "icing conditions"	Bk	2
		82-23-06		MLG door installation	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		85-04-01	R1	Hydraulic and oxygen lines insp.	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		87-13-11		Landing gear selector	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3
		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-07		MLG doors	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		95-25-07		MLG actuator tang and hardware	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		97-11-13		Generator fault transformer wiring	Bk	3
		98-04-05		Inspect wing trailing edge ribs	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		99-21-05		Landing gear actuator	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4
		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW 05-07	
SA227 Series	A5SW	90-24-03		Rudder trim link assemblies	Bk	3
		2000-03-17		Pitch trim actuator	Bk	4
SA227-TT	A5SW	82-05-05	R1	Placard on "icing conditions"	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		84-13-01		Generator control J-box	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3
		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-08-09		AFM nose wheel steering system limitations	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA227-TT continued		95-24-11		Install foreign object barriers in floorboards	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		97-11-13		Generator fault transformer wiring	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4
		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW	05-07
SA227-TT(300)	--	2002-08-02		Brake shuttle valve	Bk	4
		2005-06-13		Wing spar center web cutout	BW	05-07
SA227-AT	A5SW	82-05-05	R1	Placard on icing conditions	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		84-13-01		Generator control J-box	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		90-14-01		Passenger seat	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3
		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-08-09		AFM nose wheel steering system limitations	Bk	3
		93-09-05		Inspect elevator controls	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-01-07		Lower wing skin panel insp.	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		97-11-13		Generator fault transformer wiring	Bk	3
		98-06-25		Inspect cargo door lower belt frames	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4
		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW	05-07

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA226-TC	A8SW	76-20-04		Wheel wells	Bk	1
		77-18-05		Variable authority steering system	Bk	1
		79-13-07		Baggage compartment	Bk	1
		79-25-04		Models incorporating Rosemount servos	Bk	1
		80-09-08	R2	Door latching mechanism	Bk	2
		81-15-01		Structural wear or damage	Bk	2
		81-24-04		Change to AFM "icing conditions"	Bk	2
		81-26-04		Cable guard & retainer installation	Bk	2
		82-23-06		MLG door installation	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		84-13-01		Generator control J-box	Bk	2
		85-04-01	R1	Hydraulic and oxygen lines insp.	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		87-13-11		Landing gear selector	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		90-14-01		Passenger seat	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3
		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-09-05		Inspect elevator controls	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-07		MLG doors	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-18-05		Aluminum cargo door receptacles	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		95-25-07		MLG actuator tang and hardware	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		97-11-13		Generator fault transformer wiring	Bk	3
		98-04-05		Inspect wing trailing edge ribs	Bk	3
		98-06-25		Inspect cargo door lower belt frames	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		99-21-05		Landing gear actuator rod ends	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4
		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW 05-07	
SA227-AC	A8SW	82-05-05	R1	Placard on "icing conditions"	Bk	2
		83-15-09		Nose wheel steering systems mod.	Bk	2
		84-13-01		Generator control J-box	Bk	2
		85-22-06	R1	Stall avoidance system (SAS)	Bk	2
		86-10-08		Elevator gust lock system	Bk	2
		87-02-02		Primary control cables	Bk	2
		90-03-19	R1	Electrical system	Bk	3
		90-05-06	R1	Main landing gear doors	Bk	3
		90-14-01		Passenger seat	Bk	3
		92-18-07		Power lever detent arms	Bk	3
		92-19-08		Rudder pedal link attachment	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA227-AC continued		93-07-12		Horizontal stabilizer rear spar	Bk	3
		93-08-09		AFM nose wheel steering system limitations	Bk	3
		93-09-05		Inspect elevator controls	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-01-07		Lower wing skin panel inspection	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		97-11-13		Generator fault transformer wiring	Bk	3
		98-06-25		Inspect cargo door lower belt frames	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2000-17-01		Parking brake system	Bk	4
		2000-17-11		MLG drag brace assemblies	Bk	4
		2002-01-16		POH/AFM appendix-icing	Bk	4
		2002-08-01		Brake master cylinders	Bk	4
		2002-08-02		Brake shuttle valve	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW	05-07
SA227-BC	A8SW	92-18-07		Power lever detent arms	Bk	3
		93-08-09		AFM nose wheel steering system limitations	Bk	3
		93-15-01		Horizontal stabilizer	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		96-20-08		Replace side cockpit window	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
		97-10-13		Elevator torque tube arm	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW	05-07
SA227-PC	A8SW	2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
SA227-CC	A18SW	94-07-10	R1	Wing skin	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW	05-07

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA227-DC	A18SW	93-08-09		AFM nose wheel steering system limitations	Bk	3
		94-07-10	R1	Wing skin	Bk	3
		95-17-09	R1	Essential bus current limiters	Bk	3
		95-24-11		Install foreign object barriers in floorboards	Bk	3
		96-03-03		Replace power control cable nuts	Bk	3
		96-09-16		AFM - Icing	Bk	3
		96-19-05		MLG or NLG assemblies or yokes	Bk	3
		97-02-02		Control column pitch bearing attaching nuts	Bk	3
		98-19-15	R1	Pitch trim actuator *(see Bk 4 for paper copy)*	Bk	3
		99-06-02		Wing spar center web	Bk	3
		2000-06-04		AFM – Limitation section – ice protection sys	Bk	4
		2003-19-10		Main/auxiliary fuel boost pump wiring	Bk	4
		2005-06-13		Wing spar center web cutout	BW 05-07	
MAULE AEROSPACE TECHNOLOGY						
M4 Series	3A23	79-12-01		Tail-to-fuselage attach tube	Bk	1
		81-14-02		Rudder pedal V-bar	Bk	2
		84-09-07		Plug type drain fittings repl.	Bk	2
Bee Dee M-4	3A23	65-18-01		Upper fuselage fabric	Bk	1
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-4	3A23	65-18-01		Upper fuselage fabric	Bk	1
		68-07-08		Rudder trim tab control	Bk	1
		69-20-02		Aileron control system pulley	Bk	1
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-4C	3A23	68-07-08		Rudder trim tab control	Bk	1
		69-20-02		Aileron control system pulley	Bk	1
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-4S	3A23	68-07-08		Rudder trim tab control	Bk	1
		69-20-02		Aileron control system pulley	Bk	1
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-4T	3A23	68-07-08		Rudder trim tab control	Bk	1
		69-20-02		Aileron control system pulley	Bk	1
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-4-210	3A23	65-18-01		Upper fuselage fabric	Bk	1
		65-28-04		Fuel system modifications	Bk	1
		68-07-08		Rudder trim tab control	Bk	1
		69-20-02		Aileron control system pulley	Bk	1
		75-11-02		Fuel lines	Bk	1
		96-10-05		Relocate Gascolator and fuel pump	Bk	3
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-4-210C	3A23	68-07-08		Rudder trim tab control	Bk	1
		69-20-02		Aileron control system pulley	Bk	1
		75-11-02		Fuel lines	Bk	1
		96-10-05		Relocate Gascolator and fuel pump	Bk	3
		98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
M-4-220	3A23	71-17-01	Fuel line blockage	Bk	1
		73-11-06	Engine overheat	Bk	1
		98-15-18	Inspect front & rear wing lift struts	Bk	3
M-4-220S	3A23	68-07-08	Rudder trim tab control	Bk	1
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-4-220C	3A23	68-07-08	Rudder trim tab control	Bk	1
		69-20-02	Aileron control system pulley	Bk	1
		71-06-06	Seat track and guide	Bk	1
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-4-180	--	71-17-01	Fuel line blockage	Bk	1
		73-11-06	Engine overheat	Bk	1
M-4-180C	3A23	71-06-06	Seat track and guide	Bk	1
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-4-180S	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
M-4-180T	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
M-4-210S	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
M-4-210T	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
M-4-220T	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
M-5 Series	3A23	79-12-01	Tail-to-fuselage attach tube	Bk	1
		81-14-02	Rudder pedal V-bar	Bk	2
		84-09-07	Plug type drain fittings repl.	Bk	2
M-5-180C	3A23	86-17-11	Fuel crossover supply line	Bk	2
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-5-200	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-5-210C	3A23	75-11-02	Fuel lines	Bk	1
		78-13-08	Engine fuel supply	Bk	1
		86-17-11	Fuel crossover supply line	Bk	2
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-5-210TC	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
M-5-220C	3A23	86-17-11	Fuel crossover supply line	Bk	2
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-5-235C	3A23	78-13-08	Engine fuel supply	Bk	1
		82-03-05	Engine stoppage prevention	Bk	2
		86-17-11	Fuel crossover supply line	Bk	2
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
M-6-180	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-6-235	3A23	82-03-05	Engine stoppage prevention	Bk	2
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-7-235, M-7-235A	3A23	97-26-14	AFM - Limitation Section - Power levers	Bk	3
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-7-235B	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-7-235C	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-7-260	3A23	2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-7-260C	3A23	2000-09-06	Detect and correct crimping of Sleeve	Bk	4
M-7-420C	3A23	2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-160	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-160C	3A23	2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-180	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-180A	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-180B	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-180C	3A23	2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-235	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MX-7-420	3A23	97-26-14	AFM - Limitation Section - Power levers	Bk	3
		98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MXT-7-160	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MXT-7-180		98-15-18	Inspect front & rear wing lift struts	Bk	3
MXT-7-180A	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4
MXT-7-420	3A23	97-26-14	AFM - Limitation Section - Power levers	Bk	3
		98-15-18	Inspect front & rear wing lift struts	Bk	3
MT-7-235	3A23	98-15-18	Inspect front & rear wing lift struts	Bk	3
		2000-09-06	Detect and correct crimping of Sleeve	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
MT-7-260	3A23	2000-09-06		Detect and correct crimping of Sleeve	Bk	4
M-8-235	3A23	98-15-18		Inspect front & rear wing lift struts	Bk	3
		2000-09-06		Detect and correct crimping of Sleeve	Bk	4
McCLISH THOMAS H.						
B, B75L, B85C	A-715	75-12-05		Support struts and longerons	Bk	1
McKINNON ENTERPRISES, INC.						
G21 Series	4A24	73-07-05		Elevator or rudder torque tube assys	Bk	1
MDB FLUGTECHNIK AG						
(*See SME Aero Inc.*)						
MESSERSCHMITT-BOLKOW-BLOHM GMBH						
(See Daimlerchrysler Aerospace Ag)						
MEYERS AIRCRAFT COMPANY						
(See PROP JETS, INC.)						
MITSUBISHI AIRCRAFT INTERNATIONAL AND MITSUBISHI HEAVY INDUSTRIES LTD.						
MU-2B Series	A2PC	79-24-02		Outer fuel tank wiring	Bk	1
		2000-02-25		AFM - Ice protection systems	Bk	4
MU-2B	A2PC	73-19-03		Nose gear actuating system failure	Bk	1
		74-11-01		Windshield outer panes	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1
		80-15-03		Rear baggage compartment	Bk	2
		81-06-01	R1	Engine aft nacelles	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		87-04-03		Flap flexible shaft	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		97-04-13		Vent check valve assembly	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-10	A2PC	71-14-01		Fuel tank fungus coating peeling	Bk	1
		73-19-03		Nose gear actuating system failure	Bk	1
		74-11-01		Windshield outer panes	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1
		80-15-03		Rear baggage compartment	Bk	2
		81-06-01	R1	Engine aft nacelles	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shaft	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		91-23-08		Rudder trim tab	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-04-13		Vent check valve assembly	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-15	A2PC	71-14-01		Fuel tank fungus coating peeling	Bk	1
		73-19-03		Nose gear actuating system failure	Bk	1
		74-11-01		Windshield outer panes	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1
		80-15-03		Rear baggage compartment	Bk	2
		81-06-01	R1	Engine aft nacelles	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shaft	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		91-23-08		Rudder trim tab	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-04-13		Vent check valve assembly	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-20	A2PC	71-14-01		Fuel tank fungus coating peeling	Bk	1
		73-19-03		Nose gear actuating system failure	Bk	1
		74-11-01		Windshield outer panes	Bk	1
		75-16-13		Main wing flap	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		80-15-03		Rear baggage compartment	Bk	2
		81-06-01	R1	Engine aft nacelles	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
MU-2B-20 continued		88-23-01		Torque tube joints	Bk	2
		91-23-08		Rudder trim tab	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-04-13		Vent check valve assembly	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-25	A2PC, A10SW	73-19-03		Nose gear actuating system failure	Bk	1
		74-11-01		Windshield outer panes	Bk	1
		75-16-13		Main wing flap	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1
		80-15-03		Rear baggage compartment	Bk	2
		81-06-01	R1	Engine aft nacelles	Bk	2
		81-25-04	R1	Electrical wiring inspection	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		83-09-02		Strobe light assemblies	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		87-12-02		Generator shield jumper wires	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2006-17-05		Flight checks		
MU-2B-26	A2PC,	75-03-06		Cracks and optical distortion	Bk	1
	A10SW	75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1
		81-06-01	R1	Engine aft nacelles	Bk	2
		81-25-04	R1	Electrical wiring inspection	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		83-09-02		Strobe light assemblies	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		87-12-02		Generator shield jumper wires	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
MU-2B-26 continued		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-26A	A10SW	81-25-04	R1	Electrical wiring inspection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-11-04		Hub arm assembly	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-14-08		Flight idle blade angles		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-30	A2PC	71-14-01		Fuel tank fungus coating peeling	Bk	1
		74-11-01		Windshield outer panes	Bk	1
		75-16-13		Main wing flap	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		76-22-04		Main landing gear	Bk	1
		78-03-05		Cowling latches	Bk	1
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		83-09-02		Strobe light assemblies	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		91-23-08		Rudder trim tab	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-04-13		Vent check valve assembly	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-35	A2PC, A10SW	74-11-01		Windshield outer panes	Bk	1
		75-16-13		Main wing flap	Bk	1
		75-16-20		Propeller pitch control lever	Bk	1
		76-22-04		Main landing gear	Bk	1
		78-03-05		Cowling latches	Bk	1
		81-25-04	R1	Electrical wiring inspection	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		83-09-02		Strobe light assemblies	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		87-12-02		Generator shield jumper wires	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
MU-2B-36	A2PC,	75-03-06		Cracks and optical distortion	Bk	1
	A10SW	75-16-20		Propeller pitch control lever	Bk	1
		78-03-05		Cowling latches	Bk	1
		80-04-01		Avionic equipment mounting shelf	Bk	2
		82-08-02		Electrical wiring inspection	Bk	2
		82-21-03		Fire detection	Bk	2
		83-09-02		Strobe light assemblies	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-15-03		NLG strut assembly	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		91-23-08		Rudder trim tab	Bk	3
		93-07-11		Elevator nose-down trim	Bk	3
		94-04-16		Elevator nose-down trim	Bk	3
		94-11-04		Hub arm assembly	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-36A	A10SW	80-04-01		Avionic equipment mounting shelf	Bk	2
		81-25-04	R1	Electrical wiring inspection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-11-04		Hub arm assembly	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-14-08		Flight idle blade angles		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-40	A10SW	79-24-02		Outer fuel tank wiring	Bk	1
		81-25-04	R1	Electrical wiring inspection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-20-01		Pitot system modification	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yokes	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-11-04		Hub arm assembly	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-14-08		Flight idle blade angles		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		
MU-2B-60	A10SW	79-24-02		Outer fuel tank wiring	Bk	1
		80-04-01		Avionic equipment mounting shelf	Bk	2
		81-25-04	R1	Electrical wiring inspection	Bk	2
		84-12-04		Temp. placard anti-ice system	Bk	2
		84-25-02		Trim tab brackets	Bk	2
		86-20-01		Pitot system modification	Bk	2
		86-26-02		POH/AFM appendix-icing	Bk	2
		87-04-03		Flap flexible shafts	Bk	2
		88-13-01		Autopilots	Bk	2
		88-21-01	R1	Control yoke	Bk	2
		88-23-01		Torque tube joints	Bk	2
		93-07-11		Elevator nose-down trim	Bk	3
		94-11-04		Hub arm assembly	Bk	3
		96-25-02		AFM - Icing limitations	Bk	3
		97-25-02		AFM - Limitations - Power levers	Bk	3
		98-20-39		Wing tip tanks forward attachment fitting bolt	Bk	3
		2000-09-15	R1	Install pneumatic deice monitoring system	Bk	4
		2003-17-04		Cockpit windshield or cabin window	Bk	4
		2003-22-07	R1	AFM - Limitations Section - Icing	Bk	4
		2006-13-15		Wing attach barrel nuts, bolts		
		2006-14-08		Flight idle blade angles		
		2006-15-07		Airplane Flight Manual (AFM)		
		2006-17-01		Airplane Flight Manual (AFM)		
		2006-17-05		Flight checks		

MONTANAIR, INC.
(See AUGUSTAIR, INC.)

MOONEY AIRCRAFT CORPORATION
(See UNIVAIR)

M20 Series	2A3	75-23-04		Electric gear systems	Bk	1
M-20	2A3	57-10-01		Landing gear bellcrank bracket	Bk	1
		58-23-03		Aileron counterbalance brace	Bk	1
		59-06-03		Hinge bearing brackets	Bk	1
		59-14-02		Fuel selector valve	Bk	1
		61-22-07		Fuel and oil pressure gage lines	Bk	1
		63-10-05		Empennage attach brackets	Bk	1
		65-22-03		Tail truss	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		67-11-05	Tail truss replacement	Bk	1
		73-21-01	Flight control landing gear system	Bk	1
		77-17-04	Control wheel shaft	Bk	1
		86-19-10	Wood structure	Bk	2
(Mark) M20A	2A3	58-19-03	Carburetor air box rework	Bk	1
		59-06-03	Hinge bearing brackets	Bk	1
		59-11-03	Exhaust heater inspection	Bk	1
		59-14-02	Fuel selector valve	Bk	1
		59-25-06	Carburetor alternate air source	Bk	1
		61-22-07	Fuel and oil pressure gage lines	Bk	1
		63-10-05	Empennage attach brackets	Bk	1
		65-22-03	Tail truss	Bk	1
		67-11-05	Tail truss replacement	Bk	1
		73-21-01	Flight control landing gear systems	Bk	1
		77-17-04	Control wheel shaft	Bk	1
		86-19-10	Wood structure	Bk	2
M-20B	2A3	61-22-07	Fuel and oil pressure gage lines	Bk	1
		73-21-01	Flight control landing gear systems	Bk	1
		77-17-04	Control wheel shaft	Bk	1
		85-24-03	Fuel tank bays and rib station insp.	Bk	2
		98-24-11	Inspect aileron control links	Bk	3
M-20C	2A3	66-07-05	Electric landing gear	Bk	1
		67-23-06	Dukes fuel pump	Bk	1
		73-21-01	Flight control landing gear systems	Bk	1
		75-04-09	Landing gear actuator	Bk	1
		75-09-08	Engine mount members	Bk	1
		76-10-05	Leaking fuel	Bk	1
		77-17-04	Control wheel shaft	Bk	1
		78-17-01	Emergency locator transmitter	Bk	1
		85-24-03	Fuel tank bays and rib station insp.	Bk	2
		98-24-11	Inspect aileron control links	Bk	3
		2004-25-04	Water entering fuel bladders	Bk	4
M20D	2A3	66-07-05	Electric landing gear	Bk	1
		67-23-06	Dukes fuel pump	Bk	1
		73-21-01	Flight control landing gear systems	Bk	1
		75-09-08	Engine mount members	Bk	1
		77-17-04	Control wheel shaft	Bk	1
		85-24-03	Fuel tank bays and rib station insp.	Bk	2
		98-24-11	Inspect aileron control links	Bk	3
		2004-25-04	Water entering fuel bladders	Bk	4
M20E	2A3	65-12-03	Speed range vibration stresses	Bk	1
		66-07-05	Electric landing gear	Bk	1
		67-23-06	Dukes fuel pump	Bk	1
		73-21-01	Flight control landing gear systems	Bk	1
		75-04-09	Landing gear actuator	Bk	1
		75-09-08	Engine mount members	Bk	1
		76-10-05	Leaking fuel	Bk	1
		77-08-06	Engine oil	Bk	1
		77-17-04	Control wheel shaft	Bk	1
		77-18-01	Engine oil cooler	Bk	1
		80-13-03	Fuel pumps	Bk	2
		85-24-03	Fuel tank bays and rib station insp.	Bk	2
		98-24-11	Inspect aileron control links	Bk	3
		2004-25-04	Water entering fuel bladders	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
M20F	2A3	67-22-07		Rudder assembly	Bk	1
		73-21-01		Flight control landing gear systems	Bk	1
		75-04-09		Landing gear actuator	Bk	1
		75-09-08		Engine mount members	Bk	1
		76-10-05		Leaking fuel	Bk	1
		77-08-06		Engine oil	Bk	1
		77-17-04		Control wheel shaft	Bk	1
		77-18-01		Engine oil cooler	Bk	1
		78-15-02		MLG side brace bolts	Bk	1
		78-17-01		Emergency locator transmitter	Bk	1
		79-06-04		Elevator control lock	Bk	1
		80-13-03		Fuel pumps	Bk	2
		85-24-03		Fuel tank bays and rib station insp.	Bk	2
		97-26-08		Fuel filler cap assembly	Bk	3
		98-24-11		Inspect aileron control links	Bk	3
		2004-25-04		Water entering fuel bladders	Bk	4
M20G	2A3	73-21-01		Flight control landing gear systems	Bk	1
		75-09-08		Engine mount members	Bk	1
		77-17-04		Control wheel shaft	Bk	1
		85-24-03		Fuel tank bays and rib station insp.	Bk	2
		98-24-11		Inspect aileron control links	Bk	3
		2004-25-04		Water entering fuel bladders	Bk	4
M20J	2A3	77-06-01		Instrument conditions	Bk	1
		77-08-06		Engine oil	Bk	1
		77-18-01		Engine oil cooler	Bk	1
		78-15-02		MLG side brace bolts	Bk	1
		78-17-01		Emergency locator transmitter	Bk	1
		79-06-04		Elevator control lock	Bk	1
		80-13-03		Fuel pumps	Bk	2
		80-17-03		Oil pressure fittings	Bk	2
		85-24-03		Fuel tank bays and rib station insp.	Bk	2
		88-25-11		Baggage door mechanism	Bk	2
		92-08-15		Rudder imbalance	Bk	3
		95-26-16	R1	Inspect alternate air door assembly	Bk	3
		97-26-08		Fuel filler cap assembly	Bk	3
		98-21-26		MLG leg bracket	Bk	3
		98-24-11		Inspect aileron control links	Bk	3
		2004-25-04		Water entering fuel bladders	Bk	4
M20K	2A3	80-02-12		Fuselage tubular structure	Bk	2
		85-24-03		Fuel tank bays and rib station insp.	Bk	2
		88-25-11		Baggage door mechanism	Bk	2
		95-17-06		Exhaust transition tube	Bk	3
		95-18-12		Fuel selector valve	Bk	3
		98-21-26		MLG leg bracket	Bk	3
		98-24-11		Inspect aileron control links	Bk	3
M20L	2A3	97-26-08		Fuel filler cap assembly	Bk	3
		98-24-11		Inspect aileron control links	Bk	3
M20M	2A3	98-21-26		MLG leg bracket	Bk	3
		98-24-11		Inspect aileron control links	Bk	3
		2004-23-17		V-clamp and heat shield	Bk	4
M20R	2A3	95-12-16		Inspect exhaust system for cracks	Bk	3
		98-21-26		MLG leg bracket	Bk	3
		98-24-11		Inspect aileron control links	Bk	3
		99-11-07		Placard - Air conditioning system	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
M22	A6SW	85-24-03		Fuel tank bays and rib station insp.	Bk	2
MOONEY MITE AIRCRAFT CORPORATION						
M18 Series	A-803	51-03-01		Fuel line rework	Bk	1
		53-17-01		Control stick boot	Bk	1
		59-22-03		Empennage	Bk	1
M-18C	A-803	79-11-05	R1	Wood deterioration	Bk	1
		79-18-07		Wood deterioration	Bk	1
M-8C55	A-803	79-11-05	R1	Wood deterioration	Bk	1
		79-18-07		Wood deterioration	Bk	1
M-18L	A-803	50-01-01		Engine mount reinforcement	Bk	1
		53-24-03		Landing gear bellcrank	Bk	1
		79-11-05	R1	Wood deterioration	Bk	1
		79-18-07		Wood deterioration	Bk	1
M-18LA	A-803	79-11-05	R1	Wood deterioration	Bk	1
		79-18-07		Wood deterioration	Bk	1
MORANE-SAULNIER						
(See S.O.C.A.T.A-Groupe Aero..)						
MORAVAN A.S.						
(Formerly Moravan National Corp.)						
ZLIN 526L	A30EU	88-18-06		Cabin tubular structure	Bk	2
Z-143L	A76EU	2002-22-01		Engine crankcase ventilation lines	Bk	4
Z-242L	A76EU	2002-22-01		Engine crankcase ventilation lines	Bk	4
		2003-11-12		Structural failure of wing	Bk	4
MORRISEY AVIATION, INC.						
(See VARGA AIRCRAFT)						
MULTITECH ENGINEERING CORP.						
(Formerly TEMCO, NAVION)						
(Temco) D-16, D-16A,	2A1	55-06-01		Fuselage fuel tank enclosure	Bk	1
Twin Navion		63-16-05		Main landing gear actuating cylinders	Bk	1
		63-16-06		Gear selector valve end fitting	Bk	1
		63-21-05		Main and nose retraction links	Bk	1
		64-08-04		Nose landing gear	Bk	1
NAVAL AIRCRAFT FACTORY						
N3N-3	A-2-569	60-03-06		Control stick	Bk	1
NAVION AIRCRAFT CO. (NORTH AMERICAN, RYAN)						
(See MULTITECH, THOMPSON ENTERPRISE)						
NAVION AIRCRAFT COMPANY, LTD						
(Formerly Jimmie Thompson Enterprise)						
(See Thompson, Jimmie for ADs in Book 1)						
(See Sierra Hotel Aero, Inc.)						
NOORDUYN NORSEMAN AIRCRAFT LTD.						
Army UC-64	A-2-578	46-23-05		Horizontal stabilizer drain holes	Bk	1
		46-23-06		Surface combustion fuel burning heater	Bk	1
		48-49-02		Float wire brace	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
Army UC-64A	A-2-578	46-23-05	Horizontal stabilizer drain holes	Bk	1
		46-23-06	Surface combustion fuel burning heater	Bk	1
		48-49-02	Float wire brace	Bk	1
Army UC-64B	A-2-578	46-23-05	Horizontal stabilizer drain holes	Bk	1
		46-23-06	Surface combustion fuel burning heater	Bk	1
		48-49-02	Float wire brace	Bk	1
Army UC-64AS	A-2-578	48-49-02	Float wire brace	Bk	1

NORTH AMERICAN AVIATION, INC., OHIO
(Also see THOMPSON ENTERPRISE)
(SEE ROCKWELL INTERNATIONAL)

NORTH AMERICAN ROCKWELL
(See AIRCRAFT PARTS & DEVELOPMENT CORP., S.L. INDUSTRIES, GULFSTREAM AMERICAN)

OSTMECKLENBURGISCHE FLUGZEUGBAU GMBH

OMF-100-160	A46CE	2004-24-02	Tubing for main landing gear leg	Bk	4

PACIFIC AEROSPACE CORPORATION, LTD

750XL		2005-03-04	Aileron pushrod ends and elevator control pushrod ends	BW 05-03	
		2005-24-07	Left and right outer panel attachment lugs	BW 05-25	
		2005-26-53	Airplane Flight Manual (AFM)	BW 06-02	
		2006-11-18	Cockpit center console	BW 06-12	
		2006-13-05	Airplane Flight Manual (AFM) that reduces the maximum takeoff weight from 7,500 pounds to 7,125 pounds	BW 06-13	
FU24-954	A9PC	2004-03-29	Vertical fin base	Bk	4
FU24A-954	A9PC	2004-03-29	Vertical fin base	Bk	4

PANSTWOWE ZAKLADY LOTNICZE
(Formerly Wytwornia Spzetu Komunikacy Jnego
(See EADS-PZL Warszawa-Okecie S.A.)

PARTENAVIA COSTRUZIONI AERONAUTICHE S.p.A.
(See Vulcanair S.p.A.)

PIAGGIO & C.
(See INDUSTRIE AERONAUTICHE E MECCANICHE)

P.136-L1	A-813	58-17-04	Water rudder modification	Bk	1
		59-23-01	Water rudder cable guard	Bk	1
		61-26-03	Fuel vent lines	Bk	1
P.136-L2	A-813	58-17-04	Water rudder modification	Bk	1
		59-22-01	Oil breather lines	Bk	1
		59-23-01	Water rudder cable guard	Bk	1
		60-23-03	Oil lines	Bk	1
		61-26-03	Fuel vent lines	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PIAGGIO AERO INDUSTRIES S.p.A						
(Formerly Industrie Aeronautiche E Meccaniche)						
(For Ads in Book 3 see Industrie Aeronautiche E Meccaniche)						
P-180	A59EU	91-19-06		Vertical stabilizer	Bk	3
		96-09-09		Install shield on front section of engine cradle	Bk	3
		96-18-20		Outflow/safety valves	Bk	3
		96-19-02		Emergency exit door	Bk	3
		97-14-14		By-pass duct damage in baggage compartment	Bk	3
		97-15-14		Torque tube bottom flange assembly	Bk	3
		97-22-11		AFM - Limitations section - power levers	Bk	3
		98-06-05		AFM, POH - autopilot	Bk	3
		98-08-05		MLG drag brace link and retraction actuator	Bk	3
		98-12-13		Low pitch stop switch support	Bk	3
		98-13-07		Lavatory water tube/hose connections	Bk	3
		98-23-14		Inspect elevator & aileron control retaining pins	Bk	3
		99-07-10		Inspect engine nacelle inner panels	Bk	3
		99-11-06		Environmental control system bleed tubes	Bk	3
		2000-07-11		Prevent the brake hydraulic fluid from leaking	Bk	4
		2001-05-04		Detect and remove problem flap actuators	Bk	4
		2002-08-04		Horizontal stabilizer hinge bushings	Bk	4
		2002-23-10		First outboard flap control rod, bleed air ducts	Bk	4
		2003-04-08		Placard passenger lavatory seat	Bk	4
		2003-17-03		Firewall shutoff and crossfeed valve	Bk	4
PILATUS AIRCRAFT LTD.						
B4-PC11		2005-08-07		Control-column support	BW	05-09
B4-PC11A		2005-08-07		Control-column support	BW	05-09
B4-PC11AF		2005-08-07		Control-column support	BW	05-09
PC-6 Series	7A15	66-01-03		Fuel valve	Bk	1
		66-28-05		Rudder pedal support	Bk	1
		67-12-05		Pulley fairleads	Bk	1
		67-13-03		Rudder control lever rivets	Bk	1
		67-21-02		Elevator attachment bracket	Bk	1
		67-32-04		Stabilizer cable trim control clamps	Bk	1
		68-10-06		Horizontal stabilizer	Bk	1
		68-17-03	R1	Rudder end rib	BW	06-13
		69-04-04		Aileron balance bolt	Bk	1
		69-07-02		Aileron balance unit	Bk	1
		69-19-01		Pivot bolt rotation	Bk	1
		69-20-01		Rudder trim control cable	Bk	1
		71-23-01		Safety of aileron cable turnbuckles	Bk	1
		75-27-06		Fuel leak fittings	Bk	1
		75-27-07		Rudder bars	Bk	1
		76-01-09		Elevator attach brackets	Bk	1
		77-13-06		Landing flaps	Bk	1
		77-20-06		Wing strut corrosion	Bk	1
		90-19-01		Rudder pedal supports	Bk	3
		96-22-13		Hinge brackets on horizontal stabilizer	Bk	3
		2005-17-01		Stabilizer-trim attachment and structural components	BW	05-17
		2006-13-11		Aileron assembly	BW	06-13
		2006-13-12		Fuel starvation during maximum climb	BW	06-13
PC-6	7A15	85-16-09		Vertical/horizontal stabilizer	Bk	2
		2001-02-04		Lower lug assembly	Bk	4
		2003-09-01		Wing bellcrank assemblies	Bk	4
		2003-13-04		Ribs of inboard integral fuel tanks	Bk	4
		2005-17-01		Stabilizer-trim attachment and structural components	BW	05-17
		2006-15-02		Aileron control bellcrank assemblies		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2006-15-03		Integral fuel tank wing ribs		
PC-6/A Series	7A15	75-26-17		Engine mount	Bk	1
		2005-17-01		Stabilizer-trim attachment and structural components	BW 05-17	
PC-6/B-H2	7A15	69-05-05		Power lever travel	Bk	1
		2005-17-01		Stabilizer-trim attachment and structural components	BW 05-17	
		2006-15-02		Aileron control bellcrank assemblies		
		2006-15-03		Integral fuel tank wing ribs		
PC-6/B1-H2	7A15	69-05-05		Power lever travel	Bk	1
		70-18-03		Flight manual and switch	Bk	1
		97-22-08		AFM - Limitations Section - Power levers	Bk	3
		2005-17-01		Stabilizer-trim attachment and structural components	BW 05-17	
		2006-15-02		Aileron control bellcrank assemblies		
		2006-15-03		Integral fuel tank wing ribs		
PC-6/B2-H2	7A15	97-22-08		AFM - Limitations Section - Power levers	Bk	3
		2005-17-01		Stabilizer-trim attachment and structural components	BW 05-17	
		2006-15-02		Aileron control bellcrank assemblies		
		2006-15-03		Integral fuel tank wing ribs		
PC-6/B2-H4	7A15	97-22-08		AFM - Limitations Section - Power levers	Bk	3
		2005-17-01		Stabilizer-trim attachment and structural components	BW 05-17	
PC-7	A50EU	98-16-16		MLG and NLG leg seal unit	Bk	3
		2000-01-10		Elevator and rudder trim tab pivot arms	Bk	4
		2001-05-02		Elevator and rudder attachment brackets	Bk	4
		2001-26-13		Landing-Gear extension system	Bk	4
		2002-22-03		Main landing gear front attachment brackets	Bk	4
		2003-20-05		Forward and aft dihedral fittings	Bk	4
		2004-04-01		Engine-driven pump housing	Bk	4
		2004-23-01		Fuel booster pump	Bk	4
		2006-23-01		Main landing gear bay		
PC-12	A78EU	97-22-08		AFM - Limitations Section - Power levers	Bk	3
		98-04-16		Aileron tie-rod jam nuts	Bk	3
		98-05-06		Inspect elevator	Bk	3
		98-07-18		Propeller de-icing controller	Bk	3
		98-08-26		Fuel tank underwing access panels	Bk	3
		98-11-01	R2	Fuel tank inward vent valves	Bk	3
		98-11-20		Lavatory wall and passenger seat configuration	Bk	3
		98-20-28		AFM -Limitations Section - icing	Bk	3
		98-21-27		Passenger seats and seat rail covers	Bk	3
		99-06-05		Alternate flap system	Bk	3
		99-06-17		Second generator control unit	Bk	3
		99-14-03		Standby magnetic compass	Bk	3
		99-17-01		Flap drive shafts	Bk	3
		99-24-09		Inboard flap attachment fittings	Bk	3
		2000-02-31		Stick pusher system	Bk	4
		2000-11-14		Activate pneumatic wing and tail deicing boots	Bk	4
		2000-21-14		Inspect torque oil-pressure tubes	Bk	4
		2000-26-17		Windshield deicing system	Bk	4
		2001-11-02		Prevent damage to electrical components	Bk	4
		2001-22-15		Unflanged lightening holes	Bk	4
		2001-25-10		Flap power drive-unit circuit breaker	Bk	4
		2002-06-10		Oxygen tubing and connector assembly	Bk	4
		2002-14-22		Main landing gear assembly bolts	Bk	4
		2003-07-10		Switch caps	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2003-09-11		Pedestal leg assemblies on passenger seats	Bk	4
		2003-11-17		Pressure dome	Bk	4
		2003-14-07		Nose landing gear drag link	Bk	4
		2003-20-15		Fuel booster pump	Bk	4
		2004-04-01		Engine-driven pump housing	Bk	4
		2004-06-05		MLG shock absorber attachment bolts	Bk	4
		2004-12-11		Flap flexshafts	Bk	4
		2005-01-11		Main Landing Gear (MLG) Actuator	BW 05-01	
		2005-04-16		Windshield de-ice wiring system	BW 05-05	
		2005-11-06		Pitch actuator	BW 05-12	
PC-12 continued		2005-22-04		Nose landing gear (NLG), main landing gear (MLG), and MLG shock absorber assemblies	BW 05-22	
		2005-22-13		Left and right main landing gear (MLG) assemblies	BW 05-23	
		2006-08-11		Crew seat bucket assemblies	BW 06-09	
		2006-16-13		Lug fittings		
PC-12/45	A78EU	98-04-16		Aileron tie-rod jam nuts	Bk	3
		98-07-18		Propeller de-icing controller	Bk	3
		98-08-26		Fuel tank underwing access panels	Bk	3
		98-11-01	R2	Fuel tank inward vent valves	Bk	3
		98-11-20		Lavatory wall and passenger seat configuration	Bk	3
		98-20-28		AFM -Limitations Section - icing	Bk	3
		98-21-27		Passenger seats and seat rail covers	Bk	3
		99-06-05		Alternate flap system	Bk	3
		99-06-17		Second generator control unit	Bk	3
		99-14-03		Standby magnetic compass	Bk	3
		99-17-01		Flap drive shafts	Bk	3
		99-24-09		Inboard flap attachment fittings	Bk	3
		2000-02-31		Stick pusher system	Bk	4
		2000-11-14		Activate pneumatic wing and tail deicing boots	Bk	4
		2000-21-14		Inspect torque oil-pressure tubes	Bk	4
		2000-26-17		Windshield deicing system	Bk	4
		2001-11-02		Prevent damage to electrical components	Bk	4
		2001-22-15		Unflanged lightening holes	Bk	4
		2001-25-10		Flap power drive-unit circuit breaker	Bk	4
		2002-06-10		Oxygen tubing and connector assembly	Bk	4
		2002-14-22		Main landing gear assembly bolts	Bk	4
		2003-07-10		Switch caps	Bk	4
		2003-09-11		Pedestal leg assemblies on passenger seats	Bk	4
		2003-11-17		Pressure dome	Bk	4
		2003-14-07		Nose landing gear drag link	Bk	4
		2003-20-15		Fuel booster pump	Bk	4
		2004-04-01		Engine-driven pump housing	Bk	4
		2004-06-05		MLG shock absorber attachment bolts	Bk	4
		2004-12-11		Flap flexshafts	Bk	4
		2005-01-11		Main Landing Gear (MLG) Actuator	BW 05-01	
		2005-04-16		Windshield de-ice wiring system	BW 05-05	
		2005-11-06		Pitch actuator	BW 05-12	
		2005-22-04		Nose landing gear (NLG), main landing gear (MLG), and MLG shock absorber assemblies	BW 05-22	
		2005-22-13		Left and right main landing gear (MLG) assemblies	BW 05-23	
		2006-08-11		Crew seat bucket assemblies	BW 06-09	
		2006-16-13		Lug fittings		

PILATUS BRITTEN-NORMAN, LTD.
(See BRITTEN-NORMAN)
(See B-N Group LTD)

PINE AIR
(See KWAD COMPANY)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.

PIPER AIRCRAFT CORPORATION
(See PIPER AIRCRAFT INC, THE NEW)

PIPER AIRCRAFT, INC., THE NEW
(Formerly Piper Aircraft Corporation)
(AD's in Book 1 under Piper Aircraft Corp.)
(See Latino Americana de Aviacion for TC 2A8, Rev20 and TC 2A10, Rev23)

E-2	ATC 455	99-01-05	Wing lift struts or forks	Bk	3
F-2	ATC 525	99-01-05	Wing lift struts or forks	Bk	3
TG-8	GTC 10	99-01-05	Wing lift struts or forks	Bk	3
J-2 Series	ATC 595	99-26-19	Wing lift struts or forks	Bk	3
J-3 Series	ATC 660,	52-07-03	Lift strut rework	Bk	1
	A-698,	58-01-07	Control system turnbuckles	Bk	1
	A-691,	78-10-03	Fuel venting	Bk	1
	TC 695,	85-06-04	Fuel tank	Bk	2
	A-692				
J-3	ATC 660	47-50-03	Canvas seat inspection	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-01-07	Control system turnbuckles	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
J3C Series	A-691	47-50-03	Canvas seat inspection	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		50-05-01	Nicopress sleeve rework	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-01-07	Control system turnbuckles	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		99-01-05	Wing lift struts or forks	Bk	3
J3C-65	A-691	46-37-01	Fuel strainer gasket	Bk	1
		46-37-02	Fuel strainer position	Bk	1
		47-50-06	Shock strut cracks	Bk	1
J3C-65S	A-691	46-37-01	Fuel strainer gasket	Bk	1
		46-37-02	Fuel strainer position	Bk	1
		47-50-06	Shock strut cracks	Bk	1
J3F Series	A-692	47-50-03	Canvas seat inspection	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-01-07	Control system turnbuckles	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		99-01-05	Wing lift struts or forks	Bk	3
J3L Series	A-698	47-50-03	Canvas seat inspection	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-01-07	Control system turnbuckles	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		99-01-05	Wing lift struts or forks	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
J3P	TC 695	47-50-03	Canvas seat inspection	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-01-07	Control system turnbuckles	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
J4 Series	A-703, TC 708, A-740, TC 721	85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
J4, J4A, J4A-S	A-703	68-05-01	Exhaust mufflers	Bk	1
		78-10-03	Fuel venting	Bk	1
		99-01-05	Wing lift struts or forks	Bk	3
J4B	TC 708	68-05-01	Exhaust mufflers	Bk	1
J4E (L-4E)	A-740	68-05-01	Exhaust mufflers	Bk	1
		99-01-05	Wing lift struts or forks	Bk	3
J4F	TC 721	68-05-01	Exhaust mufflers	Bk	1
J5 Series (AE-1, HE-1)	A-725	58-01-07	Control system turnbuckles	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
J5C	A-725	99-01-05	Wing lift struts or forks	Bk	3
L-14	TC 760	99-01-05	Wing lift struts or forks	Bk	3
PA-11	A-691	47-50-06	Shock strut cracks	Bk	1
		48-03-03	Header tank installation	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		50-05-01	Nicopress sleeve rework	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-11S	A-691	50-05-01	Nicopress sleeve rework	Bk	1
		52-07-03	Lift strut rework	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-12	A-780	46-36-02	Airscoop rework	Bk	1
		46-36-03	Muffler brace	Bk	1
		46-37-01	Fuel strainer gasket	Bk	1
		47-22-03	Landing gear tie strap	Bk	1
		47-47-01	Landing gear reinforcement	Bk	1
		47-47-02	Battery box insulating spacer	Bk	1
		47-47-04	Starter solenoid replacement	Bk	1
		48-01-02	Cowl support braces	Bk	1
		48-13-03	Battery hold down brackets	Bk	1
		48-13-04	Fuse-clip attachment	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		48-14-01	Fuel line elbow	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		49-27-02	Aileron bellcrank castings	Bk	1
		50-05-01	Nicopress sleeve rework	Bk	1
		51-21-02	Aileron hinge brackets	Bk	1
		60-01-07	Tail brace wires	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		76-06-06	PA-14 wing flaps	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-12S	A-780	46-37-01	Fuel strainer gasket	Bk	1
		47-47-03	Seaplane fuselage inspection	Bk	1
		49-14-01	Elevator connector tube fitting	Bk	1
		50-05-01	Nicopress sleeve rework	Bk	1
		51-21-02	Aileron hinge brackets	Bk	1
		60-01-07	Tail brace wires	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		76-06-06	PA-14 wing flaps	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-14	A-797	49-27-02	Aileron bellcrank castings	Bk	1
		60-01-07	Tail brace wires	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-15	A-800	50-23-01	Shock strut fittings	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-16	1A1	51-23-03	Battery box insulation	Bk	1
		57-22-01	Fire prevention rework	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		78-10-03	Fuel venting	Bk	1
		85-06-04	Fuel tank	Bk	2
		99-01-05	Wing lift struts or forks	Bk	3
PA-16S	1A1	57-22-01	Fire prevention rework	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		78-10-03	Fuel venting	Bk	1
		99-01-05	Wing lift struts or forks	Bk	3
PA-17	A-805	50-23-01	Shock strut fittings	Bk	1
		58-12-02	Aileron hinge brackets	Bk	1
		68-05-01	Exhaust mufflers	Bk	1
		74-17-04	Fabric reinforcement	Bk	1
		85-06-04	Fuel tank	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		99-01-05		Wing lift struts or forks	Bk	3
PA-18 Series	1A2	53-04-01		Control stick attachment	Bk	1
		60-10-08		Fuel selector valve	Bk	1
		62-02-05	R1	Rudder cable attachment lug	Bk	1
		68-05-01		Exhaust mufflers	Bk	1
		78-10-03		Fuel venting	Bk	1
		85-06-04		Fuel tank	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-18	1A2	51-19-02		Oil radiator hose	Bk	1
		53-24-04		Fuel-hydraulic lines	Bk	1
		59-10-08		Gas tank cap vent	Bk	1
		72-01-07		Failure of engine mount	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-18A	1A2,	54-19-01		Brake line cover plate	Bk	1
	AR-7	59-10-08		Gas tank cap vent	Bk	1
		62-02-05	R1	Rudder cable attachment lug	Bk	1
		72-01-07		Failure of engine mount	Bk	1
		85-06-04		Fuel tank	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-18-105	1A2	72-01-07		Failure of engine mount	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-18-125	1A2	72-01-07		Failure of engine mount	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-18-135	1A2	72-01-07		Failure of engine mount	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-18-150	1A2	61-16-05		Control cable replacement	Bk	1
		69-23-03		Lower longeron inspection	Bk	1
		81-06-08		Lower fuselage attachment tab	Bk	2
PA-18A-150	1A2	61-16-05		Control cable replacement	Bk	1
	AR-7	99-01-05		Wing lift struts or forks	Bk	3
PA-18S-150	1A2	61-16-05		Control cable replacement	Bk	1
PA-18AS-150	1A2	61-16-05		Control cable replacement	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-19	1A2	68-05-01		Exhaust mufflers	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-19S	1A2	68-05-01		Exhaust mufflers	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-18A-125	--	61-16-05		Control cable replacement	Bk	1
		72-01-07		Failure of engine mount	Bk	1
PA-18A-135	1A2	61-16-05		Control cable replacement	Bk	1
	AR-7	72-01-07		Failure of engine mount	Bk	1
		99-01-05		Wing lift struts or forks	Bk	3
PA-20 Series	1A4	57-22-01		Fire prevention rework	Bk	1
		60-01-07		Tail brace wires	Bk	1
		60-10-08		Fuel selector valve	Bk	1
		68-05-01		Exhaust mufflers	Bk	1
		72-21-03		Fuel line failure	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		74-17-04		Fabric reinforcement	Bk	1
		78-10-03		Fuel venting	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		85-06-04		Fuel tank	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-20	1A4	51-19-02		Oil radiator hose	Bk	1
		51-23-03		Battery box insulation	Bk	1
		53-24-04		Fuel-hydraulic lines	Bk	1
		58-16-01		Cigar lighter fuse	Bk	1
		59-10-08		Gas tank cap vent	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-20-115	1A4	85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-20-135	1A4	85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-20S	1A4	85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-20S-115	1A4	85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-20S-135	1A4	85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22 Series	1A6	51-27-03		Nose wheel drain	Bk	1
		55-07-02		Landing gear tube reinforcement	Bk	1
		55-22-03		Fuel tank cap	Bk	1
		57-22-01		Fire prevention rework	Bk	1
		58-16-01		Cigar lighter fuse	Bk	1
		60-01-07		Tail brace wires	Bk	1
		60-10-08		Fuel selector valve	Bk	1
		67-24-02	R1	Engine fuel starvation	Bk	1
		68-05-01		Exhaust mufflers	Bk	1
		72-21-03		Fuel line failure	Bk	1
		73-09-06		Throttle hangup	Bk	1
		74-17-04		Fabric reinforcement	Bk	1
		78-10-03		Fuel venting	Bk	1
		85-06-04		Fuel tank	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22	1A6	51-19-02		Oil radiator hose	Bk	1
		51-23-03		Battery box insulation	Bk	1
		53-24-04		Fuel-hydraulic lines	Bk	1
		55-08-04		Ignition filter replacement	Bk	1
		59-10-08		Gas tank cap vent	Bk	1
		64-05-04		Upper main oleo bearings	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-22-108	1A6	64-05-04		Upper main oleo bearings	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22-135	1A6	60-01-07		Tail brace wires	Bk	1
		64-05-04		Upper main oleo bearings	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22S-135		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22-150	1A6	60-01-07		Tail brace wires	Bk	1
		60-05-03	R1	Safety belt	Bk	1
		61-16-05		Control cable replacement	Bk	1
		64-05-04		Upper main oleo bearings	Bk	1
		73-09-06		Throttle hangup	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22S-150	1A6	61-16-05		Control cable replacement	Bk	1
		73-09-06		Throttle hangup	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22-160	1A6	60-01-07	R1	Tail brace wires	Bk	1
		60-05-03	R1	Safety belt	Bk	1
		61-16-05		Control cable replacement	Bk	1
		64-05-04		Upper main oleo bearings	Bk	1
		73-09-06		Throttle hangup	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-22S-160	1A6	61-16-05		Control cable replacement	Bk	1
		73-09-06		Throttle hangup	Bk	1
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		99-01-05		Wing lift struts or forks	Bk	3
PA-23 Series	1A10	55-21-02		Front wing spar attachment fitting	Bk	1
		57-21-01		Rudder trim tab pin	Bk	1
		58-22-03		Goodrich G-3-787 wheel	Bk	1
		63-07-03		Rudder trim tabs	Bk	1
		63-24-03		Rudder trim tab control rod assy	Bk	1
		71-18-03		Left nose wheel door hinge	Bk	1
		79-11-06		Landing gear selector lever	Bk	1
PA-23	1A10	55-11-02		Thermal relief valves	Bk	1
		55-13-01		Idler bellcrank installation	Bk	1
		55-14-02		Hydraulic cylinder replacement	Bk	1
		56-27-03		Aileron balance weight brackets	Bk	1
		57-01-02		Stabilizer attachment bolts	Bk	1
		57-05-03		Elevator push-pull tube	Bk	1
		57-10-02		Oil pressure gage line	Bk	1
		57-13-08		Anti-retraction device	Bk	1
		57-19-01		Elevator rod end bearing	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		58-01-06		Stabilizer fitting	Bk	1
		58-04-03		Rudder trim tab adjustment screw	Bk	1
		59-08-03		Operating limitations placard	Bk	1
		60-03-07		Engine starter solenoid	Bk	1
		60-03-08	R3	Fuel control cable and wire	Bk	1
PA-23 continued		63-12-02		Elevator rib cracks	Bk	1
		63-26-03	R3	Tail area inspection	Bk	1
		69-13-03		Heater exhaust tube	Bk	1
		71-12-01		Engine control support bracket	Bk	1
		74-22-05		Full valve stem and cap nut	Bk	1
		78-08-03		Hinge bracket assembly	Bk	1
		80-18-10		Fuel selector valves	Bk	2
		80-26-04	R1	Rudder pulley at cabin step	Bk	2
		81-04-05	R1	Flap-spar hinge attachment	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		88-21-07	R1	Fuel filler compartment	Bk	2
		92-13-04		Fuel tank modifications	Bk	3
		93-06-02		Fuel hose	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-09-13		Flap control torque tube	Bk	4
PA-23-150 listed under PA-23						
PA-23-160	1A10	60-03-08	R3	Fuel control cable and wire	Bk	1
		63-07-03		Rudder trim tabs	Bk	1
		63-24-03		Rudder trim tab control rod assy	Bk	1
		63-26-03	R3	Tail area inspection	Bk	1
		69-13-03		Heater exhaust tube	Bk	1
		71-12-01		Engine control support bracket	Bk	1
		74-22-05		Full valve stem and cap nut	Bk	1
		78-08-03		Hinge bracket assembly	Bk	1
		80-18-10		Fuel selector valves	Bk	2
		80-26-04	R1	Rudder pulley at cabin step	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		88-21-07	R1	Fuel filler compartment	Bk	2
		92-13-04		Fuel tank modifications	Bk	3
		93-06-02		Fuel hose	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-09-13		Flap control torque tube	Bk	4
PA-23-235	1A10	69-13-03		Heater exhaust tube	Bk	1
		72-11-01		Possible fire from fuel vapor	Bk	1
		74-06-01		AiResearch turbochargers	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		74-22-05		Full valve stem and cap nut	Bk	1
		80-18-10		Fuel selector valves	Bk	2
		80-26-04	R1	Rudder pulley at cabin step	Bk	2
		81-04-05	R1	Flap-spar hinge attachment	Bk	2
		83-22-01	R1	Fuel weight limitations *(See Book 3 for paper copy)*	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		88-21-07	R1	Fuel filler compartment	Bk	2
		93-06-02		Fuel hose	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		99-05-09		Induction air filter	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-09-13		Flap control torque tube	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2005-01-10		Turbocharger Oil Reservoir	BW 05-01	
PA-23-250	1A10	64-21-05		Hartzell propeller governors	Bk	1
		66-18-03		Induction system icing	Bk	1
		68-07-04		Engine mount	Bk	1
		68-21-03		Exhaust tailpipe	Bk	1
		69-13-03		Heater exhaust tube	Bk	1
		70-22-05		Electrical system modification	Bk	1
		71-12-01		Engine control support bracket	Bk	1
		71-12-05		Electric trim switch mod.	Bk	1
		71-21-06		Engine fire wall flex duct	Bk	1
		72-11-01		Possible fire from fuel vapor	Bk	1
		72-14-05		Engine exhaust system stacks	Bk	1
		72-21-07		Longitudinal stability	Bk	1
		74-06-01		AiResearch turbochargers	Bk	1
		74-10-01		Outboard flap hinge	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		74-22-05		Full valve stem and cap nut	Bk	1
		75-11-05		Glare shield panel	Bk	1
		76-11-07		Magnetic compass deviations	Bk	1
		77-01-05		Strobe NAV light wire	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-23-09		Fuel flow	Bk	1
		78-02-03		Stabilator	Bk	1
				(See Book 3 for paper copy)		
		79-26-01		Stabilator skins and frame	Bk	1
		80-18-10		Fuel selector valves	Bk	2
		80-26-04	R1	Rudder pulley at cabin step	Bk	2
		81-04-05	R1	Flap-spar hinge attachment	Bk	2
		83-22-01	R1	Fuel weight limitations	Bk	2
				(See Book 3 for paper copy)		
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln.	Bk	2
				(See Book 3 for paper copy)		
		88-21-07	R1	Fuel filler compartment	Bk	2
		93-06-02		Fuel hose	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		99-05-09		Induction air filter	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-09-13		Flap control torque tube	Bk	4
		2005-01-10		Turbocharger Oil Reservoir	BW 05-01	
PA-E23-250	1A10	66-18-03		Induction system icing	Bk	1
		68-21-03		Exhaust tailpipe	Bk	1
		69-13-03		Heater exhaust tube	Bk	1
		71-12-05		Electric trim switch mod.	Bk	1
		72-11-01		Possible fire from fuel vapor	Bk	1
		72-14-05		Engine exhaust system stacks	Bk	1
		74-06-01		AiResearch turbochargers	Bk	1
		74-22-05		Full valve stem and cap nut	Bk	1
		77-23-09		Fuel flow	Bk	1
		80-18-10		Fuel selector valves	Bk	2
		83-22-01	R1	Fuel weight limitations	Bk	2
				(See Book 3 for paper copy)		
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln.	Bk	2
				(See Book 3 for paper copy)		
		88-21-07	R1	Fuel filler compartment	Bk	2
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-09-13		Flap control torque tube	Bk	4
		2005-01-10		Turbocharger Oil Reservoir	BW 05-01	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-24 Series	1A15	61-16-06		Fuel selector valve handles	Bk	1
		62-26-05		Exhaust system	Bk	1
		63-27-03		Landing gear retraction motor circuit	Bk	1
		68-05-01		Exhaust mufflers	Bk	1
PA-24 (PA-24-180)	1A15	58-25-05		Door latch modification	Bk	1
		59-06-05		Nose gear bungee	Bk	1
		59-07-05		Oil cooler lines clearance	Bk	1
		59-12-09		Control wheel sprocket stud	Bk	1
		59-13-02		Aileron balance weight	Bk	1
		59-26-02		Fuel cell vent tubes	Bk	1
		60-24-03		Fuel vent tubes	Bk	1
		62-10-03		Aileron counterweight bay rework	Bk	1
		64-22-03		Landing gear safety switch	Bk	1
		65-25-03		Nose landing gear drag link clevis	Bk	1
		68-13-03		Fuel cell collapse	Bk	1
		72-22-05		Operation limitation placard	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		75-05-02		Engine oil	Bk	1
		75-12-06		Fin forward spar	Bk	1
		75-27-08		Torque tube bearing fittings	Bk	1
		77-08-01		Aileron spar cracks	Bk	1
		77-13-21		Prevent landing gear collapse	Bk	1
		79-20-10		Incorporation of Piper Kit 763893	Bk	1
		82-23-01	R1	Placard near flap actuator	Bk	2
		83-19-03		Lower spar cap inspection	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		94-13-10		Stabilizer torque tube	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-24-250	1A15	59-06-05		Nose gear bungee	Bk	1
		59-12-09		Control wheel sprocket stud	Bk	1
		59-13-02		Aileron balance weight	Bk	1
		59-26-02		Fuel cell vent tubes	Bk	1
		60-24-03		Fuel vent tubes	Bk	1
		61-16-06		Fuel selector valve handles	Bk	1
		61-20-02		Exhaust stack reinforcement	Bk	1
		62-10-03		Aileron counterweight bay rework	Bk	1
		62-26-05		Exhaust system	Bk	1
		63-27-03		Landing gear retraction motor circuit	Bk	1
		64-10-04		Carburetor air box deflector vanes	Bk	1
		64-22-03		Landing gear safety switch	Bk	1
		65-11-04		Stabilator control system	Bk	1
		65-25-03		Nose landing gear drag link clevis	Bk	1
		68-13-03		Fuel cell collapse	Bk	1
		72-22-05		Operation limitation placard	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		75-05-02		Engine oil	Bk	1
		75-12-06		Fin forward spar	Bk	1
		75-27-08		Torque tube bearing fittings	Bk	1
		76-19-07		Stabilator weight assy	Bk	1
		77-08-01		Aileron spar cracks	Bk	1
		77-13-21		Prevent landing gear collapse	Bk	1
		79-20-10		Incorporation of Piper Kit 763893	Bk	1
		82-23-01	R1	Placard near flap actuator	Bk	2
		83-19-03		Lower spar cap inspection	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-24-250 continued		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln.	Bk	2
				(See Book 3 for paper copy)		
		94-13-10		Stabilizer torque tube	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-24-260	1A15	65-11-04		Stabilator control system	Bk	1
		66-18-04		Baggage door latch	Bk	1
		71-12-05		Electric trim switch mod.	Bk	1
		72-22-05		Operation limitation placard	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		75-05-02		Engine oil	Bk	1
		75-12-06		Fin forward spar	Bk	1
		75-27-08		Torque tube bearing fittings	Bk	1
		76-19-07		Stabilator weight assy	Bk	1
		77-08-01		Aileron spar cracks	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-13-21		Prevent landing gear collapse	Bk	1
		79-20-10		Incorporation of Piper Kit 763893	Bk	1
		82-23-01	R1	Placard near flap actuator	Bk	2
		83-19-03		Lower spar cap inspection	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln.	Bk	2
				(See Book 3 for paper copy)		
		91-21-09		Air induction system	Bk	3
		94-13-10		Stabilizer torque tube	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-24-400	1A15	65-11-04		Stabilator control system	Bk	1
		66-30-07		Fuel purge valve hose assembly	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		75-12-06		Fin forward spar	Bk	1
		75-27-08		Torque tube bearing fittings	Bk	1
		77-08-01		Aileron spar cracks	Bk	1
		77-13-21		Prevent landing gear collapse	Bk	1
		79-12-08		Fuel selector valves	Bk	1
		79-20-10		Incorporation of Piper Kit 763893	Bk	1
		83-10-01		Water and fuel system insp.	Bk	2
		83-19-03		Lower spar cap inspection	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln.	Bk	2
				(See Book 3 for paper copy)		
		94-13-10		Stabilizer torque tube	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
PA-28 Series	2A13	62-19-03		Propeller attach bolts	Bk	1
		64-06-06		Control wheels	Bk	1
		67-20-04		Main landing gear torque link	Bk	1
		67-26-02		Fuel selector valve	Bk	1
PA-28-140	2A13	65-06-06		Fuel quantity gauge sender units	Bk	1
		67-12-06		Inspect tubes for internal corrosion	Bk	1
		67-26-03		Fuel systems screens and filters	Bk	1
		69-22-02		Failure of control wheel	Bk	1
		70-16-05		Cracks in muffler	Bk	1
		70-18-05		Landing gear torque link bolts	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-14-06		To prevent grounding of magnetos	Bk	1
		71-21-08		Binding of fuel selector handle	Bk	1
		72-08-06		Main landing gear torque links	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-24-02		Throttle movement placard	Bk	1
		74-06-02		AVCON mufflers	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-28-140 continued		74-09-04		Rear seat belt installation	Bk	1
		74-13-04		Throttle control cable	Bk	1
		75-02-03		Nose wheel fork assembly	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		77-23-03		Rod end bearings	Bk	1
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-01	R1	Landing light support and seal assembly	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-28-150	2A13	62-26-06		Exhaust system	Bk	1
		65-06-06		Fuel quantity gauge sender units	Bk	1
		66-20-05		Propeller spinner	Bk	1
		67-12-06		Inspect tubes for internal corrosion	Bk	1
		67-26-03		Fuel systems screens and filters	Bk	1
		69-22-02		Failure of control wheel	Bk	1
		70-16-05		Cracks in muffler	Bk	1
		70-18-05		Landing gear torque link bolts	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-14-06		To prevent grounding of magnetos	Bk	1
		72-08-06		Main landing gear torque links	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-24-02		Throttle movement placard	Bk	1
		75-02-03		Nose wheel fork assembly	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		86-17-01		Ammeter replacement	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-01	R1	Landing light support and seal assembly	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-28-151	2A13	74-14-04		Reduced weight placard	Bk	1
		74-24-12		Aileron centering assembly	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		75-16-04		Carburetor air box valve	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		77-01-03		Carburetor air filter boxes	Bk	1
		77-23-03		Rod end bearings	Bk	1
		81-23-05		Seat springs and battery box	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-26-05		Induction air filter	Bk	3
PA-28-160	2A13	62-26-06		Exhaust system	Bk	1
		65-06-06		Fuel quantity gauge sender units	Bk	1
		66-20-05		Propeller spinner	Bk	1
		67-12-06		Inspect tubes for internal corrosion	Bk	1
		67-26-03		Fuel systems screens and filters	Bk	1
		69-22-02		Failure of control wheel	Bk	1
		70-16-05		Cracks in muffler	Bk	1
		70-18-05		Landing gear torque link bolts	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-14-06		To prevent grounding of magnetos	Bk	1
		72-08-06		Main landing gear torque links	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-24-02		Throttle movement placard	Bk	1
		75-02-03		Nose wheel fork assembly	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		86-17-01		Ammeter replacement	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-28-160 continued		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-01	R1	Landing light support and seal assembly	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
		2005-19-20		Bushing screw thread expanders	BW 05-20	
PA-28-161	2A13	77-23-03		Rod end bearings	Bk	1
		79-02-05		Fuel flow	Bk	1
		79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		81-23-05		Seat springs and battery box	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-26-05		Induction air filter	Bk	3
		2004-14-12		Control wheel attaching hardware	Bk	4
		2005-19-20		Bushing screw thread expanders	BW 05-20	
PA-28S-160	2A13	67-26-03		Fuel systems screens and filters	Bk	1
		70-16-05		Cracks in muffler	Bk	1
		72-24-02		Throttle movement placard	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		95-26-13		Inspect oil cooler hoses	Bk	3
		99-26-05		Induction air filter	Bk	3
PA-28-180	2A13	65-06-06		Fuel quantity gauge sender units	Bk	1
		66-20-05		Propeller spinner	Bk	1
		67-12-06		Inspect tubes for internal corrosion	Bk	1
		67-26-03		Fuel systems screens and filters	Bk	1
		69-15-01		Control wheel pin	Bk	1
		69-22-02		Failure of control wheel	Bk	1
		70-16-05		Cracks in muffler	Bk	1
		70-18-05		Landing gear torque link bolts	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-14-06		To prevent grounding of magnetos	Bk	1
		71-21-08		Binding of fuel selector handle	Bk	1
		72-08-06		Main landing gear torque links	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-17-05		Electric trim switch	Bk	1
		74-09-04		Rear seat belt installation	Bk	1
		74-26-07		To detect incorrect placard	Bk	1
		75-02-03		Nose wheel fork assembly	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		75-24-02		Loose seats	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		77-23-03		Rod end bearings	Bk	1
		86-17-01		Ammeter replacement	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-01	R1	Landing light support and seal assembly	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
		2005-19-20		Bushing screw thread expanders	BW 05-20	
PA-28-181	2A13	77-01-01		Fuel quantity gage	Bk	1
		77-23-03		Rod end bearings	Bk	1
		79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-02		Throttle cable	Bk	2
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-28-181 continued		99-05-09		Induction air filter	Bk	3
		2004-14-12		Control wheel attaching hardware	Bk	4
		2005-19-20		Bushing screw thread expanders	BW 05-20	
PA-28S-180	2A13	67-26-03		Fuel systems screens and filters	Bk	1
		70-16-05		Cracks in muffler	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		95-26-13		Inspect oil cooler hoses	Bk	3
		99-26-05		Induction air filter	Bk	3
PA-28R-180	2A13	68-12-04		Gear retraction fittings	Bk	1
		69-12-01		Air induction hose	Bk	1
		69-15-01		Control wheel pin	Bk	1
		70-09-02		Propeller spinner	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-21-08		Binding of fuel selector handle	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-17-05		Electric trim switch	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		75-24-02		Loose seats	Bk	1
		76-15-08		Nose gear trunnion	Bk	1
		77-23-03		Rod end bearings	Bk	1
		80-19-01		Carbon monoxide in cabin	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		94-14-14		NLG modification	Bk	3
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
PA-28R-200	2A13	69-12-01		Air induction hose	Bk	1
		69-15-01		Control wheel pin	Bk	1
		70-09-02		Propeller spinner	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-21-08		Binding of fuel selector handle	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-17-05		Electric trim switch	Bk	1
		74-09-04		Rear seat belt installation	Bk	1
		75-08-03		Fuel drain valves	Bk	1
		75-24-02		Loose seats	Bk	1
		76-15-08		Nose gear trunnion	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		77-23-03		Rod end bearings	Bk	1
		80-19-01		Carbon monoxide in cabin	Bk	2
		81-11-02	R1	Oil drain valves	Bk	2
		82-06-11	R1	NLG, inspect, rig, modify	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		94-14-14		NLG modification	Bk	3
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
PA-28-201T	2A13	79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-28R-201	2A13	77-23-03		Rod end bearings	Bk	1
		79-02-05		Fuel flow	Bk	1
		79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		80-19-01		Carbon monoxide in cabin	Bk	2
		81-11-02	R1	Oil drain valves	Bk	2
		82-06-11	R1	NLG, inspect, rig, modify	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		94-14-14		NLG modification	Bk	3
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		2004-14-12		Control wheel attaching hardware	Bk	4
PA-28R-201T	2A13	77-23-03		Rod end bearings	Bk	1
		79-02-05		Fuel flow	Bk	1
		79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		82-06-11	R1	NLG, inspect, rig, modify	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		94-14-14		NLG modification	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-28RT-201	2A13	79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		80-19-01		Carbon monoxide in cabin	Bk	2
		81-11-02	R1	Oil drain valves	Bk	2
		82-06-11	R1	NLG, inspect, rig, modify	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		94-14-14		NLG modification	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
PA-28RT-201T	2A13	79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		82-06-11	R1	NLG, inspect, rig, modify	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		94-14-14		NLG modification	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-28-235	2A13	65-06-06		Fuel quantity gauge sender units	Bk	1
		67-12-06		Inspect tubes for internal corrosion	Bk	1
		67-26-03		Fuel systems screens and filters	Bk	1
		69-15-01		Control wheel pin	Bk	1
		69-22-02		Failure of control wheel	Bk	1
		70-18-05		Landing gear torque link bolts	Bk	1
		70-26-04		Stabilizer balance weight tube	Bk	1
		71-14-06		To prevent grounding of magnetos	Bk	1
		72-08-06		Main landing gear torque links	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-17-05		Electrim trim switch	Bk	1
		74-09-04		Rear seat belt installation	Bk	1
		74-18-06		Fuel quantity placards	Bk	1
		74-19-01		Outer wing spars	Bk	1
		75-02-03		Nose wheel fork assembly	Bk	1
		75-24-02		Loose seats	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-28-235 continued		76-18-04		Fuel valve	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		77-12-01		Fuel system	Bk	1
		77-23-03		Rod end bearings	Bk	1
		78-23-01		Fuel drain assembly	Bk	1
		79-22-02		Fuel leakage	Bk	1
		86-17-01		Ammeter replacement	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-28-236	2A13	79-13-03		Fire hazard prevention	Bk	1
		79-22-02		Fuel leakage	Bk	1
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
PA-30	A1EA	64-09-05		Induction system alternate air doors	Bk	1
		64-16-06		Nose gear retraction tubes	Bk	1
		64-21-05		Hartzell propeller governor	Bk	1
		64-28-03		Heavy walled torque tube	Bk	1
		65-11-04		Stabilator control system	Bk	1
		66-18-04		Baggage door latch	Bk	1
		66-28-06		Stabilator system	Bk	1
		67-19-05		Oxygen cylinder mounting channels	Bk	1
		69-13-03		Heater exhaust tube	Bk	1
		69-24-04		Minimum control speed	Bk	1
		70-15-17		Operating limitation placard	Bk	1
		70-22-05		Electrical system modifications	Bk	1
		71-12-05		Electric trim switch mod.	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		74-16-08		Aft bulkhead assembly	Bk	1
		75-27-08		Torque tube bearing fittings	Bk	1
		76-18-05		Forward fin attachment	Bk	1
		77-08-01		Aileron spar cracks	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-13-21		Prevent landing gear collapse	Bk	1
		78-12-07		Fuel selector valve	Bk	1
		79-12-08		Fuel selector valve	Bk	1
		79-20-10		Incorporation of Piper Kit 763893	Bk	1
		82-23-01	R1	Placard near flap actuator	Bk	2
		83-10-01		Water and fuel system inspection	Bk	2
		83-19-03		Lower spar cap inspection	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		94-13-10		Stabilizer torque tube	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
PA-39	A1EA	71-12-05		Electric trim switch mod.	Bk	1
		74-13-03		Stabilator attach bolts	Bk	1
		74-16-08		Aft bulkhead assembly	Bk	1
		75-27-08		Torque tube bearing fittings	Bk	1
		76-18-05		Forward fin attachment	Bk	1
		77-08-01		Aileron spar cracks	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-13-21		Prevent landing gear collapse	Bk	1
		78-12-07		Fuel selector valve	Bk	1
		79-12-08		Fuel selector valve	Bk	1
		79-20-10		Incorporation of Piper Kit 763893	Bk	1
		82-23-01	R1	Placard near flap actuator	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-39 continued		83-10-01		Water and fuel system inspection	Bk	2
		83-19-03		Lower spar cap inspection	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		94-13-10		Stabilizer torque tube	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
PA-40	A1EA	99-14-01		AFM - Limitations Section - icing	Bk	3
PA-31	A20SO	67-25-06		Oil cooler hoses	Bk	1
		68-13-01		Electrical wire arcing	Bk	1
		68-20-04		Elevator torque tube	Bk	1
		69-06-04		Elevator friction system	Bk	1
		69-11-05		Stall strips	Bk	1
		69-13-04		Landing gear warning	Bk	1
		70-22-05		Electrical system modification	Bk	1
		71-01-04		Toxic fumes from battery	Bk	1
		71-12-05		Electric trim switch mod.	Bk	1
		74-26-04		Explosion hazards	Bk	1
		74-26-10		Shutting down engine	Bk	1
		75-09-10		Push-pull tube end fittings	Bk	1
		76-04-11		Loose bolts	Bk	1
		77-01-06		Horizontal stabilizer	Bk	1
		77-03-03		Aircraft data plate	Bk	1
		77-07-03		Electrical terminals	Bk	1
		77-08-02		Electrical short	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-12-02		Elevator balance weights	Bk	1
		77-14-14		Skin deformation & loose/missing rivets	Bk	1
		77-19-06		Aileron cables	Bk	1
		77-24-01		Stabilizers and fins	Bk	1
		78-01-02		Elevator bungee	Bk	1
		78-05-05		Cabin door latch	Bk	1
		78-08-10		Fuel selector lever	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		79-20-07		Lighter circuit breaker	Bk	1
		80-17-02		Elevator balance weights	Bk	2
		80-17-06		Placards	Bk	2
		80-18-10		Fuel selector valves	Bk	2
		82-16-05	R1	Turbocharger tailpipe instln.	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		92-27-05		Aileron control systems	Bk	3
		93-23-13		Engine baffle seals	Bk	3
		93-24-02	R1	Elevator control tube assembly	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-10-15		Inspect wing attachments of WS 147.5	Bk	3
		96-12-12		Fuselage station bulkhead	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		96-24-13		Landing gear selector cable	Bk	3
		97-07-03		Nose wheel assembly	Bk	3
		98-08-18		Elevator bungee spring	Bk	3
		98-09-25		Lower spar splice plate	Bk	3
		99-06-01		Horizontal stabilizer rear spar	Bk	3
		99-12-05		Elevator spar assembly	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-31 continued		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4
PA-31-300	A20SO	68-13-01		Electrical wire arcing	Bk	1
		68-20-04		Elevator torque tube	Bk	1
		69-06-04		Elevator friction system	Bk	1
		69-11-05		Stall strips	Bk	1
		69-13-04		Landing gear warning	Bk	1
		70-22-05		Electrical system modification	Bk	1
		71-01-04		Toxic fumes from battery	Bk	1
		71-12-05		Electric trim switch mod.	Bk	1
		74-26-04		Explosion hazards	Bk	1
		74-26-10		Shutting down engine	Bk	1
		75-09-10		Push-pull tube end fittings	Bk	1
		76-04-11		Loose bolts	Bk	1
		77-08-02		Electrical short	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-12-02		Elevator balance weights	Bk	1
		77-19-06		Aileron cables	Bk	1
		78-05-05		Cabin door latch	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		80-18-10		Fuel selector valves	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		93-23-13		Engine baffle seals	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-10-15		Inspect wing attachments of WS 147.5	Bk	3
		96-12-12		Fuselage station bulkhead	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		97-07-03		Nose wheel assembly	Bk	3
		98-08-18		Elevator bungee spring	Bk	3
		98-09-25		Lower spar splice plate	Bk	3
		99-06-01		Horizontal stabilizer rear spar	Bk	3
		99-12-05		Elevator spar assembly	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4
PA-31-325	A20SO	76-04-11		Loose bolts	Bk	1
		76-15-07		Elevator balance weights	Bk	1
		77-01-06		Horizontal stabilizer	Bk	1
		77-07-03		Electrical terminals	Bk	1
		77-08-02		Electrical short	Bk	1
		77-10-09		Vibration effects	Bk	1
		77-14-14		Skin deformation & loose/missing rivets	Bk	1
		77-19-06		Aileron cables	Bk	1
		77-24-01		Stabilizers and fins	Bk	1
		78-01-02		Elevator bungee	Bk	1
		78-05-05		Cabin door latch	Bk	1
		78-08-10		Fuel selector lever	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		79-20-07		Lighter circuit breaker	Bk	1
		80-13-06		Air door catch assy attach	Bk	2
		80-17-02		Elevator balance weights	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-31-325 continued		80-17-06		Placards	Bk	2
		80-18-10		Fuel selector valves	Bk	2
		82-16-05	R1	Turbocharger tailpipe instln.	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		93-23-13		Engine baffle seals	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-10-15		Inspect wing attachments of WS 147.5	Bk	3
		96-12-12		Fuselage station bulkhead	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		96-24-13		Landing gear selector cable	Bk	3
		97-07-03		Nose wheel assembly	Bk	3
		98-08-18		Elevator bungee spring	Bk	3
		98-09-25		Lower spar splice plate	Bk	3
		99-06-01		Horizontal stabilizer rear spar	Bk	3
		99-12-05		Elevator spar assembly	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4
PA-31-350	A20SO	74-26-10		Shutting down engine	Bk	1
		75-06-04		Forward rudder control cable	Bk	1
		75-09-10		Push-pull rube end fittings	Bk	1
		76-04-10		Toxic fumes	Bk	1
		76-04-11		Loose bolts	Bk	1
		76-15-07		Elevator balance weights	Bk	1
		77-01-06		Horizontal stabilizer	Bk	1
		77-07-03		Electrical terminals	Bk	1
		77-08-02		Electrical short	Bk	1
		77-09-10		Electric trim switch	Bk	1
		77-14-14		Skin deformation & loose/missing rivets	Bk	1
		77-19-06		Aileron cables	Bk	1
		77-24-01		Stabilizers and fins	Bk	1
		78-01-02		Elevator bungee	Bk	1
		78-05-05		Cabin door latch	Bk	1
		78-26-11		Elevator control system	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		79-20-07		Lighter circuit breaker	Bk	1
		80-13-06		Air door catch assy attach	Bk	2
		80-17-02		Elevator balance weights	Bk	2
		80-17-06		Placards	Bk	2
		80-18-10		Fuel selector valves	Bk	2
		82-16-05	R1	Turbocharger tailpipe instln	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		93-23-13		Engine baffle seals	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-10-15		Inspect wing attachments of WS 147.5	Bk	3
		96-12-12		Fuselage station bulkhead	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		96-24-13		Landing gear selector cable	Bk	3
		97-07-03		Nose wheel assembly	Bk	3
		98-08-18		Elevator bungee spring	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-31-350 continued		98-09-25		Lower spar splice plate	Bk	3
		99-06-01		Horizontal stabilizer rear spar	Bk	3
		99-12-05		Elevator spar assembly	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4
PA-31P	A8EA	71-12-05		Electric trim switch mod.	Bk	1
		74-26-10		Shutting down engine	Bk	1
		75-09-10		Push-pull tube end fittings	Bk	1
		75-16-02		Rudder nose gear	Bk	1
		75-22-14		Propeller air dome pressure	Bk	1
		76-04-11		Loose bolts	Bk	1
		76-06-09		Engine exhaust system	Bk	1
		76-11-01		Vibration effects	Bk	1
		76-11-06		Switch bus bar link	Bk	1
		77-08-02		Electrical short	Bk	1
		77-09-10		Electric trim switch	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		80-02-15		Elevator butt rib cracks	Bk	2
		80-18-10		Fuel selector valves	Bk	2
		81-23-06		Flap track structure	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		85-05-01		Inspection of F.S. 332.0 bulkhead	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		87-21-01		Fuel filler openings	Bk	2
		93-24-02	R1	Elevator control tube assembly	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		96-24-13		Landing gear selector cable	Bk	3
		97-07-03		Nose wheel assembly	Bk	3
		98-08-18		Elevator bungee spring	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4
PA-31P-350	A8EA	87-21-01		Fuel filler openings	Bk	2
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		99-06-01		Horizontal stabilizer rear spar	Bk	3
		99-12-05		Elevator spar assembly	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-31T	A8EA	75-16-02		Rudder nose gear	Bk	1
		76-03-01		Elevator trim tab system	Bk	1
		76-04-11		Loose bolts	Bk	1
		76-18-06		Elevator structure	Bk	1
		77-08-02		Electrical short	Bk	1
		78-02-01		Main landing gear	Bk	1
		78-08-12		Flap system operation	Bk	1
		78-12-06		Nose landing gear wheel assy	Bk	1
		78-13-06		Main landing gear wheel assy	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		79-19-09		Electroluminescent panel inverters	Bk	1
		80-01-08		Oil cooler inlet hose	Bk	2
		80-02-15		Elevator butt rib cracks	Bk	2
		80-11-06		Aircraft data plate	Bk	2
		80-14-08		AFM revision	Bk	2
		80-25-05		Voltage regulator modification	Bk	2
		81-01-01		Propeller deice relay	Bk	2
		81-23-06		Flap track structure	Bk	2
		82-11-04		Emergency exit window modification	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		93-24-02	R1	Elevator control tube assembly	Bk	3
		96-10-13		Inspect bulkhead assembly	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		96-24-13		Landing gear selector cable	Bk	3
		97-26-12		AFM - Limitations Section - Power levers	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4
PA-31T1	A8EA	78-02-01		Main landing gear	Bk	1
		79-12-02		Elevator surface travel	Bk	1
		79-14-02		Control wheel shaft stud	Bk	1
		79-19-09		Electroluminescent panel inverters	Bk	1
		80-01-08		Oil cooler inlet hose	Bk	2
		80-02-15		Elevator butt rib cracks	Bk	2
		80-11-06		Aircraft data plate	Bk	2
		80-25-05		Voltage regulator modification	Bk	2
		81-01-01		Propeller deice relay	Bk	2
		81-23-06		Flap track structure	Bk	2
		82-11-04		Emergency exit window modification	Bk	2
		82-27-13	R2	Flap extension system	Bk	2
		85-08-05		Strut housing inspection	Bk	2
		96-10-13		Inspect bulkhead assembly	Bk	3
		96-10-14		Inspect MLG sidebraces	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		96-21-11		MLG actuator reinforcement bracket	Bk	3
		97-26-12		AFM - Limitations Section - Power levers	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-06-06		AFM – Ice protection systems	Bk	4
		2000-25-01		MLG Door Hinges	Bk	4
		2001-06-01		Correct damage to the elevator structure	Bk	4
		2003-24-07		Rudder torque tube assembly corrosion	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
PA-31T2	A8EA	82-11-04	Emergency exit window modification	Bk	2
		85-08-05	Strut housing inspection	Bk	2
		96-10-13	Inspect bulkhead assembly	Bk	3
		96-10-14	Inspect MLG sidebraces	Bk	3
		96-21-03	Inspect for cracks of aileron spar	Bk	3
		96-21-04	Inspect hydraulic hoses	Bk	3
		96-21-11	MLG actuator reinforcement bracket	Bk	3
		97-02-01	Landing gear emergency extension air line	Bk	3
		97-26-12	AFM - Limitations Section - Power levers	Bk	3
		99-14-01	AFM - Limitations Section - icing	Bk	3
		2000-06-06	AFM – Ice protection systems	Bk	4
		2000-25-01	MLG Door Hinges	Bk	4
		2001-06-01	Correct damage to the elevator structure	Bk	4
		2003-24-07	Rudder torque tube assembly corrosion	Bk	4
PA-31T3	A8EA	85-08-05	Strut housing inspection	Bk	2
		96-10-13	Inspect bulkhead assembly	Bk	3
		96-21-03	Inspect for cracks of aileron spar	Bk	3
		96-21-04	Inspect hydraulic hoses	Bk	3
		96-21-11	MLG actuator reinforcement bracket	Bk	3
		97-26-12	AFM - Limitations Section - Power levers	Bk	3
		2000-06-06	AFM – Ice protection systems	Bk	4
		2000-25-01	MLG Door Hinges	Bk	4
		2001-06-01	Correct damage to the elevator structure	Bk	4
		2003-24-07	Rudder torque tube assembly corrosion	Bk	4
PA-32 Series	A3SO	67-20-04	Main landing gear torque link	Bk	1
		67-26-02	Fuel selector valve	Bk	1
		68-01-03	Forward & rear wing-to-fuselage fittings	Bk	1
PA-32-260	A3SO	67-03-07	Fuel tank selector valve	Bk	1
		67-12-06	Inspect tubes for internal corrosion	Bk	1
		67-26-03	Fuel system screens and filters	Bk	1
		69-15-01	Control wheel pin	Bk	1
		69-22-02	Failure of control wheel	Bk	1
		70-18-05	Landing gear torque link bolts	Bk	1
		70-26-04	Stabilator balance weight tube	Bk	1
		71-09-05	Front seat belt attaching hardware	Bk	1
		72-08-06	Main landing gear torque links	Bk	1
		72-14-07	Bolts in stabilator hinge fittings	Bk	1
		72-17-05	Electric trim switch	Bk	1
		74-09-02	Stall warning light	Bk	1
		74-18-13	Nose gear vibration	Bk	1
		74-19-01	Outer wing spars	Bk	1
		75-02-03	Nose wheel fork assembly	Bk	1
		75-10-03	Baggage door	Bk	1
		75-24-02	Loose seats	Bk	1
		76-18-04	Fuel valve	Bk	1
		77-01-01	Fuel quantity gage	Bk	1
		77-12-01	Fuel system	Bk	1
		77-23-03	Rod end bearings	Bk	1
		78-23-01	Fuel drain assembly	Bk	1
		80-14-01	Fuel tank vent system	Bk	2
		80-14-03	Bendix, King or Narco transmitters	Bk	2
		86-17-01	Ammeter replacement	Bk	2
		95-26-13	Inspect oil cooler hoses	Bk	3
		96-10-03	Flap handle attach bolt	Bk	3
		99-05-09	Induction air filter	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-32-300	A3SO	67-26-03		Fuel systems screens and filters	Bk	1
		67-30-06		Engine air induction system	Bk	1
		69-15-01		Control wheel pin	Bk	1
		69-22-02		Failure of control wheel	Bk	1
		70-18-05		Landing gear torque link bolts	Bk	1
		70-26-04		Stabilator balance weight tube	Bk	1
		71-09-05		Front seat belt attaching hardware	Bk	1
		72-08-06		Main landing gear torque links	Bk	1
		72-14-07		Bolts in stabilator hinge fittings	Bk	1
		72-17-05		Electric trim switch	Bk	1
		74-09-02		Stall warning light	Bk	1
		74-18-13		Nose gear vibration	Bk	1
		74-19-01		Outer wing spars	Bk	1
		75-02-03		Nose wheel fork assembly	Bk	1
		75-10-03		Baggage door	Bk	1
		75-24-02		Loose seats	Bk	1
		76-18-04		Fuel valve	Bk	1
		77-01-01		Fuel quantity gage	Bk	1
		77-12-01		Fuel system	Bk	1
		77-23-03		Rod end bearings	Bk	1
		78-23-01		Fuel drain assembly	Bk	1
		80-14-01		Fuel tank vent system	Bk	2
		80-14-02		Throttle cable	Bk	2
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-32R-300	A3SO	76-11-09		Fuel leakage	Bk	1
		76-15-08		Nose gear trunnion	Bk	1
		76-18-04		Fuel valve	Bk	1
		77-23-03		Rod end bearings	Bk	1
		78-16-08		Loss of engine oil	Bk	1
		78-23-01		Fuel drain assembly	Bk	1
		80-14-01		Fuel tank vent system	Bk	2
		80-14-02		Throttle cable	Bk	2
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		81-24-07		NLG modification	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		93-05-10		Nose landing gear	Bk	3
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-05-09		Induction air filter	Bk	3
PA-32RT-300	A3SO	78-16-08		Loss of engine oil	Bk	1
		78-22-07		Control column travel	Bk	1
		78-23-01		Fuel drain assembly	Bk	1
		79-26-04		Rudder skin cracks	Bk	1
		80-14-01		Fuel tank vent system	Bk	2
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		81-24-07		NLG modification	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		93-05-10		Nose landing gear	Bk	3
		95-26-13		Inspect oil cooler hoses	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
PA-32RT-300T	A3SO	78-22-07	Control column travel	Bk	1
		78-23-01	Fuel drain assembly	Bk	1
		79-13-04	Fuel leakage prevention	Bk	1
		79-26-04	Rudder skin cracks	Bk	1
		80-14-01	Fuel tank vent system	Bk	2
		80-14-03	Bendix, King or Narco transmitters	Bk	2
		80-20-05	Turbocharger exhaust system	Bk	2
		81-24-07	NLG modification	Bk	2
		86-17-01	Ammeter replacement	Bk	2
		93-05-10	Nose landing gear	Bk	3
		95-26-13	Inspect oil cooler hoses	Bk	3
		96-10-03	Flap handle attach bolt	Bk	3
PA-32S-300	A3SO	67-26-03	Fuel systems screens and filters	Bk	1
		67-30-06	Engine air induction system	Bk	1
		70-26-04	Stabilator balance weight tube	Bk	1
		71-09-05	Front seat belt attaching hardware	Bk	1
		77-12-01	Fuel system	Bk	1
		78-23-01	Fuel drain assembly	Bk	1
		95-26-13	Inspect oil cooler hoses	Bk	3
		99-26-05	Induction air filter	Bk	3
PA-32-301	A3SO	80-14-03	Bendix, King or Narco transmitters	Bk	2
		86-17-01	Ammeter replacement	Bk	2
		95-26-13	Inspect oil cooler hoses	Bk	3
		96-10-03	Flap handle attach bolt	Bk	3
		99-05-09	Induction air filter	Bk	3
PA-32-301FT	A3SO	2004-14-12	Control wheel attaching hardware	Bk	4
PA-32-301XTC	A3SO	2004-14-12	Control wheel attaching hardware	Bk	4
PA-32-301T	A3SO	80-14-03	Bendix, King or Narco transmitters	Bk	2
		86-17-01	Ammeter replacement	Bk	2
		95-26-13	Inspect oil cooler hoses	Bk	3
		96-10-03	Flap handle attach bolt	Bk	3
PA-32R-301 (SP), (HP)	A3SO	80-14-03	Bendix, King or Narco transmitters	Bk	2
		81-24-07	NLG modification	Bk	2
		86-17-01	Ammeter replacement	Bk	2
		93-05-10	Nose landing gear	Bk	3
		95-26-13	Inspect oil cooler hoses	Bk	3
		96-10-03	Flap handle attach bolt	Bk	3
		99-05-09	Induction air filter	Bk	3
		2004-14-12	Control wheel attaching hardware	Bk	4
PA-32R-301T	A3SO	80-14-03	Bendix, King or Narco transmitters	Bk	2
		81-24-07	NLG modification	Bk	2
		86-17-01	Ammeter replacement	Bk	2
		93-05-10	Nose landing gear	Bk	3
		95-26-13	Inspect oil cooler hoses	Bk	3
		96-10-03	Flap handle attach bolt	Bk	3
		2004-14-12	Control wheel attaching hardware	Bk	4
PA-34 Series	A7SO	93-24-14	Nose gear trunnion	Bk	3
PA-34-200	A7SO	72-14-07	Bolts in stabilator hinge fittings	Bk	1
		72-17-01	Induction air box valve	Bk	1
		72-18-06	Stabilator tip balance weights	Bk	1
		73-11-02	Main landing gear support structure	Bk	1
		73-13-01	Rudder trim tab	Bk	1
		73-14-02	Cracks in exhaust system	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-34-200 continued		74-17-08		Fuel line clamps	Bk	1
		74-19-01		Outer wing spars	Bk	1
		75-20-03		Usable fuel data	Bk	1
		75-24-02		Loose seats	Bk	1
		77-23-03		Rod end bearings	Bk	1
		80-09-04		Vertical fin and stabilator attach	Bk	2
		83-14-05		Heat exchanger/tailpipe assys.	Bk	2
		88-04-05		Baggage compartment door	Bk	2
		92-08-04		Rudder system	Bk	3
		92-13-05		Clevis-head bolt	Bk	3
		94-13-11		MLG trunnion	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2005-13-16		Nose landing gear (NLG)	BW 05-13	
PA-34-200T	A7SO	75-20-03		Usable fuel data	Bk	1
		75-24-02		Loose seats	Bk	1
		75-25-03		Engine oil	Bk	1
		77-23-03		Rod end bearings	Bk	1
		78-21-03		Fuel lines	Bk	1
		80-09-04		Vertical fin and stabilator attach	Bk	2
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		86-17-01		Ammeter replacement	Bk	2
		88-04-05		Baggage compartment door	Bk	2
		92-08-04		Rudder system	Bk	3
		92-13-05		Clevis-head bolt	Bk	3
		94-13-11		MLG trunnion	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		97-01-01	R1	Main gear side brace stud	Bk	3
		99-05-09		Induction air filter	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-11-14		Heater fuel pump	Bk	4
		2005-13-16		Nose landing gear (NLG)	BW 05-13	
		2005-15-10		Combustion heater fuel pumps	BW 05-16	
PA-34-220T	A7SO	82-04-08		Landing gear retraction	Bk	2
		88-04-05		Baggage compartment door	Bk	2
		92-08-04		Rudder system	Bk	3
		94-13-11		MLG trunnion	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		99-05-09		Induction air filter	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2003-11-14		Heater fuel pump	Bk	4
		2004-14-12		Control wheel attaching hardware	Bk	4
		2005-13-16		Nose landing gear (NLG)	BW 05-13	
		2005-15-10		Combustion heater fuel pumps	BW 05-16	
PA-36-285	A9SO,	74-13-07		Fuel shutoff lever placard	Bk	1
	A10SO	74-14-06		Wing spar	Bk	1
		74-21-02		Stall warning system	Bk	1
		75-01-02		Elevator control forces	Bk	1
		75-20-07		Front bearing plate bolt	Bk	1
		76-05-07	R2	Rudder control system	Bk	1
		77-02-06		Wing attachment fittings	Bk	1
		77-04-02		Directional control	Bk	1
		77-21-03		Rudder spar cracks	Bk	1
		78-26-05		Aileron systems control	Bk	1
		79-01-03		Wing spar carry thru assy	Bk	1
		79-12-09		Engine mount attach brackets	Bk	1
		81-24-01		Rudder control/harness cable assys	Bk	2
		83-20-03		Structural components replacements	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-36-285 continued		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. ..... *(See Book 3 for paper copy)*	Bk	2
PA-36-300	A9SO,	76-05-07	R2	Rudder control forces	Bk	1
	A10SO	78-26-05		Aileron systems control	Bk	1
		81-24-01		Rudder control/harness cable assys	Bk	2
		83-20-03		Structural components replacements	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. ..... *(See Book 3 for paper copy)*	Bk	2
		92-15-15		Engine mount attach points	Bk	3
PA-36-375	A9SO,	76-05-07	R2	Rudder control forces	Bk	1
	A10SO	78-26-05		Aileron systems control	Bk	1
		81-24-01		Rudder control/harness cable assys	Bk	2
		83-20-03		Structural components replacements	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. ..... *(See Book 3 for paper copy)*	Bk	2
		92-15-15		Engine mount attach points	Bk	3
PA-38-112	A18SO	78-22-01		Rudder or elevator binding	Bk	1
		78-23-04		Wing rear spar	Bk	1
		78-23-09		Control wheels	Bk	1
		78-26-06		Vertical fin attach. plate	Bk	1
		79-03-02		Rudder hinge bearing	Bk	1
		79-08-02		Stabilizer bracket fitting	Bk	1
		79-17-05		Fuel gauges and engine instruments	Bk	1
		80-22-13		Rudder upper hinge	Bk	2
		81-23-07		Engine mount assembly	Bk	2
		82-02-01		Aileron balance weights	Bk	2
		82-27-08		Forward fin spar web	Bk	2
		83-14-08		Stall characteristics	Bk	2
		83-19-01		Forward and aft fin spars repair/mod.	Bk	2
		85-11-06		Control loss	Bk	2
		90-19-03		Main landing gear system	Bk	3
		98-03-16		Upper rudder hinge bracket	Bk	3
PA-42	A23SO	90-02-11		POH/AFM changes - fuel	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		96-21-04		Inspect hydraulic hoses	Bk	3
		97-26-12		AFM - Limitations Section - Power levers	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-14-08		Pneumatic wing and tail deicing boots.....	Bk	4
PA-42-720	A23SO	90-02-11		POH/AFM changes - fuel	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		97-26-12		AFM - Limitations Section - Power levers	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-14-08		Pneumatic wing and tail deicing boots.....	Bk	4
PA-42-720R	A32SO	90-02-11		POH/AFM changes - fuel	Bk	3
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		2000-14-08		Pneumatic wing and tail deicing boots.....	Bk	4
PA-42-1000	A23SO	86-18-10		Tip tank vent lines	Bk	2
		86-21-10		POH/AFM changes	Bk	2
		96-21-03		Inspect for cracks of aileron spar	Bk	3
		97-26-12		AFM - Limitations Section - Power levers	Bk	3
		99-14-01		AFM - Limitations Section - icing	Bk	3
		2000-14-08		Pneumatic wing and tail deicing boots.....	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
PA-44-180	A19SO	79-02-02		Fuel supply lines	Bk	1
		79-05-11		Engine power control loss	Bk	1
		79-12-11		Fuel primer mod kits	Bk	1
		80-12-03		Nose landing gear	Bk	2
		80-14-03		Bendix, King or Narco transmitters	Bk	2
		80-21-11		Left and right ailerons	Bk	2
		81-10-01		Nose cone spars	Bk	2
		81-10-04		Aileron modification	Bk	2
		81-16-10		Outboard leading edge skin	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		94-13-11		MLG trunnion	Bk	3
		94-14-14		NLG modification	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		2003-11-14		Heater fuel pump	Bk	4
		2004-14-12		Control wheel attaching hardware	Bk	4
		2005-15-10		Combustion heater fuel pumps	BW 05-16	
PA-44-180T	A19SO	81-16-10		Outboard leading edge skin	Bk	2
		85-02-05	R1	Piper P/N's 81090-02, 683-107 placard instln. *(See Book 3 for paper copy)*	Bk	2
		86-20-11		Ammeter replacement	Bk	2
		94-13-11		MLG trunnion	Bk	3
		94-14-14		NLG modification	Bk	3
		96-10-03		Flap handle attach bolt	Bk	3
		2003-11-14		Heater fuel pump	Bk	4
		2005-15-10		Combustion heater fuel pumps	BW 05-16	
PA-46-310P	A25SO	87-04-01		Air valve linkage	Bk	2
		88-25-08		Engine cooling system	Bk	2
		92-13-06		Elevator guide tube	Bk	3
		92-13-07		Empennage countersunk rivets	Bk	3
		92-15-14		Air-driven attitude gyro	Bk	3
		98-04-26		AFM - Limitations Section - icing	Bk	3
		99-15-04	R1	Turbine inlet temperature sys. calibration *(see Bk 4 for Paper copy)*	Bk	3
		2001-12-01		Flap drive bellcrank assemblies	Bk	4
PA-46-350P	A25SO	92-13-06		Elevator guide tube	Bk	3
		92-13-07		Empennage countersunk rivets	Bk	3
		92-15-14		Air-driven attitude gyro	Bk	3
		95-23-12		Placard - Manifold pressure limits	Bk	3
		98-04-26		AFM - Limitations Section - icing	Bk	3
		99-15-04	R1	Turbine inlet temperature sys. calibration *(see Bk 4 for Paper copy)*	Bk	3
		99-16-06		Wing attach fittings	Bk	3
		2001-12-01		Flap drive bellcrank assemblies	Bk	4
		2004-14-12		Control wheel attaching hardware	Bk	4
PA-46-500TP	A25SO	2001-12-01		Flap drive bellcrank assemblies	Bk	4
		2004-03-32		Electronic control modules	Bk	4
		2004-14-12		Control wheel attaching hardware	Bk	4
		2004-15-19		Emergency oxygen system	Bk	4

PITTS AVIATION ENTERPRISES, INC.
(See CHRISTEN INDUSTRIES)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
POLSKIE ZAKLADY LOTNICZE SPOLKA ZO.O						
(Formerly Wytwornia Sprzetu Komunikacyjnego)						
(For AD's in Book 2 see Wytwornia Sprzetu)						
(See Panstwowe Zaklady for TC A55EU)						
PZL M18	A47EU	83-06-07		Yaw axis flight control	Bk	2
		83-06-09		Inflight engine shut-down prevention	Bk	2
		83-07-02		Counterweights reinforcement	Bk	2
		83-07-11		Left and right braking levers	Bk	2
		83-07-19		Primary flight control	Bk	2
		86-13-01		Check for cracks	Bk	2
		87-03-09		Engine mount nuts	Bk	2
		90-17-15		Vertical fin and rib	Bk	3
		90-20-03		Aileron control system	Bk	3
		90-20-04		Engine push-pull cables	Bk	3
		91-12-07		Electro-hydraulic control system	Bk	3
		2000-18-12		Centerwing-to-outboard wing attach joints	Bk	4
PZL M18A	A47EU	90-20-03		Aileron control system	Bk	3
		90-20-04		Engine push-pull cables	Bk	3
		2000-18-12		Centerwing-to-outboard wing attach joints	Bk	4
PZL M18B	A47EU	2000-18-12		Centerwing-to-outboard wing attach joints	Bk	4
PZL M2601	A44CE	2006-03-17		Fuselage frame No. XI	BW 06-04	
PROP JETS, INC.						
Interceptor 200 Series	3A18	66-28-01		Elevator trim system	Bk	1
		67-23-01		Main landing gear	Bk	1
QUALITY AEROSPACE, INC.						
(formerly Ayres Corporation)						
(See Ayres Corp. for ADs in Book 1, 2, 3)						
(See Thrush Aircraft, Inc.)						
RAVEN INDUSTRIES, INC.						
(See AEROSTAR)						
RAYTHEON AIRCRAFT CORPORATION						
(Formerly BEECH AIRCRAFT)						
(For AD's in Book 1and 2 See Beech)						
Army AT-11,	A-2-582	47-06-08		Starter solenoid and buss lead wires	Bk	1
Navy SNB-1		47-06-09		Landing gear retracting mechanism	Bk	1
		47-30-06		Generator relay control switch	Bk	1
		47-30-07		Tripfree circuit breaker	Bk	1
		47-33-03		Tail cone drain holes	Bk	1
		47-33-05		Horizontal stabilizer spar	Bk	1
		48-14-03		Wing center section spar	Bk	1
		48-34-01		Stabilizer attachment fittings	Bk	1
		48-51-01		Control wheel shaft inspection	Bk	1
		49-15-03		Fuel tank vent system	Bk	1
		65-03-01		Gap seal strips	Bk	1
		75-27-09	R2	Wing structure	Bk	1
D17S	A-649	48-51-01		Control wheel shaft inspection	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
C18S	A-757	47-06-08		Starter solenoid and buss lead wire	Bk	1
		47-06-09		Landing gear retracting mechanism	Bk	1
		47-33-03		Tail cone drain holes	Bk	1
		47-33-04		Fuel tank gaskets	Bk	1
		47-33-05		Horizontal stabilizer spar	Bk	1
		48-14-03		Wing center section spar	Bk	1
		48-34-01		Stabilizer attachment fittings	Bk	1
		48-51-01		Control wheel shaft inspection	Bk	1
		49-15-03		Fuel tank vent system	Bk	1
		65-03-01		Gap seal strips	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
D18C	A-765	47-33-06		Stabilizer spar replacement	Bk	1
		47-33-07		Alternate static source	Bk	1
		47-34-01		Expansion type filler cap	Bk	1
		47-34-02		Tail cone drain holes	Bk	1
		47-34-03		Fuel cell seal	Bk	1
		48-13-01		Generator control box insulation	Bk	1
		48-34-01		Stabilizer attachment fittings	Bk	1
		49-29-02		Rudder spring bushings	Bk	1
		66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
D18S	A-765	47-33-05		Horizontal stabilizer spar	Bk	1
		47-33-06		Stabilizer spar replacement	Bk	1
		47-33-07		Alternate static source	Bk	1
		47-34-01		Expansion type filler cap	Bk	1
		47-34-02		Tail cone drain holes	Bk	1
		47-34-03		Fuel cell seal	Bk	1
		48-13-01		Generator control box insulation	Bk	1
		48-34-01		Stabilizer attachment fittings	Bk	1
		49-29-02		Rudder spring bushings	Bk	1
		59-18-02		Fuel line modification	Bk	1
		65-03-01		Gap seal strips	Bk	1
		66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
E18S	A-765	56-20-01		Tail wheel axle	Bk	1
		65-03-01		Gap seal strips	Bk	1
		66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
E18S-9700	A-765	66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
G18S	A-765	68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
H18	A-765	68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
18A, S18A	TC 630	75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
18D, S18D, A18A, SA18A, A18D, SA18D	A-684	75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
18S (C-45C) B18S (F-2)	TC 710	75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
C-45 Series	A-757 & A-765	65-03-01		Gap seal strips	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
C-45G	A-765	59-18-02		Fuel line modification	Bk	1
		60-16-01		Emergency elec. switch/seats	Bk	1
		66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
TC-45G	A-765	59-18-02		Fuel line modification	Bk	1
		60-16-01		Emergency elec. switch/seats	Bk	1
		66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
C-45H	A-765	59-18-02		Fuel line modification	Bk	1
		60-16-01		Emergency elec. switch/seats	Bk	1
		66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
TC-45H	A-765	59-18-02		Fuel line modification	Bk	1
		60-16-01		Emergency elec. switch/seats	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
TC-45J (SNB-5)	A-765	66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
JRB-6	A-765	66-30-01		Static pressure line	Bk	1
		68-23-06		Volpar tri-gear	Bk	1
		72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
3N, 3NM, 3TM	A-765	72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		78-10-01		Lower rudder torque tube	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
RC-45J (SNB-5P)	A-765	72-16-02	R3	Volpar nose gear fork	Bk	1
		72-25-06		Nose gear extension	Bk	1
		75-27-09	R2	Wing structure	Bk	1
		77-19-07		Control column assembly	Bk	1
		81-18-07		Volpar tri-gear	Bk	2
23 All Models	A1CE	64-06-01		Cabin heater/muffler weld assy	Bk	1
23	A1CE	63-06-01		Cabin door hinge	Bk	1
		65-11-01		Instrument static system	Bk	1
		65-19-02		Aileron control column links	Bk	1
		68-17-06		Parking brake	Bk	1
		70-15-03		Fuel selector valve	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
23 continued		74-23-09		Inflight situations	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
A23	A1CE	65-19-02		Aileron control column links	Bk	1
		68-17-06		Parking brake	Bk	1
		70-15-03		Fuel selector valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
A23A	A1CE	68-17-06		Parking brake	Bk	1
		70-15-03		Fuel selector valve	Bk	1
		71-25-03		Fuel and oil restrictor	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
A23-19	A1CE	68-17-06		Parking brake	Bk	1
		70-15-03		Fuel selector valve	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1
		74-23-09		Inflight situations	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
19A	A1CE	70-15-03		Fuel selector valve	Bk	1
		71-25-03		Fuel and oil restrictor	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1
		74-23-09		Inflight situations	Bk	1
		75-01-04		Fuel selector valve	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
19A continued		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
B19	A1CE	71-25-03		Fuel and oil restrictor	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1
		73-25-04		Maximum design weight placard	Bk	1
		74-05-01		Restricted fuel vent tank lines	Bk	1
		74-14-02		Carburetor and air controls	Bk	1
		74-14-05		Placard, spins	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-10-09		Wing flaps	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		78-16-06		Structural integrity of trim tab rod	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
M19A	A1CE	71-25-03		Fuel and oil restrictor	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1
		74-23-09		Inflight situations	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
A23-24	A1CE	68-17-06		Parking brake	Bk	1
		70-15-03		Fuel selector valve	Bk	1
		71-25-03		Fuel and oil restrictor	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		88-10-01		Fuel boost pump	Bk	2
		89-24-09		Aileron rod ends	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B23	A1CE	70-15-03		Fuel selector valve	Bk	1
		71-25-03		Fuel and oil restrictor	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1
		74-23-09		Inflight situations	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
C23	A1CE	71-25-03		Fuel and oil restrictor	Bk	1
		73-12-11		Carburetor air box valve	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		73-23-06		Throttle control cable	Bk	1
		74-05-01		Restricted fuel tank vent lines	Bk	1
		74-14-02		Carburetor and air controls	Bk	1
		74-14-05		Placard, spins	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-10-09		Wing flaps	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		78-16-06		Structural integrity of trim tab rod	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		89-24-09		Aileron rod ends	Bk	2
A24	A1CE	71-25-03		Fuel and oil restrictor	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		73-23-03		Flexible induction air ducts	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		77-03-05		Main landing gear	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		88-10-01		Fuel boost pump	Bk	2
		89-24-09		Aileron rod ends	Bk	2
A24R	A1CE	71-25-03		Fuel and oil restrictor	Bk	1
		73-20-07	R2	Wing attach bolts/brackets	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		76-25-05		Aileron control	Bk	1
		78-04-01		Wing flap control	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		88-10-01		Fuel boost pump	Bk	2
		89-24-09		Aileron rod ends	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B24R	A1CE	73-20-07	R2	Wing attach bolts/brackets	Bk	1
		74-05-01		Restricted fuel tank vent lines	Bk	1
		75-01-04		Fuel selector valve	Bk	1
		75-17-37		Carburetor mixture and/or heat control	Bk	1
		75-20-08		Propeller governor	Bk	1
		76-10-09		Wing flaps	Bk	1
		78-04-01		Wing flap control	Bk	1
		78-16-06		Structural integrity of trim tab rod	Bk	1
		85-05-02		Fuel selector guard mod.	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		88-10-01		Fuel boost pump	Bk	2
		89-24-09		Aileron rod ends	Bk	2
C24R	A1CE	78-04-01		Wing flap control	Bk	1
		78-16-06		Structural integrity of trim tab rod	Bk	1
		85-05-02		Fuel selector guard mod	Bk	2
		87-02-08		Stabilator hinge assemblies	Bk	2
		88-10-01		Fuel boost pump	Bk	2
T-34C (T-34C-1, 34C)	A26CE	80-07-05		Bolt and nut, wing section	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		94-04-18		Elevator arm assembly	Bk	3
		95-04-10		Wing attach bolts	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
35 All Models (Series)	A-777, 3A15	49-26-01		Trailing antenna rework	Bk	1
		49-48-01		Thompson fuel pump	Bk	1
		51-14-01		Fuel booster pump removal	Bk	1
		55-22-01		Oil outlet check valve	Bk	1
		62-08-03		Control wheels	Bk	1
		69-18-01		Fuel system modification	Bk	1
		84-09-01		Window emer. egress prov.	Bk	2
35	A-777	47-47-07		Engine identification plate	Bk	1
		47-47-08		Fuel line chafing	Bk	1
		48-08-01		Starter rework	Bk	1
		49-04-01		Aileron chain	Bk	1
		49-31-01		Emergency fuel pump "O" rings	Bk	1
		53-01-02		Fuel selector valve rework	Bk	1
		62-08-03		Control wheels	Bk	1
		63-25-01		Fuselage modification	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-18-01		Fuel selector valve warning light	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-05-04		Stabilizer attach fitting	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-21-13		Placard - Speed	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A35	A-777	49-26-01		Trailing antenna rework	Bk	1
		49-31-01		Emergency fuel pump "O" rings	Bk	1
		49-48-01		Thompson fuel pump	Bk	1
		50-42-01		Elevator tab replacement	Bk	1
		51-14-01		Fuel booster pump removal	Bk	1
		53-01-02		Fuel selector valve rework	Bk	1
		59-08-01		Landing gear limit switches	Bk	1
		62-08-03		Control wheels	Bk	1
		63-25-01		Fuselage modification	Bk	1
		69-18-01		Fuel system modification	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-18-01		Fuel selector valve warning light	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-05-04		Stabilizer attach fitting	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-21-13		Placard - Speed	Bk	4
B35	A-777	53-01-02		Fuel selector valve rework	Bk	1
		59-08-01		Landing gear limit switches	Bk	1
		62-08-03		Control wheels	Bk	1
		63-25-01		Fuselage modification	Bk	1
		69-18-01		Fuel system modification	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-18-01		Fuel selector valve warning light	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-05-04		Stabilizer attach fitting	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-21-13		Placard - Speed	Bk	4
C35	A-777	53-01-02		Fuel selector valve rework	Bk	1
		59-08-01		Landing gear limit switches	Bk	1
		62-08-03		Control wheels	Bk	1
		69-18-01		Fuel system modification	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-18-01		Fuel selector valve warning light	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
D35	A-777	62-08-03		Control wheels	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
E35	A-777	62-08-03		Control wheels	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
F35	A-777	62-08-03		Control wheels	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
G35	A-777	62-08-03		Control wheels	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
35R	A-777	63-25-01		Fuselage modification	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-05-04		Stabilizer attach fitting	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-21-13		Placard - Speed	Bk	4
H35	3A15	62-08-03		Control wheels	Bk	1
		65-14-01		Alternator support bracket	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
J35	3A15	62-08-03		Control wheels	Bk	1
		65-14-01		Alternator support bracket	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
K35	3A15	62-08-03		Control wheels	Bk	1
		65-14-01		Alternator support bracket	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
M35	3A15	62-08-03		Control wheels	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
N35	3A15	62-08-03		Control wheels	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
P35	3A15	62-08-03		Control wheels	Bk	1
		64-27-01		Control wheel column aft stop	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		76-03-05		Housing cable and battery relay	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
P35 continued		89-05-02		Elevator control fittings	Bk	2
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
S35	3A15	64-27-01		Control wheel column aft stop	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-01-07		Exhaust system failures	Bk	1
		75-05-02		Engine oil	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		92-17-01		Fuel metering unit	Bk	3
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
S35TC	--	70-03-05		Turning type takeoffs	Bk	1
V35	3A15	70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-01-07		Exhaust system failures	Bk	1
		75-05-02		Engine oil	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		92-17-01		Fuel metering unit	Bk	3
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
V35A	3A15	70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-01-07		Exhaust system failures	Bk	1
		75-05-02		Engine oil	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		92-17-01		Fuel metering unit	Bk	3
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
V35-TC	- -	70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
V35A-TC		70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
V35B	3A15	71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		74-03-02		Landing gear shock strut piston	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-01-07		Exhaust system failures	Bk	1
		75-05-02		Engine oil	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-18-19		Pilot shoulder harnesses	Bk	3
		91-20-08		Fresh air blower housing	Bk	3
		92-17-01		Fuel metering unit	Bk	3
		94-20-04	R2	V-Tail structure *(see Bk 4 for paper copy)*	Bk	3
		95-04-03		Wing spar	Bk	3
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
V35B-TC	--	71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		97-06-11		Ruddervator differential tail control rod assy	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
35-33	3A15	62-08-03		Control wheels	Bk	1
		65-14-01		Alternator support bracket	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
35-A33	3A15	62-08-03		Control wheels	Bk	1
		70-03-05		Turning type takeoffs	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		75-15-08		Engine lubrication	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
35-B33	3A15	62-08-03	Control wheels	Bk	1
		70-03-05	Turning type takeoffs	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		75-05-02	Engine oil	Bk	1
		75-15-08	Engine lubrication	Bk	1
		76-03-05	Housing cable and battery relay	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		91-17-01	Elev. trim tab actuators	Bk	3
		93-24-03	Rudder forward spar	Bk	3
		95-04-03	Wing spar	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
35-C33	3A15	70-03-05	Turning type takeoffs	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		75-05-02	Engine oil	Bk	1
		75-15-08	Engine lubrication	Bk	1
		76-03-05	Housing cable and battery relay	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		91-17-01	Elev. trim tab actuators	Bk	3
		93-24-03	Rudder forward spar	Bk	3
		95-04-03	Wing spar	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
35-C33A	3A15	70-03-05	Turning type takeoffs	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		75-05-02	Engine oil	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		91-17-01	Elev. trim tab actuators	Bk	3
		93-24-03	Rudder forward spar	Bk	3
		95-04-03	Wing spar	Bk	3
		2001-08-08	Failure of the V-band exhaust clamp	Bk	4
		2001-23-10	Flap flex shaft assembly	Bk	4
33 All Models (Series)	3A15	84-09-01	Window emer. egress prov.	Bk	2
E33	3A15	70-03-05	Turning type takeoffs	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		75-05-02	Engine oil	Bk	1
		76-03-05	Housing cable and battery relay	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		91-17-01	Elev. trim tab actuators	Bk	3
		93-24-03	Rudder forward spar	Bk	3
		95-04-03	Wing spar	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
E33A	3A15	70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	2
		93-24-03		Rudder forward spar	Bk	2
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
E33C	3A15	70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		83-17-05		Changes to AFM re maneuvers	Bk	2
		89-05-02		Elevator control fittings	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
F33	3A15	71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		76-03-05		Housing cable and battery relay	Bk	1
		91-17-01		Elev. trim tab actuators	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
F33A	3A15	71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		74-03-02		Landing gear shock strut piston	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-05-02		Engine oil	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-20-01		Firewall material	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		91-20-08		Fresh air blower housing	Bk	3
		93-03-02		Loran receiver system	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-11-03		Protect the blower motor circuit	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
F33C	3A15	70-03-05		Turning type takeoffs	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		75-05-02		Engine oil	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		79-01-01		Screws in control system	Bk	1
		83-17-05		Changes to AFM re maneuvers	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-20-08		Fresh air blower housing	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
G33	3A15	72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-05-02		Engine oil	Bk	1
		76-03-05		Housing cable and battery relay	Bk	1
		79-01-01		Screws in control system	Bk	1
		91-17-01		Elev. trim tab actuators	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
36 Series	3A15	84-09-01		Window emer. egress provisions	Bk	1
36	3A15	70-03-05		Turning type takeoffs	Bk	1
		70-12-02		Center seat tracks	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		74-12-02		Aft facing seats	Bk	1
		75-05-02		Engine oil	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2003-01-01		Right hand fuselage panel assembly rivets	Bk	4
A36	3A15	70-12-02		Center seat tracks	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		74-03-02		Landing gear shock strut piston	Bk	1
		74-12-02		Aft facing seats	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-05-02		Engine oil	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-20-01		Firewall material	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A36 continued		91-18-19		Pilot shoulder harnesses	Bk	3
		91-20-08		Fresh air blower housing	Bk	3
		92-18-11		Landing gear circuit	Bk	3
		93-03-02		Loran receiver system	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		2000-20-14		Firewall seal	Bk	4
		2000-24-04		Inspect rudder control cables	Bk	4
		2001-08-08		Failure of the V-band exhaust clamp	Bk	4
		2001-11-03		Protect the blower motor circuit	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2003-01-01		Right hand fuselage panel assembly rivets	Bk	4
A36TC	3A15	84-08-04		Oil return line check valve	Bk	2
		87-08-05		Modify fuel system	Bk	2
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-20-08		Fresh air blower housing	Bk	3
		92-17-01		Fuel metering unit	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2003-01-01		Right hand fuselage panel assembly rivets	Bk	4
B36TC	3A15	84-08-04		Oil return line check valve	Bk	2
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-20-01		Firewall material	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		91-20-08		Fresh air blower housing	Bk	3
		92-18-11		Landing gear circuit	Bk	3
		93-03-02		Loran receiver system	Bk	3
		93-24-03		Rudder forward spar	Bk	3
		95-04-03		Wing spar	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		2000-20-14		Firewall seal	Bk	4
		2000-24-04		Inspect rudder control cables	Bk	4
		2001-11-03		Protect the blower motor circuit	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2003-01-01		Right hand fuselage panel assembly rivets	Bk	4
45 Series	5A3	89-05-02		Magnesium elevator cont. fittings	Bk	2
45 (YT-34)	5A3	62-24-01		Stabilizer spar	Bk	1
		91-17-01		Elev. trim tab actuators	Bk	3
		2001-13-18	R1	Correct cracks in the wing spar assemblies	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2004-25-51		Structural integrity	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A45 (T34A, B45)	5A3	61-26-01		Oil pickup hoses	Bk	1
		62-24-01		Stabilizer spar	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-24-11		Cable and bellcrank assys	Bk	1
		91-17-01		Elev. trim tab actuators	Bk	3
		2001-13-18	R1	Correct cracks in the wing spar assemblies	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2004-25-51		Structural integrity	Bk	4
D45 (T-34B)	5A3	62-24-01		Stabilizer spar	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-24-11		Cable and bellcrank assys	Bk	1
		91-17-01		Elev. trim tab actuators	Bk	3
		2001-13-18	R1	Correct cracks in the wing spar assemblies	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2004-25-51		Structural integrity	Bk	4
50 Series	5A4	84-09-01		Window emer. egress prov.	Bk	2
50	5A4	62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
		97-14-15		Cabin side door and utility door handle	Bk	3
B50	5A4	58-13-02		Tail light assembly	Bk	1
		62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
		97-14-15		Cabin side door and utility door handle	Bk	3
C50	5A4	58-13-02		Tail light assembly	Bk	1
		62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
		97-14-15		Cabin side door and utility door handle	Bk	3
D50	5A4	58-13-02		Tail light assembly	Bk	1
		62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
D50A	5A4	62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
D50B	5A4	62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
D50C	5A4	62-08-03		Control wheels	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
D50E	5A4	62-08-03		Control wheels	Bk	1
		64-24-02		Wing attach bolts	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
E50	5A4	58-13-02		Tail light assembly	Bk	1
		62-08-03		Control wheels	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
F50	5A4	58-13-02		Tail light assembly	Bk	1
		62-08-03		Control wheels	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
G50	5A4	62-08-03		Control wheels	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
H50	5A4	62-08-03		Control wheels	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
J50	5A4	62-08-03		Control wheels	Bk	1
		64-24-02		Wing attach bolts	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-13-01		Powerplant fire detection/containment	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
60 Series	A12CE	72-22-04		Elevator movement interference	Bk	1
60	A12CE	74-05-05		Pilot's side window	Bk	1
		74-12-02		Aft facing seats	Bk	1
		75-06-09		Elevator inboard hinge support	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-14-08		Water in fuselage	Bk	1
		80-04-07		Outboard wing panel nuts	Bk	2
		83-08-05		Air conditioner modification	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		95-22-03		AFM - icing conditions	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		99-03-11		Cabin heat control wiring	Bk	3
		2001-02-10		Wing bolts	Bk	4
		2002-10-13		Exterior exit door	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A60	A12CE	71-05-03		Known icing conditions	Bk	1
		74-05-05		Pilot's side window	Bk	1
		74-12-02		Aft facing seats	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-06-09		Elevator inboard hinge support	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-14-08		Water in fuselage	Bk	1
		80-04-07		Outboard wing panel nuts	Bk	2
		83-08-05		Air conditioner modification	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		95-22-03		AFM - icing conditions	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		2001-02-10		Wing bolts	Bk	4
		2002-10-13		Exterior exit door	Bk	4
B60 (U-8F)	A12CE	74-24-03		Strobe light system	Bk	1
		76-13-05		Electrical power	Bk	1
		77-14-08		Water in fuselage	Bk	1
		80-04-07		Outboard wing panel nuts	Bk	2
		83-08-05		Air conditioner modification	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		97-25-01		Outflow/safety valve	Bk	3
		2001-02-10		Wing bolts	Bk	4
		2002-10-13		Exterior exit door	Bk	4
65 (L-23F)	3A20	62-08-03		Control wheels	Bk	1
		64-24-02		Wing attach bolts	Bk	1
		76-09-01		Emergency exit door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-16-01		Wing structure	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-08		Inspect wing main spar	Bk	2
		95-20-01	R1	Placard - cabin door	Bk	3
65-80	3A20	69-06-06		Rudder spar cracks	Bk	1
		76-09-01		Emergency exit door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-16-01		Wing structure	Bk	1
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-08		Inspect wing main spar	Bk	2
65-A80	3A20	69-06-06		Rudder spar cracks	Bk	1
		76-09-01		Emergency exit door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-16-01		Wing structure	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
65-A80 continued		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-08		Inspect wing main spar	Bk	2
		2004-23-02		Nose landing gear fork	Bk	4
65-A80-8800	3A20	69-06-06		Rudder spar cracks	Bk	1
		76-09-01		Emergency exit door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		79-16-01		Wing structure	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		2004-23-02		Nose landing gear fork	Bk	4
65-B80	3A20	69-06-06		Rudder spar cracks	Bk	1
		74-16-04		Restricted elevator travel	Bk	1
		74-24-03		Strobe light system	Bk	1
		76-09-01		Emergency exit door	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-08		Inspect wing main spar	Bk	2
		98-04-24		AFM - Limitations Section - icing	Bk	3
		2000-18-02		Elevator skin	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
65-88	3A20	69-06-06		Rudder spar cracks	Bk	1
		76-10-10		Cabin door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		2002-10-13		Exterior exit door	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
65-90	3A20	68-21-04		Ice damage to engine	Bk	1
		69-06-06		Rudder spar cracks	Bk	1
		70-22-01		Heater pressure switch	Bk	1
		70-25-04		Cracking of wing center section	Bk	1
		72-20-03		Heater overheat	Bk	1
		75-08-16		Fuel contamination	Bk	1
		76-10-10		Cabin door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-16-01		Wing structure	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
65-90 continued		81-23-01	R1	Beech kit or STC	Bk	2
		82-23-02		Elevator control	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2000-02-15		Engine and propeller installation	Bk	4
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
65-A90	3A20	68-21-04		Ice damage to engine	Bk	1
		69-06-06		Rudder spar cracks	Bk	1
		72-20-03		Heater overheat	Bk	1
		75-08-16		Fuel contamination	Bk	1
		76-10-10		Cabin door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-06		Elevator control cable	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		82-23-02		Elevator control	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2000-02-15		Engine and propeller installation	Bk	4
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
65–A90		2005-01-04		Fuel hose	BW 05-04	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A65	3A20	76-09-01		Emergency exit door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		2000-18-02		Elevator skin	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
65-A90-1, -2, -3, -4, (U-21A), (U-21G), (RU-21B), (RU-21C), (RU-21E)	3A20	68-21-04		Ice damage to engine	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
A65-8200	3A20	76-09-01		Emergency exit door	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		2000-18-02		Elevator skin	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
70	3A20	74-24-03		Strobe light system	Bk	1
		76-09-01		Emergency exit door	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-01		Powerplant fires	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		79-01-02	R2	In-flight fires	Bk	1
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut & bolt replacement	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		2000-18-02		Elevator skin	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
76	A29CE	78-20-08		Trim tabs push rods	Bk	1
		79-09-04		Engine starter relay failures	Bk	1
		79-17-06		Main landing gear	Bk	1
		79-23-06		Replacing stop bolt nuts	Bk	1
		80-07-06		Rudder and rudder trim tab	Bk	2
		80-19-12	R1	Engine mount structure	Bk	2
		82-02-03		Elevator control cable	Bk	2
		97-06-10		MLG “A” frame assembly	Bk	3
77	A30CE	79-23-05		Attachment bolt threads and nut plates	Bk	1
		80-07-06		Rudder and rudder trim tab	Bk	2
		80-07-07		Aileron control system	Bk	2
		80-21-10		Engine mount attachment	Bk	2
		82-09-03		Shoulder harness protection	Bk	2
		83-23-03		Balance weight attach bracket instln	Bk	2
		91-23-01		Nose landing gear fork	Bk	3
90 Series	3A20, 3A16, A14CE, A31CE	89-22-14		Aileron	Bk	2
		98-04-24		AFM - Limitations Section - icing	Bk	3
B90	3A20	68-21-04		Ice damage to engine	Bk	1
		69-06-06		Rudder spar cracks	Bk	1
		72-20-03		Heater overheat	Bk	1
		75-08-16		Fuel contamination	Bk	1
		76-10-10		Cabin door	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-06		Elevator control cable	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-09-03	R1	Placard -oxygen	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		82-23-02		Elevator control	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-17-01		Fuel cell nipples	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2000-02-15		Engine and propeller installation	Bk	4
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
C90	3A20	74-16-04		Restricted elevator travel	Bk	1
		74-24-03		Strobe light system	Bk	1
		76-04-02		Seat lacking pins	Bk	1
		76-10-10		Cabin door	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-07-06		Rudder control cable	Bk	1
		77-18-04		Cabin pressurization	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-06		Elevator control cable	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-09-03	R1	Placard -oxygen	Bk	2
		81-09-01		Landing gear retract system	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-17-01		Fuel cell nipples	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2000-02-15		Engine and propeller installation	Bk	4
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
C90 (SE)	--	97-25-03		AFM - Limitations - Power levers	Bk	3
		2003-02-03		Airstair door and emergency exits	Bk	4
C90A	3A20	87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-17-01		Fuel cell nipples	Bk	3
		96-11-12		Elevator electric trim tab or autopilot sys.	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		99-10-07		Elevator control cable	Bk	3
		99-18-15		Landing gear emergency hand pumps	Bk	3
		2001-11-03		Protect the blower motor circuit	Bk	4
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2002-09-12		Nacelle and spar assembly rivets	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
C90A continued		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2006-23-02				
E90	3A20	74-16-04		Restricted elevator travel	Bk	1
		74-24-03		Strobe light system	Bk	1
		76-04-02		Seat locking pins	Bk	1
		76-10-10		Cabin door	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-07-06		Rudder control cable	Bk	1
		77-18-04		Cabin pressurization	Bk	1
		77-22-01		Fuselage structure	Bk	1
		78-11-06		Elevator control cable	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-09-03	R1	Placard -oxygen	Bk	2
		81-09-01		Landing gear retract system	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
H90 (T-44A)	3A20	80-07-05		Bolt and nut, wing section	Bk	2
		80-09-03	R1	Placard -oxygen	Bk	2
		81-09-01		Landing gear retract system	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2002-01-10		MLG upper and lower torque knee	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
H90 (T-44A) continued		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
F90	A31CE	80-07-05		Bolt and nut, wing section	Bk	2
		83-07-14		One-ply window replacement	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	2
		91-12-11		Side windows	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		98-15-13		Fuel hose	Bk	3
		99-10-07		Elevator control cable	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
95 Series	3A16	84-09-01		Window emer. egress prov.	Bk	2
95	3A16	62-08-03		Control wheels	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-13-02		Propeller blade vibration	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
B95	3A16	62-08-03		Control wheels	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-13-02		Propeller blade vibration	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
B95A	3A16	62-08-03		Control wheels	Bk	1
		68-26-06		Placard installation	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-13-02		Propeller blade vibration	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
B95A continued		97-14-15	Cabin side door and utility door handle	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
D95A	3A16	68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		75-13-02	Propeller blade vibration	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
E95	3A16	68-14-01	Pneumatic de-icer system	Bk	1
		68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		75-13-02	Propeller blade vibration	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
95-55	3A16	62-08-03	Control wheels	Bk	1
		67-29-01	Rudder spar web	Bk	1
		68-26-06	Placard installation	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-26-08	Roll and pitch servo clamps	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
95-A55	3A16	62-08-03	Control wheels	Bk	1
		67-29-01	Rudder spar web	Bk	1
		68-26-06	Placard installation	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-26-08	Roll and pitch servo clamps	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2000-18-02	Elevator skin	Bk	4
		2001-23-10	Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
95-B55	3A16	67-29-01	Rudder spar web	Bk	1
		68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-14-03	Landing gear shock strut pistons	Bk	1
		73-26-08	Roll and pitch servo clamps	Bk	1
		74-03-02	Landing gear shock strut piston	Bk	1
		74-24-03	Strobe light system	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		76-22-02	"Y" type shoulder harness	Bk	1
		77-02-04	Wing tip strobe lights	Bk	1
		79-01-01	Screws in control system	Bk	1
		88-21-02	Seat tracks	Bk	2
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		91-18-19	Pilot shoulder harnesses	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2000-18-02	Elevator skin	Bk	4
		2001-23-10	Flap flex shaft assembly	Bk	4
95-B55A	3A16	68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-14-03	Landing gear shock strut pistons	Bk	1
		74-03-02	Landing gear shock strut pistons	Bk	1
		74-24-03	Strobe light system	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		76-22-02	"Y" type shoulder harness	Bk	1
		77-02-04	Wing tip strobe lights	Bk	1
		79-01-01	Screws in control system	Bk	1
		88-21-02	Seat tracks	Bk	2
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		91-18-19	Pilot shoulder harnesses	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
95-B55B	3A16	68-26-06	Placard installation	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		89-05-02	Magnesium elevator cont. Fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		2000-18-02	Elevator skin	Bk	4
		2001-23-10	Flap flex shaft assembly	Bk	4
95-C55	3A16	67-29-01	Rudder spar web	Bk	1
		68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-21-02	Failure of flex hose assemblies	Bk	1
		73-26-08	Roll and pitch servo clamps	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
95-C55 continued		90-08-14	Wing spar structure	Bk	3
		91-15-20	Engine mount	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2000-18-02	Elevator skin	Bk	4
		2001-23-10	Flap flex shaft assembly	Bk	4
95-C55A	3A16	68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-21-02	Failure of flex hose assemblies	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-15-20	Engine mount	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4
55 Series (All Models)	3A16	84-09-01	Window emer. egress prov.	Bk	2
D55	3A16	68-14-01	Pneumatic de-icer system	Bk	1
		68-26-06	Placard installation	Bk	1
		71-24-10	Security of control wheel	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-21-02	Failure of flex hose assemblies	Bk	1
		73-26-08	Roll and pitch servo clamps	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-15-20	Engine mount	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		97-14-15	Cabin side door and utility door handle	Bk	3
		2000-18-02	Elevator skin	Bk	4
		2001-23-10	Flap flex shaft assembly	Bk	4
D55A	3A16	68-26-06	Placard installation	Bk	1
		72-01-02	Oil drain tubes	Bk	1
		72-11-02	Engine fuel interruption	Bk	1
		72-22-01	Landing gear uplock rollers	Bk	1
		73-21-02	Failure of flex hose assemblies	Bk	1
		73-26-08	Roll and pitch servo clamps	Bk	1
		75-16-10	Elevator trim tab	Bk	1
		79-01-01	Screws in control system	Bk	1
		89-05-02	Elevator control fittings	Bk	2
		90-08-14	Wing spar structure	Bk	3
		91-15-20	Engine mount	Bk	3
		91-17-01	Elev. trim tab actuators	Bk	3
		2001-23-10	Flap flex shaft assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
E55	3A16	71-24-10		Security of control wheel	Bk	1
		72-01-02		Oil drain tubes	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		73-21-02		Failure of flex hose assemblies	Bk	1
		73-26-08		Roll and pitch servo clamps	Bk	1
		74-03-02		Landing gear shock strut pistons	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		76-13-05		Electrical power	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-15-20		Engine mount	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		2000-18-02		Elevator skin	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
E55A	3A16	72-01-02		Oil drain tubes	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		73-21-02		Failure of flex hose assemblies	Bk	1
		73-26-08		Roll and pitch servo clamps	Bk	1
		74-03-02		Landing gear shock strut pistons	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		76-13-05		Electrical power	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		79-01-01		Screws in control system	Bk	1
		88-21-02		Seat tracks	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-15-20		Engine mount	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
56 Series (All Models)	3A16	84-09-01		Window emer. egress prov.	Bk	2
56TC	3A16	67-29-01		Rudder spar web	Bk	1
		68-14-01		Pneumatic de-icer system	Bk	1
		71-24-09		Airspeed placard and indicator markings	Bk	1
		71-24-10		Security of control wheel	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		79-01-01		Screws in control system	Bk	1
		89-05-02		Elevator control fittings	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
56TC continued		2000-18-02		Elevator skin	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
A56TC	3A16	71-24-10		Security of control wheel	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		90-08-14		Wing spar structure	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		2000-18-02		Elevator skin	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
58 Series (All Models)	3A16	84-09-01		Window emer. egress prov.	Bk	2
58	3A16	71-24-10		Security of control wheel	Bk	1
		72-01-02		Oil drain tubes	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		72-22-01		Landing gear uplock rollers	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		73-21-02		Failure of flex hose assemblies	Bk	1
		74-03-02		Landing gear shock strut piston	Bk	1
		74-12-02		Aft facing seats	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		76-13-05		Electrical power	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-16-11		Placard -icing	Bk	2
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-15-20		Engine mount	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		92-23-04		Engine controls support structure	Bk	3
		93-01-23		Crossfeed check valves	Bk	3
		93-03-02		Loran receiver system	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		2000-18-02		Elevator skin	Bk	4
		2000-22-18		Rudder bellcrank interconnect tube	Bk	4
		2000-24-04		Inspect rudder control cables	Bk	4
		2001-11-03		Protect the blower motor circuit	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
		2003-01-01		Right hand fuselage panel assembly rivets	Bk	4
58A	3A16	72-01-02		Oil drain tubes	Bk	1
		72-11-02		Engine fuel interruption	Bk	1
		73-14-03		Landing gear shock strut piston	Bk	1
		73-21-02		Failure of flex hose assemblies	Bk	1
		74-03-02		Landing gear shock strut piston	Bk	1
		74-12-02		Aft facing seats	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-16-10		Elevator trim tab	Bk	1
		76-13-05		Electrical power	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
58A continued		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		90-08-14		Wing spar structure	Bk	3
		91-15-20		Engine mount	Bk	3
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		92-23-04		Engine controls support structure	Bk	3
		93-01-23		Crossfeed check valves	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		2001-11-03		Protect the blower motor circuit	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
		2003-01-01		Right hand fuselage panel assembly rivets	Bk	4
58P	A23CE	76-17-02		Cabin window	Bk	1
		77-08-04		Engine mount fittings	Bk	1
		77-13-08		Right and left truss assembly	Bk	1
		79-01-01		Screws in control system	Bk	1
		85-11-04		AFM placard - seats	Bk	2
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		92-23-04		Engine controls support structure	Bk	3
		97-09-09		Cabin window upper longeron	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		2000-18-02		Elevator skin	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-10-13		Exterior exit door	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
58PA	A23CE	76-17-02		Cabin window	Bk	1
		77-08-04		Engine mount fittings	Bk	1
		77-13-08		Right and left truss assembly	Bk	1
		79-01-01		Screws in control system	Bk	1
		85-11-04		AFM placard-seats	Bk	2
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		92-23-04		Engine controls support structure	Bk	3
		97-09-09		Cabin window upper longeron	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
58TC Series	A23CE	84-09-01		Window emer. egress prov.	Bk	2
58TC	A23CE	77-08-04		Engine mount fittings	Bk	1
		77-13-08		Right and left truss assembly	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		92-23-04		Engine controls support structure	Bk	3
		97-14-15		Cabin side door and utility door handle	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
58TC continued		2000-18-02		Elevator skin	Bk	4
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
58TCA	A23CE	77-08-04		Engine mount fittings	Bk	1
		77-13-08		Right and left truss assembly	Bk	1
		79-01-01		Screws in control system	Bk	1
		87-18-06	R1	Seat recline actuator handle	Bk	2
		88-21-02		Seat tracks	Bk	2
		91-17-01		Elev. trim tab actuators	Bk	3
		91-18-19		Pilot shoulder harnesses	Bk	3
		92-23-04		Engine controls support structure	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		2001-23-10		Flap flex shaft assembly	Bk	4
		2002-11-07		Rotating beacon circuit breaker switch	Bk	4
99 Series	A14CE	69-06-06		Rudder spar cracks	Bk	1
		69-08-02		Elevator spar web	Bk	1
		69-24-02	R3	Maximum speed	Bk	1
		70-10-01		Instrument panel circuit boards	Bk	1
		71-05-03		Known icing conditions	Bk	1
		71-06-01		Faults, failures, improper oper.	Bk	1
		72-09-03		Security of control wheel adapters	Bk	1
		72-26-01		Nose compartment door latch	Bk	1
		74-16-03		Restricted elevator travel	Bk	1
		90-12-07		Wing attach bolts & nuts	Bk	3
		92-15-13		Wing structure	Bk	3
99	A14CE	72-10-04	R2	Landing gear system	Bk	1
		72-20-03		Heater overheat	Bk	1
		75-15-07		Landing gear system	Bk	1
		76-22-03		Elevator control	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-07-05		Bolt and nut, wing section	Bk	2
		81-18-08	R3	Revised AFM	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		90-15-18		Vertical stabilizer main spar	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		2001-11-04		Eliminate and prevent future fatigue cracks	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW	05-04

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
99A	A14CE	72-10-04	R2	Landing gear system	Bk	1
		72-20-03		Heater overheat	Bk	1
		75-15-07		Landing gear system	Bk	1
		76-22-03		Elevator control	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-07-05		Bolt and nut, wing section	Bk	2
		81-18-08	R3	Revised AFM	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		90-15-18		Vertical stabilizer main spar	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		2001-11-04		Eliminate and prevent future fatigue cracks	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
A99A	A14CE	72-10-04	R2	Landing gear system	Bk	1
		72-20-03		Heater overheat	Bk	1
		75-15-07		Landing gear system	Bk	1
		76-22-03		Elevator control	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		81-18-08	R3	Revised AFM	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		90-15-18		Vertical stabilizer main spar	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		2001-11-04		Eliminate and prevent future fatigue cracks	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
A99	A14CE	72-10-04	R2	Landing gear system	Bk	1
		81-18-08	R3	Revised AFM	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		97-25-03		AFM - Limitations - Power levers	Bk	3
		2001-11-04		Eliminate and prevent future fatigue cracks	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B99	A14CE	72-10-04	R2	Landing gear system	Bk	1
		72-20-03		Heater overheat	Bk	1
		74-24-03		Strobe light system	Bk	1
		75-15-07		Landing gear system	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		76-22-03		Elevator control	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-07-05		Bolt and nut, wing section	Bk	2
		81-18-08	R3	Revised AFM	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		90-15-18		Vertical stabilizer main spar	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		2001-11-04		Eliminate and prevent future fatigue cracks	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
C99	A14CE	85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		2001-11-04		Eliminate and prevent future fatigue cracks	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
100	A14CE	74-16-03		Restricted elevator travel	Bk	1
		74-24-03		Strobe light system	Bk	1
		76-10-10		Cabin door	Bk	1
		76-22-03		Elevator control	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-09-03	R1	Placard -oxygen	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Inspect wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
100 continued		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		98-15-13		Fuel hose	Bk	3
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
A100 (U-21F)	A14CE	74-16-03		Restricted elevator travel	Bk	1
		74-18-04		Fuel sump drain line	Bk	1
		74-24-03		Strobe light system	Bk	1
		76-04-02		Seat locking pins	Bk	1
		76-10-10		Cabin door	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		76-22-03		Elevator control	Bk	1
		77-02-04		Wing tip strobe lights	Bk	1
		77-18-04		Cabin pressurization	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-09-03	R1	Placard -oxygen	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Insp. wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
A100A	A14CE	85-22-05		Nut and bolt replacement	Bk	2
		97-25-03		AFM - Limitations - Power levers	Bk	3
A100C	A14CE	97-25-03		AFM - Limitations - Power levers	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B100	A14CE	76-22-02		"Y" type shoulder harness	Bk	1
		76-22-03		Elevator control	Bk	1
		77-18-04		Cabin pressurization	Bk	1
		78-22-05		Elevator control push rods	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-09-03	R1	Placard -oxygen	Bk	2
		81-23-01	R1	Beech kit or STC	Bk	2
		85-01-01		Acrylic windows	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		86-24-09		POH/AFM appendix-icing	Bk	2
		87-03-06	R1	Elevator hinge attachment	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		88-04-07		Insp. wing spar nuts	Bk	2
		89-25-10		Inspect wing main spar	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-07-05		Rudder trim tab	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-22-28		"B" nuts on engine inlet	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
200 Series	A24CE	75-14-03		Autopilot	Bk	1
		89-22-14		Aileron	Bk	2
		96-17-10		Outflow/Safety valve	Bk	3
200 (A100-1) (U-21J)	A24CE	74-24-03		Strobe light system	Bk	1
		75-25-01		Generator output leads	Bk	1
		75-26-04		Fuel transfer system	Bk	1
		76-03-07		Rudder control	Bk	1
		76-04-02		Seat locking pins	Bk	1
		76-09-02		Bolt hole edge distance	Bk	1
		76-10-10		Cabin door	Bk	1
		76-12-10		Wing deicing	Bk	1
		76-22-02		"Y" type shoulder harness	Bk	1
		77-02-07		Propeller feathering	Bk	1
		77-13-07		Aileron control system	Bk	1
		77-18-04		Cabin pressurization	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-07-05		Bolt and nut, wing section	Bk	2
		80-09-03	R1	Placard -oxygen	Bk	2
		83-07-14		One-ply window replacement	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
200 (A100-1) (U-21J) continued		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-02-03		Wing main outboard spars	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW	05-02
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW	05-04
		2005-01-18		Fuselage stringers	BW	05-03
200C	A24CE	80-07-05		Bolt and nut, wing section	Bk	2
		80-09-03	R1	Placard -oxygen	Bk	2
		83-07-14		One-ply window replacement	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW	05-02
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW	05-04
		2005-01-18		Fuselage stringers	BW	05-03

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
200CT	A24CE	83-07-14		One-ply window replacement	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
200T	A24CE	77-18-04		Cabin pressurization	Bk	1
		79-01-01		Screws in control system	Bk	1
		80-07-05		Bolt and nut, wing section	Bk	2
		80-09-03	R1	Placard -oxygen	Bk	2
		83-07-14		One-ply window replacement	Bk	2
		85-22-05		Nut and Bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A200 (C-12A) (C-12C)	A24CE	76-04-02		Seat locking pins	Bk	1
		76-09-02		Bolt hold edge distance	Bk	1
		80-07-05		Bolt and nut, wing section	Bk	2
		80-09-03	R1	Placard -oxygen	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
A200C (UC-12B)	A24CE	80-07-05		Bolt and nut, wing section	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
A200CT	A24CE	85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A200CT continueed		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
A200CT (C-12D), (C-12F), (FWC-12D), (RC-12D), (RC-12G), (RC-12H), (RC-12K), (RC-12P), (RC-12Q)	A24CE	98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-18		Fuselage stringers	BW 05-03	
B200	A24CE	83-07-14		One-ply window replacement	Bk	2
		85-22-05		Nut and bolt replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-10		Wing spar attachment	Bk	3
		91-12-11		Side windows	Bk	3
		92-06-11		Autopilot/flight director wiring	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		96-17-10		Outflow/Safety valve	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-10-05		Engine fire detector system	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		99-18-15		Landing gear emergency hand pumps	Bk	3
		2001-11-03		Protect the blower motor circuit	Bk	4
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
		2006-23-02		Flight controls		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B200C	A24CE	83-07-14		One-ply window replacement	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-10		Wing spar attachment	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-10-05		Engine fire detector system	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
		2006-23-02		Flight controls		
B200C (C-12R) (C-12F)	A24CE	98-10-05		Engine fire detector system	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-18		Fuselage stringers	BW 05-03	
B200C (UC-12F), (UC-12M)	A24CE	2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-18		Fuselage stringers	BW 05-03	
B200CT	A24CE	87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		98-15-13		Fuel hose	Bk	3
B200CT continued		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
B200T	A24CE	87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-10		Wing spar attachment	Bk	3
		91-12-11		Side windows	Bk	3
		92-10-12		Engine cowling doors	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		95-13-03		Electrical landing gear motor	Bk	3
		96-03-13		MLG drag leg lock link	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-10-05		Engine fire detector system	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-20-38	R1	AFM - limitations Section - Icing	BW 05-02	
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2003-13-16		Aft pressure bulkhead of fuselage	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
300 Series	A24CE	89-22-14		Aileron	Bk	2
		96-17-10		Outflow/Safety valve	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
300	A24CE	87-04-24		Elevator trim cable system	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		89-19-04	R1	Wing fuel bay skin panels	Bk	2
		90-08-17		Fuselage moisture drain system	Bk	3
		91-12-10		Wing spar attachment	Bk	3
		91-12-11		Side windows	Bk	3
		92-06-11		Autopilot/flight director wiring	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-01-20		Cowling access door latches	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
300 continued		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
300C	--	92-15-01		Truss-to-firewall bolt	Bk	3
B300	A24CE	91-20-14	R1	Performance charts & information	Bk	3
		92-06-11		Autopilot/flight director wiring	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		94-01-01		Inspect cabin seats for cracks	Bk	3
		96-17-10		Outflow/Safety valve	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-04-24		AFM - Limitations Section - icing	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-02-16		Elevator trim tab system	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		99-18-15		Landing gear emergency hand pumps	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-02	
		2006-19-09		Passenger seat mod kit		
		2006-23-02		Flight controls		
B300C	A24CE	91-20-14	R1	Performance charts and information	Bk	3
		92-06-11		Autopilot/flight director wiring	Bk	3
		92-15-01		Truss-to-firewall bolt	Bk	3
		93-25-07		Fuselage stringers	Bk	3
		94-01-01		Inspect cabin seats for cracks	Bk	3
		97-23-17		Inspect pneumatic tubing	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-15-13		Fuel hose	Bk	3
		98-21-35		Actuator clevis assembly in MLG	Bk	3
		99-02-16		Elevator trim tab system	Bk	3
		99-09-10		Landing gear hand pump suction line	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-02-03		Airstair door and emergency exits	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2005-01-04		Fuel hose	BW 05-04	
		2005-01-18		Fuselage stringers	BW 05-03	
		2006-23-02		Flight controls		
300LW	A24CE	91-12-10		Wing spar attachment	Bk	3
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
390	A00010WI	2002-11-02		Icing conditions	Bk	4
		2002-19-04		Fuel probe brackets	Bk	4
		2003-07-09		AFM - Landing performance	Bk	4
		2003-09-10		Aft power distribution box	Bk	4
		2003-10-05		AFM - Landing performance	Bk	4
		2004-15-01		Hydraulic system assemblies	Bk	4
		2004-25-15		Main landing gear wire harness assemblies	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2005-18-22		Left-hand and right-hand engine assembly cable	BW 05-19	
		2005-19-07		Rudder pedal arm assemblies	BW 05-19	
		2005-25-07		Air conditioning motor module	BW 05-25	
		2006-02-51		Hydraulic tube assembly	BW 06-03	
		2006-18-16		Wing spigot bearing retainer kit		
1900	A24CE	85-21-07	R1	POH/AFM Addendum	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-05-02		POH/AFM changes	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		94-20-05		Hot battery bus fuse assembly	Bk	3
		95-14-02		Instrument air systems	Bk	3
		96-09-13		AFM - Icing	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-15-13	R2	Airstair door handle and latch housing	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		97-26-15		MLG actuator rod end bearing	Bk	3
		98-21-20		Exterior marking placards	Bk	3
		98-26-16		Emergency exit doors	Bk	3
		99-01-03		Outboard flap attachment brackets and aft roller bearings	Bk	3
		99-04-08		MLG hydraulic actuators	Bk	3
		2000-20-07		Cockpit voice recording system	Bk	4
		2001-18-07		Flap extension/retraction failures	Bk	4
		2001-22-16		Engine truss assemblies	Bk	4
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-03-18		Elevator control system	Bk	4
		2003-20-10		Elevator trim system installation	Bk	4
		2004-01-13		Vent blower assemblies	Bk	4
		2004-09-07		Canted bulkhead	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-18-21		Elevator hinge support attachments	BW 05-19	
		2006-18-51		Wing rear lower spar caps		
		2006-24-11		Forward, vertical, and aft flanges		
1900C and 1900C (C-12J)	A24CE	85-21-07	R1	POH/AFM Addendum	Bk	2
		87-04-24		Elevator trim cable system	Bk	2
		87-05-02		POH/AFM changes	Bk	2
		87-22-01	R1	Nose landing gear fork	Bk	2
		92-06-11		Autopilot/flight director wiring	Bk	3
		93-01-16		Stall warning vane housing	Bk	3
		94-20-05		Hot battery bus fuse assembly	Bk	3
		95-14-02		Instrument air systems	Bk	3
		96-09-13		AFM - Icing	Bk	3
		96-22-12		Inspect fuel filter assemblies	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-15-13	R2	Airstair door handle and latch housing	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		97-26-15		MLG actuator rod end bearing	Bk	3
		98-21-20		Exterior marking placards	Bk	3
		98-26-16		Emergency exit doors	Bk	3
		99-01-03		Outboard flap attachment brackets and aft roller bearings	Bk	3
		99-04-08		MLG hydraulic actuators	Bk	3
		2000-19-04		Wing fuel quantity wiring harness	Bk	4
		2000-20-07		Cockpit voice recording system	Bk	4
		2001-18-07		Flap extension/retraction failures	Bk	4
		2001-22-16		Engine truss assemblies	Bk	4
1		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-03-18		Elevator control system	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2003-20-10		Elevator trim system installation	Bk	4
		2004-01-13		Vent blower assemblies	Bk	4
		2004-09-07		Canted bulkhead	Bk	4
		2004-09-30		Landing gear electrical power current limiter	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2004-23-02		Nose landing gear fork	Bk	4
		2005-18-21		Elevator hinge support attachments	BW 05-19	
		2006-18-51		Wing rear lower spar caps		
		2006-24-11		Forward, vertical, and aft flanges		
1900D	A24CE	94-20-05		Hot battery bus fuse assembly	Bk	3
		95-02-17		Elevator trim tab control cable	Bk	3
		95-14-02		Instrument air systems	Bk	3
		95-26-14		Inspect cabin partition bracket	Bk	3
		96-09-13		AFM - Icing	Bk	3
		96-15-01		Windshield heat control circuit breakers	Bk	3
		96-22-12		Inspect fuel filter assemblies	Bk	3
		97-03-01		Right-hand exhaust stacks	Bk	3
		97-06-06		Pilot and copilot chairs	Bk	3
		97-10-14		Stabilon attachment angles	Bk	3
		97-15-13	R2	Airstair door handle and latch housing	Bk	3
		97-17-08		Propeller mounting bolts	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		97-26-15		MLG actuator rod end bearing	Bk	3
		98-09-12		Inspect communication systems	Bk	3
		98-13-11		Ground idle low pitch stop system	Bk	3
		98-21-20		Exterior marking placards	Bk	3
		98-26-16		Emergency exit doors	Bk	3
		99-01-03		Outboard flap attachment brackets and aft roller bearings	Bk	3
		99-04-08		MLG hydraulic actuators	Bk	3
		99-09-15		Flight control mechanism	Bk	3
		99-12-07		Passenger oxygen container and mask assy	Bk	3
		99-16-12		Electric elevator trim	Bk	3
		99-18-15		Landing gear emergency hand pumps	Bk	3
		2000-19-04		Wing fuel quantity wiring harness	Bk	4
		2000-20-07		Cockpit voice recording system	Bk	4
		2001-04-05		NAV Flag	Bk	4
		2001-11-03		Protect the blower motor circuit	Bk	4
		2001-18-07		Flap extension/retraction failures	Bk	4
		2001-22-16		Engine truss assemblies	Bk	4
		2002-23-11		Elevator balance weight attachment screws	Bk	4
		2003-03-18		Elevator control system	Bk	4
		2003-04-26		Alternating current (AC) inverter	Bk	4
		2003-09-12		Fuselage	Bk	4
		2003-20-10		Elevator trim system installation	Bk	4
		2004-01-13		Vent blower assemblies	Bk	4
		2004-09-07		Canted bulkhead	Bk	4
		2004-17-02		Throttle/prop cross shaft assembly bolts	Bk	4
		2006-18-51		Wing rear lower spar caps		
		2006-24-11		Forward, vertical, and aft flanges		
2000	A38CE	96-17-10		Outflow/Safety valve	Bk	3
		96-22-12		Inspect fuel filter assemblies	Bk	3
		97-25-01		Outflow/safety valve	Bk	3
		97-25-03		AFM - Limitations - Power levers	Bk	3
		98-04-25		AFM - Limitations Section - icing	Bk	3
		99-02-14		Inspect engine stainless steel fuel line	Bk	3
		99-10-06		Wing cove skin	Bk	3
		2003-02-03		Airstair door and emergency exits	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.

REARWIN
(See COMMONWEALTH AIRCRAFT, INC.)

REGAL AIR
(See CESSNA)

REIMS AVIATION, S.A.
(See CESSNA)

REPUBLIC
(See STOL AMPHIBIAN CORP.)

REVO, INC.
(See Global Amphibians, LLC)
(Formerly Global Amphibians)

Colonial C-1	1A13	57-06-01		Landing gear lock	Bk	1
		57-13-01		Engine strut fittings	Bk	1
		59-12-05		Plastic control surface locks	Bk	1
		59-15-02		Throttle handle rivets	Bk	1
		59-17-04		Wing spar attaching bolts	Bk	1
		67-11-01		Fuel pressure gage instrument line	Bk	1
		72-07-11		Flap pushrod end bearings	Bk	1
		74-25-08		Wing rear spar fittings	Bk	1
		74-26-02		Rudder control	Bk	1
		79-21-09	R1	Electrical system	Bk	1
Colonial C-2	1A13	59-12-05		Plastic control surface locks	Bk	1
		59-15-02		Throttle handle rivets	Bk	1
		59-17-04		Wing spar attaching bolts	Bk	1
		60-22-01		Engine mount	Bk	1
		67-11-01		Fuel pressure gage instrument line	Bk	1
		72-07-11		Flap pushrod end bearings	Bk	1
		74-25-08		Wing rear spar fittings	Bk	1
		74-26-02		Rudder control	Bk	1
		79-21-09	R1	Electrical system	Bk	1
		98-10-12		Horizontal & vertical stabilizer attachment fitting	Bk	3
		2005-12-02		Horizontal stabilizer attachment	BW	05-12
LA-4	1A13	64-17-05		Engine breather tube	Bk	1
		65-15-03		Nose gear drag strut bolt	Bk	1
		67-11-01		Fuel pressure gage instrument line	Bk	1
		72-07-11		Flap pushrod end bearings	Bk	1
		74-26-02		Rudder control	Bk	1
		76-02-01		Engine power	Bk	1
		79-21-09	R1	Electrical system	Bk	1
		98-10-12		Stabilizer attachment fitting	Bk	3
		2000-10-22		Inspect wing spar fitting	Bk	4
		2002-21-05		Wing spar doublers or angles	Bk	4
		2005-12-02		Horizontal stabilizer attachment	BW	05-12
LA-4A	1A13	64-17-05		Engine breather tube	Bk	1
		67-11-01		Fuel pressure gage instrument line	Bk	1
		72-07-11		Flap pushrod end bearings	Bk	1
		74-26-02		Rudder control	Bk	1
		76-02-01		Engine power	Bk	1
		79-21-09	R1	Electrical system	Bk	1
		98-10-12		Stabilizer attachment fitting	Bk	3
		2000-10-22		Inspect wing spar fitting	Bk	4
		2002-21-05		Wing spar doublers or angles	Bk	4
		2005-12-02		Horizontal stabilizer attachment	BW	05-12

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
LA-4P	1A13	64-17-05		Engine breather tube	Bk	1
		67-11-01		Fuel pressure gage instrument line	Bk	1
		72-07-11		Flap pushrod end bearings	Bk	1
		74-26-02		Rudder control	Bk	1
		76-02-01		Engine power	Bk	1
		79-21-09	R1	Electrical system	Bk	1
		98-10-12		Stabilizer attachment fitting	Bk	3
		2000-10-22		Inspect wing spar fitting	Bk	4
		2002-21-05		Wing spar doublers or angles	Bk	4
		2005-12-02		Horizontal stabilizer attachment	BW 05-12	
LA-4-200	1A13	72-07-11		Flap pushrod end bearings	Bk	1
		74-09-06		Fuel restrictor fitting	Bk	1
		74-26-02		Rudder control	Bk	1
		76-02-01		Engine power	Bk	1
		76-12-11		Engine power loss	Bk	1
		76-24-02		Engine oil coolers	Bk	1
		78-14-05		Main beam fittings	Bk	1
		79-06-01		Engine mounts with cracked straps	Bk	1
		79-21-09	R1	Electrical system	Bk	1
		98-10-12		Stabilizer attachment fitting	Bk	3
		2000-10-22		Inspect wing spar fitting	Bk	4
		2002-21-05		Wing spar doublers or angles	Bk	4
		2005-12-02		Horizontal stabilizer attachment	BW 05-12	
Lake 250	1A13	86-23-05		Fuel shutoff valve mounting plate	Bk	2
		94-22-02		Automatic flight control system	Bk	3
		2000-10-22		Inspect wing spar fitting	Bk	4
		2002-21-05		Wing spar doublers and angles	Bk	4

ROCKWELL INTERNATIONAL - COMMANDER AIRCRAFT DIV.
(Formerly AERO COMMANDER, NORTH AMERICAN ROCKWELL)
(See AYRES CORP., GULFSTREAM AMERICAN)
(For ADs in Bk 1 see North American Avn)

Army BC-1A	A-2-575	46-11-01		Landing gear retracting strut	Bk	1
		46-17-01		Flap control universal joint pins	Bk	1
		46-46-02		Elevator stop	Bk	1
		49-07-02		Fuel system placard	Bk	1
		50-09-01		Stabilizer spar fittings and shims	Bk	1
		2005-12-51		Upper and lower wing attach angle	BW 05-15	
AT-6 (SNJ-2)	A-2-575	46-11-01		Landing gear retracting strut	Bk	1
		46-17-01		Flap control universal joint pins	Bk	1
		46-46-02		Elevator stop	Bk	1
		49-07-02		Fuel system placard	Bk	1
		50-09-01		Stabilizer spar fittings and shims	Bk	1
		50-38-01		Fuselage structure corrosion	Bk	1
		2005-12-51		Upper and lower wing attach angle	BW 05-15	
AT-6A (SNJ-3)	A-2-575	46-11-01		Landing gear retracting strut	Bk	1
		46-17-01		Flap control universal joint pins	Bk	1
		46-46-02		Elevator stop	Bk	1
		49-07-02		Fuel system placard	Bk	1
		50-09-01		Stabilizer spar fittings and shims	Bk	1
		50-38-01		Fuselage structure corrosion	Bk	1
		2005-12-51		Upper and lower wing attach angle	BW 05-15	
AT-6B	A-2-575	46-11-01		Landing gear retracting strut	Bk	1
		46-17-01		Flap control universal joint pins	Bk	1
		46-46-02		Elevator stop	Bk	1
		49-07-02		Fuel system placard	Bk	1
		50-09-01		Stabilizer spar fittings and shims	Bk	1
		50-38-01		Fuselage structure corrosion	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2005-12-51		Upper and lower wing attach angle	BW	05-15
AT-6C (SNJ-4)	A-2-575	46-11-01		Landing gear retracting strut	Bk	1
		46-17-01		Flap control universal joint pins	Bk	1
		46-46-02		Elevator stop	Bk	1
		49-07-02		Fuel system placard	Bk	1
		50-09-01		Stabilizer spar fittings and shims	Bk	1
		50-38-01		Fuselage structure corrosion	Bk	1
		2005-12-51		Upper and lower wing attach angle	BW	05-15
AT-6D (SNJ-5)	A-2-575	50-38-01		Fuselage structure corrosion	Bk	1
		81-14-10		Vertical and horizontal stabilizers	Bk	2
		2005-12-51		Upper and lower wing attach angle	BW	05-15
AT-6F (SNJ-6, -7)	A-2-575	50-38-01		Fuselage structure corrosion	Bk	1
		81-14-10		Vertical and horizontal stabilizers	Bk	2
		2005-12-51		Upper and lower wing attach angle	BW	05-15
T-6G		81-14-10		Vertical and horizontal stabilizers	Bk	2
		2005-12-51		Upper and lower wing attach angle	BW	05-15
Nomad NA-260 (T-28A)	1A18	58-22-02		Landing gear trunnion shaft	Bk	1
		61-05-05		Wright R-1300-1A engines	Bk	1
ROBERT E. RUST						
(Formerly deHavilland)						
DH.C1 Chipmunk 21, 22, 22A	A44EU	2003-05-05		Steel fuselage center-section tie bar	Bk	4
		2003-05-06		Structural integrity	Bk	4
		2003-17-16		Tailplane attachment brackets	Bk	4
RYAN AERONAUTICAL CO.						
(See also THOMPSON ENTERPRISE)						
ST-3KR	A-749	46-06-01		Front fin spar	Bk	1
		51-28-03		Fuel valve placard	Bk	1
SCOTTISH AVIATION						
(See BRITISH AEROSPACE CORP.)						
SHORT BROTHERS, LTD.						
SC-7 Series 2	A15EU	69-26-01		Flap shroud attachment lugs	Bk	1
		2000-02-16		Wing attachment bushes	Bk	4
		2003-13-07		Flight control system rod	Bk	4
		2003-17-05		Critical structure	Bk	4
SC-7 Series 3	A15EU	69-26-01		Flap shroud attachment lugs	Bk	1
		70-15-05		Altimeter stand-by correction label	Bk	1
		70-15-12		Engine drain line	Bk	1
		77-24-02		Flap support structure	Bk	1
		81-06-03		Aileron servo control cable	Bk	2
		83-06-08		MLG brake flange	Bk	2
		83-07-04	R1	Flight control system	Bk	2
		83-07-08		Ground/air lever mechanism	Bk	2
		83-07-16		Vertical fin	Bk	2
		83-07-21		Cargo door locking pin	Bk	2
		83-14-01		Flap attachments	Bk	2
		2000-02-16		Wing attachment bushes	Bk	4
		2003-13-07		Flight control system rod	Bk	4
		2003-17-05		Critical structure	Bk	4
SIAI MARCHETTI, S.P.A.						
(See AGUSTA S.P.A., AermacchiS.p.A.)						
SF600, SF600A	A61EU	97-22-12		AFM - Limitations Section - Power levers	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		98-05-15	AFM - Limitations Section - icing	Bk	3
SIERRA HOTEL AERO, INC.					
(Formerly Navion)					
(See Thompson, Jimmie for ADs in Book 1)					
Navion Series	A-782	47-11-01	Rudder-nose gear steering bellcrank	Bk	1
		47-11-02	Hartzell propeller blade rework	Bk	1
		47-21-04	Fuel scupper drain line	Bk	1
		47-21-05	Propeller control friction lock	Bk	1
		47-21-07	Carburetor air intake scoop filler strip	Bk	1
		47-21-08	Generator terminal stud insulator	Bk	1
		47-21-09	Hydraulic system modifications	Bk	1
		47-21-10	Propeller guide pin dowel	Bk	1
		47-31-01	Hydraulic cylinder lines	Bk	1
		47-31-02	Carburetor vapor return line	Bk	1
		47-31-03	Fuel drain cock	Bk	1
		48-06-03	Hartzell propeller blade inspection	Bk	1
		48-08-03	Fuel valve control support clip	Bk	1
		48-29-01	Fuel pump drain	Bk	1
		49-05-03	Continental engines bearing inserts	Bk	1
		49-09-02	Booster pump rework	Bk	1
		49-11-01	Carter fuel pump rework	Bk	1
		49-12-02	Romec fuel pump vent plugs	Bk	1
		49-28-01	Unsatisfactory spinner	Bk	1
		50-10-02	Air intake hose	Bk	1
		51-07-01	Throttle housing	Bk	1
		52-24-01	Aileron control chain guard	Bk	1
		52-26-01	Stabilizer spar web	Bk	1
		53-08-01	Horizontal stabilizer fitting	Bk	1
		54-18-01	Wing-to-fuselage attachment	Bk	1
		55-01-01	Fuselage frame cracks	Bk	1
		56-03-03	Wing rear spar fitting inspection	Bk	1
		59-06-04	Hydraulic actuating cylinders	Bk	1
		63-21-05	Main and nose retraction links	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
Navion A	A-782	62-03-03	Landing gear selector valve fitting	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
		75-05-02	Engine oil	Bk	1
Navion B	A-782	52-08-02	Carburetor ducting	Bk	1
		53-03-01	Hartzell propeller vibration	Bk	1
		56-27-04	Engine cooling kit removal	Bk	1
		62-03-03	Landing gear selector valve fitting	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
Navion D	A-782	62-03-03	Landing gear selector valve fitting	Bk	1
		64-04-05	Outer wing panel	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
Navion E	A-782	62-03-03	Landing gear selector valve fitting	Bk	1
		64-04-05	Outer wing panel	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
Navion F	A-782	62-03-03	Landing gear selector valve fitting	Bk	1
		64-04-05	Outer wing panel	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
Navion G	A-782	62-03-03	Landing gear selector valve fitting	Bk	1
		64-04-05	Outer wing panel	Bk	1
		68-20-06	Rudder horn inspection	Bk	1
Navion H	A-782	68-20-06	Rudder horn inspection	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.

SILVAIRE
(See LUSCOMBE)

SKY ENTERPRISES, INC.
(Formerly Stol Amphibian)
(For ADs in Bk 1 see Stol Amphibian)

(Republic) RC-3	A-769	47-21-11		Firewall stud bushings	Bk	1
		47-21-12		"No Smoking" placard	Bk	1
		47-21-13		Elevator push-pull tube rivets	Bk	1
		47-21-14		Elevator control cable guide	Bk	1
		47-21-15		Radio filters	Bk	1
		47-21-16		Fuel strainer drain	Bk	1
		47-21-17		Backfire screen	Bk	1
		47-21-18		Mixture control support bracket	Bk	1
		47-21-19		Control clamps or brass ferrules	Bk	1
		47-21-20		Oil pressure gage line restrictor	Bk	1
		47-21-21		Tip float struts	Bk	1
		47-21-22		Engine mounting bolt lock washers	Bk	1
		47-21-23		Engine cooling fan	Bk	1
		47-47-10		Float strut rework	Bk	1
		47-47-11		Propeller reverse control spring	Bk	1
		47-47-12		Carburetor antiswirl vanes	Bk	1
		47-47-13		Hartzell propeller hub counterweight	Bk	1
		47-47-14		Oil screen inspection	Bk	1
		47-51-08		Tailwheel horns	Bk	1
		48-01-03		Elevator trim tab bushing	Bk	1
		48-11-04		Hydraulic pump handle	Bk	1
		49-03-01		AC fuel pump	Bk	1
		49-31-02		Fuel placard	Bk	1
		53-23-03		Strut fitting corrosion	Bk	1

SKY INTERNATIONAL, INC.
(Formerly AVIAT, CHRISTEN IND., WHITE INTERNATIONAL, INC.)
(For ADs in Book 1 See Christen Ind,. For AD's in Book 2 see White Int'l)

A-1	A22NM	90-20-05		Seat back	Bk	3
		91-23-02		Carburetor air intake box	Bk	3
S-1S, S-1T	A8SO	76-16-08		Rudder control	Bk	1
		96-10-12		Inspect flight control stick for cracks	Bk	3
		96-12-03	R2	Aft lower fuselage wing attach fitting	Bk	3
S-2	A8SO	96-10-12		Inspect flight control stick for cracks	Bk	3
		96-12-03	R2	Aft lower fuselage wing attach fitting	Bk	3
S-2A	A8SO	72-19-02		Aileron interconnect tubes	Bk	1
		72-19-05		Horizontal stabilizer support tube	Bk	1
		73-07-06		Horizontal stabilizer support tube	Bk	1
		73-16-06		Induction air box flapper door	Bk	1
		76-16-08		Rudder control	Bk	1
		85-01-04		Cockpit control tube assy	Bk	2
		96-10-12		Inspect flight control stick for cracks	Bk	3
		96-12-03	R2	Aft lower fuselage wing attach fitting	Bk	3
		97-26-20		Inspect longerons aft of rear cabane struts	Bk	3
S-2B, S-2S	A8SO	96-10-12		Inspect flight control stick for cracks	Bk	3
		96-12-03	R2	Aft lower fuselage wing attach fitting	Bk	3
		97-26-20		Inspect longerons aft of rear cabane struts	Bk	3

S. L. INDUSTRIES CORP.
(See DYNAC AND AIRPLANE SERVICES)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
SME Aero Inc.					
(Formerly MDB FLUGTECHNIK AG)					
MD3-160	A65EU	96-13-01	Flight Manual - Accomplishment Instructions	Bk	3
SMITH AEROSTAR					
(Formerly AEROSTAR)					
(See PIPER AIRCRAFT)					
SNOW AERONAUTICAL CO.					
(See AYRES CORPORATION)					
SOCATA - GROUPE AEROSPATIALE					
(Formerly MORANE-SAULNIER, AMERICAN GENERAL)					
MS.880B	7A14	70-17-04	Leaks in fuel system	Bk	1
		70-17-05	Battery box modification	Bk	1
		70-17-06	Firewall sealant	Bk	1
		70-20-02	Air speed cover glass	Bk	1
		71-15-03	Generator system cables	Bk	1
		75-17-18	Aileron control	Bk	1
		75-17-22	Front horizontal stabilizer	Bk	1
		75-21-04	Batteries	Bk	1
		75-22-15	Floor and control stick	Bk	1
		76-11-02	Engine cowl locks	Bk	1
		2000-22-17	Inspect elevator and rudder control clevis	Bk	4
MS.885	7A14	70-17-04	Leaks in fuel system	Bk	1
		70-17-05	Battery box modification	Bk	1
		70-17-06	Firewall sealant	Bk	1
		70-20-02	Air speed cover glass	Bk	1
		75-17-22	Front horizontal stabilizer	Bk	1
		75-22-15	Floor and control stick	Bk	1
		2000-22-17	Inspect elevator and rudder control clevis	Bk	4
MS.892A-150	7A14	75-22-15	Floor and control stick	Bk	1
		75-26-09	Elevator bellcrank	Bk	1
		76-11-02	Engine cowl locks	Bk	1
		76-24-04	Oil return pipes	Bk	1
		76-26-03	Carburetor icing	Bk	1
		92-06-10	Nose wheel axle	Bk	3
		2000-22-17	Inspect elevator and rudder control clevis	Bk	4
		2003-06-07	Engine mount assembly	Bk	4
MS.892E-150	7A14	75-17-18	Aileron control	Bk	1
		76-11-02	Engine cowl locks	Bk	1
		76-24-04	Oil return pipes	Bk	1
		76-26-03	Carburetor icing	Bk	1
		92-06-10	Nose wheel axle	Bk	3
		2000-22-17	Inspect elevator and rudder control clevis	Bk	4
		2003-06-07	Engine mount assembly	Bk	4
MS.893A	7A14	75-22-15	Floor and control stick	Bk	1
		75-26-09	Elevator bellcrank	Bk	1
		76-11-02	Engine cowl locks	Bk	1
		76-24-04	Oil return pipes	Bk	1
		76-26-03	Carburetor icing	Bk	1
		92-06-10	Nose wheel axle	Bk	3
		2000-22-17	Inspect elevator and rudder control clevis	Bk	4
		2003-06-07	Engine mount assembly	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
MS.893E	7A14	75-17-18		Aileron control	Bk	1
		76-11-02		Engine cowl locks	Bk	1
		76-24-04		Oil return pipes	Bk	1
		76-26-03		Carburetor icing	Bk	1
		92-06-10		Nose wheel axle	Bk	3
		2000-22-17		Inspect elevator and rudder control clevis	Bk	4
		2003-06-07		Engine mount assembly	Bk	4
MS.894A	7A14	70-17-04		Leaks in fuel system	Bk	1
		70-17-05		Battery box modification	Bk	1
		70-17-06		Firewall sealant	Bk	1
		70-20-02		Air speed cover glass	Bk	1
		71-15-03		Generator system cables	Bk	1
		71-16-03		Fuel line replacement	Bk	1
		71-16-07		Carburetor heating system	Bk	1
		75-22-15		Floor and control stick	Bk	1
		75-26-09		Elevator bellcrank	Bk	1
		76-11-02		Engine cowl locks	Bk	1
		76-26-03		Carburetor icing	Bk	1
		92-06-10		Nose wheel axle	Bk	3
		2000-22-17		Inspect elevator and rudder control clevis	Bk	4
		2003-06-07		Engine mount assembly	Bk	4
MS.894E	7A14	75-17-18		Aileron control	Bk	1
		76-11-02		Engine cowl locks	Bk	1
		76-26-03		Carburetor icing	Bk	1
		92-06-10		Nose wheel axle	Bk	3
		2000-22-17		Inspect elevator and rudder control clevis	Bk	4
		2003-06-07		Engine mount assembly	Bk	4
Rallye 235C, 235E	7A14	92-06-10		Nose wheel axle	Bk	3
		2000-22-17		Inspect elevator and rudder control clevis	Bk	4
100S	7A14	75-17-18		Aileron control	Bk	1
		2000-22-17		Inspect elevator and rudder control clevis	Bk	4
150T	7A14	2000-22-17		Inspect elevator and rudder control clevis	Bk	4
		2003-06-07		Engine mount assembly	Bk	4
150ST	7A14	2000-22-17		Inspect elevator and rudder control clevis	Bk	4
		2003-06-07		Engine mount assembly	Bk	4
TB9	A51EU	90-02-18	R1	Fuel system	Bk	3
		90-25-17		Engine oil cooler	Bk	3
		91-15-10		Horizontal stabilizer	Bk	3
		98-04-03		Upper seat belt attachment bolts and spacers	Bk	3
		98-04-47		Inspect MLG support ribs for cracks	Bk	3
		98-16-03		Wing front attachments	Bk	3
		2001-23-04		Lower rudder hinge fitting	Bk	4
		2001-23-05		Front seats to unlock from their fixed positions	Bk	4
		2003-04-03		Aileron control gimbal joint	Bk	4
TB10	A51EU	86-21-08		Battery tray	Bk	2
		87-03-11		Stabilator rod ends	Bk	2
		87-22-02	R1	Inspect for cracks	Bk	2
		90-02-18	R1	Fuel system	Bk	3
		90-25-17		Engine oil cooler	Bk	3
		91-15-10		Horizontal stabilizer	Bk	3
		98-04-03		Upper seat belt attachment bolts and spacers	Bk	3
		98-04-47		Inspect MLG support ribs for cracks	Bk	3
		98-08-21		Wing rear attachment fittings	Bk	3
		98-16-03		Wing front attachments	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
TB10 continued		2001-23-04		Lower rudder hinge fitting	Bk	4
		2001-23-05		Front seats to unlock from their fixed positions	Bk	4
		2003-04-03		Aileron control gimbal joint	Bk	4
TB20	A51EU	86-17-03		Elevator attachments	Bk	2
		86-21-08		Battery tray	Bk	2
		87-03-11		Stabilator rod ends	Bk	2
		87-12-09	R1	Aileron weight attach rivets	Bk	2
		87-22-02	R1	Inspect for cracks	Bk	2
		88-02-05		Main landing gear	Bk	2
		90-02-18	R1	Fuel system	Bk	3
		90-25-17		Engine oil cooler	Bk	3
		91-05-02		Inspect for cracks	Bk	3
		91-15-10		Horizontal stabilizer	Bk	3
		98-04-03		Upper seat belt attachment bolts and spacers	Bk	3
		98-18-13		Main landing gear attachment bearing	Bk	3
		2001-23-04		Lower rudder hinge fitting	Bk	4
		2001-23-05		Front seats to unlock from their fixed positions	Bk	4
		2003-04-03		Aileron control gimbal joint	Bk	4
TB21	A51EU	87-03-11		Stabilator rod ends	Bk	2
		87-12-09	R1	Aileron weight attach rivets	Bk	2
		87-22-02	R1	Inspect for cracks	Bk	2
		88-02-05		Main landing gear	Bk	2
		90-02-18	R1	Fuel system	Bk	3
		90-25-17		Engine oil cooler	Bk	3
		91-05-02		Inspect for cracks	Bk	3
		91-15-10		Horizontal stabilizer	Bk	3
		98-04-03		Upper seat belt attachment bolts and spacers	Bk	3
		98-18-13		Main landing gear attachment bearing	Bk	3
		2001-23-04		Lower rudder hinge fitting	Bk	4
		2001-23-05		Front seats to unlock from their fixed positions	Bk	4
		2002-20-04		Exhaust extension to exhaust pipe	Bk	4
		2003-04-03		Aileron control gimbal joint	Bk	4
TB200	A51EU	98-04-03		Upper seat belt attachment bolts and spacers	Bk	3
		98-04-47		Inspect MLG support ribs for cracks	Bk	3
		98-08-21		Wing rear attachment fittings	Bk	3
		2001-23-04		Lower rudder hinge fitting	Bk	4
		2001-23-05		Front seats to unlock from their fixed positions	Bk	4
		2003-04-03		Aileron control gimbal joint	Bk	4
TBM 700	A60EU	95-11-16		Install pneumatic deicers on elevator horn	Bk	3
		96-19-18		Wing skin and rear spar	Bk	3
		97-20-11		MLG inboard locking hinges	Bk	3
		98-04-04		Starter generator mounting adapter	Bk	3
		98-04-22		AFM - Limitations Section - icing	Bk	3
		98-08-27		Left-hand front side lower panel of wheel assy.	Bk	3
		98-12-02		Inspect elevator trim tab fittings for cracks	Bk	3
		98-21-15		Oxygen generators	Bk	3
		98-24-04		Inspect flap carriages for cracks	Bk	3
		99-07-11		Outboard hinge fittings of horizontal stabilizer	Bk	3
		2000-02-29		AFM – Ice protection systems	Bk	4
		2000-26-19		Abnormal venting conditions	Bk	4
		2001-04-07		Prevent loss of propeller control	Bk	4
		2001-06-05		Oil entering the gaseous oxygen system comp	Bk	4
		2001-23-06		Abnormal venting cond. of the wing fuel tank	Bk	4
		2002-03-03		Water accumulating in fuselage	Bk	4
		2002-09-11		Flap attaching bolts/screws	Bk	4
		2002-19-01		Flight control wheels	Bk	4
		2005-20-24		VHF1 antenna mounting area	BW	05-21

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
M.S. 760 (Paris 1)	7A3	66-08-05	Rudder control system rod	Bk	1
(TC 7A3 - For ADs in Bk 1 see Morane-Saulnier)		77-15-14	Landing gear wheels	Bk	1
M.S. 760A (Paris 1A)	7A3	66-08-05	Rudder control system rod	Bk	1
		77-15-14	Landing gear wheels	Bk	1
M.S. 760B (Paris II)	7A3	66-08-05	Rudder control system rod	Bk	1
		76-06-07	Inflight fire	Bk	1
GA-7	A17SO	78-20-09	Fuel selector valves	Bk	1
(TC A17SO - for ADs in		78-22-06	Elevator control	Bk	1
Bk 1 see Gulfstream Aero.,		79-03-06	Rudder assembly	Bk	1
For Bk 2 see Amer. Gen.)		79-05-06	Chafing and leakage of main fuel line	Bk	1
		79-05-07	Fuel leakage in tank ribs	Bk	1
		85-26-05	Rudder torque tube	Bk	2
		89-18-08	Fuel tank/fuel system	Bk	2
		92-06-08	Elevator binding/pitch control	Bk	3
STINSON DIVISION, CONSOLIDATED VULTEE AIRCRAFT CORP.					
(See UNIVAIR AIRCRAFT for Stinson 108 Series)					
L-5 Series	A-764	46-31-02	Torque tube aft of rear seat	Bk	1
		47-50-04	Elevator push-pull tube	Bk	1
L-5B	A-764	46-31-01	Hinged seat back	Bk	1
L-5C	A-764	46-31-01	Hinged seat back	Bk	1
L-5E	A-764	46-31-01	Hinged seat back	Bk	1
L-5E-1	A-764	46-31-01	Hinged seat back	Bk	1
L-5G	A-764	46-31-01	Hinged seat back	Bk	1
A	ATC 556	46-06-05	Wing attach fittings	Bk	1
HW-75	A-709	46-39-01	Oleo truss wear	Bk	1
10	A-709	46-39-01	Oleo truss wear	Bk	1
STOL AIRCRAFT CORPORATION					
UC-1	A6EA	53-23-03	Lift strut fittings	Bk	1
STOL AMPHIBIAN CORP.					
(See Sky Enterprises)					
SUPERIOR AIRCRAFT CO.					
Culver LCA	A-730	46-04-01	Landing gear throttle stop	Bk	1
		46-04-02	Carburetor float needle	Bk	1
LFA	A-730	46-04-01	Landing gear throttle stop	Bk	1
(Culver) V	A-778	47-02-07	Landing gear retraction adjustment	Bk	1
		47-02-08	Firewall cover plate	Bk	1
		47-02-09	Cabin heater valve box	Bk	1
		47-25-01	Fuel system rework	Bk	1
		47-25-02	Wing fillets	Bk	1
		47-25-03	Nose gear drag link	Bk	1
		47-25-04	Compass illumination	Bk	1
		47-25-05	Nose-main gear interconnection tube	Bk	1
		50-04-02	Landing gear retraction motor rework	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
(Culver) V continued		50-47-02		Sensenich propeller blades	Bk	1
		60-24-05		Fuel cells	Bk	1
V2	A-778	47-02-07		Landing gear retraction adjustment	Bk	1
		47-02-08		Firewall cover plate	Bk	1
		47-02-09		Cabin heater valve box	Bk	1
		47-25-01		Fuel system rework	Bk	1
		47-25-02		Wing fillets	Bk	1
		47-25-05		Nose-main gear interconnection tube	Bk	1
		50-04-02		Landing gear retraction motor rework	Bk	1
		50-47-02		Sensenich propeller blades	Bk	1
		60-24-05		Fuel cells	Bk	1

SWEARINGEN AVIATION CORP.
(See FAIRCHILD AIRCRAFT)

SWIFT MUSEUM FOUNDATION, INC.
(Formerly UNIVERSAL AIRCRAFT)

Aircraft equipped with Kopper Model Aeromatic F200 Propellers	---	47-50-13		Universal Kopper Propellers	Bk	1
(Globe) GC-1A	A-766	46-23-04		Addition of rivets in wing skin	Bk	1
		46-33-02		Fuselage bulkhead flange stiffener	Bk	1
		46-42-01		Cabin heater valve replacement	Bk	1
		47-06-01		Landing gear retraction adjustment	Bk	1
		47-06-02		Landing gear retraction placard	Bk	1
		47-06-03		Elevator cable collars	Bk	1
		47-06-04		Landing gear washers	Bk	1
		47-06-05		Battery vent plugs	Bk	1
		47-06-06		Engine breather line	Bk	1
		47-25-06		Carburetor flexible air duct	Bk	1
		47-25-07		Oil radiator outlet sleeve	Bk	1
		48-28-01		Fuselage bulkhead rework	Bk	1
		51-02-02		Asbestos cloth removal	Bk	1
		51-08-03		Stabilizer spar attachment	Bk	1
		51-10-05		Fuselage reinforcement rework	Bk	1
		51-11-04		Landing gear rework	Bk	1
		56-16-04		Landing gear torque knees	Bk	1
		58-10-03		Landing gear stop ring	Bk	1
GC-1B	A-766	46-23-04		Addition of rivets in wing skin	Bk	1
		46-33-02		Fuselage bulkhead flange stiffener	Bk	1
		46-42-01		Cabin heater valve replacement	Bk	1
		47-06-01		Landing gear retraction adjustment	Bk	1
		47-06-02		Landing gear retraction placard	Bk	1
		47-06-03		Elevator cable collars	Bk	1
		47-06-04		Landing gear washers	Bk	1
		47-06-05		Battery vent plugs	Bk	1
		47-06-06		Engine breather line	Bk	1
		47-25-06		Carburetor flexible air duct	Bk	1
		47-25-07		Oil radiator outlet sleeve	Bk	1
		48-28-01		Fuselage bulkhead rework	Bk	1
		51-02-02		Asbestos cloth removal	Bk	1
		51-08-03		Stabilizer spar attachment	Bk	1
		51-10-05		Fuselage reinforcement rework	Bk	1
		51-11-04		Landing gear rework	Bk	1
		56-16-04		Landing gear torque knees	Bk	1
		58-10-03		Landing gear stop ring	Bk	1
		64-05-06		Engine mount	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
TAYLORCRAFT 2000, LLC					
(Formerly Booth, Lee F. (Dba Taylorcraft Aerospace))					
(Formerly Taylorcraft Aircraft Co.)					
(See TAYLORCRAFT, INC. for BF, BL & DC Series)					
(See Taylorcraft Aircraft for Book 1 and 2)					
All Series below S/N 13001	---	51-09-03	Fuel shutoff valve clip	Bk	1
19	1A9	87-03-08	Oil pressure gauge hose	Bk	2
F19	1A9	75-18-05	Engine mount bolts	Bk	1
		78-20-11	Aileron control malfunction	Bk	1
		79-04-04	Charging circuit fire hazard	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
F21	1A9	87-03-08	Oil pressure gauge hose	Bk	2
F21A	1A9	87-03-08	Oil pressure gauge hose	Bk	2
BC Series	A-696	47-16-03	Wing strut fittings	Bk	1
		50-41-01	Elevator horn bolt	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
BCS	A-696	87-03-08	Oil pressure gauge hose	Bk	2
BC-65	A-696	47-13-02	Fuel hose	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
BCS-65	A-696	47-13-02	Fuel hose	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
BC12-65	A-696	47-13-02	Fuel hose	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
BCS12-65	A-696	47-13-02	Fuel hose	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
BC12-D	A-696	47-13-02	Fuel hose	Bk	1
		78-20-11	Aileron control malfunction	Bk	1
		87-03-08	Oil pressure gauge hose	Bk	2
BCS12-D	A-696	47-13-02	Fuel hose	Bk	1
BCS12-D1	A-696	47-13-02	Fuel hose	Bk	1
TAYLORCRAFT AIRCRAFT CO.					
(see Booth, Lee F.)					
TAYLORCRAFT, INC.					
(See TAYLORCRAFT AVIATION CORP. and AIRCRAFT ACQUISITION)					
All Series below S/N 13001	---	51-09-03	Fuel shutoff valve clip	Bk	1
BF Series	A-699	47-16-03	Wing strut fittings	Bk	1
		50-41-01	Elevator horn bolt	Bk	1
BL Series	A-700	47-16-03	Wing strut fittings	Bk	1
		50-41-01	Elevator horn bolt	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.

TEMCO AIRCRAFT CORP.
(See MULTITECH ENGINEERING CORP. for D-16 and D-16A)
(See Luscombe Aircraft Corp.)

THOMPSON ENTERPRISE, JIMMY
(Formerly NAVION)
(See Navion Aircraft Company, Ltd)

THRUSH AIRCRAFT, INC.
(Formerly Quality Aicraft, Inc.,
formerly Ayres Corporation)
(See Ayres Corp. for ADs in Book 1, 2, 3)

S2A	2A9	61-14-06	Control cables	Bk	1
		63-05-03	Wing main spar web flanges	Bk	1
		66-14-01	Wing lower spar caps	Bk	1
S-2B	2A7	63-05-03	Wing main spar web flanges	Bk	1
		66-14-01	Wing lower spar caps	Bk	1
S-2C	2A7	63-05-03	Wing main spar web flanges	Bk	1
		66-14-01	Wing lower spar caps	Bk	1
600 S-2C	2A7	66-14-01	Wing lower spar caps	Bk	1
S-2D	--	93-01-03	Wing front spar	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
600 S-2D	A3SW	79-10-10	Separation of hinge from rudder assy	Bk	1
	A4SW	80-04-06	Cracks in tubular front spar	Bk	2
S-2R Series	A3SW	2006-07-15	Lower wing spar caps	BW	06-09
	A4SW				
S-2R	A3SW	79-10-10	Separation of hinge from rudder assy	Bk	1
	A4SW	80-04-06	Cracks in tubular front spar	Bk	2
		93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-T34	A3SW	80-04-06	Cracks in tubular front spar	Bk	2
	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2RHG-T34	A4SW	2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-T15	A3SW	80-04-06	Cracks in tubular front spar	Bk	2
	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL AIRCRAFT

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
S2R-R1340	A3SW	93-01-03	Wing front spar	Bk	3
	A4SW	93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-R3S	A3SW	80-04-06	Cracks in tubular front spar	Bk	2
	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-T11	A3SW	80-04-06	Cracks in tubular front spar	Bk	2
	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-R1820	A4SW	84-09-03	Fuselage upper longerons	Bk	2
		93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-T65	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2RHG-T65	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-T45	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		93-20-06	Outboard wing huckbolts	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-G6	A4SW	93-01-03	Wing front spar	Bk	3
		93-20-05	Vertical tail attachment bracket	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-G1	A4SW	2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-G10	A4SW	93-20-05	Vertical tail attachment bracket	Bk	3
		2000-05-23	MLG fuselage attach bolts	Bk	4
S2R-G5	A4SW	2000-05-23	MLG fuselage attach bolts	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
TIGER AIRCRAFT LLC						
(Formerly American General Aircraft Holding Co., Inc.)						
(For ADds in Bk 2 and 3 see American General Aircraft Holding Co., Inc.)						
(Formerly GULFSTREAM)						
(For ADs in Bk 1 See Gulfstream Aerospace)						
AA-1	A11EA	70-05-05		Muffler inspection	Bk	1
		70-25-05		Bungee mounting plate	Bk	1
		71-04-03		Nose gear strut	Bk	1
		72-06-02		Rudder aileron & elevator control cables	Bk	1
		72-07-10		Wear on elevator bungee housing	Bk	1
		73-13-07		Placard installation	Bk	1
		75-07-04		Rudder control bar assemblies	Bk	1
		75-09-07		Mixture control wires	Bk	1
		76-17-03		Delaminations in bonded skin	Bk	1
		78-13-04		Fuel measurement gauge	Bk	1
		85-21-02		Seat belt attachment bracket	Bk	2
AA-1A	A11EA	72-06-02		Rudder aileron & elevator control cables	Bk	1
		72-07-10		Wear on elevator bungee housing	Bk	1
		73-13-07		Placard installation	Bk	1
		75-07-04		Rudder control bar assemblies	Bk	1
		75-09-07		Mixture control wires	Bk	1
		76-17-03		Delaminations in bonded skin	Bk	1
		78-13-04		Fuel measurement gauge	Bk	1
		85-21-02		Seat belt attachment bracket	Bk	2
AA-1B	A11EA	72-06-02		Rudder aileron & elevator control cables	Bk	1
		72-07-10		Wear on elevator bungee housing	Bk	1
		73-13-07		Placard installation	Bk	1
		75-07-04		Rudder control bar assemblies	Bk	1
		75-09-07		Mixture control wires	Bk	1
		76-17-03		Delaminations in bonded skin	Bk	1
		78-13-04		Fuel measurement gauge	Bk	1
		85-21-02		Seat belt attachment bracket	Bk	2
AA-1C	A11EA	85-21-02		Seat belt attachment bracket	Bk	2
AA-5	A16EA	72-06-02		Rudder aileron & elevator control cables	Bk	1
		75-07-04		Rudder control bar assemblies	Bk	1
		76-01-02		Engine cowl	Bk	1
		76-17-03		Delaminations in bonded skin	Bk	1
		77-07-04		Carburetor heat valve assy	Bk	1
		79-22-04		Aileron system	Bk	1
		81-24-03		Engine power loss prevention	Bk	2
		89-18-08		Fuel tank/fuel system	Bk	2
		95-19-15	R1	Wing spar	BW	05-18
AA-5A	A16EA	76-01-02		Engine cowl	Bk	1
		76-17-03		Delaminations in bonded skin	Bk	1
		76-22-09		Oil coolers	Bk	1
		77-07-04		Carburetor heat valve assy	Bk	1
		77-08-03		Static system	Bk	1
		79-22-04		Aileron system	Bk	1
		81-24-03		Engine power loss prevention	Bk	2
		89-18-08		Fuel tank/fuel system	Bk	2
		95-19-15	R1	Wing spar	BW	05-18

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AA-5B	A16EA	75-07-04		Rudder control bar assemblies	Bk	1
		76-01-02		Engine cowl	Bk	1
		76-04-05		Carburetor mixture control wire	Bk	1
		76-17-03		Delaminations in bonded skin	Bk	1
		76-22-09		Oil coolers	Bk	1
		77-08-03		Static system	Bk	1
		79-22-04		Aileron system	Bk	1
		81-24-03		Engine power loss prevention	Bk	2
		89-18-08		Fuel tank/fuel system	Bk	2
		95-19-15	R1	Wing spar	BW 05-18	
AG-5B		95-19-15	R1	Wing spar	BW 05-18	
TIMM AIRCRAFT CORP.						
Navy N2T	A-2-573	48-32-01		Throttle quadrant reinforcement	Bk	1
PT-220-C	TC 750	48-32-01		Throttle quadrant reinforcement	Bk	1
TRYTEK, E.J.						
(See BELLANCA, AERONCA, WAGNER)						
TWIN COMMANDER AIRCRAFT CORP.						
(Formerly GULFSTREAM)						
(For ADs in Book1 see Gulfstream Aerospace)						
500	6A1	59-04-01		Stabilizer rivets	Bk	1
		59-06-01		Elevator front spar	Bk	1
		59-16-01		Fuel line routing	Bk	1
		61-14-01		Engine mount inspection	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-15		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
500A	6A1	59-16-01		Fuel line routing	Bk	1
		61-14-01		Engine mount inspection	Bk	1
		64-02-01		Main landing gear	Bk	1
		67-22-01		Main landing gear	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
500B	6A1	59-16-01		Fuel line routing	Bk	1
		61-14-01		Engine mount inspection	Bk	1
		64-02-01		Main landing gear	Bk	1
		67-22-01		Main landing gear	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
500S	6A1	59-16-01		Fuel line routing	Bk	1
		61-14-01		Engine mount inspection	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-11		Wing front spar lower cap	Bk	3
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
500U	6A1	59-16-01		Fuel line routing	Bk	1
		61-14-01		Engine mount inspection	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
520	6A1	57-09-01		Aileron bellcrank casting	Bk	1
		58-01-01		Fuel vent line replacement	Bk	1
		59-16-01		Fuel line routing	Bk	1
		62-08-02		Fuel line modification	Bk	1
		63-08-01		Fuel gaging system	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
560	6A1	57-09-01		Aileron bellcrank casting	Bk	1
		58-01-01		Fuel vent line replacement	Bk	1
		59-04-01		Stabilizer rivets	Bk	1
		59-16-01		Fuel line routing	Bk	1
		62-08-02		Fuel line modification	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
560-A	6A1	56-02-01		Augmentor tube support clamps	Bk	1
		57-09-01		Aileron bellcrank casting	Bk	1
		57-15-01		Landing gear retaining pins	Bk	1
		58-01-01		Fuel vent line replacement	Bk	1
		59-04-01		Stabilizer rivets	Bk	1
		59-16-01		Fuel line routing	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
560A continued		94-04-13		Wing front spar lower cap	Bk	3
		94-04-15		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
560-E	6A1	57-15-01		Landing gear retaining pins	Bk	1
		58-01-01		Fuel vent line replacement	Bk	1
		59-04-01		Stabilizer rivets	Bk	1
		59-16-01		Fuel line routing	Bk	1
		67-28-01		Lower front spar cap	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-15		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
560F	2A4	64-02-01		Main landing gear	Bk	1
		67-22-01		Main landing gear	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
600 Series		2000-02-30		AFM – Ice protection systems	Bk	4
680	2A4	57-09-01		Aileron bellcrank casting	Bk	1
		57-15-01		Landing gear retaining pins	Bk	1
		58-01-01		Fuel vent line replacement	Bk	1
		59-04-01		Stabilizer rivets	Bk	1
		59-16-01		Fuel line routing	Bk	1
		67-28-01		Lower front spar cap	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-15		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
680E	2A4	59-04-01		Stabilizer rivets	Bk	1
		59-16-01		Fuel line routing	Bk	1
		60-20-01		Wing rivet replacement	Bk	1
		67-28-01		Lower front spar cap	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-15		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
680F, 680F(P)	2A4	62-05-01		Alternate induction air valve	Bk	1
		62-08-01		Fuel pressure gauge drain line	Bk	1
		64-02-01		Main landing gear	Bk	1
		67-22-01		Main landing gear	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
680FL, 680FL(P)	2A4	64-02-01		Main landing gear	Bk	1
		67-22-01		Main landing gear	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
680-T	2A4	84-10-07		Emer. LG extension system mod.	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
680-V	2A4	84-10-07		Emer. LG extension system mod.	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
680-W	2A4	84-10-07		Emer. LG extension system mod.	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
681	2A4	84-10-07		Emer. LG extension system mod.	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
681 continued		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
685	2A4	75-19-01		Flap speed	Bk	1
		82-23-05		Induction air elbow	Bk	2
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-12		Wing front spar lower cap & wing rib	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		95-13-02		Vertical stabilizer	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
690	2A4	73-13-09		Oil supply line failure	Bk	1
		75-19-01		Flap speed	Bk	1
		77-03-01		Left & right wing rivets	Bk	1
		84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		94-04-12		Wing front spar lower cap & wing rib	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
		2006-15-01		Inboard and center aileron hinge fittings		
690A	2A4	74-20-12		Pilot and co-pilot side windows	Bk	1
		75-08-05		Battery disconnect	Bk	1
		75-08-07		Bleed air line	Bk	1
		75-19-01		Flap speed	Bk	1
		77-03-01		Left & right wing rivets	Bk	1
		77-04-01		Trim system	Bk	1
		84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		94-04-12		Wing front spar lower cap & wing rib	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
		2006-15-01		Inboard and center aileron hinge fittings		
690B	2A4	77-03-01		Left & right wing rivets	Bk	1
		84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		94-04-11		Wing front spar lower cap	Bk	3
		94-04-12		Wing front spar lower cap & wing rib	Bk	3
		94-04-14		Wing front spar lower cap	Bk	3
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
690B continued		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
		2006-15-01		Inboard and center aileron hinge fittings		
690-C	2A4	84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		95-12-23		Inspect wing structure for cracks	Bk	3
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
690-D	2A4	84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
		2003-07-03		Wing and fuselage areas	Bk	4
695	2A4	84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		95-12-23		Inspect wing structure for cracks	Bk	3
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
695-A	2A4	84-19-05		Engine mount systems	Bk	2
		87-24-07	R1	POH/AFM revision-icing	Bk	2
		95-13-02		Vertical stabilizer	Bk	3
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-08-25	R1	NLG drag link bolt	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
		2003-07-03		Wing and fuselage areas	Bk	4
695-B	2A4	87-24-07	R1	POH/AFM revision-icing	Bk	2
		95-19-18		Placard - Turbulent air penetration and maneuvering speeds	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
		2000-02-30		AFM – Ice protection systems	Bk	4
		2003-07-03		Wing and fuselage areas	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
720	2A4	59-04-01		Stabilizer rivets	Bk	1
		59-16-01		Fuel line routing	Bk	1
		60-20-01		Wing rivet replacement	Bk	1
		62-08-01		Fuel pressure gauge drain line	Bk	1
		67-28-01		Lower front spar cap	Bk	1
		73-06-02		Fuel siphoning	Bk	1
		75-12-09	R2	Inadvertent structural failure	Bk	1
		87-21-07	R1	Fuel filler openings	Bk	2
		94-04-13		Wing front spar lower cap	Bk	3
		94-04-15		Wing front spar lower cap	Bk	3
		98-07-17		Flap system cable	Bk	3
		98-08-19		Inspect wing to fuselage attach points for cracks	Bk	3
		98-20-34		AFM - limitations Section - Icing	Bk	3
700	A12SW	87-21-07	R1	Fuel filler openings	Bk	2
UNIVAIR AIRCRAFT CORP.						
Aircraft equipped with Kopper Model Aeromatic F200 Propellers	---	47-50-13		Universal Kopper Propellers	Bk	1
(Stinson) 108 Series 108-1	A-767	47-50-11		Ash tray modification	Bk	1
		47-50-12		Stabilizer attachment fitting	Bk	1
		50-17-02		Rudder cable inspection	Bk	1
		50-25-01		Fuel drip strip	Bk	1
		73-20-08		(See Univair Propellers)	Bk	1
(Stinson) 108-2	A-767	49-16-02		Wing fabric inspection	Bk	1
(Stinson) 108-3	A-767	49-16-02		Wing fabric inspection	Bk	1
415 Series	A-718	46-49-01		Nose wheel replacement	Bk	1
		47-20-03		Fuel pump line alteration	Bk	1
		52-02-02		Aileron inspection	Bk	1
		54-26-02		Control cable fraying	Bk	1
		60-09-02		Nose gear bolts	Bk	1
(Erco) 415-C	A-718	46-23-01		Muffler replacement	Bk	1
		46-23-02		Engine breather line hose	Bk	1
		46-23-03		Aileron control column fitting	Bk	1
		46-38-02		Aileron control stop	Bk	1
		46-46-01		Fuselage gas tank overflow line	Bk	1
		47-20-04		Baggage compartment zipper	Bk	1
		47-20-05		Belly skin reinforcement	Bk	1
		47-20-06		Aileron reinforcement	Bk	1
		47-20-08		Battery box drain	Bk	1
		47-20-09		Voltage regulator check	Bk	1
		47-42-20		Control column shaft	Bk	1
		50-07-01		Elevator trim tab stop	Bk	1
		52-25-02		Federal nose ski	Bk	1
		55-22-02		Terneplate fuel tank	Bk	1
		57-02-01		Rudder horn attachment	Bk	1
		59-05-04		Rear spar reinforcement	Bk	1
		59-25-05		Rudder reinforcement	Bk	1
		67-06-03		Rudder bellcrank	Bk	1
		2002-16-04		Fuel line nipple and elbow	Bk	4
		2002-26-02		Wing center section	Bk	4
		2003-21-01		Wing outer panel	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
(Erco) 415-CD	A-718	46-23-01	Muffler replacement	Bk	1
		46-23-02	Engine breather line hose	Bk	1
		46-23-03	Aileron control column fitting	Bk	1
		46-38-02	Aileron control stop	Bk	1
		46-46-01	Fuselage gas tank overflow line	Bk	1
		47-20-04	Baggage compartment zipper	Bk	1
		47-20-05	Belly skin reinforcement	Bk	1
		47-20-06	Aileron reinforcement	Bk	1
		47-20-08	Battery box drain	Bk	1
		47-20-09	Voltage regulator check	Bk	1
		47-42-20	Control column shaft	Bk	1
		50-07-01	Elevator trim tab stop	Bk	1
		52-25-02	Federal nose ski	Bk	1
		55-22-02	Terneplate fuel tank	Bk	1
		57-02-01	Rudder horn attachment	Bk	1
		59-05-04	Rear spar reinforcement	Bk	1
		59-25-05	Rudder reinforcement	Bk	1
		67-06-03	Rudder bellcrank	Bk	1
		2002-16-04	Fuel line nipple and elbow	Bk	4
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Erco) 415-D	A-787	46-23-01	Muffler replacement	Bk	1
		46-23-02	Engine breather line hose	Bk	1
		46-23-03	Aileron control column fitting	Bk	1
		46-38-02	Aileron control stop	Bk	1
		46-46-01	Fuselage gas tank overflow line	Bk	1
		47-20-04	Baggage compartment zipper	Bk	1
		47-20-05	Belly skin reinforcement	Bk	1
		47-20-06	Aileron reinforcement	Bk	1
		47-20-08	Battery box drain	Bk	1
		47-20-09	Voltage regulator check	Bk	1
		47-42-20	Control column shaft	Bk	1
		50-07-01	Elevator trim tab stop	Bk	1
		55-22-02	Terneplate fuel tank	Bk	1
		57-02-01	Rudder horn attachment	Bk	1
		59-05-04	Rear spar reinforcement	Bk	1
		59-25-05	Rudder reinforcement	Bk	1
		67-06-03	Rudder bellcrank	Bk	1
		2002-16-04	Fuel line nipple and elbow	Bk	4
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Erco) 415-E	A-787	52-02-02	Aileron inspection	Bk	1
		54-26-02	Control cable fraying	Bk	1
		57-02-01	Rudder horn attachment	Bk	1
		59-05-04	Rear spar reinforcement	Bk	1
		59-25-05	Rudder reinforcement	Bk	1
		67-06-03	Rudder bellcrank	Bk	1
		2002-16-04	Fuel line nipple and elbow	Bk	4
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Erco) 415-G	A-787	52-02-02	Aileron inspection	Bk	1
		54-26-02	Control cable fraying	Bk	1
		57-02-01	Rudder horn attachment	Bk	1
		59-05-04	Rear spar reinforcement	Bk	1
		59-25-05	Rudder reinforcement	Bk	1
		67-06-03	Rudder bellcrank	Bk	1
		2002-16-04	Fuel line nipple and elbow	Bk	4
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
(Forney) F-1	A-787	57-02-01	Rudder horn attachment	Bk	1
		59-25-05	Rudder reinforcement	Bk	1
		60-09-02	Nose gear bolts	Bk	1
		67-06-03	Rudder bellcrank	Bk	1
		2002-16-04	Fuel line nipple and elbow	Bk	4
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Forney) F-1A	A-787	59-25-05	Rudder reinforcement	Bk	1
		67-06-03	Rudder bellcrank	Bk	1
		2002-16-04	Fuel line nipple and elbow	Bk	4
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Alon) A-2	A-787	2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Alon) A-2A	A-787	2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4
(Mooney) M-10	A-787	70-17-02	Rudder bellcrank tie rod screws	Bk	1
		2002-26-02	Wing center section	Bk	4
		2003-21-01	Wing outer panel	Bk	4

UNIVERSAL AIRCRAFT INDUSTRIES
(See SWIFT MUSEUM)

VARGA AIRCRAFT CORP.
(See MONTANAIR)

VULCANAIR S.p.A
(Formerly Partenavia Costruzioni Aeronautiche S.p.A.)
(For Ads in Books 2 or 3 see Partenavia Costruzioni Aeronautiche S.p.A.)

P68 Series	A31EU	83-12-04	Bellcrank attach. mounting brackets	Bk	2
		88-21-04	Stabilator trim tabs	Bk	2
		91-22-06	Placard operating limitations	Bk	3
P68	A31EU	80-01-01	Stabilator balance weight	Bk	2
		80-15-02	Rudder control system	Bk	2
		81-07-03	Propeller pitch control system	Bk	2
		81-07-08	Longitudinal trim tab	Bk	2
		82-18-11	Wheel shaft universal joints	Bk	2
		83-05-07	Oil Cooler fittings and hoses	Bk	2
		83-12-04	Flap bellcrank attach mountings	Bk	2
		83-14-03	Fin rear spar	Bk	2
		83-15-04	Torque support brackets	Bk	2
		85-08-04	Wing spars	Bk	2
		85-08-06	Aileron control	Bk	2
		87-04-20	Aileron control cable	Bk	2
		87-10-12	Leading edge wing ribs	Bk	2
		88-13-08	Engine mount	Bk	2
		89-03-03	Engine mounting system	Bk	2
		91-11-14	Fuel & Janitrol system lines	Bk	3
		98-04-20	AFM - Limitations Section - icing	Bk	3
		2002-19-08	Primary flight control system	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
P68B	A31EU	80-01-01		Stabilator balance weight	Bk	2
		80-15-02		Rudder control system	Bk	2
		81-07-03		Propeller pitch control system	Bk	2
		81-07-08		Longitudinal trim tab	Bk	2
		82-18-11		Wheel shaft universal joints	Bk	2
		83-05-07		Oil cooler fittings and hoses	Bk	2
		83-07-17		Fuel selector control	Bk	2
		83-07-22	R1	Flap selector switch replacement	Bk	2
		83-12-04		Flap bellcrank attach mountings	Bk	2
		83-14-03		Fin rear spar	Bk	2
		83-15-04		Torque support brackets	Bk	2
		85-08-04		Wing spars	Bk	2
		85-08-06		Aileron control	Bk	2
		87-04-20		Aileron control cable	Bk	2
		87-10-12		Leading edge wing ribs	Bk	2
		88-13-08		Engine mount	Bk	2
		89-03-03		Engine mounting system	Bk	2
		2002-19-08		Primary flight control system	Bk	4
P68C	A31EU	83-07-17		Fuel selector control	Bk	2
		83-07-22	R1	Flap selector switch replacement	Bk	2
		83-12-04		Flap bellcrank attach mountings	Bk	2
		83-15-04		Torque support brackets	Bk	2
		85-08-04		Wing spars	Bk	2
		85-08-06		Aileron control	Bk	2
		87-04-20		Aileron control cable	Bk	2
		87-10-12		Leading edge wing ribs	Bk	2
		88-13-08		Engine mount	Bk	2
		89-03-03		Engine mounting system	Bk	2
		91-11-14		Fuel & Janitrol system lines	Bk	3
		2002-19-08		Primary flight control system	Bk	4
P68C-TC	A31EU	83-07-22	R1	Flap selector switch replacement	Bk	2
		83-12-04		Flap bellcrank attach mountings	Bk	2
		83-15-04		Torque support brackets	Bk	2
		85-08-04		Wing spars	Bk	2
		85-08-06		Aileron control	Bk	2
		87-04-20		Aileron control cable	Bk	2
		87-10-12		Leading edge wing ribs	Bk	2
		88-13-08		Engine mount	Bk	2
		91-11-14		Fuel & Janitrol system lines	Bk	3
		2002-19-08		Primary flight control system	Bk	4
P68-OTC	--	91-11-14		Fuel & Janitrol system lines	Bk	3
P68 Observer	A31EU	83-12-04		Flap bellcrank attach mountings	Bk	2
		83-15-04		Torque support brackets	Bk	2
		85-08-04		Wing spars	Bk	2
		85-08-06		Aileron control	Bk	2
		87-04-20		Aileron control cable	Bk	2
		88-13-08		Engine mount	Bk	2
		89-03-03		Engine mounting system	Bk	2
		91-11-14		Fuel & Janitrol system lines	Bk	3
		2000-24-05		Nose landing gear upper strut	Bk	4
		2002-19-08		Primary flight control system	Bk	4
P68 “Observer 2”	A31EU	2000-24-05		Nose landing gear upper strut	Bk	4
		2002-19-08		Primary flight control system	Bk	4
P68TC	A31EU	89-03-03		Engine mounting system	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
P68TC "Observer"	A31EU	87-04-20	Aileron control cable	Bk	2
		88-13-08	Engine mount	Bk	2
		89-03-03	Engine mounting system	Bk	2
		2000-24-05	Nose landing gear upper strut	Bk	4
		2002-19-08	Primary flight control system	Bk	4
AP68TP 300 "Spartacus"	A31EU	97-22-10	AFM - Limitations Section - Power levers	Bk	3
		98-04-20	AFM - Limitations Section - icing	Bk	3
		2000-03-18	AFM – Ice protection systems	Bk	4
		2002-19-08	Primary flight control system	Bk	4
AP68TP 600 "Viator"	A31EU	97-22-10	AFM - Limitations Section - Power levers	Bk	3
		98-04-20	AFM - Limitations Section - icing	Bk	3
		2000-03-18	AFM – Ice protection systems	Bk	4
		2002-19-08	Primary flight control system	Bk	4
WACO AIRCRAFT CO.					
INF	ATC 345	46-50-01	Fuel line rework	Bk	1
KNF, MNF	ATC 313	46-50-01	Fuel line rework	Bk	1
RNF	ATC 311	46-50-01	Fuel line rework	Bk	1
UKS-7, VKS-7, VKS-7F	ATC 648	47-27-01	Wing inspection (tank area)	Bk	1
WAGNER, R.H.					
(See AERONCA)					
WEATHERLY AIRCRAFT COMPANY					
(Formerly Weatherly Aviation Company (GBECK))					
201B	A10WE	76-12-08	Airplane control	Bk	1
		76-22-11	Parking brakes	Bk	1
201C	A10WE	76-12-08	Airplane control	Bk	1
		76-22-11	Parking brakes	Bk	1
		80-05-01	Tail cone attach fittings	Bk	2
620A, 620B	A26WE	96-16-06	Inspect wing hinge pins	Bk	3
WEATHERLY AVIATION CO.					
(See Weatherly Aircraft Company**)**					
WHITE INTERNATIONAL LTD					
(Formerly AVIAT, formerly CHRISTEN IND.)					
(See Sky International, Inc.)					
WING AIRCRAFT COMPANY					
(See Emerald Enterprises)					
WYTWORNIA SPRZETU KOMUNIKACYJNEGO					
(See Polskie Zaklady Lotnicze Spolka Zo.O)					

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

AIRWORTHINESS DIRECTIVE SUMMARY SUBJECT INDEX

ROTORCRAFT, GLIDERS, BALLOONS, & AIRSHIPS

JANUARY 2007

* * * * * * * * * *

The indexes, which are published twice a year, are intended to be used as a guide only and should not be relied upon as conclusive evidence of AD applicability. Aircraft operators, inspectors, and persons performing maintenance are reminded of their responsibility under Sections 39.3, 43.11, and 43.13 of the Federal Aviation Regulations, respectively, to assure compliance with all applicable AD's.

* * * * * * * * * *

ROTORCRAFT, GLIDERS, BALLOONS, AIRSHIPS

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
ADAMS BALLOON LOFT, INC.						
(See WALZ)						
AER-PEGASO S.p.A						
(See SOCIETE C.A.R.M.A.M., S.O.C.A.T.A.)						
M.100S	G6EU	69-24-01		Horizontal Stabilizer	Bk	1
		75-17-18		Aileron control	Bk	1
		75-23-02		Aileron spars	Bk	1
		76-05-09		Rudder hinge pin	Bk	1
AERO RESOURCES, INC.						
(Formerly McCULLOCH)						
J2	H6WE	72-07-01		Rotor clearance and collective stick	Bk	1
AEROMOT-INDUSTRIA MECANICO METALURGICA LTDA						
AMT-100	TG00004AT	98-05-05		MLG attaching bolts, nuts	Bk	3
		2001-23-16		Bending/warping in the main landing gear lever	Bk	4
AMT-200	TG00004AT	97-15-07		Forward horizontal stabilizer front bolt	Bk	3
		98-05-05		MLG attaching bolts, nuts	Bk	3
		98-15-19		Flexible hoses of engine lubricating system	Bk	3
		2001-23-16		Bending/warping in the main landing gear lever	Bk	4
AERODYNE SYSTEMS ENGINEERING LTD						
(Formerly Texas Helicopter Corporation)						
(See McCreary, Gifton)						
AEROSPATIALE, Societe Nationale Industrielle Aerospatiale						
(See EUROCOPTER FRANCE.)						
AEROSTAR INTERNATIONAL						
S-40A	A15CE	75-19-04		Valve system	Bk	1
		81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		93-16-13		Fuel Hose	Bk	3
S-49A	A15CE	90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S-50A	A15CE	75-19-04		Valve system	Bk	1
		80-01-03		Parachute top release	Bk	2
		81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
S-52A	A15CE	90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
S-55A	A15CE	75-19-04		Valve system	Bk	1
		80-01-03		Parachute top release	Bk	2
		81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
S-57A	A15CE	90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
S-57S	A15CE	93-16-13		Fuel Hose	Bk	3
S-60A	A15CE	75-19-04		Valve system	Bk	1
		80-01-03		Parachute top release	Bk	2
		81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
S-60S	A15CE	93-16-13		Fuel Hose	Bk	3
S-66A	A15CE	81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
S-71A	A15CE	93-16-13		Fuel Hose	Bk	3
S-77A	A15CE	86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
78C	A15CE	93-16-13		Fuel Hose	Bk	3
90C	A15CE	93-16-13		Fuel Hose	Bk	3
CTS	A15CE	93-16-13		Fuel Hose	Bk	3
QUBE-80	A15CE	93-16-13		Fuel Hose	Bk	3
RX-6	A15CE	75-19-04		Valve system	Bk	1
		76-03-04		Gondola liner	Bk	1
		81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
RX-7	A15CE	81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
RX-8	A15CE	90-25-09		Suspension cables	Bk	3
		93-16-13		Fuel Hose	Bk	3
RXS-8	A15CE	93-16-13		Fuel Hose	Bk	3
110P	A15CE	93-16-13		Fuel Hose	Bk	3
SPII	A15CE	93-16-13		Fuel Hose	Bk	3
W100LB	A15CE	81-21-02	R1	Hook and pile fastener tape	Bk	2
		86-10-11	R1	Fuel supply hose assemblies	Bk	2
		93-16-13		Fuel Hose	Bk	3
AEROTECHNIK S.R.O.						
L 13 SEH VIVAT	G72EU	2000-20-12		Tail-fuselage hinge	Bk	4
AGUSTA, Costruzioni Aeronautiche Giovanni *(See Agusta SPA)*						
AGUSTA S.P.A. (Formerly SIAI MARCHETTI, S.P.A., *AGUSTA, COSTRUZIONI AERONAUTICHE GIOVANNI, CAPRONI VIZZOLA)* *(For ADs in Book 1 see Agusta Costruzioni Aeronaautiche Giovanni)*						
Calif A-21 Series *(TC G29EU - for ADs in Bk 1 see Caproni Vizzola)*	G29EU	75-18-02		Aileron flutter	Bk	1
A109 Series	H7EU	78-24-02		Main transmission	Bk	1
A109	H7EU	79-02-04		Tail rotor drive shaft	Bk	1
		81-02-04		Main blade pitch control	Bk	2
A109A Series	H7EU	80-15-12		Main rotor mast bearing	Bk	2
		80-16-02		Nose LG mount assembly	Bk	2
		80-22-09		Engine mount structure	Bk	2
		81-02-04		Main blade pitch control	Bk	2
		81-13-11		Main rotor blades	Bk	2
		82-01-06		Engine mount central leg	Bk	2
		82-04-04		Tail boom assemblies	Bk	2
		84-13-06	R2	Tail rotor blade grip	Bk	2
		94-22-04		Main rotor retention straps	Bk	3
A109A	H7EU	77-14-01		Main rotor flaps	Bk	1
		79-02-04		Tail rotor drive shaft	Bk	1
		79-04-02		Tailboom attachments	Bk	1
		79-19-07	R1	Tail rotor gear box	Bk	1
		80-07-10		Engine operating condition	Bk	2
		81-20-03		Drive shaft support bearings	Bk	2
		91-08-05		Main rotor blade	Bk	3
		95-13-10		Vertical fin attachment	Bk	3
		99-27-12		Inspect blade for cracks *(see Bk 4 for paper copy)*	Bk	3
		2000-08-02		Transmission Gleason Crown	Bk	4
		2000-15-20		Main rotor blade	Bk	4
A109AII Series	H7EU	94-22-04		Main rotor retention straps	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
A109AII	H7EU	84-13-06	R2	Tail rotor blade grip	Bk	2
		91-08-05		Main rotor blade	Bk	3
		95-13-10		Vertical fin attachment	Bk	3
		99-27-12		Inspect blade for cracks *(see Bk 4 for paper copy)*	Bk	3
		2000-08-02		Transmission Gleason Crown	Bk	4
		2000-15-20		Main rotor blade	Bk	4
A109C	H7EU	95-13-10		Vertical fin attachment	Bk	3
		98-13-28		Inspect tail rotor blade	Bk	3
		98-24-22		Grip assemblies	Bk	3
		2000-08-02		Transmission Gleason Crown	Bk	4
		2000-08-05		Main rotor pitch control link assy	Bk	4
		2001-24-07	R1	Failure of a blade tip cap	Bk	4
A109E	H7EU	2000-17-52		Main rotor rotating scissors assembly	Bk	4
		2000-20-06		Main transmission aft support fitting	Bk	4
		2000-25-09		Engine exhaust ejector	Bk	4
		2000-26-11		Tail rotor blade	Bk	4
		2001-17-16		Blade & subsequent loss of control of the heli.	Bk	4
		2001-20-04		Accidental opening of passenger compart. Door	Bk	4
		2001-24-07	R1	Failure of a blade tip cap	Bk	4
		2002-21-12		Main transmission assembly and supports	Bk	4
		2002-25-51		Tail rotor blade	Bk	4
		2003-26-04		Rod-end assembly	Bk	4
		2004-02-03		Door levers, links, and hardware	Bk	4
		2004-11-06		Windshield wiper electrical system	Bk	4
		2005-09-07		Fitting attachment bolt	BW	05-10
		2005-12-01		Overhead panel assembly	BW	05-12
A109K2	H7EU	97-26-09		Inspect gleason Crown for cracks	Bk	3
		98-13-28		Inspect tail rotor blade	Bk	3
		99-04-20		Breeze-Eastern rescue hoist cable	Bk	3
		2000-08-05		Main rotor pitch control link assy	Bk	4
		2000-20-06		Main transmission aft support fitting	Bk	4
		2001-24-07	R1	Failure of a blade tip cap	Bk	4
		2003-12-13		Blades	Bk	4
		2004-15-21		Tail rotor trunnion assembly	Bk	4
AB412	H79EU	98-07-10		Tail rotor blades	Bk	3
		99-26-14		Main rotor yoke	Bk	3
		2000-02-09		Rescue hoist hook assembly retention pin	Bk	4
		2001-09-11		Damage to the tail rotor yoke	Bk	4
		2001-17-33		Wire chafing, inadvertent firing of the cable cutter cartridge, loss of a hoist hook etc.	Bk	4
		2005-13-17		Tail rotor blade (blade) forward tip	BW	05-13
A119		2001-22-51		Tail rotor blade	Bk	4
		2002-21-04		Placard - Airspeed	Bk	4
		2005-09-06		Main transmission support fitting (fitting) attachment bolt (bolt)	BW	05-10
AB139	R00002RD	2006-17-51				
AIR & SPACE MFG., INC.						
18A	1H17	65-19-01		Rotor blade retention	Bk	1
		66-08-01		Lateral control system	Bk	1
		67-14-01		Rotor blade modification	Bk	1

AIRCRAFT INDUSTRIES
(Formerly LET AERONAUTICAL WORKS, G71EU)
(Formerly LETECKE ZAVODIY A.S., G24EU AND G60EU)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
(For ADs in Book 1 and 2 see LET, n.p.)						
L-33 SOLO	G71EU	99-14-02		Main wing attachment and wing spar root pins	Bk	3
Blanik L-13	G24EU	77-15-05		Fin top ribs	Bk	1
		78-23-14	R1	Tow release system	Bk	1
		80-16-03		Horizontal stabilizer	Bk	2
		99-19-33		Elevator drive bellcrank	Bk	3
		2000-20-11		Tail-fuselage hinge	Bk	4
		2005-08-14		Original control bridge	BW	05-09
L 23 Super-Blanik	G60EU	2004-25-17		Elevator rocker lever	Bk	4
AIRSHIP INDUSTRIES						
(See SLINGSBY AVIATION)						
ARROW FALCON EXPORTERS, INC.						
(Formerly Utah State University)						
(For ADs in Book 3 See Utah State University)						
UH-1H	R00007DE	99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
AVIAN BALLOONS						
Falcon II	A2NW	84-15-01		Placard -tethered flight	Bk	2
Skyhawk	A3NW	84-15-01		Placard -tethered flight	Bk	2
Sparrow	A3NM	84-15-01		Placard -tethered flight	Bk	2
BALLONBAU WORNER GMBH						
K-630/1-Stu	B4EU	2002-17-04		PVC tubes on steelwire loops of basket	Bk	4
BARRY AVIATION, LLC						
KR-03A Peregrine	G56EU	2002-16-17		Horizontal stabilizer attchment fittings	Bk	4
BELL HELICOPTER TEXTRON						
***(See CA. DEPT. OF FORESTRY, CONTINENTAL COPTERS, GARLICK, HAWKEYE ROTOR & WING, HAWKINS & POWERS, INTERNATIONAL, SMITH HELICOPTER, SOUTHERN AERO, SOUTHERN HELI., UNC HELI., U.S. HELI., WESTERN INTERNATIONAL, WILLIAMS HELI., SCOTT PAPER, SW FLORIDA, TERYJON, TEXAS, WILCO)*						
AH-1	--	96-12-26		Clean and inspect tail rotor blade	Bk	3
***OH-13 Models	H7SW,	80-10-04	R1	Tail rotor blades	Bk	2
	H5SW	80-21-09	R1	Tail rotor pitch link	Bk	2
	H2CE	81-04-03		Tail rotor drive assembly	Bk	2
		2002-03-16		Main rotor blade grips	Bk	4
	H5SW	2005-21-04		Weld assembly scissors bracket	BW	05-22
***HH-1K	H5NM	96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
***UH-1 Series	H1RM	83-03-03		Tail boom skin joint	Bk	2
	H2NM	84-18-03	R1	Clevis inspection	Bk	2
	H3SO	96-12-26		Clean and inspect tail rotor blade	Bk	3
	H13WE					
	H5SO					
	H3NM					
***UH-1E	H5NM	88-08-01		Rod end bearing assy.	Bk	2
	H9NM	88-25-05		Tail rotor grip assembly	Bk	2
	H8NM	89-08-06		Transmission internal sump oil filter	Bk	2
	H7SO	90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***UH-1H	H3SO	89-20-12		Tail rotor hub assembly	Bk	2
	H13WE	90-03-10		Tail rotor grip	Bk	3
	H15NM	90-10-05		Tail rotor gearbox	Bk	3
	R00007DE	92-23-01		Main rotor pillow blocks	Bk	3
	H7SO	94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***UH-1L	H5NM	88-08-01		Rod end bearing assy.	Bk	2
	H4NM	88-25-05		Tail rotor grip assembly	Bk	2
	H7SO	89-08-06		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
***TH-1L	H5NM	88-08-01		Rod end bearing assy.	Bk	2
	H4NM	88-25-05		Tail rotor grip assembly	Bk	2
	H7SO	89-08-06		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***UH-1A	H3SO	89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***UH-1B	H3NM	83-20-01		Tail rotor hub assembly	Bk	2
	H13WE	88-25-05		Tail rotor grip assembly	Bk	2
	H3SO	89-08-06		Transmission internal sump oil filter	Bk	2
	H5SO	90-03-10		Tail rotor grip	Bk	3
	R00012AT	90-10-05		Tail rotor gearbox	Bk	3
	H7SO	92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
***UH-1F	H2NM	83-03-03		Tail boom skin joint	Bk	2
	H11SW	84-18-03	R1	Clevis inspection	Bk	2
	H7NE	88-25-05		Tail rotor grip assembly	Bk	2
	H12NM	89-08-06		Transmission internal sump oil filter	Bk	2
	R0008AT	90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***UH-1P	H12NM	94-22-09		Tail rotor driveshaft	Bk	3
	R0008AT	95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***TH-1F	H12NM	94-22-09		Tail rotor driveshaft	Bk	3
	R00008AT	95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		
***SW204, SW204HP, SW205, SW 205A-1	H6SO	99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
		2006-19-05		Tail rotor (T/R) slider		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
47 Series	H-1	48-13-02		Fuel pump rocker pin	Bk	1
		51-27-01		Engine mount replacement	Bk	1
		52-01-06		Tail boom spoiler	Bk	1
		52-05-03		Engine mount safety strap	Bk	1
		52-21-01		Lord mount guards	Bk	1
		52-28-03		Tail rotor gearbox shaft	Bk	1
		55-16-01		Tail rotor hub fillet	Bk	1
		56-05-01		Tail rotor drive shafts	Bk	1
		56-15-02		Swashplate control ring	Bk	1
		56-25-02		Tail rotor pitch bearings	Bk	1
		57-07-02		Rotor hub equalizer link	Bk	1
		57-08-01		Tail rotor drive shafts	Bk	1
		58-26-02		M-S MA4-5AA carburetor	Bk	1
		59-05-01		Tail rotor blade inspection	Bk	1
		61-22-01		Pitch link rod end bearing	Bk	1
		62-23-02		Main rotor mast thrust bearing	Bk	1
		62-27-02		Wood tail rotor blades	Bk	1
		65-04-01		Freewheeling clutch	Bk	1
		70-08-02		Tail rotor drive shaft	Bk	1
		70-10-08		Tail rotor grips	Bk	1
		73-19-04		Main rotor blade grip	Bk	1
		74-07-01		Main rotor control tube assy	Bk	1
		74-08-02		Main control stabilizer bar assy	Bk	1
		77-21-01		Tail rotor gear boxes	Bk	1
		78-03-01		Hopper support bracket (STC SH357SW)	Bk	1
		80-10-04	R1	Tail rotor blades	Bk	2
		80-21-09	R1	Tail rotor pitch link	Bk	2
		81-04-03		Tail rotor drive assembly	Bk	2
		85-08-03		Tail rotor blade assy.	Bk	2
47B All Models	H-1	47-32-07		Manifold pipe chafing	Bk	1
		47-41-05		Gimbl ring bearing seals	Bk	1
		47-41-06		Main rotor blade	Bk	1
		47-41-07		Bungee spring jumper	Bk	1
		47-41-08		Stabilizer bar mixing levers	Bk	1
		47-51-11		Pinion gear bearings	Bk	1
		48-02-01		Tail rotor drive shaft	Bk	1
		48-03-06		Bushings installation	Bk	1
		48-10-02		Rotor blade rework	Bk	1
		48-11-05		Rotor drag brace	Bk	1
		48-12-05		Shear screw replacement	Bk	1
		48-19-01		Damper support frames	Bk	1
		49-47-02		Tail rotor drive shaft	Bk	1
		49-52-02		Main rotor hub inspection	Bk	1
		50-38-02		Cooling fan rework	Bk	1
		51-26-01		Tail rotor reinforcement	Bk	1
		51-29-01		Tail rotor gearbox shaft	Bk	1
		52-01-01		Blade grip adapter locks	Bk	1
		52-01-02		Horns and drag brace fittings	Bk	1
		52-01-03		Damper lever and link	Bk	1
		52-01-05		Rotor blade grip retaining bolt	Bk	1
		54-24-01		Antitorque pedal stops	Bk	1
		55-05-01		Pitch control link	Bk	1
		56-20-03		Tail rotor hub bolts	Bk	1
		58-23-01		Tail rotor pitch change bearings	Bk	1
		60-10-01		Scissor lever bolts	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
47B	H-1	47-32-01	Stabilizer damper clamp	Bk	1
		47-32-02	Ballast installation	Bk	1
		47-32-03	Tail rotor control pedal	Bk	1
		47-32-04	Antitorque rotor blades placard	Bk	1
		47-32-05	Main rotor mast spinner	Bk	1
		47-32-06	Rotor hub pillow blocks	Bk	1
		47-32-08	Stabilizer bar dampers	Bk	1
		47-32-09	Horizontal stabilizer	Bk	1
		47-32-10	Rotor mast assy replacement	Bk	1
		47-32-11	Antenna mast support	Bk	1
		47-32-12	Control disc links	Bk	1
		47-32-13	Tail rotor rivet replacement	Bk	1
		47-32-14	Engine mount clamps	Bk	1
		47-41-02	Oil line supports	Bk	1
		47-41-03	Fuel line replacement	Bk	1
		47-41-04	Main rotor mast plug	Bk	1
		48-19-01	Damper support frames	Bk	1
		49-47-02	Tail rotor drive shaft	Bk	1
		49-52-02	Main rotor hub inspection	Bk	1
		50-38-02	Cooling fan rework	Bk	1
		52-28-04	Tail rotor pinion shaft	Bk	1
		57-12-04	Tail rotor blade inspection	Bk	1
		58-23-01	Tail rotor pitch change bearings	Bk	1
		60-10-01	Scissor lever bolts	Bk	1
		70-11-04	Wood main rotor blades	Bk	1
		73-19-02	Tail rotor yoke	Bk	1
		75-18-06	Tail rotor pitch control	Bk	1
		76-12-01	Tail rotor hub bolt	Bk	1
		76-12-02	Tail rotor yoke	Bk	1
		85-15-04	Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
47B3	H-1	47-32-08	Stabilizer bar dampers	Bk	1
		47-32-09	Horizontal stabilizer	Bk	1
		47-32-10	Rotor mast assy replacement	Bk	1
		47-32-11	Antenna mast support	Bk	1
		47-32-12	Control disc links	Bk	1
		47-32-13	Tail rotor rivet replacement	Bk	1
		47-41-02	Oil line supports	Bk	1
		47-41-03	Fuel line replacement	Bk	1
		47-41-04	Main rotor mast plug	Bk	1
		48-19-01	Damper support frames	Bk	1
		49-47-02	Tail rotor drive shaft	Bk	1
		49-52-02	Main rotor hub inspection	Bk	1
		50-38-02	Cooling for rework	Bk	1
		51-26-01	Tail rotor reinforcement	Bk	1
		51-29-01	Tail rotor gearbox shaft	Bk	1
		52-01-01	Blade grip adapter locks	Bk	1
		52-01-02	Horn and drag brace fittings	Bk	1
		52-01-03	Damper lever and link	Bk	1
		52-01-05	Rotor blade grip retaining bolt	Bk	1
		52-28-04	Tail rotor pinion shaft	Bk	1
		54-24-01	Antitorque pedal stops	Bk	1
		55-05-01	Pitch control link	Bk	1
		56-20-03	Tail rotor hub bolts	Bk	1
		57-08-02	Parker check valve	Bk	1
		57-12-04	Tail rotor blade inspection	Bk	1
		58-23-01	Tail rotor pitch change bearings	Bk	1
		60-10-01	Scissor lever bolts	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
47B3 continued		70-11-04	Wood main rotor blades	Bk	1
		73-19-02	Tail rotor yoke	Bk	1
		75-18-06	Tail rotor pitch control	Bk	1
		76-12-01	Tail rotor hub bolt	Bk	1
		76-12-02	Tail rotor yoke	Bk	1
		85-15-04	Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
47D	H-1	48-10-02	Rotor blade rework	Bk	1
(USAF H-13B)		48-12-05	Shear screw replacement	Bk	1
		48-19-01	Damper support frames	Bk	1
		49-47-02	Tail rotor drive shaft	Bk	1
		49-52-02	Main rotor hub inspection	Bk	1
		50-38-02	Cooling fan rework	Bk	1
		51-26-01	Tail rotor reinforcement	Bk	1
		51-29-01	Tail rotor gearbox shaft	Bk	1
		52-01-01	Blade grip adapter locks	Bk	1
		52-01-02	Horn and drag brace fittings	Bk	1
		52-01-03	Damper lever and link	Bk	1
		52-01-05	Rotor blade grip retaining bolt	Bk	1
		52-28-04	Tail rotor pinion shaft	Bk	1
		54-24-01	Antitorque pedal stops	Bk	1
		55-05-01	Pitch control link	Bk	1
		56-20-03	Tail rotor hub bolts	Bk	1
		57-08-02	Parker check valve	Bk	1
		57-12-04	Tail rotor blade inspection	Bk	1
		58-23-01	Tail rotor pitch change bearings	Bk	1
		60-10-01	Scissor lever bolts	Bk	1
		70-11-04	Wood main rotor blades	Bk	1
		70-14-02	Tail rotor hub assy bolt	Bk	1
		73-19-02	Tail rotor yoke	Bk	1
		75-18-06	Tail rotor pitch control	Bk	1
		76-12-01	Tail rotor hub bolt	Bk	1
		76-12-02	Tail rotor yoke	Bk	1
		85-15-04	Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
47D1	H-1	49-34-02	Ventral fin inspection	Bk	1
(USAF H-13D, -13E,		49-47-02	Tail rotor drive shaft	Bk	1
Navy HTL-4, -5)		49-52-02	Main rotor hub inspection	Bk	1
		50-06-01	Ventral fin replacement	Bk	1
		50-38-02	Cooling fan rework	Bk	1
		51-26-01	Tail rotor reinforcement	Bk	1
		51-29-01	Tail rotor gearbox shaft	Bk	1
		52-01-01	Blade grip adapter locks	Bk	1
		52-01-07	Engine cooling fan	Bk	1
		52-07-01	Loading decal	Bk	1
		52-28-04	Tail rotor pinion shaft	Bk	1
		53-01-01	Gearbox mounting sleeve	Bk	1
		54-24-01	Antitorque pedal stops	Bk	1
		55-05-01	Pitch control link	Bk	1
		56-05-01	Tail rotor drive shafts	Bk	1
		56-20-03	Tail rotor hub bolts	Bk	1
		57-08-02	Parker check valve	Bk	1
		57-12-04	Tail rotor blade inspection	Bk	1
		58-23-01	Tail rotor pitch change bearings	Bk	1
		60-10-01	Scissor lever bolts	Bk	1
		70-11-04	Wood main rotor blades	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
47D1 continued		70-14-01		Tail rotor pitch	Bk	1
(USAF H-13D, -13E,		70-14-02		Tail rotor hub assy bolt	Bk	1
Navy HTL-4, -5)		73-19-02		Tail rotor yoke	Bk	1
		75-18-06		Tail rotor pitch control	Bk	1
		76-12-01		Tail rotor hub bolt	Bk	1
		76-12-02		Tail rotor yoke	Bk	1
		85-15-04		Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		96-06-12		Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09		Stabilizer bar damper link assembly	Bk	3
		2001-17-17		Main rotor blade grip	Bk	4
		2005-21-04		Weld assembly scissors bracket	BW 05-22	
47E	H-1	54-24-01		Antitorque pedal stops	Bk	1
(Navy HTL-3)		60-10-01		Scissor lever bolts	Bk	1
		73-19-02		Tail rotor yoke	Bk	1
		75-18-06		Tail rotor pitch control	Bk	1
		76-12-02		Tail rotor yoke	Bk	1
		85-15-04		Tail rotor blade yoke P/N 74-641-057-9	Bk	2
47G Series	H-1, 2H3	79-23-07		Soloy conversion per STC SH657NW	Bk	1
(OH-13, TH-13T)		80-10-04	R1	Tail rotor blades	Bk	2
		80-21-09	R1	Tail rotor pitch link	Bk	2
		80-23-02		See Soloy Conversions, Appliances	Bk	2
		81-04-03		Tail rotor drive assembly	Bk	2
47G	H-1	54-24-01		Antitorque pedal stops	Bk	1
(USAF H-13G,		55-05-01		Pitch control link	Bk	1
Navy HTL-6)		55-14-01		Bearing hanger support bracket	Bk	1
		55-25-01		Bellcrank attachment bolt	Bk	1
		56-01-01		Ventral fin support	Bk	1
		56-05-01		Tail rotor drive shafts	Bk	1
		56-20-03		Tail rotor hub bolts	Bk	1
		56-21-01		Hydraulic boost cylinders	Bk	1
		57-08-02		Parker check valve	Bk	1
		57-12-04		Tail rotor blade inspection	Bk	1
		58-23-01		Tail rotor pitch change bearings	Bk	1
		60-10-01		Scissor lever bolts	Bk	1
		70-11-04		Wood main rotor blades	Bk	1
		70-14-01		Tail rotor pitch	Bk	1
		70-14-02		Tail rotor hub assy bolt	Bk	1
		72-02-05		Control rod assembly	Bk	1
		73-19-02		Tail rotor yoke	Bk	1
		75-18-06		Tail rotor pitch control	Bk	1
		76-12-01		Tail rotor hub bolt	Bk	1
		76-12-02		Tail rotor yoke	Bk	1
		85-15-04		Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		96-06-12		Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09		Stabilizer bar damper link assembly	Bk	3
		2001-17-17		Main rotor blade grip	Bk	4
		2005-21-04		Weld assembly scissors bracket	BW 05-22	
47G-2	H-1	56-01-01		Ventral fin support	Bk	1
(USAF H-13H)		56-05-01		Tail rotor drive shafts	Bk	1
		56-20-03		Tail rotor hub bolts	Bk	1
		56-21-01		Hydraulic boost cylinders	Bk	1
		57-12-04		Tail rotor blade inspection	Bk	1
		58-23-01		Tail rotor pitch change bearings	Bk	1
		58-26-01		Engine cooling fin index plate assy	Bk	1
		60-10-01		Scissor lever bolts	Bk	1
		70-11-04		Wood main rotor blades	Bk	1
		70-14-01		Tail rotor pitch	Bk	1
		70-14-02		Tail rotor hub assy bolt	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
47G-2 continued		72-02-05	Control rod assembly	Bk	1
(USAF H-13H)		73-19-02	Tail rotor yoke	Bk	1
		75-18-06	Tail rotor pitch control	Bk	1
		76-12-01	Tail rotor hub bolt	Bk	1
		76-12-02	Tail rotor yoke	Bk	1
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22
47G-2A	2H3	61-14-02	Float cross tube	Bk	1
		72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22
47G-2A-1	2H3	72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22
47G-3	2H3	61-14-02	Float cross tube	Bk	1
		72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		85-15-04	Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22
47G-3B, -3B-1, -2, -2A	2H3	72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22
47G-4, -4A	2H3	72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22
47G-5, -5A	2H3	72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
		2005-21-04	Weld assembly scissors bracket	BW	05-22

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
47H-1	H-1	56-05-01	Tail rotor drive shafts	Bk	1
		56-15-01	Antitorque control system	Bk	1
		56-15-03	Elevator control system	Bk	1
		56-20-03	Tail rotor hub bolts	Bk	1
		56-21-01	Hydraulic boost cylinders	Bk	1
		57-07-01	Elevator inspection and rework	Bk	1
		57-08-02	Parker check valve	Bk	1
		57-12-01	Elevator control alignment	Bk	1
		57-12-02	Tail boom attach fittings	Bk	1
47H-1 continued		57-12-04	Tail rotor blade inspection	Bk	1
		58-23-01	Tail rotor pitch change bearing	Bk	1
		60-10-01	Scissor lever bolts	Bk	1
		70-11-04	Wood main rotor blades	Bk	1
		70-14-01	Tail rotor pitch	Bk	1
		70-14-02	Tail rotor hub assy bolt	Bk	1
		73-19-02	Tail rotor yoke	Bk	1
		75-18-06	Tail rotor pitch control	Bk	1
		76-12-01	Tail rotor hub bolt	Bk	1
		76-12-02	Tail rotor yoke	Bk	1
		85-15-04	Tail rotor blade yoke P/N 74-641-057-9	Bk	2
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
47J Series	2H1	57-12-03	Engine sprag spindle	Bk	1
		57-12-04	Tail rotor blade inspection	Bk	1
		58-02-01	Rotor blade bond separation	Bk	1
		58-09-01	Main rotor blade inspection	Bk	1
		58-17-01	Rotor counterweight bracket	Bk	1
		58-26-01	Engine cooling fan index plate assy	Bk	1
		60-10-01	Scissor lever bolts	Bk	1
		61-14-02	Float cross tube	Bk	1
		62-10-01	Elevator modification	Bk	1
		72-02-05	Control rod assembly	Bk	1
47J	2H1	85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
47J2	2H1	61-03-01	Pinion gear	Bk	1
		61-14-02	Float cross tube	Bk	1
		62-10-01	Elevator modifications	Bk	1
		72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4
47J-2A	2H1	62-10-01	Elevator modification	Bk	1
		72-02-05	Control rod assembly	Bk	1
		85-02-06	AN/NAS standard bolts	Bk	2
		91-20-10	Main rotor grip	Bk	3
		96-06-12	Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09	Stabilizer bar damper link assembly	Bk	3
		2001-17-17	Main rotor blade grip	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
47K	2H1	60-10-01		Scissor lever bolts	Bk	1
		76-21-05		Tubular spar at elevators	Bk	1
		85-02-06		AN/NAS standard bolts	Bk	2
		96-06-12		Inspect tail rotor blade & abrasion strip	Bk	3
		98-07-09		Stabilizer bar damper link assembly	Bk	3
		2001-17-17		Main rotor blade grip	Bk	4
204 Series	H1SW	81-19-02		Main rotor yoke	Bk	2
204B	H1SW	67-06-01		Tail rotor blades	Bk	1
		67-24-01		Sliders on tail rotor assy	Bk	1
		69-15-07		Float kit tube	Bk	1
		70-06-02		Tail rotor grip assy	Bk	1
		73-17-04		Tail rotor grips	Bk	1
		74-23-02		Tail rotor pitch	Bk	1
		75-26-03		Emergency exit handle	Bk	1
		75-26-05		Main rotor blades	Bk	1
		76-02-06		Main rotor blades	Bk	1
		76-12-07		Tail rotor chains	Bk	1
		77-17-05		Emergency exit latch pin	Bk	1
		78-20-07		Shoulder radius fitting	Bk	1
		78-21-02		External load link assembly	Bk	1
		79-20-05		Main rotor hub assembly	Bk	1
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-05		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-01-11		Tail rotor gearbox bearing set	Bk	3
		90-03-10		Tail rotor grip	Bk	3
		92-07-08		Swash plate support assembly	Bk	3
		92-13-10		Tail rotor driveshaft hanger bearing	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		93-17-12		Main rotor transmission lower planetary spider	Bk	3
		95-10-07		Tail rotor control system	Bk	3
		96-12-25		Tail rotor blade	Bk	3
		99-17-03		Tailboom vertical fin spar	Bk	3
		2000-15-52		Main rotor mast or trunnion	Bk	4
		2001-02-11		Prevent failure of the main rotor mast assy	Bk	4
		2002-09-51		Tail rotor grip	Bk	4
		2002-22-14		TT Strap	Bk	4
		2003-01-04		Upper and lower tang of main rotor blade	Bk	4
205 Series	H1SW	81-19-02		Main rotor yoke	Bk	2
		86-17-10	L	T/R hub assembly (See 90-03-09)	Bk	2
205A	H1SW	69-15-07		Float kit tube	Bk	1
		70-06-02		Tail rotor grip assy	Bk	1
		71-21-02		Tail fin and boom	Bk	1
		76-10-01		Tail boom	Bk	1
		78-21-02		External load link assembly	Bk	1
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-05		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-09		Tail rotor	Bk	3
		90-03-10		Tail rotor grip	Bk	3
		92-07-08		Swashplate support assembly	Bk	3
		92-13-10		Tail rotor driveshaft hanger bearing	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		93-17-12		Main rotor transmission lower planetary spider	Bk	3
		94-18-09		Main transmission lower planetary spider	Bk	3
		95-10-07		Tail rotor control system	Bk	3
		99-17-03		Tailboom vertical fin spar fin spar	Bk	3
		2000-15-52		Main rotor mast or trunnion	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
205A continued		2002-09-04		Tip weight retention block	Bk	4
		2002-09-51		Tail rotor grip	Bk	4
		2002-22-14		TT Strap	Bk	4
		2003-01-04		Upper and lower tang of main rotor blade	Bk	4
205A-1	H1SW	69-15-07		Float kit tube	Bk	1
		70-06-02		Tail rotor grip assy	Bk	1
		71-21-02		Tail fin and boom	Bk	1
		73-16-03		Landing gear cross tubes	Bk	1
		73-17-04		Tail rotor grips	Bk	1
		74-02-01		Tail rotor trunnion bearings	Bk	1
		74-23-02		Tail rotor pitch	Bk	1
		75-26-03		Emergency exit handle	Bk	1
		75-26-05		Main rotor blades	Bk	1
		76-02-06		Main rotor blades	Bk	1
		76-06-02		Fire extinguisher circuit	Bk	1
		76-10-01		Tail boom	Bk	1
		76-12-07		Tail rotor chains	Bk	1
		76-14-03		Cross tube assemblies	Bk	1
		77-10-07		Engine-to-transmission assy	Bk	1
		77-17-03		Tail rotor blade pitch horn	Bk	1
		77-17-05		Emergency exit latch pin	Bk	1
		78-14-07		Skid landing gear	Bk	1
		78-20-07		Shoulder radius fitting	Bk	1
		78-21-02		External load link assembly	Bk	1
		79-20-05		Main rotor hub assembly	Bk	1
		80-03-07		Fuselage main beams splice	Bk	2
		80-21-05		Landing gear cross tubes	Bk	2
		86-17-10	L	T/R hub assembly (See 90-03-09)	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-05		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-09		Tail rotor	Bk	3
		90-03-10		Tail rotor grip	Bk	3
		92-07-08		Swashplate support assembly	Bk	3
		92-13-10		Tail rotor driveshaft hanger bearing	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		92-27-21		Tail rotor driveshaft	Bk	3
		93-17-12		Main rotor transmission lower planetary spider	Bk	3
		94-18-09		Main transmission lower planetary spider	Bk	3
		95-10-07		Tail rotor control system	Bk	3
		98-11-14		Tail rotor yoke assembly	Bk	3
		99-17-03		Tailboom vertical fin spar fin spar	Bk	3
		99-18-02		Vertical fin spar cap	Bk	3
		2000-15-52		Main rotor mast or trunnion	Bk	4
		2001-08-04		Actuator piston unthreading from its rod end	Bk	4
		2001-13-01		failure of the tail rotor counterweight bellcrank	Bk	4
		2002-09-04		Tip weight retention block	Bk	4
		2002-09-51		Tail rotor grip	Bk	4
		2002-22-14		TT Strap	Bk	4
		2003-01-04		Upper and lower tang of main rotor blade	Bk	4
205B	H1SW	92-07-08		Swashplate support assembly	Bk	3
		92-13-10		Tail rotor driveshaft hanger bearing	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		92-27-21		Tail rotor driveshaft	Bk	3
		93-17-12		Main rotor transmission lower planetary spider	Bk	3
		94-18-09		Main transmission lower planetary spider	Bk	3
		98-11-14		Tail rotor yoke assembly	Bk	3
		99-18-02		Vertical fin spar cap	Bk	3
		2000-15-52		Main rotor mast or trunnion	Bk	4
		2001-08-04		Actuator piston unthreading from its rod end	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
205B continued		2001-13-01		failure of the tail rotor counterweight bellcrank	Bk	4
		2002-09-04		Tip weight retention block	Bk	4
		2002-09-51		Tail rotor grip	Bk	4
		2002-22-14		TT Strap	Bk	4
		2003-01-04		Upper and lower tang of main rotor blade	Bk	4
206	H2SW	82-16-12		Chadwick C-22 Auxilary Fuel System	Bk	2
206A	H2SW	67-22-02		Grounding of fuel boost pumps	Bk	1
		68-04-02		Failure of exhaust stack clamps	Bk	1
		69-11-02		Cyclic control system	Bk	1
		69-11-04		Control pedal force	Bk	1
		69-12-07		Magnesium tail boom	Bk	1
		69-15-02		Magnesium cyclic bellcrank support	Bk	1
		69-16-02		Hydraulic actuators	Bk	1
		69-17-02		Cyclic control system	Bk	1
		70-07-03		Planetary gear support spiders	Bk	1
		70-14-05		Voltage regulator	Bk	1
		70-14-06		Fire wall to compressor seal	Bk	1
		71-08-03		Partial separation kit	Bk	1
		71-18-04		Main rotor blade spar	Bk	1
		72-19-01		Main rotor retention straps	Bk	1
		73-08-03		Pylon support link	Bk	1
		73-12-01		Vertical fin skin cracks	Bk	1
		73-19-08		Strap fittings and pins	Bk	1
		73-19-09		Pitch link assemblies	Bk	1
		73-21-03		Vertical fin support forgings	Bk	1
		74-08-12		Tail boom skin splice	Bk	1
		74-19-03		Horizontal stabilizer ribs	Bk	1
		74-24-01		Main rotor blade grips	Bk	1
		74-25-10		Rotor brake disc	Bk	1
		75-06-03		Pitch link assembly	Bk	1
		75-06-10		Cabin roof straps	Bk	1
		75-09-09		Tail rotor control tube	Bk	1
		75-18-07		Rotor blade pillow block assys	Bk	1
		76-04-09		Main rotor hub yokes	Bk	1
		76-15-03		Replacement straps	Bk	1
		77-10-06		Tail rotor drive shaft	Bk	1
		78-11-02	R1	Rotor blade straps	Bk	1
		78-16-01		Tail rotor drive shaft	Bk	1
		79-10-01		External load carrying devices	Bk	1
		80-17-05		Tail rotor blades	Bk	2
		80-18-04	R1	Main rotor trunnion	Bk	2
		81-18-01	R1	Main rotor trunnions *(see Bk 4 for paper copy)*	Bk	2
		85-25-01		Cyclic control stick	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		86-24-01		T/R assembly	Bk	2
		87-10-11		Main rotor mast assy	Bk	2
		88-23-03		Tail rotor yoke assembly	Bk	2
		89-10-11	R1	RFM limitations	Bk	2
		89-22-01	R1	Main rotor blades	Bk	2
		90-21-03		Tail rotor blade assembly	Bk	3
		91-03-12		Emergency float bags	Bk	3
		92-01-05		Main rotor blades	Bk	3
		92-06-12		Transmission failure	Bk	3
		92-09-07		Vertical fin supports	Bk	3
		94-15-07		Main rotor blades	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		94-24-11		Tail rotor drive shaft	Bk	3
		95-09-06		Fuel valve switch	Bk	3
		95-11-14		Crosstubes	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
206A continued		96-06-04		Inspect driveshaft assembly	Bk	3
		2001-02-03		Raised forging boss	Bk	4
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2004-24-08		Tail rotor blades	Bk	4
		2005-16-04		High forward crosstube	BW 05-17	
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW 05-22	
206A-1 (OH-58A)	H2SW	71-08-03		Particle separation kit	Bk	1
		72-19-01		Main rotor retention straps	Bk	1
		73-08-03		Pylon support link	Bk	1
		73-19-08		Strap fittings and pins	Bk	1
		73-19-09		Pitch link assemblies	Bk	1
		74-24-01		Main rotor blade grips	Bk	1
		75-06-03		Pitch link assembly	Bk	1
		75-18-07		Rotor blade pillow block assys	Bk	1
		76-04-09		Main rotor hub yokes	Bk	1
		76-15-03		Replacement straps	Bk	1
		78-11-02	R1	Rotor blade straps	Bk	1
		80-17-05		Tail rotor blades	Bk	2
		80-18-04	R1	Main rotor trunnion	Bk	2
		81-18-01	R1	Main rotor trunnions *(see Bk 4 for paper copy)*	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		90-21-03		Tail rotor blade assembly	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW 05-22	
206B (OH-58B)	H2SW	71-18-04		Main rotor blade spar	Bk	1
		72-19-01		Main rotor retention straps	Bk	1
		73-08-03		Pylon support link	Bk	1
		73-12-01		Vertical fin skin cracks	Bk	1
		73-19-08		Strap fittings and pins	Bk	1
		73-19-09		Pitch link assemblies	Bk	1
		73-21-03		Vertical fin support forgings	Bk	1
		74-08-12		Tail boom skin splice	Bk	1
		74-19-03		Horizontal stabilizer ribs	Bk	1
		74-24-01		Main rotor blade grips	Bk	1
		74-25-10		Rotor brake disc	Bk	1
		75-06-03		Pitch link assembly	Bk	1
		75-06-10		Cabin roof straps	Bk	1
		75-09-09		Tail rotor control tube	Bk	1
		75-18-07		Rotor blade pillow block assys	Bk	1
		76-04-09		Main rotor hub yokes	Bk	1
		76-05-01		Inboard ribs	Bk	1
		76-15-03		Replacement straps	Bk	1
		77-10-06		Tail rotor drive shaft	Bk	1
		78-11-02	R1	Rotor blade straps	Bk	1
		78-16-01		Tail rotor drive shaft	Bk	1
		79-10-01		External load carrying devices	Bk	1
		80-17-05		Tail rotor blades	Bk	2
		80-18-04	R1	Main rotor trunnion	Bk	2
		81-18-01	R1	Main rotor trunnions *(see Bk 4 for paper copy)*	Bk	2
		85-25-01		Cyclic control stick	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		86-24-01		T/R assembly	Bk	2
		87-10-11		Main rotor mast assy	Bk	2
		88-23-03		Tail rotor yoke assembly	Bk	2
		89-10-11	R1	RFM limitations	Bk	2
		89-22-01	R1	Main rotor blades	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
206B continued		90-13-01	R1	Tail rotor blade assembly	Bk	3
(OH-58B)		90-21-03		Tail rotor blade assembly	Bk	3
		91-03-12		Emergency float bags	Bk	3
		92-01-05		Main rotor blades	Bk	3
		92-06-12		Transmission failure	Bk	3
		92-09-07		Vertical fin supports	Bk	3
		94-15-07		Main rotor blades	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		94-24-11		Tail rotor drive shaft	Bk	3
		95-09-06		Fuel valve switch	Bk	3
		95-11-14		Crosstubes	Bk	3
		95-24-06		RFMS changes - autorotation	Bk	3
		96-06-04		Inspect driveshaft assembly	Bk	3
		2001-02-03		Raised forging boss	Bk	4
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2004-24-08		Tail rotor blades	Bk	4
		2005-16-04		High forward crosstube	BW	05-17
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW	05-22
206B-1	H2SW	72-19-01		Main rotor retention straps	Bk	1
		73-08-03		Pylon support link	Bk	1
		73-19-08		Strap fittings and pins	Bk	1
		73-19-09		Pitch link assemblies	Bk	1
		74-24-01		Main rotor blade grips	Bk	1
		75-06-03		Pitch link assembly	Bk	1
		75-18-07		Rotor blade pillow block assys	Bk	1
		76-04-09		Main rotor hub yokes	Bk	1
		76-15-03		Replacement straps	Bk	1
		78-11-02	R1	Rotor blade straps	Bk	1
		80-17-05		Tail rotor blades	Bk	2
		80-18-04	R1	Main rotor trunnion	Bk	2
		81-18-01	R1	Main rotor trunnions *(see Bk 4 for paper copy)*	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		88-23-03		Tail rotor yoke assembly	Bk	2
		90-21-03		Tail rotor blade assembly	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW	05-22
206L	H2SW	76-14-05		Fuel system components	Bk	1
		78-11-02	R1	Rotor blade straps	Bk	1
		78-24-06	R1	Horizontal stabilizer	Bk	1
		80-17-05		Tail rotor blades	Bk	2
		80-18-04	R1	Main rotor trunnion	Bk	2
		81-18-01	R1	Main rotor trunnions *(see Bk 4 for paper copy)*	Bk	3
		82-05-03		Horizontal stabilizer assembly	Bk	2
		83-03-04		Damage check of shear heads	Bk	2
		85-09-04		Main rotor blades	Bk	2
		85-25-01		Cyclic control stick	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		86-24-01		T/R assembly	Bk	2
		87-10-11		Main rotor mast assy	Bk	2
		88-23-03		Tail rotor yoke assembly	Bk	2
		88-26-03		Fuel system flow switches	Bk	2
		89-20-13		Horizontal stabilizer	Bk	2
		89-22-01	R1	Main rotor blades	Bk	2
		90-13-01	R1	Tail rotor blade assembly	Bk	3
		90-21-03		Tail rotor blade assembly	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
206L continued		91-03-12		Emergency float bags	Bk	3
		92-01-05		Main rotor blades	Bk	3
		92-06-12		Transmission failure	Bk	3
		94-15-07		Main rotor blades	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		94-24-11		Tail rotor drive shaft	Bk	3
		95-09-06		Fuel valve switch	Bk	3
		95-11-14		Crosstubes	Bk	3
		95-24-06		RFMS changes - autorotation	Bk	3
		96-18-05		Inspect tailboom	Bk	3
		99-17-19		Mast and trunnion	Bk	3
		2001-02-03		Raised forging boss	Bk	4
		2002-25-07		Tailboom skin	Bk	4
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2004-24-08		Tail rotor blades	Bk	4
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW 05-22	
206L-1	H2SW	78-11-02	R1	Rotor blade straps	Bk	1
		78-24-06	R1	Horizontal stabilizer	Bk	1
		80-18-04	R1	Main rotor trunnion	Bk	2
		80-22-11		Main rotor grip	Bk	2
		81-06-05	R1	Fuel/oil line damage	Bk	2
		81-18-01	R1	Main rotor trunnions *(see Bk 4 for paper copy)*	Bk	2
		82-05-03		Horizontal stabilizer assembly	Bk	2
		83-03-04		Damage check of shear heads	Bk	2
		85-09-04		Main rotor blades	Bk	2
		85-25-01		Cyclic control stick	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		86-19-12		See Allison, Engine	Bk	2
		87-10-11		Main rotor mast assy	Bk	2
		87-15-01		Stabilizer assembly	Bk	2
		88-23-03		Tail rotor yoke assembly	Bk	2
		88-26-03		Fuel system flow switches	Bk	2
		89-20-13		Horizontal stabilizer	Bk	2
		89-22-01	R1	Main rotor blades	Bk	2
		90-13-01	R1	Tail rotor blade assembly	Bk	3
		90-21-03		Tail rotor blade assembly	Bk	3
		91-03-12		Emergency float bags	Bk	3
		92-01-05		Main rotor blades	Bk	3
		92-06-12		Transmission failure	Bk	3
		94-15-07		Main rotor blades	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		94-24-11		Tail rotor drive shaft	Bk	3
		95-09-06		Fuel valve switch	Bk	3
		95-11-14		Crosstubes	Bk	3
		96-18-05		Inspect tailboom	Bk	3
		96-23-01		Kratos indicator	Bk	3
		99-17-19		Mast and trunnion	Bk	3
		2001-02-03		Raised forging boss	Bk	4
		2002-25-07		Tailboom skin	Bk	4
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2004-22-13		Adjustable stop screws of magnetic brake	Bk	4
		2004-24-08		Tail rotor blades	Bk	4
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW 05-22	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
206L-3	H2SW	78-11-02	R1	Rotor blade straps	Bk	1
		85-09-04		Main rotor blades	Bk	2
		85-25-01		Cyclic control stick	Bk	2
		85-26-06		Tail rotor blades	Bk	2
		86-19-12		See Allison, Engine	Bk	2
		87-10-11		Main rotor mast assy	Bk	2
		87-15-01		Stabilizer assembly	Bk	2
		88-23-03		Tail rotor yoke assembly	Bk	2
		89-20-13		Horizontal stabilizer	Bk	2
		89-22-01	R1	Main rotor blades	Bk	2
		90-13-01	R1	Tail rotor blade assembly	Bk	3
		90-21-03		Tail rotor blade assembly	Bk	3
		91-03-12		Emergency float bags	Bk	3
		92-01-05		Main rotor blades	Bk	3
		92-06-12		Transmission failure	Bk	3
		94-15-07		Main rotor blades	Bk	3
		94-19-02		Swashplate support assembly	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		94-24-11		Tail rotor drive shaft	Bk	3
		95-09-06		Fuel valve switch	Bk	3
		95-11-14		Crosstubes	Bk	3
		96-18-05		Inspect tailboom	Bk	3
		99-17-19		Mast and trunnion	Bk	3
		2001-02-03		Raised forging boss	Bk	4
		2002-25-07		Tailboom skin	Bk	4
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2004-22-13		Adjustable stop screws of magnetic brake	Bk	4
		2004-24-08		Tail rotor blades	Bk	4
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW 05-22	
206L-4	H2SW	94-15-07		Main rotor blades	Bk	3
		94-20-03		Main rotor hub trunnion	Bk	3
		95-11-14		Crosstubes	Bk	3
		99-13-03		Collective idler link or lever	Bk	3
		99-13-10		Hydraulic relief valve	Bk	3
		99-17-19		Mast and trunnion	Bk	3
		2001-13-51		Prevent failure of a driveshaft	Bk	4
		2001-20-03		Tail rotor yoke	Bk	4
		2002-25-07		Tailboom skin	Bk	4
		2003-13-14		Eaton Tedeco chip detector	Bk	4
		2004-24-08		Tail rotor blades	Bk	4
		2005-21-03		Tail rotor blade (blade) root doublers (doublers)	BW 05-22	
212	H4SW	74-02-01		Tail rotor trunnion bearings	Bk	1
		74-20-05		Elevator modification	Bk	1
		75-07-01		High frequency vibration	Bk	1
		75-26-03		Emergency exit handle	Bk	1
		75-26-05		Main rotor blades	Bk	1
		76-02-06		Main rotor blades	Bk	1
		76-14-03		Cross tube assemblies	Bk	1
		77-05-02		Main rotor blades	Bk	1
		77-10-05		Cracks in main rotor blades skin	Bk	1
		77-17-03		Tail rotor blade pitch horn	Bk	1
		77-17-05		Emergency exit latch pin	Bk	1
		78-09-02		Emergency float kits	Bk	1
		78-14-07		Skid landing gear	Bk	1
		78-17-03		Spiral bevel gear	Bk	1
		78-20-07		Shoulder radius fitting	Bk	1
		78-21-02		External load link assembly	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
212 continued		79-05-08		Emer. flotation (ditching) equipment	Bk	1
		79-20-05		Main rotor hub assembly	Bk	1
		80-21-05		Landing gear cross tubes	Bk	2
		81-10-07		Swashplate support	Bk	2
		81-19-01		Main rotor yoke	Bk	2
		86-17-09	L	T/R hub assembly (See 90-03-09)	Bk	2
		89-08-05		Transmission internal sump oil filter	Bk	2
		90-03-09		Tail rotor	Bk	3
		90-26-11		Drag brace assemblies	Bk	3
		92-07-08		Swashplate support assembly	Bk	3
		92-09-05		Torque adapter	Bk	3
		92-13-10		Tail rotor driveshaft hanger bearing	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		93-05-01		Main rotor yoke assembly	Bk	3
		93-17-12		Main rotor transmission lower planetary spider	Bk	3
		94-18-09		Main transmission lower planetary spider	Bk	3
		98-11-15		Tail rotor yoke assembly	Bk	3
		2000-15-52		Main rotor mast or trunnion	Bk	4
		2001-08-04		Actuator piston unthreading from its rod end	Bk	4
		2001-13-01		failure of the tail rotor counterweight bellcrank	Bk	4
		2002-09-04		Tip weight retention block	Bk	4
		2002-19-05		Vertical fin spar cap	Bk	4
		2002-22-14		TT Strap	Bk	4
		2003-01-04		Upper and lower tang of main rotor blade	Bk	4
		2005-20-38		Reservoir assembly adapter (adapter)	BW	05-21
214 Series	H6SW H10SW	81-12-03		Spindle retention bolts	Bk	2
214B Series	H10SW	81-12-03		Spindle retention bolts	Bk	2
	H6SW	85-23-05	L	Collective sleeve	Bk	2
214B	H6SW	77-03-04		Fuselage splice fitting	Bk	1
		77-17-05		Emergency exit latch pin	Bk	1
		78-08-08		Tail fin spar	Bk	1
		81-02-10		Clutch assembly	Bk	2
	H10SW	81-12-03		Spindle retention bolts	Bk	2
		82-06-07		Tail rotor yoke	Bk	2
		84-05-51	T	Collective sleeves	Bk	2
		85-18-06		Main rotor drag brae assembly	Bk	2
		86-20-06		M/R drag brace assembly	Bk	2
		87-11-06		Locking plates	Bk	2
		93-21-10		Main rotor yoke assembly	Bk	3
		97-06-02		Lower planetary spider	Bk	3
		97-15-04		Main transmission upper planetary carrier	Bk	3
		98-18-01		Main rotor trunnion	Bk	3
		98-23-18		Kaynar Tech. manufactured barrel nut	Bk	3
		99-02-17		Tail rotor yoke assembly	Bk	3
		99-05-07		Pillow block bearing bolts	Bk	3
		2001-03-03		Prevent failure of a strap fitting	Bk	4
		2002-22-14		TT Strap	Bk	4
214B-1	H6SW	77-03-04		Fuselage splice fitting	Bk	1
		77-17-05		Emergency exit latch pin	Bk	1
		78-08-08		Tail fin spar	Bk	1
		81-02-10		Clutch assembly	Bk	2
	H10SW	81-12-03		Spindle retention bolts	Bk	2
		82-06-07		Tail rotor yoke	Bk	2
		84-05-51	T	Collective sleeves	Bk	2
		85-18-06		Main rotor drag brace assembly	Bk	2
		86-20-06		M/R drag brace assembly	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
214B-1 continued		87-11-06		Locking plates	Bk	2
		93-21-10		Main rotor yoke assembly	Bk	3
		97-06-02		Lower planetary spider	Bk	3
		97-15-04		Main transmission upper planetary carrier	Bk	3
		98-18-01		Main rotor trunnion	Bk	3
		98-23-18		Kaynar Tech. manufactured barrel nut	Bk	3
		99-02-17		Tail rotor yoke assembly	Bk	3
		99-05-07		Pillow block bearing bolts	Bk	3
		2001-03-03		Prevent failure of a strap fitting	Bk	4
		2002-22-14		TT Strap	Bk	4
214ST Series	H10SW	81-12-03		Spindle retention bolts	Bk	2
		85-18-06		Main rotor drag brace assembly	Bk	2
		85-23-05	L	Collective sleeve	Bk	2
214ST	H10SW	81-12-03		Spindle retention bolts	Bk	2
		82-26-07	R1	Tailboom separation	Bk	2
		84-05-51	T	Collective sleeves	Bk	2
		84-15-05		Collective lever assembly	Bk	2
		84-18-51	T	Main rotor spindles	Bk	2
		85-18-06		Main rotor drag brace assembly	Bk	2
		86-12-01	L	Locking plate	Bk	2
		86-12-06		Main rotor yoke assemblies	Bk	2
		86-20-06		M/R drag brace assembly	Bk	2
		87-11-06		Locking plates	Bk	2
		88-09-01		Tail rotor gearbox	Bk	2
		88-12-03		Main rotor drag brace assy.	Bk	2
		96-07-12		Inspect tailboom assembly for cracks	Bk	3
		97-06-02		Lower planetary spider	Bk	3
214ST continued		97-06-03		Fatigue failure of the mast	Bk	3
		97-15-04		Main transmission upper planetary carrier	Bk	3
		97-17-06		Solenoid valve assemblies	Bk	3
		97-19-09		Bearing bolts	Bk	3
		98-18-01		Main rotor trunnion	Bk	3
		98-23-18		Kaynar Tech. manufactured barrel nut	Bk	3
		99-04-13		Tail rotor yoke	Bk	3
222 Series	H9SW	82-16-06		Main rotor spar doublers	Bk	2
		87-19-01		STC SH1879SO label removal	Bk	2
222	H9SW	82-09-53		Swashplate drive links	Bk	2
		83-02-51		Walking beam assemblies	Bk	2
		83-09-03		Main rotor trunnion, torquemeter	Bk	2
		84-12-02		Support fittings	Bk	2
		85-14-11		Linkage rivets	Bk	2
		87-09-02	R2	Drive hub assembly	Bk	2
		87-13-01		RFM Changes - engine	Bk	2
		87-15-07		M/R flapping bearing	Bk	2
		88-02-03		M/R yoke	Bk	2
		89-17-05		Horizontal stabilizers	Bk	2
		89-25-04		Tail rotor support bracket bulkhead	Bk	2
		93-08-14		Main rotor flapping bearings	Bk	3
		96-18-15		Tail rotor blade	Bk	3
		99-09-20		Main rotor flapping bearing assembly	Bk	3
		99-23-04		Inspect torque of vertical fin attachment bolts	Bk	3
		2000-04-15		Swashplate drive pin	Bk	4
		2000-10-14		Inspect yoke attatchment bolts	Bk	4
		2001-01-51		Loss of control of the helicopter	Bk	4
		2001-19-52		Main rotor pendulum weight support	Bk	4
		2002-08-54		Main rotor grip and pitch horn	Bk	4
		2002-20-02		Forward tooling hole sealant	Bk	4
		2003-08-07		Main rotor pendulum weights	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
222 continued		2003-13-13	Magnetic brake assembly	Bk	4
		2004-20-07	Main rotor yoke	Bk	4
		2005-03-10	Main rotor grip (grip)	BW	05-04
		2005-04-09	Tail rotor blades	BW	05-040
		2006-13-14	Tail rotor counterweight bellcrank		
222B	H9SW	83-02-51	Walking beam assemblies	Bk	2
		85-14-11	Linkage rivets	Bk	2
		87-13-01	RFM changes - engine	Bk	2
		87-15-06	Tail boom assembly	Bk	2
		87-15-07	M/R flapping bearing	Bk	2
		88-02-03	M/R yoke	Bk	2
		89-17-05	Horizontal stabilizers	Bk	2
		89-25-04	Tail rotor support bracket bulkhead	Bk	2
		93-08-14	Main rotor flapping bearings	Bk	3
		96-18-15	Tail rotor blade	Bk	3
		99-09-20	Main rotor flapping bearing assembly	Bk	3
		99-23-04	Inspect torque of vertical fin attachment bolts	Bk	3
		2000-04-15	Swashplate drive pin	Bk	4
		2000-10-14	Inspect yoke attatchment bolts	Bk	4
		2001-01-51	Loss of control of the helicopter	Bk	4
		2001-19-52	Main rotor pendulum weight support	Bk	4
		2002-08-54	Main rotor grip and pitch horn	Bk	4
		2002-20-02	Forward tooling hole sealant	Bk	4
		2003-08-07	Main rotor pendulum weights	Bk	4
		2003-13-13	Magnetic brake assembly	Bk	4
		2004-20-07	Main rotor yoke	Bk	4
		2005-03-10	Main rotor grip (grip)	BW	05-04
		2005-04-09	Tail rotor blades	BW	05-04
		2006-13-14	Tail rotor counterweight bellcrank		
222U	H9SW	85-14-11	Linkage rivets	Bk	2
		87-13-01	RFM changes - engine	Bk	2
		87-15-06	Tail boom assembly	Bk	2
		87-15-07	M/R flapping bearing	Bk	2
		88-02-03	M/R yoke	Bk	2
		89-17-05	Horizontal stabilizers	Bk	2
		93-08-14	Main rotor flapping bearings	Bk	3
		96-18-15	Tail rotor blade	Bk	3
		99-09-20	Main rotor flapping bearing assembly	Bk	3
		99-23-04	Inspect torque of vertical fin attachment bolts	Bk	3
		2000-04-15	Swashplate drive pin	Bk	4
		2000-10-14	Inspect yoke attatchment bolts	Bk	4
		2001-01-51	Loss of control of the helicopter	Bk	4
		2001-19-52	Main rotor pendulum weight support	Bk	4
		2002-08-54	Main rotor grip and pitch horn	Bk	4
		2002-20-02	Forward tooling hole sealant	Bk	4
		2003-08-07	Main rotor pendulum weights	Bk	4
		2003-13-13	Magnetic brake assembly	Bk	4
		2004-20-07	Main rotor yoke	Bk	4
		2005-03-10	Main rotor grip (grip)	BW	05-04
		2005-04-09	Tail rotor blades	BW	05-04
		2006-13-14	Tail rotor counterweight bellcrank		
230	H9SW	96-18-15	Tail rotor blade	Bk	3
		99-09-05	Main rotor flapping bearing assembly	Bk	3
		99-16-09	Vertical fin attachment bolts	Bk	3
		2000-04-15	Swashplate drive pin	Bk	4
		2000-10-14	Inspect yoke attatchment bolts	Bk	4
		2001-01-51	Loss of control of the helicopter	Bk	4
		2001-19-52	Main rotor pendulum weight support	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2002-08-54		Main rotor grip and pitch horn	Bk	4
		2002-20-02		Forward tooling hole sealant	Bk	4
		2003-08-07		Main rotor pendulum weights	Bk	4
230 continued		2004-20-07		Main rotor yoke	Bk	4
		2005-03-10		Main rotor grip (grip)	BW 05-04	
		2005-04-09		Tail rotor blades	BW 05-04	
		2006-13-14				
412	H4SW	82-26-51	R1	Yoke assemblies service time	Bk	2
		85-07-01		Main rotor pitch horn	Bk	2
		86-16-11	L	Inspect T/R hub assembly (See 90-03-09)	Bk	2
		89-08-05		Transmission internal sump oil filter	Bk	2
		90-03-09		Tail rotor	Bk	3
		92-09-05		Torque adapter	Bk	3
		92-13-10		Tail rotor driveshaft hanger bearing	Bk	3
		93-02-07		Vertical fin spar	Bk	3
		93-17-12		Main rotor trans lwr planetary spider	Bk	3
		94-18-09		Main transmission lower planetary spider	Bk	3
		97-07-06		Swashplate support assembly	Bk	3
		97-11-04		Mast and spline plate	Bk	3
		99-23-23		Inspect and measure yolk	Bk	3
		2000-18-09		Inspect cap angle	Bk	4
		2001-08-04		Actuator piston unthreading from its rod end	Bk	4
		2001-09-11		Damage to the tail rotor yoke	Bk	4
		2001-13-01		failure of the tail rotor counterweight bellcrank	Bk	4
		2002-09-04		Tip weight retention block	Bk	4
		2005-20-38		Reservoir assembly adapter (adapter)	BW 05-21	
412EP	H4SW	97-11-04		Mast and spline plate	Bk	3
		99-23-23		Inspect and measure yolk	Bk	3
		2000-18-09		Inspect cap angle	Bk	4
		2001-08-04		Actuator piston unthreading from its rod end	Bk	4
		2001-09-11		Damage to the tail rotor yoke	Bk	4
		2001-13-01		failure of the tail rotor counterweight bellcrank	Bk	4
		2002-09-04		Tip weight retention block	Bk	4
		2005-20-38		Reservoir assembly adapter (adapter)	BW 05-21	
412CF	H4SW	99-23-23		Inspect and measure yolk	Bk	3
		2000-18-09		Inspect cap angle	Bk	4
		2001-08-04		Actuator piston unthreading from its rod end	Bk	4
		2001-09-11		Damage to the tail rotor yoke	Bk	4
		2001-13-01		failure of the tail rotor counterweight bellcrank	Bk	4
		2002-09-04		Tip weight retention block	Bk	4
427		2001-13-51		Prevent failure of a driveshaft	Bk	4
		2003-04-12		Auxiliary fin assemblies	Bk	4
		2003-04-14		Hydraulic solenoid tee fitting	Bk	4
430	H9SW	98-24-31		Forward fairing assembly	Bk	3
		99-23-03		Inspect torque of vertical fin attachment bolts	Bk	3
		2000-16-04		Inspect main rotor adapter assemblies	Bk	4
		2000-16-06		Flight control	Bk	4
		2000-22-13		Fuel quantity indicating system	Bk	4
		2001-01-51		Loss of control of the helicopter	Bk	4
		2001-05-09		Prevent loss of electrical power	Bk	4
		2002-01-07		Alert Service Bulletin No. 430-01-19	Bk	4
		2002-20-02		Forward tooling hole sealant	Bk	4
		2005-04-09		Tail rotor blades	BW 05-04	
		2006-13-14				
407	H2SW	97-24-17		Tail rotor drive coupling disc pack	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		98-12-22		Tail rotor drive system bearing supports	Bk	3
		98-19-13		Driveshaft	Bk	3
		99-22-13		Inspect fin assy for reduced skin thickness	Bk	3
		99-23-18		Revised life limit	Bk	3
		2000-04-20		Hydraulic relief valve	Bk	4
407 continued		2000-04-25		Door latch rod assembly	Bk	4
		2000-14-16		Tail rotor blades	Bk	4
		2001-01-52	R1	Prevent tail rotor blades from striking tailboom	Bk	4
		2001-13-02		Identifying a specific warning horn	Bk	4
		2001-13-51		Prevent failure of a driveshaft	Bk	4
		2002-11-09		Forward bearing hanger bracket	Bk	4
		2002-17-03		Electrical bonding	Bk	4
		2002-22-10		Horizontal stabilizer slat	Bk	4
		2003-02-06		Tailboom	Bk	4
		2003-05-03		Tailboom	Bk	4
		2003-05-11		Swashplate drive link cup washer	Bk	4
		2004-10-07		Oil cooler blower bearing	Bk	4
		2005-03-07		Crosstube assembly	BW	05-04

BOEING COMPANY, VERTOL DIVISION
(See BOEING DEFENSE & SPACE GROUP)

BOEING DEFENSE & SPACE GROUP
(Formerly BOEING CO. VERTOL DIV.)
(AD's for Book 1 under Boeing Co. Vertol Div.)

H21 Series	HR-35,	64-19-06		Spiral bevel pinion gears	Bk	1
	H1AL,	64-27-04		Wood rotor blade root socket	Bk	1
	H2SO,	68-06-01		Transmission drive shaft	Bk	1
	1H12					
42 Series	1H12	58-20-04		Clutch coupling replacement	Bk	1
(H-21B, C)		60-23-05		Bellcrank assembly retirement	Bk	1
		64-19-06		Spiral bevel pinion gears	Bk	1
		64-27-04		Wood rotor blade root socket	Bk	1
		68-06-01		Transmission drive shaft	Bk	1
44 Series	1H12	58-20-04		Clutch coupling replacement	Bk	1
		59-09-04		Fan disc assembly	Bk	1
		59-19-02		Engine cooling fan assembly	Bk	1
		59-20-01		Spar weight assembly straps	Bk	1
		60-10-10		Rotor blade retirement	Bk	1
		60-23-05		Bellcrank assembly retirement	Bk	1
		64-19-06		Spiral bevel pinion gears	Bk	1
		68-06-01		Transmission drive shaft	Bk	1
107-11	1H16	63-13-05		Forward rotor transmission	Bk	1
		63-24-04		Quill shafts and collector gears	Bk	1
		64-06-07		Stability augmentation systems	Bk	1
		64-21-06	R2	Sockets & rotor housings	Bk	1
		66-13-05		Fire detection system	Bk	1
		72-16-10		Aft transmission ring	Bk	1
		73-08-01		Aft transmission quill shaft	Bk	1
		74-17-02		Rotor blade inspection system	Bk	1
		76-25-03		Main rotor blade spars	Bk	1
		80-11-08		Cyclic stick boots	Bk	2
		80-25-08		Tension-torsion strap assemblies	Bk	2
		83-07-06		Synchronizing shaft	Bk	2
		87-11-05		Components fatigue failure	Bk	2
		88-12-09		Main rotor shaft	Bk	2
		88-14-03		Main rotor hubs	Bk	2
		2005-24-05		Quill shaft	BW	05-24

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
234	H9EA	82-20-06	R1	Main rotor hubs inspection	Bk	2
		82-20-52		Transmission	Bk	2
		83-16-51		Main rotor blade tip cap	Bk	2
		83-18-51	R2	Pitch shafts	Bk	2
		83-25-51	R1	Rotor head horizontal hinge pins	Bk	2
		84-03-51		Forward main rotor tie bars	Bk	2
		84-10-51	R1	Forward rotor drive shaft	Bk	2
		84-15-03		Cylinders -flight control system	Bk	2
		85-23-51	R1	Main rotor head vertical hinge pins insp.	Bk	2
		86-23-51		Transmissions	Bk	2
		87-25-05		Landing gear spindle	Bk	2
		91-03-01		Rotor blade rod ends	Bk	3
		95-22-09		Spiral bevel ring gear bolted connection	Bk	3
		2004-06-51		Aft vertical shaft assembly	Bk	4

BOLKOW APPARATEBAU GMBH
(See Daimlerchrysler Aerospace Ag)

BRANTLY HELICOPTER
(See HYNES, MICHAEL K.)

BRANTLY INTERNATIONAL, INC.
(Formerly Hynes, Michael K.)
(For ADs in Bk 1 see Hynes, Michael K.)

B-2	2H2	60-06-03		Tail rotor guard	Bk	1
		60-07-02		Tail rotor drive shaft	Bk	1
		60-10-02		Rotor blade inspection	Bk	1
		60-26-03		Drive shaft coupling	Bk	1
		61-04-01		Clutch bolts	Bk	1
		61-11-01		Landing gear drag brace	Bk	1
		61-11-02		Oil system modification	Bk	1
		61-16-03		Seat modification	Bk	1
		61-16-04		Transmission mount lug	Bk	1
		61-18-02		Tail rotor modification	Bk	1
		61-23-01		Rotor blade bond separation	Bk	1
		62-05-02		Fuel pump seals	Bk	1
		62-06-01		Seat back adjustment	Bk	1
		65-28-01		Tail rotor blades	Bk	1
		67-09-02		Main rotor mast	Bk	1
		68-04-04	R2	Tail rotor blade	Bk	1
		68-05-02		Tail rotor drive shaft	Bk	1
		71-17-05		Main rotor mast	Bk	1
		72-21-02		Pylon bearing shaft	Bk	1
		2006-08-07		Upper tail rotor vertical gearbox (gearbox)	BW	06-09
B-2A	2H2	60-06-03		Tail rotor guard	Bk	1
		60-10-02		Rotor blade inspection	Bk	1
		60-26-03		Drive shaft coupling	Bk	1
		61-04-01		Clutch bolts	Bk	1
		61-11-01		Landing gear drag brace	Bk	1
		61-11-02		Oil system modification	Bk	1
		61-16-03		Seat modification	Bk	1
		61-18-02		Tail rotor modification	Bk	1
		61-23-01		Rotor blade bond separation	Bk	1
		62-05-02		Fuel pump seals	Bk	1
		62-06-01		Seat back adjustment	Bk	1
		65-28-01		Tail rotor blades	Bk	1
		67-09-02		Main rotor mast	Bk	1
		68-04-04	R2	Tail rotor blade	Bk	1
		68-05-02		Tail rotor drive shaft	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
B-2A continued		71-17-05		Main rotor mast	Bk	1
		72-21-02		Pylon bearing shaft	Bk	1
		2006-08-07		Upper tail rotor vertical gearbox (gearbox)	BW	06-09
B-2B	2H2	60-06-03		Tail rotor guard	Bk	1
		60-10-02		Rotor blade inspection	Bk	1
		60-26-03		Drive shaft coupling	Bk	1
		61-04-01		Clutch bolts	Bk	1
		61-11-01		Landing gear drag brace	Bk	1
		61-11-02		Oil system modification	Bk	1
		61-16-03		Seat modification	Bk	1
		61-18-02		Tail rotor modification	Bk	1
		61-23-01		Rotor blade bond separation	Bk	1
		62-05-02		Fuel pump seals	Bk	1
		62-06-01		Seat back adjustment	Bk	1
		65-28-01		Tail rotor blades	Bk	1
		67-09-02		Main rotor mast	Bk	1
		68-04-04	R2	Tail rotor blade	Bk	1
		68-05-02		Tail rotor drive shaft	Bk	1
		71-17-05		Main rotor mast	Bk	1
		72-21-02		Pylon bearing shaft	Bk	1
		2006-08-07		Upper tail rotor vertical gearbox (gearbox)	BW	06-09
305	H3SW	68-05-02		Tail rotor drive shaft	Bk	1
		76-08-06		Main rotor hub clevis bearing	Bk	1

BRDITSCHKA, HEINO
(See HB AIRCRAFT INDUSTRIES)

BURKHART GROB FLUGZEUGBAU
(See GROB-WERKE, SCHEMPP-HIRTH)

BURKHART GROB LUFT-UND RAUMFAHRT
(Formerly GROB-WERKE GMBH & CO.)
(For AD's in Bk 1 see Grob-Werke)
(See Grob-Werke for AD's under TC A49CE and G33EU)

Burkhart Grob Gliders	--	76-09-10		Aileron control system	Bk	1
		76-11-03		Tow release mechanism	Bk	1
G103 Twin Astir	G39EU	86-18-09		Rudder control lever	Bk	2
		88-12-08		Tow-hook knob	Bk	2
		90-02-09		Wing spar spigots	Bk	3
		91-02-04		Aileron control system	Bk	3
		94-17-06		Inspect airbrake stops	Bk	3
		97-24-10		Airbrake over-center lever	Bk	3
		2003-19-14	R2	Airspeed indicators	BW	05-21
		2005-26-12		Center of gravity (CG) release hook attachment brackets.	BW	06-01
		2005-26-14		Elevator lever.	BW	06-01
G103 Twin II	G39EU	86-16-02		Inspect airbrake operating lever	Bk	2
		86-17-08		Airbrake pivot lever stop pad	Bk	2
		87-25-10		Rudder lever	Bk	2
		88-12-08		Tow-hook knob	Bk	2
		89-08-02		Control systems	Bk	2
		90-02-09		Wing spar spigots	Bk	3
		91-02-04		Aileron control system	Bk	3
		94-17-06		Inspect airbrake stops	Bk	3
		99-20-11		Fastening nut at rear control stick	Bk	3
		2005-26-12		Center of gravity (CG) release hook attachment brackets.	BW	06-01

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
G103A Twin II ACRO	G39EU	86-16-02		Inspect airbrake operating lever	Bk	2
		86-17-08		Airbrake pivot lever stop pad	Bk	2
		87-25-10		Rudder lever	Bk	2
		88-12-08		Tow-hook knob	Bk	2
		89-08-02		Control systems	Bk	2
		90-02-09		Wing spar spigots	Bk	3
		99-20-11		Fastening nut at rear control stick	Bk	3
		2003-19-14	R2	Airspeed indicators	BW	05-21
		2005-26-12		Center of gravity (CG) release hook attachment brackets.	BW	06-01
G103C Twin III ACRO		2003-19-14	R2	Airspeed indicators	BW	05-21
		2005-26-12		Center of gravity (CG) release hook attachment brackets.	BW	06-01
G103C Twin III SL	G57EU	2005-26-12		Center of gravity (CG) release hook attachment brackets.	BW	06-01
		2006-08-01		Propeller bearing and pulley wheel	BW	06-08
G109	G43EU	85-19-05		Placard -spinning prohibited	Bk	2
		85-19-07	R1	Landing gear legs	Bk	2
		94-17-06		Inspect airbrake stops	Bk	3
		97-15-12		Damper unit and rudder bell crank lever	Bk	3
		98-24-20		Landing gear legs	Bk	3
G109B	G43EU	85-19-07	R1	Landing gear legs	Bk	2
		86-15-09		Placard-limitation section	Bk	2
		91-12-06		Rib stud plate	Bk	3
		94-17-06		Inspect airbrake stops	Bk	3
		95-08-13		Elevator inner hinges	Bk	3
		98-23-10		Engine mounting frame	Bk	3
		98-24-09		Elevator and trim tab	Bk	3
		98-24-20		Landing gear legs	Bk	3
CALIFORNIA DEPT. OF FORESTRY						
UH-1F	H2NM	83-03-03		Tail boom skin joint	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3

CAPRONI VIZZOLA
(See Agusta S.p.A.)

C.A.R.M.A.M.
(See AER-PEGASO and SOCIETE C.A.R.M.A.M)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
CENTRAIR						
101	G46EU	86-02-04		Tow release cable guide	Bk	2
		98-19-14		Airbrake control system	Bk	3
		99-09-07		Unsecured battery discharge	Bk	3
		2000-24-23		Airbrake control system	Bk	4
		2005-08-06		Elevator or aileron hinge pins	BW	05-10
		2005-08-12		Rudder pedals	BW	05-09
		2005-24-01		Limitations Section of the glider maintenance	BW	05-24
101A	G46EU	86-02-04		Tow release cable guide	Bk	2
		98-19-14		Airbrake control system	Bk	3
		99-09-07		Unsecured battery discharge	Bk	3
		2000-24-23		Airbrake control system	Bk	4
		2005-08-06		Elevator or aileron hinge pins	BW	05-09
		2005-08-12		Rudder pedals	BW	05-09
		2005-24-01		Limitations Section of the glider maintenance	BW	05-24
101P	G46EU	86-02-04		Tow release cable guide	Bk	2
		98-19-14		Airbrake control system	Bk	3
		99-09-07		Unsecured battery discharge	Bk	3
		2000-24-23		Airbrake control system	Bk	4
		2005-08-06		Elevator or aileron hinge pins	BW	05-09
		2005-08-12		Rudder pedals	BW	05-09
		2005-24-01		Limitations Section of the glider maintenance	BW	05-24
101AP	G46EU	86-02-04		Tow release cable guide	Bk	2
		98-19-14		Airbrake control system	Bk	3
		99-09-07		Unsecured battery discharge	Bk	3
		2000-24-23		Airbrake control system	Bk	4
		2005-08-06		Elevator or aileron hinge pins	BW	05-09
		2005-08-12		Rudder pedals	BW	05-09
		2005-24-01		Limitations Section of the glider maintenance	BW	05-24
201 (all types)	G54EU	96-02-01		Aileron mass balance	Bk	3
201B	G54EU	90-13-11		Rear cockpit airbrake handle	Bk	3
		2000-24-22		Rear canopy strap	Bk	4
CONN, SIDNEY						
All Models	A14SO	75-12-08		Throttle or trigger valves	Bk	1
Firefly 5	A14SO	81-05-03		Fuel tank shut-off valve modification	Bk	2
Firefly 6	A14SO	75-17-36		Brass nipple failure	Bk	1
		81-05-03		Fuel tank shut-off valve modification	Bk	2
Firefly 6B	A14SO	75-17-36		Brass nipple failure	Bk	1
		81-05-03		Fuel tank shut-off valve modification	Bk	2
Firefly 7	A14SO	75-17-36		Brass nipple failure	Bk	1
		81-05-03		Fuel tank shut-off valve modification	Bk	2
Firefly 7B	A14SO	81-05-03		Fuel tank shut-off valve modification	Bk	2
		84-04-03		Jumper cords	Bk	2
Firefly 8-24	A14SO	81-05-03		Fuel tank shut-off valve modification	Bk	2
CONTINENTAL COPTERS, INC.						
OH-13H	H5SW	80-10-04	R1	Tail rotor blades	Bk	2
		80-21-09	R1	Tail rotor pitch link	Bk	2
		81-04-03		Tail rotor drive assembly	Bk	2
		2002-03-16		Main rotor blade grips	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
COSTRUZIONI AERONAUTICHE GIOVANNI AGUSTA						
(See AGUSTA)						
DG FLUGZEUGBAU GMBH						
(Formerly Glaser-Dirks Flugzeugbau)						
DG-500	G08CE	2000-23-32		Inspect push rod guide	Bk	4
		2006-02-12		Rudder mount assembly	BW	06-04
DG-500M, -500MB	G59EU	96-04-12		Airbrake control hook-up shaft	Bk	3
		98-04-30		Inspect propeller mounting plate for cracks	Bk	3
		98-12-04		Rudder gap seal	Bk	3
		98-15-20		C.G. tow release cable pulley	Bk	3
		2000-23-32		Inspect push rod guide	Bk	4
		2001-05-01		Engine crankshaft	Bk	4
		2004-18-12		Warner LA10 spindle drive	Bk	4
		2005-10-23		Propeller	BW	05-11
		2005-26-11		Starter ring gear to the lower drive belt pulley adapter.	BW	06-01
		2006-02-12		Rudder mount assembly	BW	06-04
DG-1000S						
		2006-16-20		Elevator control		
DIAMOND AIRCRAFT INDUSTRIES						
Austria						
(Formerly HOAC Austria)						
(For ADs in Bk 2 see HOAC)						
H-36 "Dimona"	G-51EU	87-05-04		Wing/fuselage attachment	Bk	2
		88-14-05		Horizontal tail surface mount	Bk	2
		90-15-08		Wing attachments	Bk	3
		91-14-15		Fuel tank	Bk	3
		98-09-24		Inspect elevator rib area for damage	Bk	3
H 36 R “Super Dimona”	G51EU	98-09-24		Inspect elevator rib area for damage	Bk	3
HK 36R “Super Dimona”	G-51EU	95-18-13		Inspect exhaust system for corrosion	Bk	3
		2002-15-01	R1	Long aileron push rods	Bk	4
HK 36 TC, HK 36 TS	G07CE	2002-15-01	R1	Long aileron push rods	Bk	4
HK 36 TTC-ECO	G07CE	2002-15-01	R1	Long aileron push rods	Bk	4
HK 36 TTC, HK 36 TTS	G07CE	98-09-14		Banjo bolt	Bk	3
		2002-15-01	R1	Long aileron push rods	Bk	4
EAGLE AIRCRAFT						
Eagle 150B		2001-09-16		Damaged rudder cables	Bk	4
		2002-02-01		Throttle control assembly	Bk	4
		2003-19-07		Canard rear spar	Bk	4
		2004-11-04		Canard inboard flap hinge support brackets	Bk	4
		2004-26-01		Undercarriage attach bracket	Bk	4
EAGLE BALLOONS, LTD.						
(Formerly SEMCO BALLOON)						
TC-4A	A13WE	73-24-02		Vertical fuel hose coupler	Bk	1
		75-11-03		Deflation system	Bk	1
		80-14-09		Gondola fittings	Bk	2
		2005-05-14		Co-pilot rudder pedal assembly	BW	05-06

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
"Model T"	A1NW	73-24-02		Vertical fuel hose coupler	Bk	1
		75-11-03		Deflation system	Bk	1
		80-14-09		Gondola fittings	Bk	2
Challenger	A13SO	75-11-03		Deflation system	Bk	1
		80-14-09		Gondola fittings	Bk	2
30-AL	A12WE	73-24-02		Vertical fuel hose coupler	Bk	1
EIRIAVION OY						
PIK-20	G31EU	84-15-07		Rudder bottom hinge bracket	Bk	2
		92-07-07		Flaps and ailerons	Bk	3
PIK-20B	G31EU	84-15-07		Rudder bottom hinge bracket	Bk	2
		92-07-07		Flaps and ailerons	Bk	3
PIK-20D	G31EU	77-16-08		Wing panels	Bk	1
		84-15-07		Rudder bottom hinge bracket	Bk	2
ENSTROM HELICOPTER CORPORATION						
F-28 Series	H1CE	88-11-06		Horizontal stabilizer	Bk	2
F-28	H1CE	74-12-01		Forged idler yoke	Bk	1
		77-20-02		Tail rotor spindle	Bk	1
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
F-28A	H1CE	72-11-04		Failure tail rotor drive pins	Bk	1
		74-12-01		Forged idler yoke	Bk	1
		74-17-07		Main rotor gear box	Bk	1
		75-22-01		Main rotor system	Bk	1
		75-22-10		Hub lock washer	Bk	1
		76-05-11		Tail cone attach bolts	Bk	1
		77-20-02		Tail rotor spindle	Bk	1
		82-16-09		Main rotor blade grips	Bk	2
		82-24-01		Drivebelt clutch mechanism	Bk	2
		83-04-04		Main rotor gearboxes	Bk	2
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-02		Swashplate bearings	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		97-20-04		Voltage regulator and over-voltage relay	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
F-28C	H1CE	77-06-04		Tail rotor assembly	Bk	1
		77-15-04		Tail rotor pitch link assy	Bk	1
		77-20-02		Tail rotor spindle	Bk	1
		77-25-05		Idle mixture	Bk	1
		79-02-01		Turbochargers	Bk	1
		79-10-06	R1	Tail rotor blade grips	Bk	1
		82-16-09		Main rotor blade grips	Bk	2
		82-24-01		Drivebelt clutch mechanism	Bk	2
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		93-24-13		Trim system	Bk	3
F-28C continued		94-13-03		Inspect tail rotor spindle	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-02		Swashplate bearings	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		97-20-04		Voltage regulator and over-voltage relay	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
F-28C-2		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		93-24-13		Trim system	Bk	3
		94-13-03		Inspect tail rotor spindle	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-02		Swashplate bearings	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
F-28F	H1CE	82-16-09		Main rotor blade grips	Bk	2
		82-24-01		Drivebelt clutch mechanism	Bk	2
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		93-24-13		Trim system	Bk	3
		94-13-03		Inspect tail rotor spindle	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
TH-28		01-25-02		Failure of a hub plate	Bk	4
280	H1CE	75-22-10		Hub lock washer	Bk	1
		76-05-11		Tail cone attach bolts	Bk	1
		77-20-02		Tail rotor spindle	Bk	1
		82-16-09		Main rotor blade grips	Bk	2
		82-24-01		Drivebelt clutch mechanism	Bk	2
		83-04-04		Main rotor gearboxes	Bk	2
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-02		Swashplate bearings	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		97-20-04		Voltage regulator and over-voltage relay	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
280C	H1CE	77-06-04		Tail rotor assembly	Bk	1
		77-15-04		Tail rotor pitch link assy	Bk	1
		77-20-02		Tail rotor spindle	Bk	1
		77-25-05		Idle mixture	Bk	1
		79-02-01		Turbochargers	Bk	1
		79-10-06	R1	Tail rotor blade grips	Bk	1
		82-16-09		Main rotor blade grips	Bk	2
		82-24-01		Drivebelt clutch mechanism	Bk	2
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		93-24-13		Trim system	Bk	3
		94-13-03		Inspect tail rotor spindle	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
280C continued		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-02		Swashplate bearings	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		97-20-04		Voltage regulator and over-voltage relay	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
280F	H1CE	82-16-09		Main rotor blade grips	Bk	2
		82-24-01		Drivebelt clutch mechanism	Bk	2
		90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		90-17-03		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		93-24-13		Trim system	Bk	3
		94-13-03		Inspect tail rotor spindle	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
280FX	H1CE	90-01-06		Tail rotor gearbox	Bk	3
		90-17-02		Tail rotor drive shaft couplings	Bk	3
		93-15-10		Composite-wrapped main rotor shaft	Bk	3
		93-24-13		Trim system	Bk	3
		94-13-03		Inspect tail rotor spindle	Bk	3
		94-17-15		Main rotor feathering bearing	Bk	3
		96-06-03		Main rotor transmission clutch assembly	Bk	3
		2002-08-03		Main rotor shaft failure	Bk	4
480		2001-25-02		Failure of a hub plate	Bk	4
ENTWICKLUNGSGEMEINSCHAFT						
Phoebus A1	G16EU	70-21-03		Chute coupling	Bk	1
		75-18-01		Rudder control	Bk	1
Phoebus B1	G16EU	70-21-03		Chute coupling	Bk	1
		75-18-01		Rudder control	Bk	1
Phoebus C	G16EU	70-21-03		Chute coupling	Bk	1
ERICKSON AIR-CRANE CO.						
(See Firefly Aviation Helicopter Services)						
EUROCOPTER CANADA LIMITED						
(Formerly MESSERSCHMITT-BOLKOW-BLOHM HELI. CANADA)						
BO-105LS A-3	H6NE	92-11-01		Torque indication hose assembly	Bk	3
		97-26-02		Inspect main rotor mast flange for cracks	Bk	3
		2000-18-13		TT strap	Bk	4
		2006-15-14		Fixed bolts and nuts, main rotor nuts		
EUROCOPTER DEUTSCHLAND						
(Formerly MESSERSCHMITT-BOLKOW-BLOHM-GMBH)						
(For ADs in Book 1 see Messerschmitt-Bolkow)						
BO-105 Series	H3EU	75-14-01		Hose assemblies	Bk	1
		75-14-02		Rotor hub quadruple nuts	Bk	1
		77-11-02		Main rotor	Bk	1
		78-19-03		Safety belts	Bk	1
		79-24-06		Tail rotor blades	Bk	1
		80-10-02		Tail rotor system	Bk	2
		80-16-01	R1	Engine cowling assemblies	Bk	2
		81-03-01		Drive shafts	Bk	2
		84-16-01	L	Tail rotor blade inspection	Bk	2
		85-08-01		Vertical fin spar and skins	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
BO-105 Series continued		85-26-02		Hydraulic actuator	Bk	2
		87-09-03		Rotor blade bolts	Bk	2
		87-19-01		STC SH479GL labels	Bk	2
		87-26-02	R1	Main rotor control rods	Bk	2
BO-105	H3EU	96-08-04		Tandem hydraulic system	Bk	3
BO-105A	H3EU	75-17-13		Tail rotor blade tip cap	Bk	1
		75-17-27		Main rotor head assembly	Bk	1
		76-18-09		Main rotor actuator	Bk	1
		76-18-10		Engine mount assembly	Bk	1
		76-26-05		Rotor brake	Bk	1
		77-04-06		Main rotor gearbox	Bk	1
		77-08-07		External load release	Bk	1
		77-15-01		Tail rotor drive system	Bk	1
		77-16-07		Main rotor gearbox	Bk	1
BO-105A		77-21-07		Wiring	Bk	1
		96-08-04		Tandem hydraulic system	Bk	3
		97-26-02		Inspect main rotor mast flange for cracks	Bk	3
		2000-17-08		TT strap	Bk	4
		2002-13-06		T-T strap	Bk	4
BO-105C Series	H3EU	90-23-08		Continuous ignition system	Bk	3
		96-08-04		Tandem hydraulic system	Bk	3
		97-26-02		Inspect main rotor mast flange for cracks	Bk	3
		2000-17-08		TT strap	Bk	4
		2000-26-01		Tension torsion (TT) strap	Bk	4
		2002-13-06		T-T strap	Bk	4
BO-105C	H3EU	75-17-13		Tail rotor blade tip cap	Bk	1
		75-17-27		Main rotor head assembly	Bk	1
		76-18-09		Main rotor actuator	Bk	1
		76-18-10		Engine mount assembly	Bk	1
		76-26-05		Rotor brake	Bk	1
		77-04-06		Main rotor gearbox	Bk	1
		77-08-07		External load release	Bk	1
		77-15-01		Tail rotor drive system	Bk	1
		77-16-07		Main rotor gearbox	Bk	1
		77-21-07		Wiring	Bk	1
		2002-13-06		T-T strap	Bk	4
BO-105S Series	H3EU	90-23-08		Continuous ignition system	Bk	3
		96-08-04		Tandem hydraulic system	Bk	3
		97-26-02		Inspect main rotor mast flange for cracks	Bk	3
		2000-17-08		TT strap	Bk	4
		2002-13-06		T-T strap	Bk	4
BO-105LS Series	H3EU	87-09-03		Rotor blade bolts	Bk	2
		96-08-04		Tandem hydraulic system	Bk	3
		97-26-02		Inspect main rotor mast flange for cracks	Bk	3
		2000-17-08		TT strap	Bk	4
		2002-13-06		T-T strap	Bk	4
BK117 Series	H13EU	87-09-03		Rotor blade bolts	Bk	2
		87-19-01		STC SH1853SO labels	Bk	2
		91-06-11		Landing gear bonding jumpers	Bk	3
		2000-06-07		Bevel gear	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
BK117A-1	H13EU	88-22-02		RFM revisions	Bk	2
		88-23-02		VNE placards	Bk	2
		95-08-12		Access door	Bk	3
		95-21-12		Inspect main rotor blades	Bk	3
		97-23-07		Record new life limit of clutch	Bk	3
		97-26-03		Inspect main rotor mast flange for cracks	Bk	3
		98-24-13		Tail boom vertical fin	Bk	3
		2000-08-16		Cowling doors	Bk	4
		2000-26-06		Failure of tension torsion	Bk	4
		2004-01-10		TR transmission & INT gearbox magnetic plugs	Bk	4
		2004-13-05		Skin paneling of vertical fin	Bk	4
BK117A-3	H13EU	86-09-03	R1	Tail rotor blades	Bk	2
		88-22-02		RFM revisions	Bk	2
		88-23-02		VNE placards	Bk	2
		95-08-12		Access door	Bk	3
		95-21-12		Inspect main rotor blades	Bk	3
		97-23-07		Record new life limit of clutch	Bk	3
		97-26-03		Inspect main rotor mast flange for cracks	Bk	3
		98-24-13		Tail boom vertical fin	Bk	3
		2000-08-16		Cowling doors	Bk	4
		2000-26-06		Failure of tension torsion	Bk	4
		2004-01-10		TR transmission & INT gearbox magnetic plugs	Bk	4
		2004-13-05		Skin paneling of vertical fin	Bk	4
BK117A-4	H13EU	88-22-02		RFM revisions	Bk	2
		88-23-02		VNE placards	Bk	2
		95-08-12		Access door	Bk	3
		95-21-12		Inspect main rotor blades	Bk	3
		97-23-07		Record new life limit of clutch	Bk	3
		97-26-03		Inspect main rotor mast flange for cracks	Bk	3
		98-24-13		Tail boom vertical fin	Bk	3
		2000-08-16		Cowling doors	Bk	4
		2000-26-06		Failure of tension torsion	Bk	4
		2004-01-10		TR transmission & INT gearbox magnetic plugs	Bk	4
		2004-13-05		Skin paneling of vertical fin	Bk	4
BK117B-1	H13EU	95-08-12		Access door	Bk	3
		95-21-12		Inspect main rotor blades	Bk	3
		97-23-07		Record new life limit of clutch	Bk	3
		97-26-03		Inspect main rotor mast flange for cracks	Bk	3
		98-24-13		Tail boom vertical fin	Bk	3
		2000-08-16		Cowling doors	Bk	4
		2000-26-06		Failure of tension torsion	Bk	4
		2004-01-10		TR transmission & INT gearbox magnetic plugs	Bk	4
		2004-13-05		Skin paneling of vertical fin	Bk	4
BK117B-2	H13EU	95-08-12		Access door	Bk	3
		95-21-12		Inspect main rotor blades	Bk	3
		97-23-07		Record new life limit of clutch	Bk	3
		97-26-03		Inspect main rotor mast flange for cracks	Bk	3
		98-24-13		Tail boom vertical fin	Bk	3
		2000-08-16		Cowling doors	Bk	4
		2000-26-06		Failure of tension torsion	Bk	4
		2004-01-10		TR transmission & INT gearbox magnetic plugs	Bk	4
		2004-13-05		Skin paneling of vertical fin	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
BK117C-1	H13EU	95-08-12		Access door	Bk	3
		95-21-12		Inspect main rotor blades	Bk	3
		97-23-07		Record new life limit of clutch	Bk	3
		97-26-03		Inspect main rotor mast flange for cracks	Bk	3
		98-24-13		Tail boom vertical fin	Bk	3
		2000-08-16		Cowling doors	Bk	4
		2000-26-06		Failure of tension torsion	Bk	4
		2004-01-10		TR transmission & INT gearbox magnetic plugs	Bk	4
		2004-13-05		Skin paneling of vertical fin	Bk	4
BK117C-2						
		2006-26-51		Tail rotor control lever		
EC135 Series	H88EU	2000-10-07		Oil cooler fan splined drive shaft	Bk	4
		2000-13-08		Tail rotor drive shaft vibration survey	Bk	4
		2001-26-52		Erroneous flight or navigation display info.	Bk	4
		2002-11-01		Fail caution indication display software	Bk	4
		2002-14-17		Main rotor hub shaft	Bk	4
EC135P1, EC135P2	H88EU	99-22-01		Inspect tail boom frame flange	Bk	3
		2004-22-11		RFM - Emergency Procedure Section	Bk	4
EC135T1, EC135T2		2000-01-19		Main rotor blade expansion bolt	Bk	4
		2000-26-02		Replace stator blade assembly	Bk	4
		2000-26-12		Prevent damage to the hose	Bk	4
		2004-22-11		RFM - Emergency Procedure Section	Bk	4
EUROCOPTER FRANCE						
(Formerly AEROSPATIALE)						
(For ADs in Bk 1 see Aerospatiale)						
Alouette III SA315B	H1IN	73-09-03		Main rotor gear box	Bk	1
		75-16-06		Tail rotor gear box	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-26-02		Main rotor head	Bk	1
		75-27-05		Main rotor blades	Bk	1
		81-03-04		Main gearshaft	Bk	2
		81-06-04		Transmission deck & bellcrank support	Bk	2
		81-21-01		ERC cargo hook assys	Bk	2
		84-01-03	R1	"A" frame support assys	Bk	2
		85-07-07		Control rod	Bk	2
		88-12-11		Main drive shaft	Bk	2
		93-23-04		Install V_{NE} placard	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		99-05-14		Main rotor blade cuff attachment fitting	Bk	3
		99-07-08		Main rotor blade root reinforcement strip	Bk	3
		99-21-25		Inspect MGB magnetic plug for metal particles	Bk	3
		2000-02-32		Horizontal stabilizer spar tube	Bk	4
		2000-05-11		Tail rotor blade	Bk	4
		2001-04-13		Prevent a blade separation	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
		2003-15-51		Blade	Bk	4
Alouette III SA316B	H1IN	73-09-03		Main rotor gear box	Bk	1
		75-16-06		Tail rotor gear box	Bk	1
		75-21-03		Tail boom	Bk	1
		75-22-21		Main gear boxes	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-26-02		Main rotor head	Bk	1
		75-27-05		Main rotor blades	Bk	1
		76-18-02		Tail rotor controls	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		77-14-03		Tail rotor directional control	Bk	1
		81-03-04		Main gearshaft	Bk	2
		81-06-04		Transmission deck & bellcrank support	Bk	2
Alouette III SA316B continued		84-01-03	R1	"A" frame support assys	Bk	2
		88-12-11		Main drive shaft	Bk	2
		93-23-04		Install V_{NE} placard	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		98-24-23		Horizontal stabilizer	Bk	3
		99-05-14		Main rotor blade cuff attachment fitting	Bk	3
		99-08-06		Main rotor blade root reinforcement strip	Bk	3
		99-21-25		Inspect MGB magnetic plug for metal particles	Bk	3
		2000-05-11		Tail rotor blade	Bk	4
		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2001-04-13		Prevent a blade separation	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-15-51		Blade	Bk	4
Alouette III SA316C	H1IN	73-09-03		Main rotor gear box	Bk	1
		75-21-03		Tail boom	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-26-02		Main rotor head	Bk	1
		75-27-05		Main rotor blades	Bk	1
		76-18-02		Tail rotor controls	Bk	1
		78-23-03		Flight control support fittings	Bk	1
		81-03-04		Main gearshaft	Bk	2
		81-06-04		Transmission deck & bellcrank support	Bk	2
		84-01-03	R1	"A" frame support assys	Bk	2
		88-12-11		Main drive shaft	Bk	2
		93-23-04		Install V_{NE} placard	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		98-24-23		Horizontal stabilizer	Bk	3
		99-05-14		Main rotor blade cuff attachment fitting	Bk	3
		99-08-06		Main rotor blade root reinforcement strip	Bk	3
		99-21-25		Inspect MGB magnetic plug for metal particles	Bk	3
		2000-05-11		Tail rotor blade	Bk	4
		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2001-04-13		Prevent a blade separation	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-15-51		Blade	Bk	4
Alouette III SA319B	H1IN	73-09-03		Main rotor gear box	Bk	1
		75-16-06		Tail rotor gear box	Bk	1
		75-21-03		Tail boom	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-26-02		Main rotor head	Bk	1
		75-27-05		Main rotor blades	Bk	1
		76-18-02		Tail rotor controls	Bk	1
		78-23-03		Flight control support fittings	Bk	1
		81-03-04		Main gearshaft	Bk	2
		81-06-04		Transmission deck & bellcrank support	Bk	2
		84-01-03	R1	"A" frame support assys	Bk	2
		88-12-11		Main drive shaft	Bk	2
		93-23-04		Install V_{NE} placard	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		98-24-23		Horizontal stabilizer	Bk	3
		99-05-14		Main rotor blade cuff attachment fitting	Bk	3
		99-08-06		Main rotor blade root reinforcement strip	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		99-21-25		Inspect MGB magnetic plug for metal particles	Bk	3
		2000-05-11		Tail rotor blade	Bk	4
Alouette III SA319B continued		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2001-04-13		Prevent a blade separation	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-15-51		Blade	Bk	4
Alouette III SE3160	H1IN	75-16-06		Tail rotor gear box	Bk	1
		75-21-03		Tail boom	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-26-02		Main rotor head	Bk	1
		75-27-05		Main rotor blades	Bk	1
		76-18-02		Tail rotor controls	Bk	1
		77-14-03		Tail rotor directional control	Bk	1
		84-01-03	R1	"A" frame support assys	Bk	2
		88-12-11		Main drive shaft	Bk	2
		93-23-04		Install V_{NE} placard	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		98-24-23		Horizontal stabilizer	Bk	3
		99-05-14		Main rotor blade cuff attachment fitting	Bk	3
		99-08-06		Main rotor blade root reinforcement strip	Bk	3
		99-21-25		Inspect MGB magnetic plug for metal particles	Bk	3
		2000-05-11		Tail rotor blade	Bk	4
		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2001-04-13		Prevent a blade separation	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
		2003-15-51		Blade	Bk	4
SA.341G Gazelle	H6EU	75-17-20		Main rotor blade	Bk	1
		75-17-25		Main rotor head	Bk	1
		75-17-26		Over-torquing of engine	Bk	1
		75-22-07		Main gear boxes	Bk	1
		75-27-04		Fuel system modification	Bk	1
		76-02-02		Tail rotor drive system	Bk	1
		76-02-03		Hydraulic unit	Bk	1
		76-07-10		Main gear box attach	Bk	1
		77-22-04		Landing gear	Bk	1
		98-06-36		Inspect tail gearbox support tripod	Bk	3
		99-11-03		Main rotor head pitch change rod	Bk	3
		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2002-08-16		Tie Bar	Bk	4
		2003-04-13		Electric hoist junction box	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
SA342J	H6EU	98-06-36		Inspect tail gearbox support tripod	Bk	3
		99-11-03		Main rotor head pitch change rod	Bk	3
		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2002-08-16		Tie Bar	Bk	4
		2003-04-13		Electric hoist junction box	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
SA330 Series	H4EU	80-18-51		Hydraulic fluid an electrical wires	Bk	2
		81-21-06		Main rotor heads	Bk	2
		82-12-07		Tail rotor transmission assy.	Bk	2
		88-15-02		Main rotor head spindles	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
SA330F	H4EU	75-17-14	Main rotor blades	Bk	1
		75-22-08	Pyrotechnic shears	Bk	1
		76-19-06	Main rotor blades	Bk	1
		77-14-02	Forward engine mount	Bk	1
		78-21-04	Yaw control bellcrank	Bk	1
		78-24-03	Main gear box	Bk	1
		79-21-04	Tail boom structure	Bk	1
		81-01-52	Jettisonable pilot door	Bk	2
		82-18-04	Main bevel gear wheel	Bk	2
		98-08-13	Inspect spider arm roots for cracks	Bk	3
		98-12-16	Intermediate gearbox (IGB) fairing safety stop	Bk	3
		98-13-40	Common ground of transformer-rectifiers	Bk	3
		98-23-03	Bonding braids	Bk	3
		98-23-09	Tail rotor shaft flapping hinge retainer	Bk	3
		99-07-02	Main rotor blade	Bk	3
		2000-06-05	Tail rotor blade	Bk	4
		2000-10-05	Emergency flotation gear nitrogen cylinder	Bk	4
		2000-22-19	Tail rotor blades	Bk	4
		2002-12-14	RFM - atmospheric conditions	Bk	4
		2002-15-08	Cargo hook	Bk	4
		2002-18-05	Collector bearing	Bk	4
		2002-18-06	Gearbox	Bk	4
		2002-20-03	Metal ferry fuel tank	Bk	4
		2002-25-01	Tail rotor pitch change spider assembly	Bk	4
		2003-14-12	Main or tail rotor part	Bk	4
SA330G	H4EU	75-17-14	Main rotor blades	Bk	1
		75-22-08	Pyrotechnic shears	Bk	1
		76-19-06	Main rotor blades	Bk	1
		77-14-02	Forward engine mount	Bk	1
		78-21-04	Yaw control bellcrank	Bk	1
		78-24-03	Main gear box	Bk	1
		81-01-52	Jettisonable pilot door	Bk	2
		82-18-04	Main bevel gear wheel	Bk	2
		98-08-13	Inspect spider arm roots for cracks	Bk	3
		98-12-16	Intermediate gearbox (IGB) fairing safety stop	Bk	3
		98-13-40	Common ground of transformer-rectifiers	Bk	3
		98-23-03	Bonding braids	Bk	3
		98-23-09	Tail rotor shaft flapping hinge retainer	Bk	3
		99-07-02	Main rotor blade	Bk	3
		2000-06-05	Tail rotor blade	Bk	4
		2000-10-05	Emergency flotation gear nitrogen cylinder	Bk	4
		2000-22-19	Tail rotor blades	Bk	4
		2002-12-14	RFM - atmospheric conditions	Bk	4
		2002-15-08	Cargo hook	Bk	4
		2002-18-05	Collector bearing	Bk	4
		2002-18-06	Gearbox	Bk	4
		2002-20-03	Metal ferry fuel tank	Bk	4
		2002-25-01	Tail rotor pitch change spider assembly	Bk	4
		2003-14-12	Main or tail rotor part	Bk	4
SA330J	H4EU	81-01-52	Jettisonable pilot door	Bk	2
		82-18-04	Main bevel gear wheel	Bk	2
		82-19-03	Main rotor spindles	Bk	2
		82-25-04	Flapping hinge pin nut	Bk	2
		98-08-13	Inspect spider arm roots for cracks	Bk	3
		98-12-16	Intermediate gearbox (IGB) fairing safety stop	Bk	3
		98-13-40	Common ground of transformer-rectifiers	Bk	3
		98-23-03	Bonding braids	Bk	3
		98-23-09	Tail rotor shaft flapping hinge retainer	Bk	3
		99-07-02	Main rotor blade	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA330J continued		99-07-07		Main rotor head sleeve	Bk	3
		2000-06-05		Tail rotor blade	Bk	4
		2000-10-05		Emergency flotation gear nitrogen cylinder	Bk	4
		2000-22-19		Tail rotor blades	Bk	4
		2002-12-14		RFM - atmospheric conditions	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-18-05		Collector bearing	Bk	4
		2002-18-06		Gearbox	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-25-01		Tail rotor pitch change spider assembly	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
AS332C	H4EU	82-22-05		Main rotor spindles	Bk	2
		85-22-09	R1	Placard -icing conditions	Bk	2
		87-21-09		AC electrical generation system	Bk	2
		98-06-32		Main rotor blade horn eye bolt bearing	Bk	3
		98-06-39		Inspect shim washers of cockpit door tenons	Bk	3
		98-07-20		Tail rotor blades	Bk	3
		98-08-13		Inspect spider arm roots for cracks	Bk	3
		98-12-15		Inspect stirrup front tabs for cracks	Bk	3
		98-13-39		Inspect tail rotor shaft flapping hinge retainer	Bk	3
		98-23-04		Main rotor blade	Bk	3
		98-24-21		Rotor drive engine-to-main gearbox coupling	Bk	3
		99-02-13		Main rotor hub spindles or hinge pins	Bk	3
		99-06-04		Inspect circuit breakers	Bk	3
		99-07-02		Main rotor blade	Bk	3
		99-21-13		Bolts of hoist arm lower fitting	Bk	3
		99-22-12		“CONNECTRAL” green electrical module	Bk	3
		99-23-17		Main gearbox epicyclic module attachment bolt	Bk	3
		2000-06-05		Tail rotor blade	Bk	4
		2000-20-17		Spar tube	Bk	4
		2001-25-07		Prevent power loss due to fuel starvation	Bk	4
		2002-12-14		RFM - atmospheric conditions	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-18-05		Collector bearing	Bk	4
		2002-18-06		Gearbox	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-22-09		RFM - Limitations - icing	Bk	4
		2002-25-01		Tail rotor pitch change spider assembly	Bk	4
		2003-11-13		Hydraulic reservoir adapter	Bk	4
		2003-11-21		RFM - Limitations - OEI	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-21-08		Main rotor blade	Bk	4
		2003-24-02		Anti-torque pedal adjustment lever	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-03-27		Bevel gears	Bk	4
AS332C1	--	2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
AS332CL	--	85-22-09	R1	Placard -icing conditions	Bk	2
AS332L	H4EU	82-22-05		Main rotor spindles	Bk	2
		85-22-09	R1	Placard -icing conditions	Bk	2
		87-21-09		AC electrical generation system	Bk	2
		98-06-32		Main rotor blade horn eye bolt bearing	Bk	3
		98-06-39		Inspect shim washers of cockpit door tenons	Bk	3
		98-07-20		Tail rotor blades	Bk	3
		98-08-13		Inspect spider arm roots for cracks	Bk	3
		98-12-15		Inspect stirrup front tabs for cracks	Bk	3
		98-13-39		Inspect tail rotor shaft flapping hinge retainer	Bk	3
		98-23-04		Main rotor blade	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AS332L continued		98-24-21		Rotor drive engine-to-main gearbox coupling	Bk	3
		99-02-13		Main rotor hub spindles or hinge pins	Bk	3
		99-06-04		Inspect circuit breakers	Bk	3
		99-07-02		Main rotor blade	Bk	3
		99-21-13		Bolts of hoist arm lower fitting	Bk	3
		99-22-12		“CONNECTRAL” green electrical module	Bk	3
		99-23-17		Main gearbox epicyclic module attachment bolt	Bk	3
		2000-06-05		Tail rotor blade	Bk	4
		2000-20-17		Spar tube	Bk	4
		2001-25-07		Prevent power loss due to fuel starvation	Bk	4
		2002-12-14		RFM - atmospheric conditions	Bk	4
		2002-14-01		RFM - Limitations section - Skis	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-18-05		Collector bearing	Bk	4
		2002-18-06		Gearbox	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-22-09		RFM - Limitations - icing	Bk	4
		2002-25-01		Tail rotor pitch change spider assembly	Bk	4
		2003-11-13		Hydraulic reservoir adapter	Bk	4
		2003-11-21		RFM - Limitations - OEI	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-21-08		Main rotor blade	Bk	4
		2003-24-02		Anti-torque pedal adjustment lever	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-03-27		Bevel gears	Bk	4
AS332L1	H4EU	85-22-09	R1	Placard -icing conditions	Bk	2
		98-06-32		Main rotor blade horn eye bolt bearing	Bk	3
		98-06-39		Inspect shim washers of cockpit door tenons	Bk	3
		98-07-20		Tail rotor blades	Bk	3
		98-08-13		Inspect spider arm roots for cracks	Bk	3
		98-12-15		Inspect stirrup front tabs for cracks	Bk	3
		98-13-39		Inspect tail rotor shaft flapping hinge retainer	Bk	3
		98-23-04		Main rotor blade	Bk	3
		98-24-21		Rotor drive engine-to-main gearbox coupling	Bk	3
		99-02-13		Main rotor hub spindles or hinge pins	Bk	3
		99-06-04		Inspect circuit breakers	Bk	3
		99-07-02		Main rotor blade	Bk	3
		99-21-13		Bolts of hoist arm lower fitting	Bk	3
		99-22-12		“CONNECTRAL” green electrical module	Bk	3
		99-23-17		Main gearbox epicyclic module attachment bolt	Bk	3
		2000-06-05		Tail rotor blade	Bk	4
		2000-20-17		Spar tube	Bk	4
		2001-25-07		Prevent power loss due to fuel starvation	Bk	4
		2002-12-14		RFM - atmospheric conditions	Bk	4
		2002-14-01		RFM - Limitations section - Skis	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-18-05		Collector bearing	Bk	4
		2002-18-06		Gearbox	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-22-09		RFM - Limitations - icing	Bk	4
		2002-25-01		Tail rotor pitch change spider assembly	Bk	4
		2003-11-13		Hydraulic reservoir adapter	Bk	4
		2003-11-21		RFM - Limitations - OEI	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-21-08		Main rotor blade	Bk	4
		2003-24-02		Anti-torque pedal adjustment lever	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-03-27		Bevel gears	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
AS332L2	H4EU	98-04-48	Vibration absorber weight support assembly	Bk	3
		98-06-39	Inspect shim washers of cockpit door tenons	Bk	3
		98-08-13	Inspect spider arm roots for cracks	Bk	3
		98-12-15	Inspect stirrup front tabs for cracks	Bk	3
		98-24-21	Rotor drive engine-to-main gearbox coupling	Bk	3
		99-06-04	Inspect circuit breakers	Bk	3
		99-07-02	Main rotor blade	Bk	3
		99-10-15	Main rotor head drag damper	Bk	3
		99-11-10	Power-loss PCB	Bk	3
		2000-06-05	Tail rotor blade	Bk	4
		2000-12-03	Inspect plate slats	Bk	4
		2001-12-16	Sleeve-to-blade-damper assembly bolt	Bk	4
		2001-25-07	Prevent power loss due to fuel starvation	Bk	4
		2002-01-06	Main frame 5295	Bk	4
		2002-09-03	Life raft inflation cylinder air vent	Bk	4
		2002-12-02	Fire-extinguishing bottle	Bk	4
		2002-12-03	Main rotor shaft non-rotating scissors	Bk	4
		2002-15-08	Cargo hook	Bk	4
		2002-20-03	Metal ferry fuel tank	Bk	4
		2003-21-08	Main rotor blade	Bk	4
		2003-24-02	Anti-torque pedal adjustment lever	Bk	4
Alouette II SE3130	7H1	58-14-01	Rotor blade bonding	Bk	1
		58-22-04	Tail rotor drive shaft	Bk	1
		59-05-06	Oilite bearing replacement	Bk	1
		60-11-09	Rotor blades	Bk	1
		61-16-07	Main rotor hubs	Bk	1
		61-22-08	Tail rotor gear box bolts	Bk	1
		63-19-05	Main rotor hub	Bk	1
		63-19-06	Main rotor shaft	Bk	1
		67-15-04	Tail rotor gear box drive shaft	Bk	1
		75-16-06	Tail rotor gear box	Bk	1
		75-24-14	Excessive vibration	Bk	1
		75-27-05	Main rotor blades	Bk	1
		85-07-07	Control rod	Bk	2
		98-12-20	Horizontal stabilizer spar tube	Bk	3
		98-16-02	Tail rotor blade	Bk	3
		99-09-16	Inspect main rotor blade	Bk	3
		2000-03-06	Horizontal stabilizer spar tube	Bk	4
		2000-05-11	Tail rotor blade	Bk	4
		2002-01-30	MGB magnet plug	Bk	4
Alouette Astazou SA3180	7H1	72-16-08	Cracks in sleeves gear box oil line	Bk	1
		75-16-06	Tail rotor gear box	Bk	1
		75-24-14	Excessive vibration	Bk	1
		75-27-05	Main rotor blades	Bk	1
		85-07-07	Control rod	Bk	2
		88-12-11	Main drive shaft	Bk	2
		98-12-20	Horizontal stabilizer spar tube	Bk	3
		98-16-02	Tail rotor blade	Bk	3
		99-09-16	Inspect main rotor blade	Bk	3
		2000-03-06	Horizontal stabilizer spar tube	Bk	4
		2000-05-11	Tail rotor blade	Bk	4
		2001-18-51	Loss of power to the tail rotor	Bk	4
		2002-01-30	MGB magnet plug	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
Alouette II SE313B	7H1	75-16-06		Tail rotor gear box	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-27-05		Main rotor blades	Bk	1
		81-06-04		Transmission deck & bellcrank support	Bk	2
		85-07-07		Control rod	Bk	2
		98-12-20		Horizontal stabilizer spar tube	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		99-09-16		Inspect main rotor blade	Bk	3
		2000-03-06		Horizontal stabilizer spar tube	Bk	4
		2000-05-11		Tail rotor blade	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
Alouette Astazou SA318B	7H1	72-16-08		Cracks in sleeves gear box oil line	Bk	1
		75-16-06		Tail rotor gear box	Bk	1
		75-24-14		Excessive vibration	Bk	1
		81-06-04		Transmission deck & bellcrank support	Bk	2
		85-07-07		Control rod	Bk	2
		88-12-11		Main drive shaft	Bk	2
		98-12-20		Horizontal stabilizer spar tube	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		99-09-16		Inspect main rotor blade	Bk	3
		2000-03-06		Horizontal stabilizer spar tube	Bk	4
		2000-05-11		Tail rotor blade	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
Alouette Astazou SA318C	7H1	72-16-08		Cracks in sleeves gear box oil line	Bk	1
		75-16-06		Tail rotor gear box	Bk	1
		75-24-14		Excessive vibration	Bk	1
		75-27-05		Main rotor blades	Bk	1
		81-06-04		Transmission deck & bellcrank support	Bk	2
		85-07-07		Control rod	Bk	2
		88-12-11		Main drive shaft	Bk	2
		98-12-20		Horizontal stabilizer spar tube	Bk	3
		98-16-02		Tail rotor blade	Bk	3
		99-09-16		Inspect main rotor blade	Bk	3
		2000-03-06		Horizontal stabilizer spar tube	Bk	4
		2000-05-11		Tail rotor blade	Bk	4
		2001-18-51		Loss of power to the tail rotor	Bk	4
		2002-01-30		MGB magnet plug	Bk	4
AS-350 Series	H9EU	80-14-15		Flange inspection	Bk	2
		80-15-05		Spherical thrust bearing rear block	Bk	2
		80-15-13		Rotating drive adapter	Bk	2
		80-22-08		Tail rotor transmission	Bk	2
		81-09-06		Bevel gear modules	Bk	2
		81-13-09	R2	Tail rotor blades pitch horn	Bk	2
		82-10-01		Tail rotor blades	Bk	2
		82-13-05	R1	Upper vertical fin	Bk	2
		82-20-05		Tail rotor drive shaft	Bk	2
		83-07-05	R3	Main rotor mast	Bk	2
		86-19-15	R1	Main rotor head sleeves	Bk	2
		90-23-03		Main rotor servo control	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AS350B	H9EU	81-15-02		Float gear mounting brackets	Bk	2
		83-11-01	R1	Emergency flotation system	Bk	2
		95-11-06		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-08-06		Engine oil tank breather pipe	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-15-08		Main gearbox (MGB)	Bk	4
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-03-08		Fuel bleed lever	BW	05-04
		2006-11-17		Geneva cyclic control sticks	BW	06-12
		2006-19-01		Main servo-control (MSC)		
AS350B1	H9EU	95-11-06		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-08-06		Engine oil tank breather pipe	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-15-08		Main gearbox (MGB)	Bk	4
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-03-08		Fuel bleed lever	BW	05-04
		2006-11-17		Geneva cyclic control sticks	BW	06-12
		2006-19-01		Main servo-control (MSC)		
AS350B2	H9EU	95-11-06		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
		2002-04-07	Collective control locking device	Bk	4
AS350B2 continued		2002-06-04	Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08	Cargo hook	Bk	4
		2002-20-03	Metal ferry fuel tank	Bk	4
		2003-02-05	Middle rail roller	Bk	4
		2003-08-06	Engine oil tank breather pipe	Bk	4
		2003-14-12	Main or tail rotor part	Bk	4
		2003-15-08	Main gearbox (MGB)	Bk	4
		2003-22-06	Outboard spherical bearing ball	Bk	4
		2003-22-11	Main servocontrol	Bk	4
		2003-25-01	Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-05-23	Main rotor swashplate bearing	Bk	4
		2005-03-08	Fuel bleed lever	BW	05-04
		2006-11-17	Geneva cyclic control sticks	BW	06-12
		2006-19-01	Main servo-control (MSC)		
AS350B3	H9EU	2000-10-09	Crouzet single-pole circuit breaker	Bk	4
		2000-16-52	Fairing heat shield	Bk	4
		2000-20-19	Main rotor head or gearbox suspension	Bk	4
		2001-04-14	Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32	Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55	Failure of the tail rotor blade	Bk	4
		2002-03-52	Bonding between metal bushing & arm ends	Bk	4
		2002-06-04	Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08	Cargo hook	Bk	4
		2002-20-03	Metal ferry fuel tank	Bk	4
		2003-02-05	Middle rail roller	Bk	4
		2003-08-05	ASU No. 2 printed circuit board (PCB)	Bk	4
		2003-14-12	Main or tail rotor part	Bk	4
		2003-15-08	Main gearbox (MGB)	Bk	4
		2003-20-12	Siren cargo hook locking catch	Bk	4
		2003-22-06	Outboard spherical bearing ball	Bk	4
		2003-22-11	Main servocontrol	Bk	4
		2003-25-01	Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-05-23	Main rotor swashplate bearing	Bk	4
		2004-11-05	Air exhaust duct and fuel transfer line	Bk	4
		2005-03-08	Fuel bleed lever	BW	05-04
		2006-11-17	Geneva cyclic control sticks	BW	06-12
		2006-19-01	Main servo-control (MSC)		
AS350BA	H9EU	95-11-06	MGB oil pressure switch	Bk	3
		96-07-03	Cyclic pitch change control rod	Bk	3
		98-06-12	Bolts of tailboom	Bk	3
		2000-10-09	Crouzet single-pole circuit breaker	Bk	4
		2000-20-19	Main rotor head or gearbox suspension	Bk	4
		2001-04-14	Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32	Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55	Failure of the tail rotor blade	Bk	4
		2002-03-52	Bonding between metal bushing & arm ends	Bk	4
		2002-04-07	Collective control locking device	Bk	4
		2002-06-04	Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08	Cargo hook	Bk	4
		2002-20-03	Metal ferry fuel tank	Bk	4
		2003-02-05	Middle rail roller	Bk	4
		2003-08-06	Engine oil tank breather pipe	Bk	4
		2003-14-12	Main or tail rotor part	Bk	4
		2003-15-08	Main gearbox (MGB)	Bk	4
		2003-22-06	Outboard spherical bearing ball	Bk	4
		2003-22-11	Main servocontrol	Bk	4
		2003-25-01	Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-05-23	Main rotor swashplate bearing	Bk	4
		2005-03-08	Fuel bleed lever	BW	05-04

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2006-11-17		Geneva cyclic control sticks	BW	06-12
		2006-19-01		Main servo-control (MSC)		
AS350C	H9EU	81-15-02		Float gear mounting brackets	Bk	2
		83-11-01	R1	Emergency flotation system	Bk	2
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-03-08		Fuel bleed lever	BW	05-04
		2006-11-17		Geneva cyclic control sticks	BW	06-12
AS350D	H9EU	81-15-02		Float gear mounting brackets	Bk	2
		83-11-01	R1	Emergency flotation system	Bk	2
		95-11-06		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-08-06		Engine oil tank breather pipe	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-15-08		Main gearbox (MGB)	Bk	4
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-03-08		Fuel bleed lever	BW	05-04
		2006-11-17		Geneva cyclic control sticks	BW	06-12
		2006-19-01		Main servo-control (MSC)		
AS350D-1	H9EU	81-15-02		Float gear mounting brackets	Bk	2
		83-11-01	R1	Emergency flotation system	Bk	2
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-03-08		Fuel bleed lever	BW	05-04
		2006-11-17		Geneva cyclic control sticks	BW	06-12
EC130 B4	H9EU	2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2004-01-14		Air intake cowling forward attachment fitting	Bk	4
		2004-11-05		Air exhaust duct and fuel transfer line	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2005-03-08		Fuel bleed lever	BW	05-04
		2006-10-19		Throttle twist grip (twist grip) assembly	BW	06-13
AS355 Series	H11EU	81-13-09	R2	Tail rotor blades pitch horns	Bk	2
		82-10-01		Tail rotor blades	Bk	2
		82-13-05	R1	Upper vertical fin	Bk	2
		82-20-05		Tail rotor drive shaft	Bk	2
		83-07-05	R3	Main rotor mast	Bk	2
		83-08-04	R3	Epicyclic planet pinion cages	Bk	2
		83-19-04		Splined flange inspection	Bk	2
		86-19-15	R1	Main rotor head sleeves	Bk	2
		87-13-05	R1	Main gearbox suspension bars	Bk	2
		87-19-01		STC SH673GL label removal	Bk	2
		88-25-09		Tail rotor drive shaft	Bk	2
		90-23-03		Main rotor servo control	Bk	3
AS355E	H11EU	89-01-01		Engine automatic relight system	Bk	2
		95-11-05		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-21-09	R1	Magnetic chip detector plug (chip detector) and the main gearbox (MGB) oil-sight glass	BW	06-12
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-01-09		Circuit breakers	Bk	4
		2004-01-51		Main gearbox or combiner gearbox	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-10-14		Main or combiner gearboxes	BW	05-11
		2006-19-01		Main servo-control (MSC)		
AS355F	H11EU	89-01-01		Engine automatic relight system	Bk	2
		95-11-05		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-21-09	R1	Magnetic chip detector plug (chip detector) and the main gearbox (MGB) oil-sight glass	BW	06-12

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
AS355F continued		2004-01-09		Circuit breakers	Bk	4
		2004-01-51		Main gearbox or combiner gearbox	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-10-14		Main or combiner gearboxes	BW	05-11
AS355F1	H11EU	89-01-01		Engine automatic relight system	Bk	2
		95-11-05		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-21-09	R1	Magnetic chip detector plug (chip detector) and the main gearbox (MGB) oil-sight glass	BW	06-12
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-01-09		Circuit breakers	Bk	4
		2004-01-51		Main gearbox or combiner gearbox	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-10-14		Main or combiner gearboxes	BW	05-11
AS355F2	H11EU	95-11-05		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-21-09	R1	Magnetic chip detector plug (chip detector) and the main gearbox (MGB) oil-sight glass	BW	06-12
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-01-09		Circuit breakers	Bk	4
		2004-01-51		Main gearbox or combiner gearbox	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-10-14		Main or combiner gearboxes	BW	05-11

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
AS355N	H11EU	95-11-05		MGB oil pressure switch	Bk	3
		96-07-03		Cyclic pitch change control rod	Bk	3
		98-06-12		Bolts of tailboom	Bk	3
		2000-10-09		Crouzet single-pole circuit breaker	Bk	4
		2000-20-19		Main rotor head or gearbox suspension	Bk	4
		2000-25-08		Rotation of the main gearbox	Bk	4
		2001-04-14		Eliminate confusion and unnecessary costs	Bk	4
		2001-17-32		Rotation of the spider assembly bearing spacers	Bk	4
		2001-26-55		Failure of the tail rotor blade	Bk	4
		2002-03-52		Bonding between metal bushing & arm ends	Bk	4
		2002-06-04		Tail rotor hub pitch change plate bearing	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-22-16		Starter-generator (S-G) attachment clamp	Bk	4
		2003-02-05		Middle rail roller	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-21-09	R1	Magnetic chip detector plug (chip detector) and the main gearbox (MGB) oil-sight glass	BW	06-12
		2003-22-06		Outboard spherical bearing ball	Bk	4
		2003-22-11		Main servocontrol	Bk	4
		2003-25-01		Hoist pyrotechnic squib electrical control unit	Bk	4
		2004-01-09		Circuit breakers	Bk	4
		2004-01-51		Main gearbox or combiner gearbox	Bk	4
		2004-05-23		Main rotor swashplate bearing	Bk	4
		2005-10-14		Main or combiner gearboxes	BW	05-11
SA-360C Series	H8EU	80-21-52		Main rotor speed loss	Bk	2
		81-14-51	R1	Tail rotor fairing and hub	Bk	2
		81-26-02		Stabilizer spar tube structure	Bk	2
		82-05-04		Pilot/co-pilot seat slides	Bk	2
		97-26-18		MGB bevel pinion P/N 360A32-1021-20	Bk	3
SA-360C	H8EU	81-01-51		Tail boom	Bk	2
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-21-01		Electrical systems	Bk	3
		99-21-14		Inspect electrical master box assy	Bk	3
		2002-08-16		Tie Bar	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2006-08-06		Main gearbox (MGB) base plate	BW	06-08
SA-365 Series	H10EU	85-15-01	R2	Main rotor mask	Bk	2
		86-21-01		Main rotor head sleeves	Bk	2
SA-365C Series	H10EU	80-15-05		Spherical thrust bearing rear block	Bk	2
		81-10-09		Tail rotor gearbox mount assy	Bk	2
		81-14-51	R1	Tail rotor fairing and hub	Bk	2
		81-26-02		Stabilizer spar tube structure	Bk	2
		82-05-04		Pilot/co-pilot seat slides	Bk	2
SA365C	H10EU	81-01-51		Tail boom	Bk	2
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-21-01		Electrical systems	Bk	3
		99-21-14		Inspect electrical master box assy	Bk	3
		2000-11-18		Main rotor hub blade bolts	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2006-08-06		Main gearbox (MGB) base plate	BW	06-08

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SA365C1	H10EU	81-01-51		Tail boom	Bk	2
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-21-01		Electrical systems	Bk	3
		99-21-14		Inspect electrical master box assy	Bk	3
		2000-11-18		Main rotor hub blade bolts	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2005-03-09		Main gearbox (MGB) planet gear	BW 05-04	
		2006-08-06		Main gearbox (MGB) base plate	BW 06-08	
SA365C2	H10EU	81-01-51		Tail boom	Bk	2
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-21-01		Electrical systems	Bk	3
		99-21-14		Inspect electrical master box assy	Bk	3
		2000-11-18		Main rotor hub blade bolts	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2005-03-09		Main gearbox (MGB) planet gear	BW 05-04	
		2006-08-06		Main gearbox (MGB) base plate	BW 06-08	
SA365N, N1	H10EU	81-14-51	R1	Tail rotor fairing and hub	Bk	2
		88-08-03		Attachment beam bolts	Bk	2
		96-09-03		Door jettison handle	Bk	3
		98-05-17		Outboard fin attachment studs	Bk	3
		98-08-14		Inspect diagonal cross-member for cracks	Bk	3
		98-12-08		Main gearbox strut attachment	Bk	3
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-06-03		Main rotor head frequency adapter	Bk	3
		99-11-11		Inspect MGB planetary gear shaft for cracks	Bk	3
		99-21-14		Inspect electrical master box assy	Bk	3
		99-23-02		“CONNECTRAL” green electrical module	Bk	3
		2000-10-13		Inspect window panel	Bk	4
		2000-11-17		Inspect Kevlar tie-bar for crack or delamination	Bk	4
		2000-11-18		Main rotor hub blade bolts	Bk	4
		2000-15-19		Sand filter ejection nozzle	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-23-04		Passenger door latch support	Bk	4
		2003-08-53		Blade	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-18-03		Hose and emergency flotation gear pipe	Bk	4
		2003-20-12		Siren cargo hook locking catch	Bk	4
		2003-22-15		Fuel air vent hose	Bk	4
		2004-16-15		Main gearbox (MGB)	Bk	4
		2004-16-15	R1			
		2005-03-09		Main gearbox (MGB) planet gear	BW 05-04	
		2005-13-23		Hydraulic brake hose (hose)	BW 05-13	
		2006-06-02		Main gearbox (MGB)	BW 06-06	
		2006-09-10		Pitch control rod assembly double bearing (bearing)	BW 06-10	
AS365N2	H10EU	96-09-03		Door jettison handle	Bk	3
		98-05-17		Outboard fin attachment studs	Bk	3
		98-08-14		Inspect diagonal cross-member for cracks	Bk	3
		98-12-08		Main gearbox strut attachment	Bk	3
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-06-03		Main rotor head frequency adapter	Bk	3
		99-11-11		Inspect MGB planetary gear shaft for cracks	Bk	3
		99-23-02		“CONNECTRAL” green electrical module	Bk	3
		2000-10-13		Inspect window panel	Bk	4
		2000-11-17		Inspect Kevlar tie-bar for crack or delamination	Bk	4
		2000-11-18		Main rotor hub blade bolts	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2000-15-19		Sand filter ejection nozzle	Bk	4
AS365N2 continued		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-23-04		Passenger door latch support	Bk	4
		2003-08-53		Blade	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-18-03		Hose and emergency flotation gear pipe	Bk	4
		2003-20-12		Siren cargo hook locking catch	Bk	4
		2003-22-15		Fuel air vent hose	Bk	4
		2004-16-15		Main gearbox (MGB)	Bk	4
		2004-16-15	R1			
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2005-13-23		Hydraulic brake hose (hose)	BW	05-13
		2006-06-02		Main gearbox (MGB)	BW	06-06
		2006-09-10		Pitch control rod assembly double bearing (bearing)	BW	06-10
AS365N3	H10EU	99-11-11		Inspect MGB planetary gear shaft for cracks	Bk	3
		2000-10-13		Inspect window panel	Bk	4
		2000-11-18		Main rotor hub blade bolts	Bk	4
		2000-15-19		Sand filter ejection nozzle	Bk	4
		2001-15-19		Prevent loss of the FADEC	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-20-03		Metal ferry fuel tank	Bk	4
		2002-23-04		Passenger door latch support	Bk	4
		2003-08-53		Blade	Bk	4
		2003-14-12		Main or tail rotor part	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2003-18-03		Hose and emergency flotation gear pipe	Bk	4
		2003-19-01		Control rod	Bk	4
		2003-20-12		Siren cargo hook locking catch	Bk	4
		2003-22-15		Fuel air vent hose	Bk	4
		2004-05-28		Tail rotor	Bk	4
		2004-16-15		Main gearbox (MGB)	Bk	4
		2004-16-15	R1			
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2005-13-23		Hydraulic brake hose (hose)	BW	05-13
		2006-09-10		Pitch control rod assembly double bearing (bearing)	BW	06-10
SA366G1	H10EU	98-05-01		Main rotor head frequency adapter	Bk	3
		98-05-17		Outboard fin attachment studs	Bk	3
		98-06-35		Inspect Kevlar tie-bar	Bk	3
		98-12-08		Main gearbox strut attachment	Bk	3
		98-24-32		Tail rotor hub fairing attachment spring	Bk	3
		99-11-11		Inspect MGB planetary gear shaft for cracks	Bk	3
		99-21-14		Inspect electrical master box assy	Bk	3
		2000-08-06		Replace Connectral electrical module	Bk	4
		2000-11-17		Inspect Kevlar tie-bar for crack or delamination	Bk	4
		2000-11-18		Main rotor hub blade bolts	Bk	4
		2003-08-53		Blade	Bk	4
		2003-14-19		Servocontrol	Bk	4
		2004-16-15		Main gearbox (MGB)	Bk	4
		2004-16-15	R1			
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2006-06-02		Main gearbox (MGB)	BW	06-06
		2006-09-10		Pitch control rod assembly double bearing (bearing)	BW	06-10

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
EC155B	H10EU	2001-23-11		In-flight loss of a cabin sliding door	Bk	4
		2001-26-54		Erroneous flight or navigation display info	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2002-19-06		SMD45H multi-functional display	Bk	4
		2002-22-15		Door's locking pins	Bk	4
		2003-18-03		Hose and emergency flotation gear pipe	Bk	4
		2003-19-01		Control rod	Bk	4
		2003-19-12		Engine governor (GOV) warning light	Bk	4
		2003-20-12		Siren cargo hook locking catch	Bk	4
		2004-05-29		Tail rotor	Bk	4
		2004-12-06		Blade tip cap mounting bracket (tenon)	Bk	4
		2004-15-11		Auxiliary system unit (ASU)	Bk	4
		2004-16-15		Main gearbox (MGB)	Bk	4
		2004-16-15	R1			
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2005-06-01		Cabin sliding doors (doors)	BW	05-06
		2005-13-23		Hydraulic brake hose (hose)	BW	05-13
		2006-06-01		Electrical cable bundle	BW	06-06
		2006-09-10		Pitch control rod assembly double bearing (bearing)	BW	06-10
EC155B1	H10EU	2004-12-06		Blade tip cap mounting bracket (tenon)	Bk	4
		2004-15-11		Auxiliary system unit (ASU)	Bk	4
		2004-16-15		Main gearbox (MGB)	Bk	4
		2004-16-15	R1			
		2005-03-09		Main gearbox (MGB) planet gear	BW	05-04
		2005-06-01		Cabin sliding doors (doors)	BW	05-06
		2005-13-23		Hydraulic brake hose (hose)	BW	05-13
		2006-06-01		Electrical cable bundle	BW	06-06
		2006-09-10		Pitch control rod assembly double bearing (bearing)	BW	06-10
EC120B	R0001RD	2000-05-17		Inspect engine coupling tube for cracks	Bk	4
		2001-04-12		Prevent tube failure	Bk	4
		2001-24-08		In-flight loss of a cabin sliding door	Bk	4
		2002-13-11		Yaw control	Bk	4
		2002-15-08		Cargo hook	Bk	4
		2003-08-04		Bolted assembly of torque tube attachment	Bk	4
		2003-22-10		Bonding braid	Bk	4
		2005-09-05		Tail rotor drive shaft (drive shaft)	BW	05-10

FH1100 MANUFACTURING CORPORTATION
(Formerly Hiller Aviation)
(For ADs in Books 1 or 2 see Hiller Aviation)

FH-1100, 1100 (OH-5A)	H2WE	66-30-05		Main engine drive shaft	Bk	1
		68-02-04		Cyclic input swashplate ring	Bk	1
		68-06-05		Failure of coupling shaft	Bk	1
		68-08-09		Coupling shaft	Bk	1
		70-18-04		Transmission vertical status	Bk	1
		71-11-03		VNE placard	Bk	1
		71-22-03		Tail rotor bearing block	Bk	1
		71-24-02		Failure of transmission mount strut	Bk	1
		71-24-06		Attach lug engine mount strut	Bk	1
		71-24-08		Landing gear torque tube	Bk	1
		72-13-07		Drive shaft assemblies	Bk	1
		75-03-04		Tail fin spar	Bk	1
		77-07-08		Tail rotor tension torsion bars	Bk	1
		79-11-04		Lower housing transmissions	Bk	1
		81-10-02		Support column	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
FIREFLY AVIATION HELICOPTER SERVICES						
(Formerly Erickson Air-Crane Co.)						
UH-1F	H11SW	95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
FLUG-UND FAHRZEUGWERKE						
Diamant HBV	G13EU	75-16-19		Rudder jamming	Bk	1
		75-17-09		Lower harness attachments	Bk	1
		81-12-51		Rudder close tolerance bolt	Bk	2
Diamant 16.5	G13EU	75-16-19		Rudder jamming	Bk	1
		75-17-09		Lower harness attachments	Bk	1
		81-12-51		Rudder close tolerance bolt	Bk	2
		81-16-01		Wing spar cap	Bk	2
Diamant 18	- -	81-16-01		Wing spar cap	Bk	2
GALAXY BALLOONS, INC.						
AX-6	A18WE	75-09-14		Fuel system failure or fire	Bk	1
		81-09-02		Deflation panel system	Bk	2
		83-15-03		Propane jet modification	Bk	2
GARLICK HELICOPTERS						
UH-1B	H13WE	83-03-03		Tail boom skin joint	Bk	2
		83-20-01		Tail rotor hub assembly	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		86-07-07		Universal assembly - main rotor	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
UH-1H	H3NM	83-03-03		Tail boom skin joint	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
UH-1H continued		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
UH-1E, UH-1L,	H5NM	2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
TH-1L, HH-1K	H5NM	88-08-01		Rod end bearing assembly	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
UH-1P, TH-1F	H12NM	83-03-03		Tail boom skin joint	Bk	2
UH-1F		84-18-03	R1	Clevis inspection	Bk	2
(Formerly Western		88-25-05		Tail rotor grip assembly	Bk	2
International Aviation, Inc.)		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
GLASER-DIRKS FLUGZEUGBAU GmbH						
(See DG Flugzeugbau for Model DG-500M)						
DG-100	G32EU	78-14-03		Horizontal stabilizer	Bk	1
		88-14-02		Canopy release	Bk	2
		95-14-01		Tailplane main fitting	Bk	3
		98-13-04		Inspect airbrake control system	Bk	3
		2006-02-12		Rudder mount assembly	BW	06-04
DG-200	- -	88-14-02		Canopy release	Bk	2
DG-300	- -	88-14-02		Canopy release	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
DG-800B	G01CE	2000-20-10		Drive belt tension	Bk	4
		2001-07-01		Fuel line, exhaust sys., & piston rod of gas strut	Bk	4
		2005-08-13		Digital engine indicator (DEI)	BW	05-09
		2005-10-23		Propeller	BW	05-11
		2005-26-11		Starter ring gear to the lower drive belt pulley adapter.	BW	06-01
DG-400	G52EU	87-26-09		Engine cable terminal connectors	Bk	2
		88-02-02		Spindle motor	Bk	2
		98-11-17		Bosch electrical system regulator	Bk	3
		98-11-18		Upper rubber shock mounts	Bk	3
		98-13-04		Inspect airbrake control system	Bk	3
		98-13-06		Bungees for left engine restraining cable and bowden cable of rear engine door	Bk	3
		98-17-03		Propeller shaft	Bk	3
		98-19-17		Powerplant mount and propeller mount	Bk	3
		2002-14-18		Propeller mount plate	Bk	4
		2006-02-12		Rudder mount assembly	BW	06-04
DG-800A	G01CE	2002-14-18		Propeller mount plate	Bk	4
GLASFLUGEL						
H-301 "Libelle"	G12EU	68-07-02		Tow cable	Bk	1
		68-21-01		Horizontal stabilizer	Bk	1
		75-22-16		Elevator assembly guide	Bk	1
		85-22-11	R1	Elevator linkage inspection	Bk	2
		91-06-09		Rudder cables	Bk	3
		97-03-02		Control surface weight and static moment	Bk	3
H301B "Libelle"	G12EU	75-22-16		Elevator assembly guide	Bk	1
		85-22-11	R1	Elevator linkage inspection	Bk	2
		91-06-09		Rudder cables	Bk	3
		97-03-02		Control surface weight and static moment	Bk	3
Standard "Libelle"	G12EU	75-22-16		Elevator assembly guide	Bk	1
		85-22-11	R1	Elevator linkage inspection	Bk	2
		91-06-09		Rudder cables	Bk	3
		97-03-02		Control surface weight and static moment	Bk	3
		97-24-06		Aileron operating lever's actuating shaft welded seams	Bk	3
Standard Libelle 201	--	91-06-09		Rudder cables	Bk	3
Standard Libelle 201B	G12EU	75-22-16		Elevator assembly guide	Bk	1
		85-22-11	R1	Elevator linkage inspection	Bk	2
		91-06-09		Rudder cables	Bk	3
		97-03-02		Control surface weight and static moment	Bk	3
		97-24-06		Aileron operating lever's actuating shaft welded seams	Bk	3
Standard Libelle 203	--	91-06-09		Rudder cables	Bk	3
Club Libelle 205	G12EU	75-22-16		Elevator assembly guide	Bk	1
		97-03-02		Control surface weight and static moment	Bk	3
		2004-08-14		Rudder actuator arm	Bk	4
Kestrel	G20EU	87-11-04		Rudder actuating arm	Bk	2
		97-03-02		Control surface weight and static moment	Bk	3
		2004-09-02		Airbrake actuation shaft	Bk	4
Kestrel 604	--	91-06-09		Rudder cables	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
BS-1	--	91-06-09		Rudder cables	Bk	3
Mosquito	G38EU	96-03-12		Canopy system	Bk	3
		2004-08-14		Rudder actuator arm	Bk	4
GLOBAL HELICOPTER TECHNOLOGY, INC.						
UH-1H	R00002RC	2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
GROB-WERKE						
(Formerly Burkhart Grob Luft-Und Raumfahrt)						
G120A	A49CE	2003-19-13		Flight control system operating levers	Bk	4
		2004-22-21		Vertical stabilizer main spar and skin	Bk	4
		2005-11-08		Main landing gear front and rear spherical bearings	BW 05-12	
		2005-12-09		Nose landing gear (NLG) assembly	BW 05-13	
		2005-13-09		Main landing gear (MLG)	BW 06-07	
G102 ASTIR Series	G33EU	95-13-09		Elevator and rudder hinge	Bk	3
G102 Club Astir III	G33EU	2004-17-04		Elevator and ailerons	Bk	4
G102 Club Astir IIIb	G33EU	2004-17-04		Elevator and ailerons	Bk	4
G102 Standard Astir III	G33EU	2004-17-04		Elevator and ailerons	Bk	4
G102 ASTIR CS	G33EU	78-13-03		Elevator control assembly	Bk	1
		78-14-04		Rudder control levers	Bk	1
		84-09-05		Mod. spheric locking bolt installation	Bk	2
		85-19-06		Air brake levers	Bk	2
		94-17-06		Inspect airbrake stops	Bk	3
		97-24-08		Elevator control lever	Bk	3
		2001-26-15		Elevator control	Bk	4
		2006-17-02				
G120A		2005-13-09		Main landing gear (MLG)	BW 05-18	
		2005-22-14		Switch panels below the left-hand instrument panel	BW 05-23	
GROB-WERKE GMBH & CO.						
(See SCHEMPP-HIRTH, BURKHART GROB LUFT-UND RAUMFAHRT)						
HAGGLUND HELICOPTERS						
(Formerly Western International Aviation, Inc.)						
(See Western International for ADs in Book 3)						
UH-1H	H15NM	99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
HAWKEYE ROTOR & WING FLIGHT SCHOOL						
Wilbur M. Isenberg						
OH-13E	H2CE	80-21-09	R1	Tail rotor pitch link	Bk	2
		81-04-03		Tail rotor drive assembly	Bk	2
		85-15-04		Tail rotor blade yolk P/N 74-641-057-9	Bk	2
		2002-03-16		Main rotor blade grips	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
HAWKINS AND POWERS AVIATION						
UH-1B	H1RM	83-03-03		Tail boom skin joint	Bk	2
		83-20-01		Tail rotor hub assembly	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		86-07-07		Universal assembly - main rotor	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
HB AIRCRAFT INDUSTRIES (*HB Flugtechnik*)						
HB-23/2400	G55EU	91-07-18		Propeller	Bk	3
		96-10-02		Elevator control push rod tube	Bk	3
		96-22-16		Rudder bearing support bracket	Bk	3
HERCULES						
(See GARLICK HELICOPTERS)						
HILLER AVIATION						
(See ROGERSON HILLER)						
(*See FH1100 Manufacturing Corportation*)						
UH-12 Series	6H1	56-09-01		Tail rotor torsion bar	Bk	1
		58-02-03		Carburetor mixture control removal	Bk	1
		81-17-03		Main transmission	Bk	2
		81-18-02		Tail rotor skin cracks	Bk	2
UH-12	6H1	51-20-03		Collective pitch ballast system bracket.	Bk	1
		52-01-08		Collective pitch incidence arms	Bk	1
		52-29-01		Tail rotor drive slip joint assy inspec.	Bk	1
		53-09-03		Outboard tension bar pins	Bk	1
		53-12-01		Horizontal stabilizer spar	Bk	1
		53-24-02		Tail rotor pitch change rod	Bk	1
		55-19-01		Tail boom rear bulkhead	Bk	1
		56-27-02		Engine mount welds	Bk	1
		59-05-05		Cyclic control scissor casting	Bk	1
		59-25-03		Wobble plate screws	Bk	1
		63-04-02		Tail rotor blade	Bk	1
		71-25-08		Inspect main rotor blades	Bk	1
		73-20-03		Main rotor hub	Bk	1
		80-07-04		Main rotor blade anti-node bars	Bk	2
		97-10-16		Inspect blade spar tube and cuff	Bk	3
		2000-24-21		Control system attachments	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
UH-12A (HTE-1, H-23A)	6H1	51-20-03	Collective pitch ballast system bracket	Bk	1
		52-01-08	Collective pitch incidence arms	Bk	1
		52-29-01	Tail rotor drive slip joint assy inspec	Bk	1
		53-09-03	Outboard tension bar pins	Bk	1
		53-12-01	Horizontal stabilizer spar	Bk	1
		53-24-02	Tail rotor pitch change rod	Bk	1
		55-19-01	Tail boom rear bulkhead	Bk	1
		56-27-02	Engine mount welds	Bk	1
		59-05-05	Cyclic control scissor casting	Bk	1
		59-25-03	Wobble plate screws	Bk	1
		62-03-01	Cam follower assembly	Bk	1
		63-04-02	Tail rotor blade	Bk	1
		73-20-03	Main rotor hub	Bk	1
		97-10-16	Inspect blade spar tube and cuff	Bk	3
		97-20-15	Outboard tension-torsion bar pin	Bk	3
		2000-24-21	Control system attachments	Bk	4
UH-12B (HTE-2, H-23B, H-23C)	6H2	52-01-08	Collective pitch incidence arms	Bk	1
		52-29-01	Tail rotor drive slip joint assy inspec	Bk	1
		53-09-03	Outboard tension bar pins	Bk	1
		53-12-01	Horizontal stabilizer spar	Bk	1
		53-24-02	Tail rotor pitch change rod	Bk	1
		55-19-01	Tail boom rear bulkhead	Bk	1
		56-27-02	Engine mount welds	Bk	1
		59-05-05	Cyclic control scissor casting	Bk	1
		59-25-03	Wobble plate screws	Bk	1
		62-03-01	Cam follower assembly	Bk	1
		63-04-02	Tail rotor blade	Bk	1
		73-20-03	Main rotor hub	Bk	1
		97-10-16	Inspect blade spar tube and cuff	Bk	3
		97-20-15	Outboard tension-torsion bar pin	Bk	3
		2000-24-21	Control system attachments	Bk	4
UH-12C	6H2	59-05-05	Cyclic control scissor casting	Bk	1
		59-25-03	Wobble plate screws	Bk	1
		63-04-02	Tail rotor blade	Bk	1
		73-20-03	Main rotor hub	Bk	1
		77-24-03	Fuel control valve	Bk	1
		97-10-16	Inspect blade spar tube and cuff	Bk	3
		97-20-15	Outboard tension-torsion bar pin	Bk	3
		2000-24-21	Control system attachments	Bk	4
UH-12D (UH-23D)	4H10	59-05-05	Cyclic control scissor casting	Bk	1
		59-25-03	Wobble plate screws	Bk	1
		61-05-04	Main transmission	Bk	1
		62-06-03	Transmission & lubrication system mod	Bk	1
		63-21-03	Main rotor blades	Bk	1
		66-22-04	Mercury clutches	Bk	1
		67-08-03	Cyclic control bracket	Bk	1
		69-08-08	Tail rotor yoke	Bk	1
		69-13-07	Collective yoke support brackets	Bk	1
		73-20-03	Main rotor hub	Bk	1
		73-25-03	Finite life components	Bk	1
		74-04-03	Main rotor drag struts	Bk	1
		75-10-01	Rotor drive system	Bk	1
		76-20-06	Cable freezing control	Bk	1
		77-24-03	Fuel control valve	Bk	1
		78-18-03	Drive shaft	Bk	1
		78-22-02	Rotor blade retention system	Bk	1
		78-22-08	Flight/engine control	Bk	1
		78-23-07	Finite life components listed in AD	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
UH-12D (UH-23D)		79-03-07		Main rotor tach generator	Bk	1
		80-07-04		Main rotor blade anti-node bars	Bk	2
		80-19-02		Turbine power - Soloy conversions	Bk	2
		80-23-02		(See Soloy Conversions, Appliances)	Bk	2
		81-04-01		Rudder cable assembly	Bk	2
		81-09-08		Main rotor blade	Bk	2
		82-15-02		Main and tail rotors	Bk	2
		83-25-02		Main rotor blade doublers	Bk	2
		84-19-08		Engine mount	Bk	2
		86-17-02		Main rotor blade fork	Bk	2
		86-22-04		Main rotor blades	Bk	2
		97-10-16		Inspect blade spar tube and cuff	Bk	3
		97-20-15		Outboard tension-torsion bar pin	Bk	3
		2000-24-21		Control system attachments	Bk	4
UH-12L, UH-12L4	H1WE	59-05-05		Cyclic control scissor casting	Bk	1
		66-22-04		Mercury clutches	Bk	1
		69-08-08		Tail rotor yoke	Bk	1
		69-13-07		Collective yoke support brackets	Bk	1
		72-13-08	R1	Main rotor blades	Bk	1
		75-10-01		Rotor drive system	Bk	1
		77-24-03		Fuel control valve	Bk	1
		81-04-01		Rudder cable assembly	Bk	2
		82-13-04	R1	Torsional couplings	Bk	2
		82-15-02		Main and tail rotors	Bk	2
		90-15-01		Tail rotor blade assembly	Bk	3
		2000-24-21		Control system attachments	Bk	4

HOAC Austria
(Formerly HOFFMANN AIRCRAFT)
(See Diamond Aircraft Industries (Austria))

HOFFMANN AIRCRAFT GesmbH
(See HOAC AUSTRIA)

HPH s.r.o.

304C, 304CZ, 304CZ-17	G12CE	2004-09-03		Airbrake handle attachment rivet	Bk	4

HUGHES HELICOPTERS, INC.
(See MCDONNELL DOUGLAS HELICOPTER)

HYNES, MICHAEL K.
(Formerly BRANTLY HELICOPTER)
(See Brantly Helicopters)

INTERNATIONAL HELICOPTER

UH-1B	H5SO	83-03-03		Tail rotor drive assembly.	Bk	2
		83-20-01		Tail rotor hub assembly	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		86-07-07		Universal assembly - main rotor	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
UH-1B continued		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
INTREPRINDEREA DE CONSTRUCTII AERONAUTICE						
IS-28B2	G40EU	87-18-10		Aileron control levers	Bk	2
KAMAN AIRCRAFT CORP.						
K-240	1H3	59-10-06		Wood check plate rotor blades	Bk	1
K-1200	TR7BO	99-26-04		Clutch assembly *(See Bk 4 for paper copy)*	Bk	3
		2000-18-10		Transmission clutch	Bk	4
		2001-13-03	R1	Prevent failure of the rotor shaft	Bk	4
		2004-13-26		Blade grip	Bk	4
KAWASAKI HEAVY INDUSTRIES						
KV107-II	H1PC	78-01-17		Rotor shafts	Bk	1
		80-15-11		Quill shafts	Bk	2
		81-04-10		Cyclic stick boots	Bk	2
		81-14-05		Pitch bearing housings	Bk	2
		81-15-07		Tension-torsion strap assys	Bk	2
		83-07-06		Synchronizing shaft	Bk	2
		87-11-05		Components fatigue failure	Bk	2
		88-14-03		Main rotor hubs	Bk	2
KV107-11A	H1PC	78-01-17		Rotor shafts	Bk	1
		80-15-11		Quill shafts	Bk	2
		81-04-10		Cyclic stick boots	Bk	2
		81-14-05		Pitch bearing housings	Bk	2
		81-15-07		Tension-torsion strap assys	Bk	2
		83-07-06		Synchronizing shaft	Bk	2
		87-11-05		Components fatigue failure	Bk	2
		88-12-09		Main rotor shaft	Bk	2
		88-14-03		Main rotor hubs	Bk	2

LENAIR CORPORATION
(See OREGON, SIKORSKY(COLUMBIA))

LET AERONAUTICAL WORKS
(See AIRCRAFT INDUSTRIES)

(See AIRCRAFT INDUSTRIES)

LET, n.p.
(See LET AERONAUTICAL WORKS)

McCREARY, GIFTON
(Formerly Aerodyne Systems Engineering Ltd)
(Formerly Texas Helicopter Corporation)
(For ADs in Bk 2 see Texas Heli., ADs in Bk 3 see Aerodyne Sys.)

OH-13E, OH-13H	H7SW	80-21-09	R1	Tail rotor pitch link	Bk	2
		81-04-03		Tail rotor drive assembly	Bk	2
		85-15-04		Tail rotor blade yolk P/N 74-641-057-9	Bk	2
		2002-03-16		Main rotor blade grips	Bk	4

McCULLOCH
(See AERO RESOURCES, INC.)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
MCDONNELL DOUGLAS HELICOPTER						
(See SCHWEIZER AIRCRAFT CORPORATION)						
(See MD Helicopter, Inc.)						
McNEELY, JOHN A.						
(Formerly WALZ)						
All models	A15SO	75-12-08		Throttle or trigger valves	Bk	1
MD HELICOPTER, INC. (MDHI)						
(Formerly McDonnell Douglas Heli.)						
(See McDonnell Douglas Heli. For AD's in Book 1 and 2)						
AH-6	--	97-15-08		Transmission output drive gear	Bk	3
		98-21-12		Inspect overrunning clutch retainer	Bk	3
MH-6	--	97-15-08		Transmission output drive gear	Bk	3
		98-21-12		Inspect overrunning clutch retainer	Bk	3
369 Series	H3WE	70-16-07		Main rotor blade	Bk	1
		80-08-04		(See Chadwick, Equipment)	Bk	2
		80-24-04		Placard -front seat occupancy	Bk	2
		80-25-01		Tail rotor drive shaft	Bk	2
		81-26-01	R1	Main rotor drive shaft	Bk	2
		82-01-08		Lever control rod	Bk	2
		84-01-02	R1	Rotor system control	Bk	2
		86-01-04		Tail rotor blades	Bk	2
		89-23-14		Main rotor collective tubes	Bk	2
		90-01-08		Driveshaft coupling	Bk	3
		90-19-02		Clutch assembly	Bk	3
		91-08-02		Tail rotor blades	Bk	3
		95-03-11		Inspect tail rotor blade	Bk	3
		95-03-13		Main rotor blade attach lugs	Bk	3
369 (YOH-6A)	H3WE	74-20-04		Main rotor blade	Bk	1
		75-10-04		Tail rotor blades	Bk	1
		75-22-03		Tail rotor drive shaft	Bk	1
		75-22-04		Tail rotor blades	Bk	1
		77-21-04		Clutch and shaft assembly	Bk	1
		82-14-01		With Chadwick C-20 aux. fuel system	Bk	2
		86-01-04		Tail rotor blades	Bk	2
		86-20-07		Tail rotor drive shaft	Bk	2
		94-18-08		Tail rotor blade inspection	Bk	3
		95-03-11		Inspect tail rotor blade	Bk	3
		96-10-09		Inspect blade root end for cracks	Bk	3
		98-09-02		Overrunning clutch assembly outer race	Bk	3
369A (OH-6A)	H3WE	72-16-09		Tail rotor input gear shaft assys	Bk	1
		74-07-02		Aluminum tail rotor blades	Bk	1
		74-20-04		Main rotor blade	Bk	1
		75-10-04		Tail rotor blades	Bk	1
		75-22-03		Tail rotor drive shaft	Bk	1
		75-22-04		Tail rotor blades	Bk	1
		77-21-04		Clutch and shaft assembly	Bk	1
		86-01-04		Tail rotor blades	Bk	2
		86-20-07		Tail rotor drive shaft	Bk	2
		89-11-05		Tail rotor strap pack assemblies	Bk	2
		94-18-08		Tail rotor blade inspection	Bk	3
		95-03-11		Inspect tail rotor blade	Bk	3
		95-03-13		Main rotor blade attach lugs	Bk	3
		96-10-09		Inspect blade root end for cracks	Bk	3
		98-09-02		Overrunning clutch assembly outer race	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
369A (OH-6A) continued		98-15-26		Inspect main rotor blade for cracking	Bk	3
		2000-25-52		Main rotor mast or trunnion	Bk	4
		2003-08-51		Tail rotor blades	Bk	4
		2003-24-01		Blade fatigue	Bk	4
369D	H3WE	77-05-03		Tail rotor control system	Bk	1
		77-19-03		Main rotor retention straps	Bk	1
		77-21-04		Clutch and shaft assembly	Bk	1
		78-20-03		Fire suppression system	Bk	1
		78-26-04		Tail rotor hub assembly	Bk	1
		79-10-09		Tail rotor pitch control assy	Bk	1
		82-17-01		Output gearshaft assembly	Bk	2
		84-11-01		Control rod	Bk	2
		84-12-01	R1	Approved rotor blades	Bk	2
		86-20-07		Tail rotor drive shaft	Bk	2
		87-18-11		Main rotor transmission and drive shaft.	Bk	2
		87-18-12	R1	Main rotor transmission	Bk	2
		88-17-09	R1	Tail rotor transmission	Bk	2
		89-02-01	R1	Main rotor blade strap assemblies	Bk	2
		89-20-02		Tail rotor hubs	Bk	2
		90-12-03		Tail rotor bearing assembly	Bk	3
		90-24-07		Main rotor trans. bolts	Bk	3
		93-07-10		Airspeed limitations	Bk	3
		93-18-05		Fuel vent line	Bk	3
		94-18-08		Tail rotor blade inspection	Bk	3
		94-24-04		Pitch control assembly	Bk	3
		96-08-03		*See Flight Trails Heli., Appliances*	Bk	3
		96-10-09		Inspect blade root end for cracks	Bk	3
		97-15-08		Transmission output drive gear	Bk	3
		98-09-02		Overrunning clutch assembly outer race	Bk	3
		98-15-26		Inspect main rotor blade for cracking	Bk	3
		98-21-12		Inspect overrunning clutch retainer	Bk	3
		99-04-12		Input shaft coupling assembly	Bk	3
		99-13-09		Inspect fork assembly	Bk	3
		99-20-12		Bracket P/N 369F5190-1	Bk	3
		2000-08-22		Turbine Outlet Temperature (TOT) indicator	Bk	4
		2000-25-52		Main rotor mast or trunnion	Bk	4
		2002-13-05	R1	Tail rotor gearbox attaching bolt	Bk	4
		2003-08-51		Tail rotor blades	Bk	4
		2003-24-01		Blade fatigue	Bk	4
		2005-21-02		Main rotor blade (blade)	BW	05-22
369E	H3WE	84-11-01		Control rod	Bk	2
		84-12-01	R1	Approved rotor blades	Bk	2
		86-20-07		Tail rotor drive shaft	Bk	2
		87-18-11		Main rotor transmission and drive shaft.	Bk	2
		87-18-12	R1	Main rotor transmission	Bk	2
		88-17-09	R1	Tail rotor transmission	Bk	2
		89-02-01	R1	Main rotor blade strap assemblies	Bk	2
		89-20-02		Tail rotor hubs	Bk	2
		90-12-03		Tail rotor bearing assembly	Bk	3
		90-24-07		Main rotor trans. bolts	Bk	3
		93-07-10		Airspeed limitations	Bk	3
		93-18-05		Fuel vent line	Bk	3
		94-18-08		Tail rotor blade inspection	Bk	3
		94-24-04		Pitch control assembly	Bk	3
		96-08-03		*See Flight Trails Heli., Appliances*	Bk	3
		96-10-09		Inspect blade root end for cracks	Bk	3
		97-15-08		Transmission output drive gear	Bk	3
		98-09-02		Overrunning clutch assembly outer race	Bk	3
		98-15-26		Inspect main rotor blade for cracking	Bk	3
		98-21-12		Inspect overrunning clutch retainer	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
369E continued		99-04-12		Input shaft coupling assembly	Bk	3
		99-08-07		Engine control and warning system	Bk	3
		99-13-09		Inspect fork assembly	Bk	3
		99-20-12		Bracket P/N 369F5190-1	Bk	3
		2000-08-22		Turbine Outlet Temperature (TOT) indicator	Bk	4
		2000-25-52		Main rotor mast or trunnion	Bk	4
		2002-13-05	R1	Tail rotor gearbox attaching bolt	Bk	4
		2003-08-51		Tail rotor blades	Bk	4
		2005-21-02		Main rotor blade (blade)	BW	05-22
369F	H3WE	86-19-12		See Allison, Engine	Bk	2
		87-18-11		Main rotor transmission and drive shaft	Bk	2
		87-18-12	R1	Main rotor transmission	Bk	2
		88-17-09	R1	Tail rotor transmission	Bk	2
		89-02-01	R1	Main rotor blade strap assemblies	Bk	2
		90-12-03		Tail rotor bearing assembly	Bk	3
		90-24-07		Main rotor trans. bolts	Bk	3
		93-07-10		Airspeed limitations	Bk	3
		93-18-05		Fuel vent line	Bk	3
		94-18-08		Tail rotor blade inspection	Bk	3
		94-24-04		Pitch control assembly	Bk	3
		96-08-03		*See Flight Trails Heli., Appliances*	Bk	3
		96-10-09		Inspect blade root end for cracks	Bk	3
		97-15-08		Transmission output drive gear	Bk	3
		98-07-19		Tail rotor control rod assembly	Bk	3
		98-09-02		Overrunning clutch assembly outer race	Bk	3
		98-15-26		Inspect main rotor blade for cracking	Bk	3
		2002-13-05	R1	Tail rotor gearbox attaching bolt	Bk	4
		2003-08-51		Tail rotor blades	Bk	4
		2005-21-02		Main rotor blade (blade)	BW	05-22
369FF	H3WE	86-19-12		See Allison, Engine	Bk	2
		87-18-11		Main rotor transmission and drive shaft	Bk	2
		87-18-12	R1	Main rotor transmission	Bk	2
		88-17-09	R1	Tail rotor transmission	Bk	2
		89-02-01	R1	Main rotor blade strap assemblies	Bk	2
		90-12-03		Tail rotor bearing assembly	Bk	3
		90-24-07		Main rotor trans. bolts	Bk	3
		93-18-05		Fuel vent line	Bk	3
		94-18-08		Tail rotor blade inspection	Bk	3
		94-24-04		Pitch control assembly	Bk	3
		96-08-03		*See Flight Trails Heli., Appliances*	Bk	3
		96-10-09		Inspect blade root end for cracks	Bk	3
		97-15-08		Transmission output drive gear	Bk	3
		98-07-19		Tail rotor control rod assembly	Bk	3
		98-09-02		Overrunning clutch assembly outer race	Bk	3
		98-15-26		Inspect main rotor blade for cracking	Bk	3
		98-21-12		Inspect overrunning clutch retainer	Bk	3
		99-04-12		Input shaft coupling assembly	Bk	3
		99-08-07		Engine control and warning system	Bk	3
		99-20-12		Bracket P/N 369F5190-1	Bk	3
		2000-25-52		Main rotor mast or trunnion	Bk	4
		2002-13-05	R1	Tail rotor gearbox attaching bolt	Bk	4
		2003-08-51		Tail rotor blades	Bk	4
		2005-21-02		Main rotor blade (blade)	BW	05-22

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
369H Series	H3WE	69-21-01	Failure of input pinion shaft	Bk	1
		72-16-09	Tail rotor input gear shaft assys	Bk	1
		72-18-04	VNE limitations	Bk	1
		75-09-17	Protection of passengers	Bk	1
		77-09-01	Emergency float assemblies	Bk	1
		89-11-05	Tail rotor strap pack assemblies	Bk	2
		93-18-05	Fuel vent line	Bk	3
		94-18-08	Tail rotor blade inspection	Bk	3
369H	H3WE	74-07-02	Aluminum tail rotor blades	Bk	1
		74-20-04	Main rotor blade	Bk	1
		75-10-04	Tail rotor blades	Bk	1
		75-22-03	Tail rotor drive shaft	Bk	1
		75-22-04	Tail rotor blades	Bk	1
		76-19-03	Damper plunger	Bk	1
		77-21-04	Clutch and shaft assembly	Bk	1
		78-20-03	Fire suppression system	Bk	1
		78-26-04	Tail rotor hub assembly	Bk	1
		86-20-07	Tail rotor drive shaft	Bk	2
		96-10-09	Inspect blade root end for cracks	Bk	3
		98-09-02	Overrunning clutch assembly outer race	Bk	3
		98-15-26	Inspect main rotor blade for cracking	Bk	3
		99-04-12	Input shaft coupling assembly	Bk	3
		2000-25-52	Main rotor mast or trunnion	Bk	4
		2003-08-51	Tail rotor blades	Bk	4
		2003-24-01	Blade fatigue	Bk	4
369HM	H3WE	74-07-02	Aluminum tail rotor blades	Bk	1
		74-20-04	Main rotor blade	Bk	1
		75-06-02	Cargo carriers	Bk	1
		75-10-04	Tail rotor blades	Bk	1
		75-22-03	Tail rotor drive shaft	Bk	1
		75-22-04	Tail rotor blades	Bk	1
		76-19-03	Damper plunger	Bk	1
		77-21-04	Clutch and shaft assembly	Bk	1
		78-26-04	Tail rotor hub assembly	Bk	1
		86-20-07	Tail rotor drive shaft	Bk	2
		94-18-08	Tail rotor blade inspection	Bk	3
		96-10-09	Inspect blade root end for cracks	Bk	3
		98-09-02	Overrunning clutch assembly outer race	Bk	3
		98-15-26	Inspect main rotor blade for cracking	Bk	3
		2000-25-52	Main rotor mast or trunnion	Bk	4
		2003-08-51	Tail rotor blades	Bk	4
		2003-24-01	Blade fatigue	Bk	4
369HS	H3WE	74-07-02	Aluminum tail rotor blades	Bk	1
		74-20-04	Main rotor blade	Bk	1
		75-06-02	Cargo carriers	Bk	1
		75-10-04	Tail rotor blades	Bk	1
		75-22-03	Tail rotor drive shaft	Bk	1
		75-22-04	Tail rotor blades	Bk	1
		76-19-03	Damper plunger	Bk	1
		77-21-04	Clutch and shaft assembly	Bk	1
		78-26-04	Tail rotor hub assembly	Bk	1
		86-20-07	Tail rotor drive shaft	Bk	2
		93-07-10	Airspeed limitations	Bk	3
		94-18-08	Tail rotor blade inspection	Bk	3
		96-10-09	Inspect blade root end for cracks	Bk	3
		98-09-02	Overrunning clutch assembly outer race	Bk	3
		98-15-26	Inspect main rotor blade for cracking	Bk	3
		2000-25-52	Main rotor mast or trunnion	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
369HS continued		2003-08-51	Tail rotor blades	Bk	4
		2003-24-01	Blade fatigue	Bk	4
369HE	H3WE	74-07-02	Aluminum tail rotor blades	Bk	1
		74-20-04	Main rotor blade	Bk	1
		75-06-02	Cargo carriers	Bk	1
		75-10-04	Tail rotor blades	Bk	1
		75-22-03	Tail rotor drive shaft	Bk	1
		75-22-04	Tail rotor blades	Bk	1
		76-19-03	Damper plunger	Bk	1
		77-21-04	Clutch and shaft assembly	Bk	1
		78-26-04	Tail rotor hub assembly	Bk	1
		86-20-07	Tail rotor drive shaft	Bk	2
		93-07-10	Airspeed limitations	Bk	3
		94-18-08	Tail rotor blade inspection	Bk	3
		96-10-09	Inspect blade root end for cracks	Bk	3
		98-09-02	Overrunning clutch assembly outer race	Bk	3
		98-15-26	Inspect main rotor blade for cracking	Bk	3
		2000-25-52	Main rotor mast or trunnion	Bk	4
		2003-08-51	Tail rotor blades	Bk	4
		2003-24-01	Blade fatigue	Bk	4
500N					
	H3WE	96-08-03	See Flight Trails Heli., Appliances	Bk	3
		96-10-09	Inspect blade root end for cracks	Bk	3
		97-15-08	Transmission output drive gear	Bk	3
		98-09-02	Overrunning clutch assembly outer race	Bk	3
		98-15-26	Inspect main rotor blade for cracking	Bk	3
		98-21-12	Inspect overrunning clutch retainer	Bk	3
		99-04-12	Input shaft coupling assembly	Bk	3
		99-08-07	Engine control and warning system	Bk	3
		99-20-12	Bracket P/N 369F5190-1	Bk	3
		99-25-08	Thruster control cable conduit cap *(see Bk 4 for paper copy)*	Bk	3
		2000-08-22	Turbine Outlet Temperature (TOT) indicator	Bk	4
		2000-25-52	Main rotor mast or trunnion	Bk	4
		2004-20-08	Forward or center cable assembly connector	Bk	4
		2005-21-02	Main rotor blade (blade)	BW	05-22
600N	H3WE	98-15-26	Inspect main rotor blade for cracking	Bk	3
		99-04-12	Input shaft coupling assembly	Bk	3
		99-08-07	Engine control and warning system	Bk	3
		99-17-18	Flight control components	Bk	3
		99-20-12	Bracket P/N 369F5190-1	Bk	3
		99-25-08	Thruster control cable conduit cap *(see Bk 4 for paper copy)*	Bk	3
		2000-04-21	Internal fuel hose connections	Bk	4
		2000-08-22	Turbine Outlet Temperature (TOT) indicator	Bk	4
		2003-16-11	Main rotor drive shaft assembly	Bk	4
		2004-20-08	Forward or center cable assembly connector	Bk	4
		2004-22-12	Control support bracket	Bk	4
		2005-21-02	Main rotor blade (blade)	BW	05-22
		2006-08-12	Upper tailboom attachment fittings	BW	06-09

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
MD900	H19NM	97-12-02	Link assembly	Bk	3
		97-20-12	Main rotor swashplate bearing	Bk	3
		98-12-30	Hub assembly	Bk	3
		99-05-08	Main rotor drive shaft, Pitch plate assy and Spherical/slider main rotor bearing	Bk	3
		99-16-13	Airworthiness Limitations - Retirement life	Bk	3
		2000-10-06	Drive shaft assembly	Bk	4
		2000-18-08	Longitudinal drive link	Bk	4
		2001-25-51	Failure of the IIDS	Bk	4
		2002-10-05	Hub assembly drive plate attach flange	Bk	4
		2002-15-07	Bellcrank	Bk	4
		2002-22-51	Main rotor support static mast	Bk	4
		2002-23-03	Nonrotating swashplate assembly	Bk	4
		2003-14-51	Main rotor blade retention bolt	Bk	4
		2004-16-08	Control rod assembly fail-safe device	Bk	4
		2004-23-15	TT strap in Notar fan system	Bk	4
		2006-18-01	Notar fan system tension-torsion (TT)		

MESSERSCHMITT - BOLKOW - BLOHM - GMBH
(See BOLKOW, EUROCOPTER DEUTSCHLAND GMBH)

OFFSHORE CONSTRUCTION
(See SCOTT PAPER COMPANY)

OREGON HELICOPTERS
(Formerly LENAIR)
(See WILLIAMS HELICOPTER TECHNOLOGY)

DON PICCARD BALLOONS, INC.
(See GALAXY BALLOONS)

PRZEDSIEBIORSTWO DOSWIADCZALNO-PRODUKCYJNE SZYBOWNICTWA "PZL-BIELSKO"

SZD-50-3 "Puchacz"	G20CE	2004-11-10	Airbrake torque tube	Bk	4
		2004-21-02	Fuselage front bulkhead attachment fitting	Bk	4
		2005-25-22	Turnbuckle link	BW 05-25	
		2006-24-09	Self-locking nut		

PILATUS AIRCRAFT LTD.

B4-PC11	G25EU	75-16-05	Aileron control bolts	Bk	1
		75-16-11	Rudder control cables	Bk	1
		75-17-08	Canopy jettisoning capability	Bk	1

PILOT PERSONNEL INTERNATIONAL, INC.
(See GARLICK HELICOPTERS)

PRATT READ & CO. INC.

PR-G1	GTC 12	64-04-06	Wood bulkhead inspection	Bk	1

PZL-SWIDNIK S.A.

PW–5 "Smyk"	G11CE	2005-19-17	Left side aileron, right side aileron, and airbrake push-rod ends	BW 05-20	
PW–6U	G18CE	2005-19-17	Left side aileron, right side aileron, and airbrake push-rod ends	BW 05-20	

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
RANGER HELICOPTER SERVICES						
(See Tamarack Helicopters, Inc.)						
ROBINSON AIRCRANE, INC.						
UH-1F, UH-1P, TH-1F	R00008AT	99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
ROBINSON HELICOPTER COMPANY						
R-22 Series	H10WE	80-11-07		Main rotor blades	Bk	2
		80-21-53		Main transmission gears	Bk	2
		80-24-01		Tailcone	Bk	2
		80-26-06		Tail rotor plate	Bk	2
		81-05-52	R1	Main gear box	Bk	2
		82-03-07		Main rotor blades	Bk	2
		82-11-01		Steel tube frame	Bk	2
		82-15-07		Tail rotor drive shaft	Bk	2
		83-15-07	R1	Main rotor blade inspection	Bk	2
		84-18-04		Main rotor gearbox	Bk	2
		87-18-03		Main rotor pitch link assembly	Bk	2
		88-26-01	R2	Main rotor spindle	Bk	2
		90-17-01		Carburetor air box latches	Bk	3
		92-06-17		NAS1304-16 AF bolt inspection	Bk	3
		94-15-08		Main rotor blade inspection	Bk	3
		95-06-03		Main rotor gearbox	Bk	3
		95-11-09		FAA FM - Limitations - low-G pushovers	Bk	3
		95-23-05		Tail rotor gearboxes	Bk	3
		95-26-04		RFM - Limitation Section	Bk	3
		96-09-29		Replace V-belt sheave	Bk	3
		97-02-14		Main rotor RPM sensor resetting	Bk	3
		97-25-05		Carburetor and carburetor air temperature gage	Bk	3
		98-21-09		Fuel tank vent tube(s) in mast fairing	Bk	3
		99-02-02		Flexplates	Bk	3
R-22 Series continued		99-07-17		Sprag clutch	Bk	3
		2000-08-09		Sprag clutch	Bk	4
		2000-20-51		Inspect yoke for crack	Bk	4
		2003-04-04		Pitch control assembly	Bk	4
		2004-19-09		Blades	Bk	4
		2005-16-05		Door assembly	BW	05-17
R-44	H11NM	94-26-10		Cyclic stick assembly	Bk	3
		95-09-07		Cyclic control system	Bk	3
		95-11-10		FAA FM - Limitations - low-G pushovers	Bk	3
		96-18-22		Gear carrier securing bolts	Bk	3
		97-02-15		Main rotor RPM sensor resetting	Bk	3
		97-16-02		Up-limit switches	Bk	3
		98-04-12		Lateral cyclic trim spring shaft	Bk	3
		98-05-10		Aluminum elbows	Bk	3
		98-22-16		Inspect main rotor blade skin for fatigue cracks	Bk	3
		99-07-18		Sprag clutch	Bk	3
		99-13-11		Auxiliary fuel tank sump drain	Bk	3
		99-17-17		Yoke assembly	Bk	3
		99-23-01		Grip assembly P/N A756-6 Rev. A thru N	Bk	3
		2000-07-03		Inspect wire harness and fuel line assembly	Bk	4
		2000-08-04		Sprag clutch	Bk	4
		2001-20-18		Crack through a vertical-to-horizontal stabilizer	Bk	4
		2003-04-05		Tail rotor pitch control bearing	Bk	4
		2003-24-51	E	Main rotor swashplate bolt	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
R-44 II	H11NM	2003-24-51	E	Main rotor swashplate bolt	Bk	4
ROGERSON HILLER						
(See HILLER)						
UH-12E, UH-12E-L	4H11	56-09-01		Tail rotor torsion bar	Bk	1
(OH-23G, H-23F)		58-02-03		Carburetor mixture control removal	Bk	1
		59-05-05		Cyclic control scissor casting	Bk	1
		59-25-03		Wobble plate screws	Bk	1
		61-05-04		Main transmission	Bk	1
		62-06-03		Transmission & lubrication system mod	Bk	1
		63-21-03		Main rotor blades	Bk	1
		64-11-02		Tail rotor pinion gears	Bk	1
		66-22-04		Mercury clutches	Bk	1
		67-08-03		Cyclic control bracket	Bk	1
		69-08-08		Tail rotor yoke	Bk	1
		69-13-07		Collective yoke support brackets	Bk	1
		71-25-08		Inspect main rotor blades	Bk	1
		72-13-08	R1	Main rotor blades	Bk	1
		73-20-03		Main rotor hub	Bk	1
		74-04-03		Main rotor drag struts	Bk	1
		75-10-01		Rotor drive system	Bk	1
		76-20-06		Cable freezing control	Bk	1
		77-24-03		Fuel control valve	Bk	1
		78-18-03		Drive shaft	Bk	1
		78-22-02		Rotor blade retention system	Bk	1
		78-22-08		Flight/engine control	Bk	1
		78-23-07		Finite life components listed in AD	Bk	1
		79-03-07		Main rotor tach generator	Bk	1
		80-07-04		Main rotor blade anti-node bars	Bk	2
		80-19-02		Turbine power - Soloy conversions	Bk	2
		80-23-02		(See Soloy Conversions, `s)	Bk	2
		81-04-01		Rudder cable assembly	Bk	2
		81-09-08		Main rotor blade	Bk	2
		81-17-03		Main transmission	Bk	2
		81-18-02		Tail rotor skin cracks	Bk	2
		82-13-04	R1	Torsional couplings	Bk	2
		82-15-02		Main and tail rotors	Bk	2
		82-16-07		Torsional coupling assys	Bk	2
		83-25-02		Main rotor blade doublers	Bk	2
		84-19-08		Engine mount	Bk	2
		86-17-02		Main rotor blade fork	Bk	2
		86-22-04		Main rotor blades	Bk	2
		90-15-01		Tail rotor blade assemblies	Bk	3
		97-10-16		Inspect blade spar tube and cuff	Bk	3
		97-20-15		Outboard tension-torsion bar pin	Bk	3
		2000-24-21		Control system attachments	Bk	4
UH-12E4	--	86-22-04		Tail rotor blades	Bk	2
ROLLADEN SCHNEIDER OHG						
LS1-f	G35EU	78-23-02		Tow release mechanism	Bk	1
		82-17-02		Airspeed indicator	Bk	2
LS3	G37EU	78-23-02		Tow release mechanism	Bk	1
		82-17-02		Airspeed indicator	Bk	2
		2001-10-08		Corrosion damage to the airbrake levers	Bk	4
LS3-A	G37EU	98-22-14		Forward elevator mounting brackets	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
LS 4	G45EU	85-03-02		Air brake	Bk	2
		98-22-14		Forward elevator mounting brackets	Bk	3
		2001-01-11		Airbrake locking bracket	Bk	4
		2001-10-08		Corrosion damage to the airbrake levers	Bk	4
LS 4a	G45EU	85-03-02		Air brake	Bk	2
		98-22-14		Forward elevator mounting brackets	Bk	3
		2001-01-11		Airbrake locking bracket	Bk	4
LS-6	--	86-25-07		Placard & changes-airspeed	Bk	2
LS-6c	G83EU	2000-01-06		Instrument panel	Bk	4
		2001-10-08		Corrosion damage to the airbrake levers	Bk	4
SCHEIBE-FLUGZEUGBAU-G.m.b.H.						
L-Spatz 55	7G2	64-15-06		Outer aileron hinge brackets	Bk	1
Bergfalke-II/55	7G9	67-06-05		Aileron bell crank	Bk	1
		75-26-14		Elevator control	Bk	1
Bergfalke-III	7G9	67-06-05		Aileron bell crank	Bk	1
		75-26-14		Elevator control	Bk	1
SF 26A	G4IN	76-06-03		Lateral control	Bk	1
SF 27A	G11EU	75-23-01		Elevator actuating lever	Bk	1
SF 34	G48EU	95-18-01		Scheibe TN No. 336-2 - wing covering	Bk	3
SF 34B		95-18-01		Scheibe TN No. 336-2 - wing covering	Bk	3
SCHEMPP-HIRTH KG.						
(See GROB-WERKE)						
Cirrus	G19EU	70-02-10		Elevator aileron airbrake system	Bk	1
		91-15-07		Elevator drive lever	Bk	3
		95-09-11		Airbrake actuating lever	Bk	3
		98-18-06		Connecting rod between airbrake bellcranks	Bk	3
Standard Cirrus	G23EU	76-09-10		Aileron control system	Bk	1
		76-11-03		Tow release mechanism	Bk	1
		83-16-02		Air brake drive lever	Bk	2
		99-03-01		Tailplane locking hook	Bk	3
Cirrus VTC	- -	91-15-07		Elevator drive lever	Bk	3
		95-09-11		Airbrake actuating lever	Bk	3
Nimbus-2, -2B	G26EU	88-17-05		Elevator drive bracket	Bk	2
		97-08-02	R1	Load test of elevator control system	Bk	3
		99-03-01		Tailplane locking hook	Bk	3
Janus	G34EU	99-03-01		Tailplane locking hook	Bk	3
Janus B	- -	88-17-05		Elevator drive bracket	Bk	2
Mini-Nimbus HS-7, B	G49EU	88-17-05		Elevator drive bracket	Bk	2
		97-08-02	R1	Load test of elevator control system	Bk	3
		99-03-01		Tailplane locking hook	Bk	3
		2006-22-10				
Discus a, Discus b	G53EU	97-08-02	R1	Load test of elevator control system	Bk	3
Discus-2a, Discus 2b	G17CE	2004-08-12		Elevator control system	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.
Duo-Discus	G85EU	2003-16-51	Bonding between spar cap and spar web	Bk	4
		2004-24-11	Bonding of spar cap and spar web	Bk	4
		2006-25-14			
Ventus-2a, Ventus-2b	G04CE	2004-08-12	Elevator control system	Bk	4
SCHLEICHER, ALEXANDER					
Ka 6	7G1	64-07-05	Elevator control push rods	Bk	1
		64-09-06	Airbrake push pull rod	Bk	1
		64-14-06	Horizontal stabilizer fittings	Bk	1
		75-23-03	Elevator and control	Bk	1
Ka 6 B	7G1	75-23-03	Elevator and control	Bk	1
Ka 6 BR	7G1	75-23-03	Elevator and control	Bk	1
Ka 6 C	7G1	75-23-03	Elevator and control	Bk	1
Ka 6 CR	7G1	75-23-03	Elevator and control	Bk	1
Ka 6 E	7G1	69-05-06	Thermos bottle bracket	Bk	1
K7	7G3	61-13-03	Fuselage modification	Bk	1
		64-07-05	Elevator control push rods	Bk	1
		75-23-03	Elevator and control	Bk	1
Ka2B	7G3	64-07-05	Elevator control push rods	Bk	1
		64-14-06	Horizontal stabilizer fittings	Bk	1
		75-23-03	Elevator and control	Bk	1
K8	7G4	64-07-05	Elevator control push rods	Bk	1
		64-09-06	Airbrake push pull rod	Bk	1
		71-19-01	Airbrake bearing bracket failure	Bk	1
		75-23-03	Elevator and control	Bk	1
		98-18-05	Inspect canopy hood lock assembly	Bk	3
K8B	7G4	98-18-05	Inspect canopy hood lock assembly	Bk	3
Rhonlerche II	7G6	76-15-02	Torsion tube mount area	Bk	1
		77-25-04	Clevis pins	Bk	1
AS-K13	G15EU	68-25-05	Wheel brake cable	Bk	1
		69-05-04	Landing gear buffer plate	Bk	1
		75-23-03	Elevator and control	Bk	1
		98-13-05	Inspect main spar fitting	Bk	3
ASW-12	G21EU	95-09-12	Wing spar	Bk	3
ASW-15	G22EU	75-17-11	Improper fin-rudder nose clearance	Bk	1
		84-20-01	Bellcrank inspection	Bk	2
		95-09-12	Wing spar	Bk	3
ASW-15B	G22EU	84-20-01	Bellcrank inspection	Bk	2
		95-09-12	Wing spar	Bk	3
ASW-17	G30EU	76-07-11	Water ballast system control	Bk	1
		95-09-12	Wing spar	Bk	3
ASW-19	G36EU	84-13-04	Horizontal tailplane flutter	Bk	2
		98-04-46	Inspection hole cover entering fuselage	Bk	3
		98-12-03	Rudder panel, airbrake bellcrank,		

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
				rear canopy hinge	Bk	3
		98-17-02		Inspect tow release cable guide fittings	Bk	3
ASW-19B	G36EU	84-13-04		Horizontal tailplane flutter	Bk	2
ASW-27	G05CE	2000-04-26		Elevator control circuit	Bk	4
		2004-11-12		Center of gravity	Bk	4
ASK 21	G47EU	84-23-03		Placard and AFM changes	Bk	2
		85-06-07		Main wheel box	Bk	2
		87-10-07		Rudder pedal	Bk	2
		95-11-15	R1	Parallel rocker	Bk	3
		98-06-37		Tow release cable assembly	Bk	3
		98-06-38		Elevator pushrod	Bk	3
		98-08-29		SFM - stall and spin recovery information	Bk	3
		98-09-13		Inspect S-shaped rudder pedal tube	Bk	3
		98-10-07		SFM - Weight and balance	Bk	3
		98-12-03		Rudder panel, airbrake bellcrank, rear canopy hinge	Bk	3
ASH-26E	G03CE	99-09-09		Inspect rotor interior air cooling system	Bk	3
		99-15-13		Inspect internal cooling air fan	Bk	3
		2000-04-16		Carbon fiber shroud	Bk	4
ASH-25M	G09CE	2000-04-16		Carbon fiber shroud	Bk	4
		2004-10-08		Fuel line fittings	Bk	4

SCHWEIZER AIRCRAFT CORP.
(See MCDONNELL DOUG. HELI.)
(See AG CAT for all models of G-164)
(For all models 269 see McDonnell Douglas Helicopter for AD's in Bk 1)

SGS 1-23 et al	1G1	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS 1-23H	1G1	71-17-09		Loose rudder fittings	Bk	1
SGS 1-26 et al	1G10	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS 1-34, 1-34R	G3EA	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS 2-8	GTC 5	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS 2-32	G1EA	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS 2-33 Series	G2EA	76-13-11	R1	Aft fuselage longerons	Bk	1
		77-23-10		Spar web and bolts	Bk	1
SGS 2-33, -33A, -33AK	G2EA	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGU 1-19	G-17	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGU 2-22 Series	G-18	76-13-11	R1	Aft fuselage longerons	Bk	1
SGU 2-22 et al	G-18	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SGS 1-35C	G4EA	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS1-36	G5EA	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGU 1-7, 1-20, 1-21,	--	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
SGS 2-12, 1-24	--	87-02-01		Inspect tow-release installation	Bk	2
		87-17-01		Tow release installation	Bk	2
269 Series	4H12	67-21-01		Air scoop	Bk	1
(TH-55A)		69-21-01		Failure of input pinion shaft	Bk	1
		70-17-03		Flapping hinge bolts	Bk	1
		75-08-12		Actuator and cover	Bk	1
		76-10-02		Lateral control	Bk	1
		77-07-01		Clutch actuator	Bk	1
		78-02-02		Tail rotor control pedals	Bk	1
		81-17-04		Drive shaft assemblies	Bk	2
		82-15-03		Rotor system	Bk	2
		88-17-04		Aft cluster fittings	Bk	2
		89-20-03	R1	Tail rotor blades	Bk	2
		93-17-13		Lower coupling drive shaft	Bk	3
		93-21-03		Magnesium tailboom fitting	Bk	3
		94-12-06		Lower pulley bearings	Bk	3
		94-13-04		Clutch control spring assembly	Bk	3
		94-16-04		Tail rotor pedal support structure	Bk	3
		95-03-12		Clutch control spring assembly	Bk	3
		95-21-02		Main rotor drive shaft	Bk	3
		97-05-06		Main rotor thrust bearing	Bk	3
		97-23-06		Inspect ring gear teeth	Bk	3
		98-18-11		Main rotor blade	Bk	3
		2000-16-05		Shaft	Bk	4
		2003-13-15	R1	Tailboom support strut or lug on cluster fitting	Bk	4
269A	4H12	62-11-04		Operating limitations	Bk	1
		62-14-03		Tail rotor blade	Bk	1
		62-21-03		Modification	Bk	1
		64-06-04		Lower coupling drive shaft	Bk	1
		64-28-02		Main rotor blade flapping hinge bearing.	Bk	1
		66-03-02		Tail position lights	Bk	1
		67-11-03		Main rotor gear drive	Bk	1
		68-26-01		Lower coupling drive shaft	Bk	1
		69-04-03		Rotor blade	Bk	1
		70-01-06		Lateral pitch idler bell crank	Bk	1
		70-08-01		Flapping hinge bolts	Bk	1
		71-20-05		Idler pulley bearings	Bk	1
		74-21-04		Canopy slats	Bk	1
		75-15-02		Throttle and engine power control	Bk	1
		77-23-08		Cracks in main rotor blades	Bk	1
		78-25-04		Pinion assemblies	Bk	1
		78-26-04		Tail rotor hub assembly	Bk	1
		79-23-03	R1	Tail rotor blades	Bk	1
		80-18-07		Main transmission assembly	Bk	2
		82-15-01	R1	Main transmission	Bk	2
		88-17-04		Aft cluster fittings	Bk	2
		90-06-10		Throttle cable assembly	Bk	3
		93-05-11		Fuel pump drain tube assembly	Bk	3
		93-17-13		Lower coupling drive shaft	Bk	3
		93-21-03		Magnesium tailboom fitting	Bk	3
		94-12-06		Lower pulley bearings	Bk	3
		94-13-04		Clutch control spring assembly	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		94-16-04		Tail rotor pedal support structure	Bk	3
		95-03-12		Clutch control spring assembly	Bk	3
269A continued		95-21-02		Main rotor drive shaft	Bk	3
		97-05-06		Main rotor thrust bearing	Bk	3
		97-23-06		Inspect ring gear teeth	Bk	3
		98-18-11		Main rotor blade	Bk	3
		2000-16-05		Shaft	Bk	4
		2003-13-15	R1	Tailboom support strut or lug on cluster fitting	Bk	4
269A-1	4H12	62-21-03		Modification	Bk	1
		64-06-04		Lower coupling drive shaft	Bk	1
		64-28-02		Main rotor blade flapping hinge bearing.	Bk	1
		66-03-02		Tail position lights	Bk	1
		67-11-03		Main rotor gear drive	Bk	1
		68-26-01		Lower coupling drive shaft	Bk	1
		69-04-03		Rotor blade	Bk	1
		70-01-06		Lateral pitch idler bell crank	Bk	1
		70-08-01		Flapping hinge bolts	Bk	1
		71-20-05		Idler pulley bearings	Bk	1
		74-21-04		Canopy slats	Bk	1
		75-15-02		Throttle and engine power control	Bk	1
		77-23-08		Cracks in main rotor blades	Bk	1
		78-25-04		Pinion assemblies	Bk	1
		78-26-04		Tail rotor hub assembly	Bk	1
		79-23-03	R1	Tail rotor blades	Bk	1
		80-18-07		Main transmission assembly	Bk	2
		82-15-01	R1	Main transmission	Bk	2
		88-17-04		Aft cluster fittings	Bk	2
		90-06-10		Throttle cable assembly	Bk	3
		93-05-11		Fuel pump drain tube assembly	Bk	3
		93-17-13		Lower coupling drive shaft	Bk	3
		93-21-03		Magnesium tailboom fitting	Bk	3
		94-12-06		Lower pulley bearings	Bk	3
		94-13-04		Clutch control spring assembly	Bk	3
		94-16-04		Tail rotor pedal support structure	Bk	3
		95-03-12		Clutch control spring assembly	Bk	3
		95-21-02		Main rotor drive shaft	Bk	3
		97-05-06		Main rotor thrust bearing	Bk	3
		97-23-06		Inspect ring gear teeth	Bk	3
		98-18-11		Main rotor blade	Bk	3
		2000-16-05		Shaft	Bk	4
		2003-13-15	R1	Tailboom support strut or lug on cluster fitting	Bk	4
269A-2	4H12	64-28-02		Main rotor blade flapping hinge bearing.	Bk	1
		67-11-03		Main rotor gear drive	Bk	1
		68-26-01		Lower coupling drive shaft	Bk	1
		69-04-03		Rotor blade	Bk	1
		70-01-06		Lateral pitch idler bell crank	Bk	1
		70-08-01		Flapping hinge bolts	Bk	1
		77-23-08		Cracks in main rotor blades	Bk	1
269B	4H12	64-06-04		Lower coupling drive shaft	Bk	1
		64-28-02		Main rotor blade flapping hinge bearing.	Bk	1
		66-03-02		Tail position lights	Bk	1
		67-11-03		Main rotor gear drive	Bk	1
		68-26-01		Lower coupling drive shaft	Bk	1
		69-04-03		Rotor blade	Bk	1
		70-01-06		Lateral pitch idler bell crank	Bk	1
		70-08-01		Flapping hinge bolts	Bk	1
		71-20-05		Idler pulley bearings	Bk	1
		74-21-04		Canopy slats	Bk	1
		75-15-02		Throttle and engine power control	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		77-23-08		Cracks in main rotor blades	Bk	1
		78-25-04		Pinion assemblies	Bk	1
269B continued		78-26-04		Tail rotor hub assembly	Bk	1
		79-23-03	R1	Tail rotor blades	Bk	1
		80-18-07		Main transmission assembly	Bk	2
		82-15-01	R1	Main transmission	Bk	2
		88-17-04		Aft cluster fittings	Bk	2
		90-06-10		Throttle cable assembly	Bk	3
		93-05-11		Fuel pump drain tube assembly	Bk	3
		93-17-13		Lower coupling drive shaft	Bk	3
		93-21-03		Magnesium tailboom fitting	Bk	3
		94-12-06		Lower pulley bearings	Bk	3
		94-13-04		Clutch control spring assembly	Bk	3
		94-16-04		Tail rotor pedal support structure	Bk	3
		95-03-12		Clutch control spring assembly	Bk	3
		95-21-02		Main rotor drive shaft	Bk	3
		97-05-06		Main rotor thrust bearing	Bk	3
		97-23-06		Inspect ring gear teeth	Bk	3
		98-18-11		Main rotor blade	Bk	3
		2000-16-05		Shaft	Bk	4
		2003-13-15	R1	Tailboom support strut or lug on cluster fitting	Bk	4
269C Series	4H12	90-09-07		Cyclic control rod assembly	Bk	3
		91-05-18		Tailboom	Bk	3
		94-12-06		Lower pulley bearings	Bk	3
		94-13-04		Clutch control spring assembly	Bk	3
		94-16-04		Tail rotor pedal support structure	Bk	3
		95-03-12		Clutch control spring assembly	Bk	3
		2000-16-05		Shaft	Bk	4
269C	4H12	73-11-01		Idler pulley bearing failure	Bk	1
		74-21-04		Canopy slats	Bk	1
		78-25-04		Pinion assemblies	Bk	1
		78-26-04		Tail rotor hub assembly	Bk	1
		79-23-03	R1	Tail rotor blades	Bk	1
		80-18-07		Main transmission assembly	Bk	2
		82-15-01	R1	Main transmission	Bk	2
		88-12-02		Tail rotor retention strap	Bk	2
		88-17-04		Aft cluster fittings	Bk	2
		90-06-10		Throttle cable assembly	Bk	3
		90-09-07		Cyclic control rod assembly	Bk	3
		93-05-11		Fuel pump drain tube assembly	Bk	3
		93-17-13		Lower coupling drive shaft	Bk	3
		94-12-06		Lower pulley bearings	Bk	3
		95-21-02		Main rotor drive shaft	Bk	3
		97-23-06		Inspect ring gear teeth	Bk	3
		98-18-11		Main rotor blade	Bk	3
		99-04-14		Main rotor blade	Bk	3
		2000-16-05		Shaft	Bk	4
		2003-13-15	R1	Tailboom support strut or lug on cluster fitting	Bk	4
		2005-10-12		Lateral control trim actuator assembly	BW	05-11
269C-1		2005-10-12		Lateral control trim actuator assembly	BW	05-11
269D	4H12	98-18-11		Main rotor blade	Bk	3
		98-26-06		Shaft	Bk	3
		2000-16-05		Shaft	Bk	4
		2003-09-05		Horizontal stabilizer endplate	Bk	4
		2005-10-12		Lateral control trim actuator assembly	BW	05-11

SCOTT PAPER COMPANY.
(Formerly OFFSHORE CONSTRUCTION)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER *	SUBJECT	BOOK	NO.

(See Williams Helicopter)

SEMCO BALLOON
(See EAGLE BALLOONS, LTD.)

SIKORSKY AIRCRAFT, DIVISION OF UNITED AIRCRAFT CORP.

R4B	LTC-7	47-35-01	Main rotor links rework	Bk	1
		47-35-02	Tail rotor gearbox brace	Bk	1
YR-6A, R-6A, HOS-1	LTC 29	47-51-14	Pinion and ring gear inspection	Bk	1
HRS/H-19	HR1SO	74-19-04	Applicability to all HRS/H19 series	Bk	1
HRS-1/CH-19	HR1SO	70-09-05	Main rotor shaft	Bk	1
		75-04-02	Main rotor spindles	Bk	1
HRS-3/H-19B	HR1SO	70-09-05	Main rotor shaft	Bk	1
		75-04-02	Main rotor spindles	Bk	1
H-19A	HR1SO	75-04-02	Main rotor spindles	Bk	1
H-19B	HR1SO	75-04-02	Main rotor spindles	Bk	1
H-19D	HR1SO	70-09-05	Main rotor shaft	Bk	1
		75-04-02	Main rotor spindles	Bk	1
H-19G	HR1SO	70-09-05	Main rotor shaft	Bk	1
		75-04-02	Main rotor spindles	Bk	1
CH-19	HR1SO	75-04-02	Main rotor spindles	Bk	1
CH-54A	H16NM	2000-18-14	Second stage lower planetary plate	Bk	4
CH-54B	H14NM	99-15-14	Main gearbox assembly	Bk	3
H-37B (S-56)	H7EA	74-16-05	Main rotor head	Bk	1
S-51	H-2	47-32-15	Control system chain and sprockets	Bk	1
		47-50-08	Vertical hinge pins	Bk	1
		48-17-03	Planet pinion shafts wear	Bk	1
		48-18-02	Bevel drive gear splines	Bk	1
		50-08-01	Tail cone mounting longerons	Bk	1
		51-22-01	Gear shaft replacement	Bk	1
		51-23-04	Rotor link assemblies	Bk	1
		56-13-02	Main rotor hub replacement	Bk	1
		56-16-03	Main rotor blade inspection	Bk	1
		60-13-04	Rotor shank rod	Bk	1
		67-29-06	Tail rotor sleeve & tube assembly	Bk	1
S-52-3 (HO5S-1)	1H2	60-19-01	Component lines	Bk	1
S-55 Series	1H4	54-01-03	Fuel strainer screen	Bk	1
		54-13-01	Star assembly bolt replacement	Bk	1
		54-16-01	Main transmission	Bk	1
		54-19-02	Servo safety clip	Bk	1
		54-20-02	Support assembly cracks	Bk	1
		55-25-04	Tail cone skin reinforcements	Bk	1
		56-16-03	Main rotor blade inspection	Bk	1
		56-23-03	Horizontal hinge pin assembly	Bk	1
		60-13-04	Rotor shank rod	Bk	1
		63-05-02	Main rotor blades	Bk	1
		65-08-02	Main rotor blades	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		66-04-03		Main rotor blades	Bk	1
		67-17-06		Pylon lower ring	Bk	1
S-55 Series continued		67-29-07		Azimuth control rod assembly	Bk	1
		70-12-04		Main rotor shaft cracks	Bk	1
		73-16-01		Engine turbine failure	Bk	1
		75-22-12		Inflight power loss	Bk	1
S-55	1H4	71-26-03		Servo support bracket	Bk	1
		75-04-02		Main rotor spindles	Bk	1
S-55B (HO4S-3G, UH-19D, H-19D5, UH-19B)	1H4	70-12-04		Main rotor shaft cracks	Bk	1
		75-04-02		Main rotor spindles	Bk	1
		75-22-12		Inflight power loss	Bk	1
S-55C	1H4	70-12-04		Main rotor shaft cracks	Bk	1
		75-04-02		Main rotor spindles	Bk	1
		75-22-12		Inflight power loss	Bk	1
S-58 Series (HSS-1, HUS-1, H-34 CH-34, HH-34, SH-34, UH-34, VH-34 Series)	1H11	57-19-02		Hydromechanical clutch rollers	Bk	1
		59-16-04		Damper trunnion bolt	Bk	1
		60-17-03	R1	Main rotor blade assemblies	Bk	1
		60-24-04		Electrical cable	Bk	1
		61-01-03		Input bevel gear	Bk	1
		64-02-06	R1	Pylon and tail cone fittings	Bk	1
		66-19-04		Tail rotor blades	Bk	1
		74-15-06		Tail rotor gear box	Bk	1
		75-07-07		Emergency hatch handles	Bk	1
		75-07-08		Tail assembly	Bk	1
		75-13-01		Main rotor assembly	Bk	1
		82-01-07		Horizontal hinge pins	Bk	2
		85-17-08		Main rotor head bolts	Bk	2
		86-25-05		Gearbox pinions or gears	Bk	2
		89-25-01		Engine fire extinguishing system	Bk	2
		95-10-09		Transmission main gear box ring gear	Bk	3
		95-26-08		Main rotor shaft	Bk	3
		95-26-09		Main rotor shaft	Bk	3
S-58T Series	1H11	78-05-01		Fuel bypass lines	Bk	1
		78-21-05		Tail rotor blades	Bk	1
		82-01-07		Horizontal hinge pins	Bk	2
		94-12-07		Gear box assembly	Bk	3
		95-10-09		Transmission main gear box ring gear	Bk	3
CH34A, CH34C, HSS-1, HSS-1N, UH34D, UH34J	H8SW H15WE	95-26-09		Main rotor shaft	Bk	3
H34A, HH34J, SH34J	H4SO	95-26-09		Main rotor shaft	Bk	3
HUS-1	H9WE	95-26-09		Main rotor shaft	Bk	3
UH34D	H8SW, H4SO, H7NM H15WE	95-26-09		Main rotor shaft	Bk	3
UH34E	H7NM	95-26-09		Main rotor shaft	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S-61 Series	1H15,	65-08-02		Main rotor blades	Bk	1
(USAF CH-3C,	H2EA,	66-19-04		Tail rotor blades	Bk	1
HH-3C, CH-3E, HH-3E)	H8EA	67-29-05		Rotary wing hub hinge pins	Bk	1
		68-19-07		Rotor blade spindles	Bk	1
		70-09-03		Tail gear box pitch beams	Bk	1
		71-05-01		Main landing gear axle	Bk	1
		71-21-03		Link in servo valve input linkage	Bk	1
		72-03-01		Alum. forgings flight control system	Bk	1
		78-20-05	R4	Main rotor spindles	Bk	1
		79-12-10		Tail rotor blade	Bk	1
		80-17-07		Horizontal hinge pins	Bk	2
		84-01-51		Rotary wing head shaft nut	Bk	2
		84-25-01		Main gearbox inspection	Bk	2
		86-23-08		Main rotor hub lower plate	Bk	2
		89-07-09		Main rotor gearbox	Bk	2
		90-01-04		Main rotor hub upper plate	Bk	3
		91-12-01		Sleeve & spindle assemblies	Bk	3
		2000-13-06		Pylon upper and lower hing web fittings	Bk	4
S-61A	H2EA	68-20-08		Functional test of AFCS	Bk	1
(SH-3A, HSS-2, CH-3B)		68-21-06		Deactivate AFCS	Bk	1
		70-08-03		Heater inlet check valve	Bk	1
		70-15-01		Cabin heater blower	Bk	1
		72-16-06		Electrical feeder wire gage	Bk	1
		72-25-04		Loss of main rotor control	Bk	1
		73-15-01		Rear fuselage and pylon fittings	Bk	1
		74-20-07	R5	Main rotor blades	Bk	1
		74-20-09		Main rotor blades	Bk	1
		76-08-01	R1	Tail rotor pylon	Bk	1
		78-12-05		Fixed S-61L type landing gears	Bk	1
		84-11-03		Possible flange failure	Bk	2
		85-18-05	R2	Main rotor blades	Bk	2
		87-15-11		Gearbox brackets	Bk	2
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
S-61B	H2EA	72-25-04		Loss of Main rotor control	Bk	1
S-61D	H2EA	72-25-04		Loss of main rotor control	Bk	1
(SH-3D)		73-15-01		Rear fuselage and pylon fittings	Bk	1
		76-08-01	R1	Tail rotor pylon	Bk	1
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
S-61E	H2EA	73-15-01		Rear fuselage and pylon fittings	Bk	1
(RH-3A)		76-08-01	R1	Tail rotor pylon	Bk	1
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
S-61L	1H15,	68-20-08		Functional test of AFCS	Bk	1
	H8EA	68-21-06		Deactivate AFCS	Bk	1
		70-08-03		Heater inlet check valve	Bk	1
		70-15-01		Cabin heater blower	Bk	1
		72-16-06		Electrical feeder wire gage	Bk	1
		72-25-04		Loss of main rotor control	Bk	1
		73-15-01		Rear fuselage and pylon fittings	Bk	1
		74-20-07	R5	Main rotor blades	Bk	1
		74-20-09		Main rotor blades	Bk	1
		74-25-05		Main rotor blades	Bk	1
		74-25-06		Takeoff gross weight limitation	Bk	1
		75-12-01		Main rotor blades	Bk	1
		75-17-33		Baggage doors	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S-61L continued		75-26-10		Component replacement	Bk	1
		76-03-02		Fractures in barrel nuts	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
		76-08-01	R1	Tail rotor pylon	Bk	1
		78-12-05		Fixed S-61L type landing gears	Bk	1
		84-11-03		Possible flange failure	Bk	2
		85-15-05	L	Main rotor horn eyebolt/eyebolt assembly	Bk	2
		85-18-05	R2	Main rotor blades	Bk	2
		87-15-11		Gearbox brackets	Bk	2
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
		2004-15-22		Engine chip detector	Bk	4
S-61N	1H15	68-20-08		Functional test of AFCS	Bk	1
		68-21-06		Deactivate AFCS	Bk	1
		70-08-03		Heater inlet check valve	Bk	1
		70-15-01		Cabin heater blower	Bk	1
		72-16-06		Electrical feeder wire gage	Bk	1
		72-25-04		Loss of main rotor control	Bk	1
		74-20-07	R5	Main rotor blades	Bk	1
		74-20-09		Main rotor blades	Bk	1
		74-25-05		Main rotor blades	Bk	1
		74-25-06		Takeoff gross weight limitation	Bk	1
		75-08-15		Baggage doors	Bk	1
		75-12-01		Main rotor blades	Bk	1
		75-17-33		Baggage doors	Bk	1
		75-26-10		Component replacement	Bk	1
		76-03-02		Fractures in barrel nuts	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
		78-05-07		Main landing gear	Bk	1
		78-12-05		Fixed S-61L type landing gears	Bk	1
		84-11-03		Possible flange failure	Bk	2
		85-15-05	L	Main rotor horn eyebolt/eyebolt assembly	Bk	2
		85-18-05	R2	Main rotor blades	Bk	2
		87-15-11		Gearbox brackets	Bk	2
		89-04-01	R3	Truss tube assemblies	Bk	2
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
		2004-15-22		Engine chip detector	Bk	4
S-61NM	1H15	74-20-07	R5	Main rotor blades	Bk	1
		74-20-09		Main rotor blades	Bk	1
		74-25-05		Main rotor blades	Bk	1
		74-25-06		Takeoff gross weight limitation	Bk	1
		75-12-01		Main rotor blades	Bk	1
		75-17-33		Baggage doors	Bk	1
		75-26-10		Component replacement	Bk	1
		76-03-02		Fractures in barrel nuts	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
		78-12-05		Fixed S-61L type landing gears	Bk	1
		85-15-05	L	Main rotor horn eyebolt/eyebolt assembly	Bk	2
		85-18-05	R2	Main rotor blades	Bk	2
		87-15-11		Gearbox brackets	Bk	2
		89-04-01	R3	Truss tube assemblies	Bk	2
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
		2004-15-22		Engine chip detector	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S-61R	1H15	70-08-03		Heater inlet check valve	Bk	1
(CH-3C, HH-3C,		70-15-01		Cabin heater blower	Bk	1
(CH-3E, HH-3E)		72-16-06		Electrical feeder wire gage	Bk	1
		72-25-04		Loss of main rotor control	Bk	1
		74-20-07	R5	Main rotor blades	Bk	1
		74-20-09		Main rotor blades	Bk	1
		74-25-05		Main rotor blades	Bk	1
		75-12-01		Main rotor blades	Bk	1
		76-03-02		Fractures in barrel nuts	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
		85-18-05	R2	Main rotor blades	Bk	2
		87-15-11		Gearbox brackets	Bk	2
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
		2004-15-22		Engine chip detector	Bk	4
S-61V	H2EA	72-25-04		Loss of main rotor control	Bk	1
(VH-3A, HSS-2Z)		73-15-01		Rear fuselage and pylon fittings	Bk	1
		74-20-07	R5	Main rotor blades	Bk	1
		76-08-01	R1	Tail rotor pylon	Bk	1
		85-18-05	R2	Main rotor blades	Bk	2
		87-15-11		Gearbox brackets	Bk	2
		97-19-06		Blade trailing edge pocket assemblies	Bk	3
		98-26-02		Shaft	Bk	3
S-62 Series	1H13	81-06-53	R1	Rotor brake discs	Bk	2
S-62A	1H13	63-17-06		Input shaft helical gears	Bk	1
		65-08-02		Main rotor blades	Bk	1
		66-04-03		Main rotor blades	Bk	1
		70-12-04		Main rotor shaft cracks	Bk	1
		71-26-03		Servo support bracket	Bk	1
		75-04-02		Main rotor spindles	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
S-64A	H1EA	74-16-05		Main rotor head	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
S-64E	H4EA &	74-16-05		Main rotor head	Bk	1
	H6EA	75-11-11		Gear box shaft and gear assembly	Bk	1
		76-06-01		Hydraulic pumps	Bk	1
		85-18-01		Main rotor blade outboard spars	Bk	2
		85-25-03		Torque tube inner bracket assembly	Bk	2
		90-26-12		Main rotor blades	Bk	3
		97-19-10		Inspect main transmission plates	Bk	3
S-64F	H6EA	75-11-11		Gear box shaft and gear assembly	Bk	1
(CH-54B)		76-06-01		Hydraulic pumps	Bk	1
		97-10-15		Main gearbox second stage lower planetary plate	Bk	3
S-70A	H5NE	2002-11-10		Jackpad mounting bolt retention nut	Bk	4
S-70C	H3NE	2002-11-10		Jackpad mounting bolt retention nut	Bk	4
S-76 Series	H1NE	89-07-12		Tail rotor horn	Bk	2
		2000-11-52		Main rotor blades	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S-76A Model/Series	H1NE	79-25-08		Hydraulic pumps	Bk	1
		80-14-16	R1	Main rotor blade spindle	Bk	2
		80-22-55	R4	Main rotor damper rods	Bk	2
		81-07-51	R1	Main rotor spindles	Bk	2
		81-09-07		Main rotor blades	Bk	2
		81-21-04		Main rotor scissors assembly	Bk	2
		81-23-04		Main gearbox overhaul	Bk	2
		82-06-08		DC generators	Bk	2
		82-06-51		Main gearbox shaft and spur pinions	Bk	2
		82-17-03		Rotor brake assembly	Bk	2
		82-25-01	R1	R & L MLG positioning rod ends	Bk	2
		84-08-01		Shaft bearing assembly	Bk	2
		84-10-02		Main rotor blade spar	Bk	2
		84-15-04		Tail rotor controls	Bk	2
		84-17-01		Main rotor pitch horn	Bk	2
		84-19-51	R1	Center firewall supports	Bk	2
		85-15-06		Tail rotor drive shaft bearings	Bk	2
		86-14-07		Push rod assembly	Bk	2
		86-19-12		See Allison, Engine	Bk	2
		86-19-14		Tail rotor assembly	Bk	2
		87-12-06		Generator control unit	Bk	2
		87-23-07	R1	Electrical door locking actuators	Bk	2
		87-25-02		Ground connections	Bk	2
		91-08-03		Forward spar cap	Bk	3
		91-24-13		Vertical pylon forward spar cap and web	Bk	3
		94-14-20	R1	Tail rotor blades *(see Bk 4 for Paper copy)*	Bk	3
		98-17-15		Inspect swashplate assy uniball bearing retainer	Bk	3
		99-11-04		RFM – Landing gross weights and climb	Bk	3
		99-19-30		Tail gearbox forward fairing	Bk	3
		2000-12-09		Inspect soft-start control assembly	Bk	4
		2001-01-04		Threaded joint in the rod assembly	Bk	4
		2001-10-06		Failure of the shaft	Bk	4
		2002-05-06		Main & nose landing gear	Bk	4
		2002-15-51		Main rotor blade	Bk	4
		2002-21-07		Main rotor spindle attachment bolt	Bk	4
		2003-04-15		Rotor brake disc (RBD)	Bk	4
		2003-14-18		Main landing gear brake disc	Bk	4
		2004-06-04		Electrical wiring for autopilots	Bk	4
		2005-22-01		Main rotor lower bifilar arm assembly	BW	05-22
S-76B	H1NE	86-14-07		Push rod assembly	Bk	2
		86-19-14		Tail rotor assembly	Bk	2
		87-12-06		Generator control unit	Bk	2
		87-23-07	R1	Electrical door locking actuators	Bk	2
		87-25-02		Ground connections	Bk	2
		88-03-01	L	See Pratt & Whitney	Bk	2
		88-05-01	R1	Engine support cross beam	Bk	2
		96-15-03		Drive shaft assemblies	Bk	3
		98-17-15		Inspect swashplate assy uniball bearing retainer	Bk	3
		99-19-30		Tail gearbox forward fairing	Bk	3
		2001-01-04		Threaded joint in the rod assembly	Bk	4
		2001-03-51		Prevent failure of the shaft	Bk	4
		2001-10-06		Failure of the shaft	Bk	4
		2001-25-06		Attitude & heading reference (AHRS) fail signal	Bk	4
		2002-15-51		Main rotor blade	Bk	4
		2002-21-07		Main rotor spindle attachment bolt	Bk	4
		2003-04-15		Rotor brake disc (RBD)	Bk	4
		2003-14-18		Main landing gear brake disc	Bk	4
		2004-06-04		Electrical wiring for autopilots	Bk	4
		2005-22-01		Main rotor lower bifilar arm assembly	BW	05-22

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S-76C	H1NE	98-17-15		Inspect swashplate assy uniball bearing retainer	Bk	3
		99-01-09		Fuel supply line	Bk	3
		99-07-01		RFM – Operating limitations	Bk	3
		99-19-30		Tail gearbox forward fairing	Bk	3
		2001-01-04		Threaded joint in the rod assembly	Bk	4
		2001-03-51		Prevent failure of the shaft	Bk	4
		2001-10-06		Failure of the shaft	Bk	4
		2001-25-06		Attitude & heading reference (AHRS) fail signal	Bk	4
		2002-15-51		Main rotor blade	Bk	4
		2002-21-07		Main rotor spindle attachment bolt	Bk	4
		2003-04-15		Rotor brake disc (RBD)	Bk	4
		2003-14-18		Main landing gear brake disc	Bk	4
		2004-06-04		Electrical wiring for autopilots	Bk	4
		2005-22-01		Main rotor lower bifilar arm assembly	BW	05-22
S-92A		2005-12-03		Main gearbox (MGB) lubrication/scavenge pump vespel spline adapters (vespel spline adapters)	BW	05-13
		2005-13-13		Tail gear box output housing	BW	05-13
		2006-11-14		Main transmission assembly mounting bolt (bolt)	BW	06-12
		2006-15-19				

SLINGSBY AVIATION, LTD.
(Formerly AIRSHIP, SLINGSBY SAILPANE LTD)
(See VICKERS-SLINGSBY, WESTINGHOUSE AIRSHIPS)

T.51 Series	G5EU	73-17-02		Corrosion of wing spars	Bk	1
		98-22-15		Spar assembly and adjoining structure	Bk	3
T.53.B	G17EU	69-03-04		Elevator control bracket	Bk	1
		69-11-07		Fuselage center section	Bk	1
		69-19-04		Glider trim	Bk	1
		85-12-10		Placard -welded frame/brackets	Bk	2
T.59.D	G27EU	73-13-05		Aileron unbalance condition	Bk	1
		75-17-10		Elevator actuator bracket	Bk	1
		75-17-12		Dive brake retraction failure	Bk	1
		75-23-06		Rudder cable	Bk	1

SLINGSBY SAILPLANE, LTD.
(See VICKERS-SLINGSBY, SLINGSBY AVIATION LTD)

S.M. & T. AIRCRAFT
(Formerly U.S. Helicopters)
(See U.S. Helicopters for ADs in Books 2 & 3)

UH-1A	H3SO	83-03-03		Tail boom skin joint	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
UH-1B	H3SO	83-03-03		Tail boom skin joint	Bk	2
		83-20-01		Tail rotor hub assembly	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		86-07-07		Universal assembly - main rotor	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
UH-1H	H3SO	83-03-03		Tail boom skin joint	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
SMITH HELICOPTER						
UH-1E	H8NM	88-08-01		Rod end bearing assemblies	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grips	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4

S.N.I.A.S.
(Formerly SUD AVIATION)
(See AEROSPATIALE)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
SOCIETE C.A.R.M.A.M.						
(See AER-PEGASO)						
M.200	G14EU	69-24-01		Horizontal stabilizer	Bk	1
		75-23-02		Aileron spars	Bk	1
SOUTHERN AERO CORPORATION						
(See UNC HELICOPTERS)						
SOUTHERN HELICOPTER, INC.						
UH-1B	R00012AT	99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
SOUTHWEST FLORIDA AVIATION						
SW204 (UH-1B),	H6SO	89-20-12		Tail rotor hub assembly	Bk	2
		92-23-01		Main rotor pillow blocks	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
SW205 (UH-1H)	H6SO	90-03-10		Tail rotor grip	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
SW204HP (UH-1B/HP)	H6SO	90-10-05		Tail rotor gearbox	Bk	3
		92-23-01		Main rotor pillow blocks	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
SW205A-1	H6SO	92-23-01		Main rotor pillow blocks	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
START & FLUG GmbH						
(*See Ursula Hanle)*						
STEMME GmbH						
S10	G58EU	95-17-08		Rudder control cable system	Bk	3
		98-08-03		Horizontal stabilizer	Bk	3
		98-12-06		FM - Limitation Section - Fuel	Bk	3
		98-19-01		Pitot tube O-ring	Bk	3
		98-24-10		Flap drive rocker	Bk	3
		98-24-30		Flight control system	Bk	3
		2000-26-18		Airbrake eyebolts	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
S10 continued		2003-07-05		Firewall and oil lines	Bk	4
		2004-14-21		Drive shafts	Bk	4
		2006-17-03				
S10V	G58EU	98-08-03		Horizontal stabilizer	Bk	3
		98-12-06		FM - Limitation Section - Fuel	Bk	3
		98-15-24		Propeller suspension fork	Bk	3
		98-24-30		Flight control system	Bk	3
		2000-15-03		Propeller blade suspension forks	Bk	4
		2000-26-18		Airbrake eyebolts	Bk	4
		2003-07-05		Firewall, fuel and oil lines	Bk	4
		2004-14-21		Drive shafts	Bk	4
		2006-17-03		Aileron push-rod and the connecting shaft		
		2006-26-02		Leaking brass fuel connection		
S10VT	G06CE	98-24-30		Flight control system	Bk	3
		99-15-03		Wastegate control	Bk	3
		2000-15-03		Propeller blade suspension forks	Bk	4
		2002-22-04		Engine compartment firewall	Bk	4
		2003-20-09		Lower cog wheel in gear box	Bk	4
		2004-14-21		Drive shafts	Bk	4
		2006-17-03		Aileron push-rod and the connecting shaft		
		2006-19-08		Exhaust bends in curvature bend area		
		2006-24-06		Pressure lines		
		2006-26-02		Leaking brass fuel connection		
SUD AVIATION						
(See AEROSPATIALE)						
SZYBOWCOWY ZAKLAD DOSWIADCZALNY						
SZD-24-4A "Foka-4"	G10EU	75-16-17		Wing, fuselage and tailplane	Bk	1
TAMARACK HELICOPTERS, INC.						
(Formerly Ranger Helicopter Services)						
UH-1F	H7NE	99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
TERYJON AVIATION, INC.						
Fast Kat I OH-13S	H2GL	80-21-09	R1	Tail rotor pitch link	Bk	2
		81-04-03		Tail rotor drive assembly	Bk	2
		2002-03-16		Main rotor blade grips	Bk	4
TEXAS HELICOPTER CORPORATION						
(See Aerodyne Systems Engineering Ltd)						
U.S. HELICOPTER, INC						
(Formerly UNC Helicopters)						
(See SM&T Aircraft)						
(For ADs in Book 2 see UNC Helicopters)						
UH-1E	H4NM	83-03-03		Tail boom skin joint	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		88-08-01		Rod end bearing assemblies	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
UH-1L	H4NM	83-03-03		Tail boom skin joint	Bk	
		84-18-03	R1	Clevis inspection	Bk	2
		88-08-01		Rod end bearing assemblies	Bk	2
		88-25-05		Tail rotor grip assembly	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
TH-1L	H4NM	83-03-03		Tail boom skin joint	Bk	2
		84-18-03	R1	Clevis inspection	Bk	2
		88-08-01		Rod end bearing assemblies	Bk	2
		89-08-06		Transmission internal sump oil filter	Bk	2
		89-20-12		Tail rotor hub assembly	Bk	2
		90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		95-10-08		Tail rotor control system	Bk	3
		96-12-26		Clean and inspect tail rotor blade	Bk	3
		97-01-06		Tail rotor slider	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4

URSULA HANLE
(Formerly START & FLUG GmbH)
(For ADs in Book 1 see START & FLUG GmbH)

H101 "Salto"	G28EU	76-10-04		Cockpit canopy fastening mechanism	Bk	1
		98-24-12		Airbrake lever	Bk	3

UNC HELICOPTERS
(Formerly SOUTHERN AERO CORP., WILLIAMS HELI.)
(See U.S. Helicopters)

UTAH STATE UNIVERSITY
(See Arrow Falcon Exporters, Inc.)

VALENTIN GmbH

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
Taifun 17E	G50EU	87-06-01		Tailplane front mounting	Bk	2
		87-25-01		Welded joints-axles	Bk	2
		88-15-01		Stall warning system	Bk	2
		2001-05-08		Improperly installed or cracked central bolts	Bk	4
		2004-20-10		Wing-locking mechanism	Bk	4
VICKERS-SLINGSBY						
(See also SLINGSBY SAILPLANE, LTD.)						
T65A (Slingsby)	G42EU	80-15-08		Main wing shear web	Bk	2
		82-07-01		PLACARD/flap airbrake system	Bk	2
		84-22-01		Elevator malfunction	Bk	2
WALZ, ELIZABETH ADAMS						
(See MCNEELY)						
WEST COAST FABRICATIONS						
(See BELL HELICOPTER)						
WESTERN INTERNATIONAL AVIATION, INC.						
(See Hagglund Helicopters)						
WESTINGHOUSE AIRSHIPS						
(Formerly SLINGSBY AVIATION)						
Skyship 600	AS1EU	89-22-15		Envelope	Bk	2
		90-12-09		Gaiter	Bk	3
		91-03-05		Ignition control unit	Bk	3
WESTLAND HELICOPTERS LIMITED						
Westland 30 Series	H12EU	98-06-06		Inspect drive shaft attachment flanges	Bk	3
30 Series 100	H12EU	84-01-52	R1	Pitch control lever	Bk	2
		84-12-51		Main rotor blade insp.	Bk	2
		85-07-06		Main rotor tie-bar pin	Bk	2
		98-07-11		Main rotor tie-bar	Bk	3
		99-01-02		Conformal pinion quill shafts in MRGB	Bk	3
30 Series 100-60	H12EU	98-07-11		Main rotor tie-bar	Bk	3
		99-01-02		Conformal pinion quill shafts in MRGB	Bk	3
WILCO AVIATION						
(See SOUTHERN AERO)						
WILLIAMS HELICOPTER TECHNOLOGY						
(Formerly OREGON HELICOPTER)						
(See UNC Helicopters)						
(Formerly SCOTT PAPER COMPANY)						
UH-1E	H7SO	90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
UH-1L	H7SO	90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

MAKE & MODEL	TC NO.	AD NUMBER	*	SUBJECT	BOOK	NO.
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4
TH-1L	H7SO	90-03-10		Tail rotor grip	Bk	3
		90-10-05		Tail rotor gearbox	Bk	3
		94-22-09		Tail rotor driveshaft	Bk	3
		99-07-15		Tail rotor yoke	Bk	3
		99-25-12		Tailboom vertical fin spar	Bk	3
		2000-15-21	R1	Mast assembly	Bk	4
		2002-01-31		Main rotor mast or trunnion	Bk	4
		2002-13-51		Tail rotor grip	Bk	4
		2002-20-01		TT strap	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

AIRWORTHINESS DIRECTIVE SUMMARY SUBJECT INDEX

ENGINES APPLICABLE TO

SMALL AIRCRAFT AND ROTORCRAFT

JANUARY 2007

* * * * * * * * * *

The indexes, which are published twice a year, are intended to be used as a guide only and should not be relied upon as conclusive evidence of AD applicability. Aircraft operators, inspectors, and persons performing maintenance are reminded of their responsibility under Sections 39.3, 43.11, and 43.13 of the Federal Aviation Regulations, respectively, to assure compliance with all applicable AD's.

* * * * * * * * * *

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER *	BOOK NO.
AIRESEARCH MFG. CO. OF ARIZONA			
(See GARRETT TURBINE ENGINE CO.)			
ALLIEDSIGNAL			
(Formerly GARRETT TURBINE ENGINE CO.,			
TEXTRON LYCOMING, AIRESEARCH MFG)			
(See Honeywell International)			
ALLISON GAS TURBINE DIVISION (GMC)			
(See Rolls-Royce Corporation)			
(See Rolls-Royce Engines)			
AVCO CORPORATION, LYCOMING DIVISION			
(See TEXTRON LYCOMING, ALLIEDSIGNAL, INC.)			
BOMBARDIER-ROTAX GmbH			
912F Series	E00051EN	98-15-16	Bk 3
		2002-16-07	Bk 4
		2002-16-26	Bk 4
		2002-19-09	Bk 4
		2002-21-16	Bk 4
		2005-01-14	BW 05-02
912S Series	E00051EN	2002-16-07	Bk 4
		2002-19-09	Bk 4
		2002-21-16	Bk 4
		2005-01-14	BW 05-02
914F Series	E00058NE	2002-10-14	Bk 4
		2002-16-07	Bk 4
		2002-16-26	Bk 4
		2002-21-16	Bk 4
		2005-01-14	BW 05-02
BRISTOL SIDDELEY			
(See ROLLS ROYCE)			
CONTINENTAL TELEDYNE CONTINENTAL MOTORS			
(See TELEDYNE CONTINENTAL)			

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
CURTISS-WRIGHT/MARQUETTE, INC.					
(For ADs in Bk 1 see Wright Aeronautical)					
Cyclone C9HE Series (R-1820-80)					
Affects specific U.S. Registered aircraft - see AD	E-259	94-14-10		Bk	3
C9GC Series	E-219	51-12-01		Bk	1
C9HD Series	E-243	51-12-01		Bk	1
		60-04-07		Bk	1
de HAVILLAND ENGINE COMPANY, LTD.					
(See ROLLS ROYCE)					
DETROIT DIESEL-ALLISON DIV.					
(See ALLISON GAS TURBINE)					
ENGINE COMPONENTS INCORPORATION (ECI)					
ECI engine cylinders - See AD for applicable Teledyne Reciprocating Engines		2004-08-10		Bk	4
FAIRCHILD ENGINE DIVISION, FAIRCHILD ENGINE AND AIRPLANE CORP.					
Ranger 6-440-C Series	E-216	52-03-01		Bk	1
		54-09-01		Bk	1
FRANKLIN ENGINE CO.					
(See Wytwornia Sprzetu Komunikacyjnego)					
GARRETT TURBINE ENGINE CO.					
(See AIRESEARCH, ALLIED SIGNAL)					
GENERAL ELECTRIC CO.					
CF700-2C	E7EA	73-23-05		Bk	1
		75-19-05		Bk	1
		78-07-06		Bk	1
		97-13-10		Bk	3
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CF700-2D	E7EA	75-19-05		Bk	1
		78-07-06		Bk	1
		80-08-06	R1	Bk	2
		85-18-03		Bk	2
		97-13-10		Bk	3
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CF700-2D-2	E7EA	75-19-05		Bk	1
		78-07-06		Bk	1
		80-08-06	R1	Bk	2
		85-18-03		Bk	2
		97-13-10		Bk	3
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CJ610-1	1E16	73-23-05		Bk	1
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
CJ610-4	1E16	73-23-05		Bk	1
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CJ610-5	1E16	73-23-05		Bk	1
		78-07-06		Bk	1
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CJ610-6	1E16	73-23-05		Bk	1
		78-07-06		Bk	1
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CJ610-8	1E16	97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CJ610-8A	1E16	80-08-06	R1	Bk	2
		85-18-03		Bk	2
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CJ610-9	1E16	75-19-05		Bk	1
		80-08-06	R1	Bk	2
		85-18-03		Bk	2
		97-25-08		Bk	3
		98-23-06		Bk	3
		2001-10-12		Bk	4
CT58-100-2	1E3	64-26-02		Bk	1
		67-01-02		Bk	1
		69-17-03		Bk	1
		76-13-02		Bk	1
		78-26-08		Bk	1
		81-02-02		Bk	2
		81-18-03		Bk	2
		97-19-17		Bk	3
		2001-18-06		Bk	4
		2004-04-06		Bk	4
CT58-110-1	1E3	64-26-02		Bk	1
		67-01-02		Bk	1
		69-17-03		Bk	1
		76-13-02		Bk	1
		78-26-08		Bk	1
		81-02-02		Bk	2
		81-18-03		Bk	2
		94-07-05		Bk	3
		97-19-17		Bk	3
		97-21-08		Bk	3
		2001-18-06		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER *	BOOK	NO.
CT58-110-2	1E3	67-01-02	Bk	1
		69-17-03	Bk	1
		76-13-02	Bk	1
		78-26-08	Bk	1
		81-02-02	Bk	2
		81-18-03	Bk	2
		94-07-05	Bk	3
		97-19-17	Bk	3
		97-21-08	Bk	3
		2001-18-06	Bk	4
CT58-140-1	1E3	64-26-02	Bk	1
		67-01-02	Bk	1
		69-17-03	Bk	1
		74-25-01	Bk	1
		76-13-02	Bk	1
		78-26-08	Bk	1
		81-02-02	Bk	2
		81-18-03	Bk	2
		91-07-17	Bk	3
		94-07-05	Bk	3
		97-19-17	Bk	3
		97-21-08	Bk	3
		2001-12-07	Bk	4
		2001-18-06	Bk	4
		2004-04-06	Bk	4
		2005-04-10	BW 05-05	
CT58-140-2	1E3	67-01-02	Bk	1
		69-17-03	Bk	1
		74-25-01	Bk	1
		76-13-02	Bk	1
		78-26-08	Bk	1
		81-02-02	Bk	2
		81-18-03	Bk	2
		94-07-05	Bk	3
		97-19-17	Bk	3
		97-21-08	Bk	3
		2001-12-07	Bk	4
		2001-18-06	Bk	4
		2004-04-06	Bk	4
		2005-04-10	BW 05-05	
CT64-820-4		2005-13-11	BW 05-13	
CT7-2A	E8NE	93-25-17	Bk	3
CT7-2D1	E8NE	2004-16-07	Bk	4
CT7-5A2	E8NE	93-25-17	Bk	3
CT7-6	E8NE	93-25-17	Bk	3
CT7-7A	E8NE	93-25-17	Bk	3
CT7-7A1	E8NE	93-25-17	Bk	3
CT7-8A	E8NE	2006-06-51	BW 06-09	
CT7-9C	E8NE	93-25-17	Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
GIPPSLAND AERONAUTICS PTY. LTD.					
GA8		2005-02-11		BW 05-03	
		2005-22-02		BW 05-22	
		2006-19-11			
GLADDEN PRODUCTS CORP.					
Kinner R-5 Series 2	TC 153	46-06-02		Bk	1
		46-06-03		Bk	1
Kinner R-55, R-56	TC 153	46-06-03		Bk	1
HONEYWELL INTERNATIONAL					
(Formerly Allied Signal and Textron Lycoming)					
LTP 101-600 Series	E7NE	79-06-06	R2	Bk	1
(TC E7NE - ADs for Book 1 in Avco)		79-20-03		Bk	1
(TC E7NE - ADs for Book 2 & 3 in Textron)		82-20-51	T	Bk	2
		86-10-04		Bk	2
LTP-101 Series	E7NE	92-15-07		Bk	3
(Book 3 Textron Lycoming)		93-13-11		Bk	3
		94-18-06		Bk	3
		95-16-04		Bk	3
		96-12-05		Bk	3
		96-12-27		Bk	3
		2001-22-07		Bk	4
		2002-03-09	R1	Bk	4
LTP101-600A-1A, -700A-1A Series	E7NE	2001-17-15		Bk	4
		2001-25-04		Bk	4
LTS-101 Series	E5NE	88-14-01		Bk	2
(TC E5NE - ADs in Book 1 See Avco Lycoming)		92-15-07		Bk	3
(TC E5NE - ADs in Book 2 & 3 See Textron)		93-13-11		Bk	3
		94-18-06		Bk	3
		95-16-04		Bk	3
		96-12-05		Bk	3
		96-12-27		Bk	3
		2001-22-07		Bk	4
		2002-03-09	R1	Bk	4
LTS 101-600 Series	E5NE	79-06-06	R2	Bk	1
		79-20-03		Bk	1
		83-16-03		Bk	2
		84-02-07		Bk	2
		84-14-01		Bk	2
		86-10-04		Bk	2
		96-06-10		Bk	3
		96-10-04		Bk	3
LTS101-600A-2, -600A-3, and -600A-3A Series	E5NE	2001-17-15		Bk	4
		2001-25-04		Bk	4
LTS 101-650B1	E5NE	95-08-14		Bk	3
		95-26-01		Bk	3
LTS 101-650C	E5NE	95-08-14		Bk	3
		95-26-01		Bk	3
LTS 101-750 Series	E5NE	86-10-04		Bk	2
LTS 101-750B1	E5NE	95-08-14		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
		95-26-01		Bk	3
LTS 101-750B2	E5NE	96-06-10		Bk	3
LTS 101-750C	E5NE	95-08-14		Bk	3
		95-26-01		Bk	3
TFE 731 Series	E6WE	81-24-08		Bk	2
		82-23-03	R1	Bk	2
		86-03-01		Bk	2
		88-18-03		Bk	2
		89-22-16	L	Bk	2
		90-03-04		Bk	3
		90-24-06		Bk	3
		92-02-18		Bk	3
		92-21-06		Bk	3
		94-07-03		Bk	3
		94-23-05		Bk	3
		95-07-02		Bk	3
		96-04-01		Bk	3
		96-05-03		Bk	3
		97-04-03		Bk	3
		98-10-15		Bk	3
		98-17-01		Bk	3
		2000-15-09		Bk	4
		2001-23-09		Bk	4
		2005-05-15		BW 05-06	
		2005-13-07		BW 05-13	
TPE-331 Series	E2WE, E3WE,	70-04-04		Bk	1
(For ADs in Book 1 see	E4WE	70-16-09		Bk	1
AIRESEARCH MFG and		70-19-02		Bk	1
Garrett)		71-05-07		Bk	1
		73-26-07	R3	Bk	1
		74-10-10		Bk	1
		74-24-05		Bk	1
		75-10-05		Bk	1
		76-16-01		Bk	1
		78-05-02		Bk	1
		78-25-08	R3	Bk	1
		79-12-04		Bk	1
		84-01-04		Bk	2
		84-10-06	R1	Bk	2
		86-08-06	R1	Bk	2
		88-12-10		Bk	2
		89-07-07	R1	Bk	2
		92-26-08		Bk	3
		93-02-01		Bk	3
		93-05-09		Bk	3
		93-15-11		Bk	3
		94-09-08		Bk	3
		94-26-07		Bk	3
		95-16-08		Bk	3
		96-06-11		Bk	3
		97-15-10		Bk	3
		98-04-15		Bk	3
		98-12-09		Bk	3
		2001-21-02		Bk	4
		2002-12-09		Bk	4
		2002-21-15		Bk	4
		2002-25-02		Bk	4
		2004-09-29		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
TSE-331 Series	E4WE	73-26-03		Bk	1
(For ADs in Book 1 see AIRESEARCH MFG		73-26-07	R3	Bk	1
and Garrett)		78-25-08	R3	Bk	1
		84-01-04		Bk	2
		89-07-07	R1	Bk	2
		92-26-08		Bk	3
		93-05-09		Bk	3
		94-09-08		Bk	3
		95-16-08		Bk	3
		98-04-15		Bk	3
		2002-21-15		Bk	4
		2002-25-02		Bk	4
		2006-14-03			
		2006-15-08			
T53 Series	E1EA	75-22-02		Bk	1
(TC E1EA - For ADs in Book 1 see Avco Lycoming)		77-17-08		Bk	1
		97-07-05		Bk	3
		97-21-07	R1	Bk	3
		2002-03-01		Bk	4
		2002-09-09		Bk	4
		2002-15-04		Bk	4
		2006-01-05		BW 06-02	
		2006-11-16		BW 06-12	
T5309	E1EA	2006-01-05		BW 06-02	
T5309C	E1EA	74-09-03		Bk	1
	(Correction in Textron Bk 2 paper copy)				
T5311 Series	E1EA	97-07-05		Bk	3
		2006-01-05		BW 06-02	
T5311A	E1EA	74-09-03		Bk	1
	(Correction for paper copy in Book 2)				
		2002-03-01		Bk	4
T5311B	E1EA	74-09-03		Bk	1
	(Correction in Textron Bk 2 paper copy)				
		2002-03-01		Bk	4
T5313 Series	E17EA	97-07-05		Bk	3
(TC E17EA - For ADs in Book 1 see Avco Lycoming)					
(TC E17EA - For ADs in Book 2 see Textron)					
T5313A	E17EA	71-08-06		Bk	1
		74-22-07		Bk	1
		75-12-12		Bk	1
T5313B	E17EA	71-08-06		Bk	1
		75-01-05		Bk	1
		75-12-12		Bk	1
		95-10-04		Bk	3
		96-17-01		Bk	3
		97-21-07	R1	Bk	3
		2002-03-01		Bk	4
		2002-15-04		Bk	4
		2006-01-05		BW 06-02	
T5317 Series	E17EA	95-10-04		Bk	3
		97-07-05		Bk	3
		2002-15-04		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
T5317A Series	E17EA	97-21-07	R1	Bk	3
		2002-03-01		Bk	4
		2006-01-05		BW	06-02
T5317B	E17EA	2002-03-01		Bk	4
		2006-01-05		BW	06-02
T5508D	E4NE	76-12-05		Bk	1
		78-07-04		Bk	1
		86-19-13		Bk	2
		94-02-01		Bk	3
KINNER					
(See Gladden Products)					
LYCOMING DIVISION					
(See Avco Lycoming and Textron)					
LYCOMING ENGINES					
(Formerly Textron Lycoming)					
O-235 Series	E-223	75-08-09		Bk	1
		78-25-01		Bk	1
		80-25-02	R2	Bk	2
		95-03-10		Bk	3
		96-09-10		Bk	3
		98-17-11		Bk	3
IO-320 Series	1E12	64-16-05		Bk	1
		65-03-03		Bk	1
		66-20-04		Bk	1
		67-22-06		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		93-11-11		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-26-01		Bk	4
		2003-14-03		Bk	4
AEIO-320 Series	1E12	87-10-06	R1	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-26-01		Bk	4
AIO-320 Series	1E12	75-09-15		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
LIO-320 Series	1E12	75-08-09		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		93-11-11		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-26-01		Bk	4
		2003-14-03		Bk	4
O-360 Series	E-286	59-10-07		Bk	1
		64-16-05		Bk	1
		66-20-04		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		79-10-03	R2	Bk	1
		79-15-02		Bk	1
		80-04-03	R2	Bk	2
		80-14-07		Bk	2
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-12-07		Bk	4
		2005-19-11		BW	05-19
HO-360 Series	E-286	64-16-05		Bk	1
		75-08-09		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
LO-360 Series	E-286	79-10-03	R2	Bk	1
		79-15-02		Bk	1
		80-04-03	R2	Bk	2
		80-14-07		Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
		2005-19-11		BW	05-19
		2006-20-09			
TVO-540 Series	1E14	73-05-01		Bk	1
		80-04-04	R1	Bk	2
		92-12-05		Bk	3
		97-15-11		Bk	3
TIVO-540 Series	1E14	68-08-08		Bk	1
		73-05-01		Bk	1
		80-04-04	R1	Bk	2
		91-08-07		Bk	3
		92-12-05		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
AIO-360 Series	1E10	73-23-01		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		84-13-05		Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4
AEIO-360 Series	1E10	75-08-09		Bk	1
		84-13-05		Bk	2
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4
		2005-19-11		BW	05-19
		2006-06-16		BW	06-07
		2006-20-09			
HIO-360 Series	1E10	64-16-05		Bk	1
		67-22-06		Bk	1
		72-21-04		Bk	1
		73-15-04		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		87-10-06	R1	Bk	2
		89-13-02		Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-12-07		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
LIO-360 Series	1E10	73-23-01		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		92-12-05		Bk	3
		93-11-11		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-26-01		Bk	4
		2005-19-11		BW	05-19
		2006-06-16		BW	06-07
		2006-20-09			
LHIO-360 Series	1E10	92-12-05		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
IO-360 Series	1E10	64-16-05		Bk	1
		66-06-03		Bk	1
		66-20-04		Bk	1
		67-22-06		Bk	1
		71-05-02		Bk	1
		71-11-02		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		93-11-11		Bk	3
		93-14-15		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-12-07		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
		2005-19-11		BW 05-19	
		2006-06-16		BW 06-07	
		2006-20-09			
HIO-540 Series	1E4	92-12-05		Bk	3
		97-15-11		Bk	3
		2003-14-03		Bk	4
IO-540 Series	1E4	63-14-03		Bk	1
		64-16-05		Bk	1
		66-20-04		Bk	1
		67-22-06		Bk	1
		69-08-09		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		78-23-08		Bk	1
		81-03-05		Bk	2
		83-22-04		Bk	2
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		93-11-11		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-01-04		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		99-04-04		Bk	3
		2002-12-07		Bk	4
		2002-19-03		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
		2004-05-24		Bk	4
		2005-19-11		BW 05-19	
		2006-20-09			

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
AEIO-540 Series	1E4	83-22-04		Bk	2
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
		2004-05-24		Bk	4
		2005-19-11		BW 05-19	
		2006-20-09			
TIO-540 Series	E14EA	71-13-01		Bk	1
		73-23-01		Bk	1
		75-09-15		Bk	1
		80-17-10		Bk	2
		83-22-04		Bk	2
		84-19-03	R1	Bk	2
		87-10-06	R1	Bk	2
		89-15-10		Bk	2
		91-08-07		Bk	3
		91-10-04		Bk	3
		91-21-01	R1	Bk	3
		92-12-05		Bk	3
		92-12-10	L	Bk	3
		93-11-11		Bk	3
		95-07-01		Bk	3
		97-01-04		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-12-07		Bk	4
		2002-19-03		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
		2004-05-24		Bk	4
		2005-19-11		BW 05-19	
		2006-20-09			
LTIO-540 Series	E14EA	83-22-04		Bk	2
		84-19-03	R1	Bk	2
		87-10-06	R1	Bk	2
		91-08-07		Bk	3
		92-12-05		Bk	3
		93-11-11		Bk	3
		95-07-01		Bk	3
		97-01-04		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
		2002-19-03		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
		2004-05-24		Bk	4
		2006-20-09			

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
O-320 Series	E-274	55-02-02		Bk	1
		59-10-07		Bk	1
		63-23-02		Bk	1
		64-16-05		Bk	1
		66-20-04		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		77-07-07		Bk	1
		77-20-07		Bk	1
		78-12-08		Bk	1
		78-12-09		Bk	1
		79-10-03	R2	Bk	1
		80-04-03	R2	Bk	2
		80-14-07		Bk	2
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-12-07		Bk	4
O-540 Series	E-295	59-10-07		Bk	1
		63-14-03		Bk	1
		64-16-05		Bk	1
		66-14-03		Bk	1
		66-20-04		Bk	1
		73-23-01		Bk	1
		75-08-09		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		93-11-11		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		99-03-05		Bk	3
		99-04-04		Bk	3
		2002-12-07		Bk	4
		2004-05-24		Bk	4
		2005-19-11		BW 05-19	
		2006-20-09			
OLSON, GEORGE, CO.					
(Formerly Warner Division, Clinton Machine Co.)					
(See Warner Div. For ADs in Bk 1)					
All Models		51-04-02		Bk	1
PORSCHE AKTIENGESELLSCHAFT, DR. ING.H.C.F.					
PFM3200N01, N02, N03	E23NE	99-04-15		Bk	3
PRATT & WHITNEY AIRCRAFT and PRATT & WHITNEY AIRCRAFT OF CANADA, LIMITED					
All Models		56-06-02		Bk	1
Wasp Jr. and R-985 Series	ATC 39, E-123,	57-05-04		Bk	1
	TC 85, TC 113,	66-14-04		Bk	1
	TC 5E-1	68-09-01		Bk	1
		70-10-02		Bk	1
		78-08-07		Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER *	BOOK	NO.
Wasp S1H1, S1H1-G, S1H2,	E-129	96-15-02	Bk	3
S1H4,S1H5-G, S3H2,		99-11-02	Bk	3
R-1340-61				
Wasp S3H1	E-143	96-15-02	Bk	3
		99-11-02	Bk	3
Wasp S3H1-G, R-1340-59	E-142	99-11-02	Bk	3
JFTD12A-4A (T73-P-1)	E15EA	97-02-13	Bk	3
JFTD12A-5A (T73-P-700)				
R-1340 Series	TC 5E-2	96-15-02	Bk	3
		99-11-02	Bk	3
PT6 Series (Canada)	E4EA	97-04-12	Bk	3
	E21NE			
	E22EA			
	E26NE			
PT6A Series	E2NE	69-23-06	Bk	1
		75-06-01	Bk	1
		75-11-04	Bk	1
		80-08-12	Bk	2
		88-24-02	Bk	2
		90-12-05	Bk	3
PT6A Series (Canada)	E4EA	68-05-03	Bk	1
		69-23-06	Bk	1
		75-06-01	Bk	1
		75-11-04	Bk	1
		78-12-04	Bk	1
		78-17-07	Bk	1
		80-04-02	Bk	2
		80-08-12	Bk	2
		86-10-05	Bk	2
		90-12-05	Bk	3
		92-15-11	Bk	3
		2001-20-01	Bk	4
		2002-23-13	Bk	4
		2004-25-18	Bk	4
PT6A-67D	E26NE	95-13-08	Bk	3
PT6B-9	E4EA	69-23-06	Bk	1
		75-11-04	Bk	1
PT6B-36	E21NE	88-03-01	Bk	2
		2004-20-04	Bk	4
PT6T Series	E22EA	76-02-08	Bk	1
		78-17-05	Bk	1
		79-11-03	Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
JT15D Series	E1NE	74-26-05		Bk	1
(Canada)		87-10-01		Bk	2
		91-01-03		Bk	3
		91-15-02		Bk	3
		92-22-15	L	Bk	3
		93-18-08		Bk	3
		93-19-03		Bk	3
		2004-04-09		Bk	4
JT15D Series	E25EA	74-26-05		Bk	1
(CT)		87-10-01		Bk	2
		91-01-03		Bk	3
		93-18-08		Bk	3
		2004-04-09		Bk	4
PW206A	E42NE	2004-17-03		Bk	4
PW206B		2004-14-22		Bk	4
PW206C		2004-14-22		Bk	4
PW206E		2004-14-22		Bk	4
		2004-17-03		Bk	4
PW207D		2004-14-22		Bk	4
PW207E		2004-14-22		Bk	4
PW530A Series	E00053EN	98-17-10		Bk	3
		2003-03-21		Bk	4
PW535A	E00059EN	2003-03-21		Bk	4
		2006-08-13		BW	06-09
PW545A	E00059EN	2003-03-21		Bk	4

RANGER AIRCRAFT ENGINES
(See FAIRCHILD ENGINE DIV.)

ROLLS-ROYCE CORPORTATION
(Formerly Allison Engine Co)
(For ADs in Books 1, 2 or 3 See Allison Engine Co.)

250-B Series	E10CE	2004-24-09		Bk	4
		2006-13-06		BW	06-13
		2006-16-04			
250-B15 Series	E10CE	72-03-06		Bk	1
		77-15-12		Bk	1
		96-19-01		Bk	3
		98-24-28		Bk	3
250-B17 Series	E10CE	72-03-06		Bk	1
		77-09-08		Bk	1
		77-15-12		Bk	1
		79-21-01	R1	Bk	1
		83-03-02	R1	Bk	2
		88-17-01		Bk	2
		96-19-01		Bk	3
		98-24-28		Bk	3
		2001-24-12		Bk	4
		2004-26-09		BW	05-01

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
		2005-10-13		BW	05-11
250 Series	E4CE, E10CE E1GL	82-24-05		Bk	2
250-C Series	E4CE	2004-24-09		Bk	4
		2006-13-06		BW	06-13
		2006-16-04			
250-C10 Series	E4CE	68-12-06		Bk	1
		68-22-02		Bk	1
		69-18-02		Bk	1
		69-18-04		Bk	1
		72-03-06		Bk	1
250-C18 Series	E4CE	68-12-06		Bk	1
		68-22-02		Bk	1
		69-16-05		Bk	1
		69-18-02		Bk	1
		69-18-04		Bk	1
		69-26-03		Bk	1
		72-03-06		Bk	1
		77-15-12		Bk	1
		78-14-08		Bk	1
		98-24-28		Bk	3
250-C19	E4CE	68-12-06		Bk	1
		72-03-06		Bk	1
250-C20 Series	E4CE	72-03-06		Bk	1
		73-19-07		Bk	1
		74-14-03		Bk	1
		77-09-08		Bk	1
		77-15-12		Bk	1
		78-14-08		Bk	1
		79-21-01	R1	Bk	1
		82-13-03		Bk	2
		83-03-02	R1	Bk	2
		88-17-01		Bk	2
		93-25-05		Bk	3
		96-19-01		Bk	3
		98-24-28		Bk	3
		2001-24-12		Bk	4
		2004-26-09		BW	05-01
		2005-10-13		BW	05-11
250-C20R Series	E4CE	98-24-28		Bk	3
250-C28 Series	E1GL	78-26-01		Bk	1
		79-06-05		Bk	1
		79-16-06		Bk	1
		79-18-13		Bk	1
		82-03-02		Bk	2
		83-01-04		Bk	2
		85-25-07	R1	Bk	2
		85-25-08		Bk	2
		85-25-09		Bk	2
		85-25-12		Bk	2
		86-16-03		Bk	2
		86-20-13		Bk	2
		89-23-12		Bk	2
		96-19-01		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
		98-24-28		Bk	3
250-C28 Series continued		2002-06-08		Bk	4
		2004-14-02		BW	05-17
		2005-20-11		BW	05-21
250-C28B	E1GL	2004-14-02		BW	05-17
		2005-20-11		BW	05-21
250-C28C	E1GL	2004-14-02		BW	05-17
		2005-20-11		BW	05-21
250-C30 Series	E1GL	79-06-05		Bk	1
		79-16-06		Bk	1
		81-13-12	R1	Bk	2
		84-17-51	R1	Bk	2
		84-24-54	R2	Bk	2
		85-06-51		Bk	2
		85-25-07	R1	Bk	2
		85-25-08		Bk	2
		86-19-12		Bk	2
		86-20-13		Bk	2
		88-07-06		Bk	2
		88-17-01		Bk	2
		96-19-01		Bk	3
		98-24-28		Bk	3
		2004-24-04		Bk	4
		2006-20-17			
250-C40B Series	E1GL	97-25-09		Bk	3
		2006-20-17			
250-C47B	E1GL	98-10-03		Bk	3
		2004-24-04		Bk	4
		2006-20-17			
250-C47M	E1GL	2004-24-04		Bk	4
		2006-20-17			
ROLLS-ROYCE LIMITED (See Allison Gas Turbine)					
GEM Mk 530 (Dart)	E-297	91-15-05		Bk	3
Gipsy Queen 30 Series	E-294	66-03-01		Bk	1
Gipsy Queen 70 Series	E-310	53-13-01		Bk	1
		68-02-01		Bk	1
RR C90	E3IN	72-25-02		Bk	1
		94-05-05	R1	Bk	3
RR O-200 Series	E3IN	72-25-02		Bk	1
		94-05-05	R1	Bk	3
		96-12-06		Bk	3
O-240 Series	E11EU	93-22-05		Bk	3
RR O-300	E4IN	72-25-02		Bk	1
		94-05-05	R1	Bk	3
IO-360 Series	--	97-26-17		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
RR TSIO-360 Series	--	92-04-09		Bk	3
		97-26-17		Bk	3
AE 2100A, AE 2100C, AE 2100D3	TE1CH	2001-17-31		Bk	4
AE 3007A and AE 3007C	TE6CH	2001-17-31		Bk	4
SOCIETE DE MOTORISATIONS AERONAUTIQUES					
SR305-230		2006-23-08			
SR305-230-1		2006-23-08			
TELEDYNE CONTINENTAL MOTORS					
A-65 Series	E-205	46-36-01		Bk	1
		81-07-06		Bk	2
		95-21-15		Bk	3
		98-17-11		Bk	3
A-75 Series	E-213	46-36-01		Bk	1
		81-07-06		Bk	2
		98-17-11		Bk	3
A-80	217	46-36-01		Bk	1
A-100	E-241	81-07-06		Bk	2
C-75 and C-85 Series	E-233	47-40-02		Bk	1
		49-50-01		Bk	1
		81-07-06		Bk	2
		93-22-05		Bk	3
		94-05-05	R1	Bk	3
		95-21-15		Bk	3
		98-17-11		Bk	3
C-90 Series	E-252	49-50-01		Bk	1
		81-07-06		Bk	2
		93-22-05		Bk	3
		94-05-05	R1	Bk	3
		98-17-11		Bk	3
O-200 Series	E-252	81-07-06		Bk	2
		93-10-02		Bk	3
		93-11-03		Bk	3
		93-22-05		Bk	3
		94-05-05	R1	Bk	3
		95-21-15		Bk	3
		96-12-06		Bk	3
		98-17-11		Bk	3
O-240 Series	--	93-22-05		Bk	3
C-125 Series	E-236	47-40-02		Bk	1
		49-50-01		Bk	1
		81-07-06		Bk	2
		94-05-05	R1	Bk	3
		2002-13-04		Bk	4
C-145 Series	E-253	49-50-01		Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
		50-20-01		Bk	1
		94-05-05	R1	Bk	3
		2002-13-04		Bk	4
O-300 Series	E-253	93-10-02		Bk	3
		93-11-03		Bk	3
		94-05-05	R1	Bk	3
		95-21-15		Bk	3
		98-17-11		Bk	3
		2002-13-04		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
GO-300	E-298	94-05-05	R1	Bk	3
		95-21-15		Bk	3
E-165 Series	E-246	50-32-01		Bk	1
		60-06-04		Bk	1
		63-15-01		Bk	1
		97-21-02		Bk	3
E-185 Series	E-246	50-32-01		Bk	1
		51-26-03		Bk	1
		56-06-01		Bk	1
		60-06-04		Bk	1
		60-12-01		Bk	1
		63-15-01		Bk	1
		95-21-15		Bk	3
		97-21-02		Bk	3
		98-17-11		Bk	3
E-225 Series	E-267	56-06-01		Bk	1
		60-06-04		Bk	1
		60-12-01		Bk	1
		63-15-01		Bk	1
		97-21-02		Bk	3
		98-17-11		Bk	3
IO-360 Series	E1CE	70-14-07		Bk	1
		74-18-07		Bk	1
		81-13-10	R1	Bk	2
		88-03-06		Bk	2
		91-19-03		Bk	3
		92-04-09		Bk	3
		93-10-02		Bk	3
		95-21-15		Bk	3
		97-26-17		Bk	3
		98-17-11		Bk	3
		98-19-02		Bk	3
		2000-23-21		Bk	4
		2002-13-04		Bk	4
TSIO-360 Series	E9CE	71-09-03		Bk	1
		74-18-07		Bk	1
		74-18-08		Bk	1
		81-13-10	R1	Bk	2
		81-23-02		Bk	2
		88-03-06		Bk	2
		91-19-03		Bk	3
		92-04-09		Bk	3
		93-10-02		Bk	3
		95-08-10		Bk	3
		95-21-15		Bk	3
		97-26-17		Bk	3
		98-19-02		Bk	3
		2000-23-21		Bk	4
		2002-13-04		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
LTSIO-360 Series	E9CE	81-13-10	R1		2
		81-23-02		Bk	2
		91-19-03		Bk	3
		92-04-09		Bk	3
		93-10-02		Bk	3
		95-08-10		Bk	3
		97-26-17		Bk	3
		98-19-02		Bk	3
		2000-23-21		Bk	4
IO-346	E3CE	91-19-03		Bk	3
IO-346A	E3CE	72-24-03		Bk	1
		79-05-09		Bk	1
		95-03-14		Bk	3
IO-346B	E3CE	95-03-14		Bk	3
O-470 Series	E-273	56-06-01		Bk	1
		63-15-01		Bk	1
		73-13-04		Bk	1
		79-05-09		Bk	1
		85-08-02		Bk	2
		88-03-06		Bk	2
		91-19-03		Bk	3
		93-08-17		Bk	3
		93-10-02		Bk	3
		95-21-15		Bk	3
		96-12-04		Bk	3
		97-21-02		Bk	3
		98-01-08	L	Bk	3
		98-17-11		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
IO-470 Series	3E1	70-14-07		Bk	1
		72-20-02		Bk	1
		77-05-04		Bk	1
		79-05-09		Bk	1
		85-08-02		Bk	2
		88-03-06		Bk	2
		91-19-03		Bk	3
		93-08-17		Bk	3
		93-10-02		Bk	3
		95-21-15		Bk	3
		97-21-02		Bk	3
		98-01-08	L	Bk	3
		98-17-11		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
IO-470-A, -C	E-273	79-05-09		Bk	1
L/IO-470	3E1	91-19-03		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
TSIO-470 Series	3E3	70-14-07		Bk	1
		72-20-02		Bk	1
		75-09-13		Bk	1
		88-03-06		Bk	2
		91-19-03		Bk	3
		93-10-02		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
IO-520 Series	E5CE	70-14-07		Bk	1
		72-24-03		Bk	1
		77-05-04		Bk	1
		77-13-22		Bk	1
		79-05-09		Bk	1
		80-01-04		Bk	2
		81-24-06		Bk	2
		86-13-04	R3	Bk	2
		87-14-02		Bk	2
		88-03-06		Bk	2
		88-17-03		Bk	2
		91-19-03		Bk	3
		93-08-17		Bk	3
		93-10-02		Bk	3
		93-16-15		Bk	3
		95-03-14		Bk	3
		95-21-15		Bk	3
		97-26-17		Bk	3
		98-01-08	L	Bk	3
		98-17-11		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
		2004-08-10		Bk	4
LIO-520 Series		97-26-17		Bk	3
		2004-08-10		Bk	4
GTSIO 520 Series	E7CE	75-09-13		Bk	1
		77-13-22		Bk	1
		79-05-09		Bk	1
		80-09-11		Bk	2
		80-25-06	R1	Bk	2
		81-24-06		Bk	2
		86-13-04	R3	Bk	2
		87-04-05		Bk	2
		88-03-06		Bk	2
		91-19-03		Bk	3
		93-10-02		Bk	3
		95-21-15		Bk	3
		98-17-11		Bk	3
		99-19-01		Bk	3
		2004-08-10		Bk	4
		2005-20-04		BW	05-20
TSIO-520 Series	E8CE	69-18-05		Bk	1
		70-13-03		Bk	1
		71-09-03		Bk	1
		72-24-03		Bk	1
		75-09-13		Bk	1
		76-13-09		Bk	1
		77-05-04		Bk	1
		77-13-22		Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
TSIO-520 Series continued		78-06-01		Bk	1
		79-05-09		Bk	1
		80-01-04		Bk	2
		80-22-05		Bk	2
		81-24-06		Bk	2
		82-09-01		Bk	2
		84-19-04	L	Bk	2
		84-25-05		Bk	2
		86-08-07		Bk	2
		86-13-04	R3	Bk	2
		87-14-02		Bk	2
		87-26-08		Bk	2
		88-03-06		Bk	2
		88-17-03		Bk	2
		89-14-01		Bk	2
		89-24-01	R1	Bk	2
		89-24-03		Bk	2
		91-19-03		Bk	3
		93-08-17		Bk	3
		93-10-02		Bk	3
		93-16-15		Bk	3
		95-21-15		Bk	3
		97-26-17		Bk	3
		98-01-08	L	Bk	3
		98-17-11		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
		2004-08-10		Bk	4
LTSIO-520	E8CE	91-19-03		Bk	3
		93-10-02		Bk	3
		97-26-17		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
		2002-13-04		Bk	4
		2004-08-10		Bk	4
IO-550	E350	86-13-04	R3	Bk	2
		87-14-02		Bk	2
		88-03-06		Bk	2
		88-17-03		Bk	2
		91-19-03		Bk	3
		93-08-17		Bk	3
		93-10-02		Bk	3
		93-16-15		Bk	3
		95-03-14		Bk	3
		95-21-15		Bk	3
		98-01-08	L	Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
		2004-08-10		Bk	4
TSIO-550	E5SO	93-10-02		Bk	3
		93-16-15		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
		2004-08-10		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
TSIOL-550 Series	E4SO	93-10-02		Bk	3
		93-16-15		Bk	3
		99-19-01		Bk	3
		2000-23-21		Bk	4
		2004-08-10		Bk	4
R-670 Series	ATC 80	95-21-15		Bk	3
W-670-9A	E-162	53-09-04		Bk	1
6-285 Series	E12CE	74-22-04		Bk	1
		79-05-09		Bk	1
		91-19-03		Bk	3
TEXTRON LYCOMING					
(See Honeywell International)					
(See AVCO) (See ALLIEDSIGNAL)					
All four cylinder piston engines equipped with rear propeller gov. and external oil line	- -	90-04-06	R1	Bk	3
Specific U.S. registered aircraft with reciprocating engines - see AD		95-26-02		Bk	3
Direct drive piston engines (some exceptions - - see AD)	- -	2004-10-14		Bk	4
All series	- -	78-23-10		Bk	1
(ADs in Avco and Textron)		79-04-05		Bk	1
320 Series		98-02-08		Bk	3
360 Series		98-02-08		Bk	3
O-290 Series	E-229	54-02-01		Bk	1
(Bk 1 ADs in Avco and Textron)		75-08-09		Bk	1
		96-09-10		Bk	3
		98-17-11		Bk	3
O-340 Series	277	59-10-07		Bk	1
(Bk 1 ADs in Avco and Textron)		64-16-05		Bk	1
		66-20-04		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
IVO-360 Series	1E1	67-22-06		Bk	1
(Bk 1 ADs in Avco and Textron)		68-08-08		Bk	1
		75-08-09		Bk	1
		75-09-15		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4
VO-360 Series	1E1	68-08-08		Bk	1
(Bk 1 ADs in Avco and Textron)		75-08-09		Bk	1
		87-10-06	R1	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
TIO-360 Series	E16EA	73-23-01		Bk	1
(Bk 1 ADs in Avco and Textron)		75-08-09		Bk	1
		75-09-15		Bk	1
		91-08-07		Bk	3
		92-12-05		Bk	3
		95-07-01		Bk	3
		96-09-10		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
LTIO-360 Series		97-15-11		Bk	3
		2003-14-03		Bk	4
LTO-360 Series	E26EA	80-04-03	R2	Bk	2
		92-12-05		Bk	2
		96-09-10		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
TO-360 Series	E26EA	80-02-13		Bk	2
		80-04-03	R2	Bk	2
		92-12-05		Bk	3
		96-09-10		Bk	3
		96-23-03		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
GO-435 Series	E-228	51-24-01		Bk	1
(Bk 1 ADs in Avco and Textron)		62-23-05		Bk	1
		69-25-08		Bk	1
		2003-14-03		Bk	4
VO-435 Series	E-279	68-08-08		Bk	1
(Bk 1 ADs in Avco and Textron)		80-04-04	R1	Bk	2
IVO-435 Series		98-17-11		Bk	3
TVO-435 Series	1E13	68-08-08		Bk	1
(Bk 1 ADs in Avco and Textron)		80-04-04	R1	Bk	2
GO-480 Series	E-275	59-10-07		Bk	1
(Bk 1 ADs in Avco and Textron)		60-11-06		Bk	1
		62-23-05		Bk	1
		69-25-08		Bk	1
		73-23-01		Bk	1
		92-12-05		Bk	3
		97-15-11		Bk	3
		2003-14-03		Bk	4
O-480 Series		92-12-05		Bk	3
		97-15-11		Bk	3
IGO-480 Series	E-275	62-23-05		Bk	1
(Bk 1 ADs in Avco and Textron)		75-09-15		Bk	1
		92-12-05		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4
		2003-14-03		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
GSO-480 Series	E-284	59-10-07		Bk	1
(Bk 1 ADs in Avco and Textron)		60-11-06		Bk	1
		62-23-05		Bk	1
		69-25-08		Bk	1
		92-12-05		Bk	3
		97-15-11		Bk	3
IGSO-480 Series	E-284	59-10-07		Bk	1
(Bk 1 ADs in Avco and Textron)		62-23-05		Bk	1
		68-08-08		Bk	1
		69-25-08		Bk	1
		73-23-01		Bk	1
		81-03-05		Bk	2
		92-12-05		Bk	3
		97-15-11		Bk	3
LIO-540 Series	---	73-23-01		Bk	1
(Bk 1 ADs in Avco and Textron)		96-23-03		Bk	3
IGO-540 Series	1E11	62-23-05		Bk	1
(Bk 1 ADs in Avco and Textron)		69-25-08		Bk	1
		73-23-01		Bk	1
		74-13-05		Bk	1
		75-09-15		Bk	1
		81-03-05		Bk	2
		92-12-05		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4
		2003-14-03		Bk	4
IGSO-540 Series	1E7	62-23-05		Bk	1
(Bk 1 ADs in Avco and Textron)		69-25-08		Bk	1
		72-21-06		Bk	1
		73-23-01		Bk	1
		74-13-05		Bk	1
		81-03-05		Bk	2
		92-12-05		Bk	3
		97-15-11		Bk	3
IVO-540 Series	E11EA	68-08-08		Bk	1
(Bk 1 ADs in Avco and Textron)		73-05-01		Bk	1
		75-09-15		Bk	1
		80-04-04	R1	Bk	2
		92-12-05		Bk	3
		95-07-01		Bk	3
		97-15-11		Bk	3
		2002-26-01		Bk	4
VO-540 Series	E-304	62-03-02		Bk	1
(Bk 1 ADs in Avco and Textron)		68-08-08		Bk	1
		73-05-01		Bk	1
		73-23-01		Bk	1
		80-04-04	R1	Bk	2
		92-12-05		Bk	3
		97-15-11		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
TIO-541 Series	E10EA	73-23-01		Bk	1
(Bk 1 ADs in Avco and Textron)		83-22-04		Bk	2
		91-08-07		Bk	3
		92-12-05		Bk	3
		95-07-01		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
TIGO-541 Series	E19EA	73-23-01		Bk	1
(Bk 1 ADs in Avco and Textron)		83-22-04		Bk	2
		91-08-07		Bk	3
		92-12-05		Bk	3
		97-15-11		Bk	3
		2002-12-07		Bk	4
		2003-14-03		Bk	4
IO-720 Series	1E15	73-23-01		Bk	1
(Bk 1 ADs in Avco and Textron)		75-09-15		Bk	1
		92-12-05		Bk	3
		95-07-01		Bk	3
		97-15-11		Bk	3
		98-17-11		Bk	3
		2002-12-07		Bk	4
		2002-26-01		Bk	4
		2003-14-03		Bk	4
TIO-720 Series		2003-14-03		Bk	4
TURBOMECA					
Astazou IIA	E2IN	76-09-05		Bk	1
Arriel 1, 1A, 1A1, 1A2	E19EU	94-25-08		Bk	3
		2000-20-01		Bk	4
		2002-14-26		Bk	4
		2003-03-12		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
Arriel 1B, 1B2	E19EU	91-24-02		Bk	3
		94-25-08		Bk	3
		2000-20-01		Bk	4
		2002-14-26		Bk	4
		2003-11-08		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
		2006-02-08		BW	06-03
		2006-06-17		BW	06-07
		2006-02-08	R1		
Arriel 1C, 1C1, 1C2	E19EU	2000-20-01		Bk	4
		2003-03-12		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
Arriel 1D, 1D1	E19EU	91-24-02		Bk	3
		94-25-08		Bk	3
		2000-20-01		Bk	4
		2002-14-26		Bk	4
		2003-03-12		Bk	4
		2003-11-08		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
		2006-02-08		BW	06-03
		2006-06-17		BW	06-07
		2006-02-08	R1		
Arriel 1E	E19EU	2003-12-14		Bk	4
Arriel 1E2	E19EU	2003-03-12		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
Arriel 1K	-	2000-20-01		Bk	4
		2003-03-12		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
Arriel 1K1	E19EU	2000-20-01		Bk	4
		2003-03-12		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
Arriel 1S, 1S1	E19EU	2000-20-01		Bk	4
		2003-03-12		Bk	4
		2003-12-14		Bk	4
		2003-16-03		Bk	4
		2006-02-08		BW	06-03
		2006-02-08	R1		
Arriel 2S1, 2B, 2C	E00054EN	2002-16-25		Bk	4
Arriel 2B, 2B1	E00054EN	2003-03-12		Bk	4
		2005-13-25		BW	05-13
		2005-25-13		BW	05-25
Arriel 2C, 2C1	E00054EN	2003-03-12		Bk	4
Arriel 2S1 Series	E00054EN	2003-03-12		Bk	4
Arrius 1A	E34NE	2000-06-09		Bk	4
		2002-01-02		Bk	4
		2005-11-01		BW	05-11
Arrius 2B, 2B1	E34NE	2001-08-14	R1	BW	06-02
		2003-19-06		Bk	4
		2005-12-08		BW	05-13
		2006-21-10			
Arrius 2B1A, 2B1A1	E34NE	2003-19-06		Bk	4
		2005-12-08		BW	05-13
		2006-21-10			
Arrius 2 B2		2005-12-08		BW	05-13
Arrius 2K1	E34NE	2003-19-06		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK NO.
Arrius 2F	E34NE	2001-08-14	R1	BW 06-02
		2003-11-10		Bk 4
		2005-09-51		BW 05-11
		2005-19-10		BW 05-19
		2005-17-15		BW 05-18
		2005-17-17		BW 05-18
Artouste II Series	E-300	2001-12-19		Bk 4
		2005-17-06		BW 05-18
Artouste III Series	E1IN	2001-12-19		Bk 4
		2005-26-13		BW 06-01
		2006-04-15		BW 06-05
Astazou XIV B AND XIV H	E13EU	2005-25-12		BW 05-25
Makila 1A, 1A1	E12NE	2000-06-11		Bk 4
		2002-15-05		Bk 4
		2002-19-02		Bk 4
Makila 1A2	E12NE	2002-15-05		Bk 4
		2002-19-02		Bk 4
		2006-07-20		BW 06-08
Turmo IV A, IV C Series	E10EU	2003-11-09		Bk 4
		2006-21-11		
		2006-23-17		
WARNER DIVISION, CLINTON MACHINE CO.				
(See Olson, George ,Co.)				
WILLIAMS INTERNATIONAL				
FJ44-1A	E3GL	97-01-05		Bk 3
		99-07-04		Bk 3
WRIGHT AERONAUTICAL DIV.				
(See Curtiss-Wright)				
C9GB Series	TC 192	51-12-01		Bk 1
Military R-1300 Series	TC 5E-14	59-12-07		Bk 1
Military R-1820 Series	TC 5E-10	51-12-01		Bk 1
		60-07-08		Bk 1
WYTWORNIA SPRZETU KOMUNIKACYJNEGO				
(Formerly Franklin Engine Co.)				
(TC E-238, E-244 - for ADs in Book 1 and 2 see Franklin Engine Co.)				
Franklin 6A4-150 Series	E-238	48-50-01		Bk 1
Affects specific U.S. Registered aircraft - see AD		96-02-04		Bk 3
Franklin 6A4-165 Series	E-238	51-15-02		Bk 1
Affects specific U.S. Registered aircraft - see AD		96-02-04		Bk 3
Franklin 6V4-178 Series	E-244	51-28-02		Bk 1
Franklin 6V4-200 Series	E-244	51-28-02		Bk 1
PZL-3S	E18EU	83-21-01		Bk 2
		86-10-12		Bk 2
		94-02-06		Bk 3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER *	BOOK NO.

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL ENGINE MAKE & MODEL	TC NO.	AD NUMBER *	BOOK	NO.
Franklin 6A-350-C1, -C1A, -C1L, -C1R -C2, -C2A,	E9EA	2003-05-01	Bk	4
4A-235 Series	E6EA	2003-05-01	Bk	4
PZL-10W	E43NE	2003-18-04	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

AIRWORTHINESS DIRECTIVE SUMMARY SUBJECT INDEX

PROPELLERS APPLICABLE TO

SMALL AIRCRAFT AND ROTORCRAFT

JANUARY 2007

* * * * * * * * * *

The indexes, which are published twice a year, are intended to be used as a guide only and should not be relied upon as conclusive evidence of AD applicability. Aircraft operators, inspectors, and persons performing maintenance are reminded of their responsibility under Sections 39.3, 43.11, and 43.13 of the Federal Aviation Regulations, respectively, to assure compliance with all applicable AD's.

* * * * * * * * * *

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
BEECH AIRCRAFT CORPORATION					
(See Raytheon Aircraft Co.)					
DOWTY AEROSPACE PROPELLERS					
R321	P61GL	2004-13-01		Bk	4
		2005-25-10		BW	05-25
R324	P61GL	2004-13-01		Bk	4
		2005-25-10		BW	05-25
R333	P61GL	2004-13-01		Bk	4
		2005-25-10		BW	05-25
R334	P61GL	2004-13-01		Bk	4
DOWTY ROTOL					
R---/4-30-4/--	P-899	76-18-03		Bk	1
CR289/3-110-F/1,/11	P6EU	81-05-04		Bk	2
		81-07-09		Bk	2
		81-13-05		Bk	2
FLOTTORP MANUFACTURING CO.					
(See Univair Aircraft Corp)					
FREEDMAN AIRCRAFT ENGINEERING CORP.					
PC-203	TC 704	48-48-01		Bk	1
PX-203	TC 746	48-48-01		Bk	1
PY-203	TC 747	48-48-01		Bk	1
HAMILTON STANDARD					
Propeller Blades		50-12-01		Bk	1
		56-22-01		Bk	1
		57-13-05		Bk	1
		58-22-01		Bk	1
		81-13-06	R2	Bk	2
		84-25-06		Bk	2
54H60 Series	P-906	98-24-34		Bk	3

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
HARTZELL PROPELLER INC.					
()HC–()(2,3,4)Y()–(), ()HC–()(2,3,4)(X,V,MV, W,Z,P,R) (F,G,L,K,R,20,30,31)–(), ()HA–()–(), HC–B(3,4)(M,P,R,T)(A,N,P)–(), HC–(D,E)(4,5) (A,B,N,P)–().		2005-14-11		BW	05-15
( )HC( )( )y( )	- -	2001-07-03		Bk	4
(All HC models with y shank blades)		2001-23-08		Bk	4
		2002-09-08		Bk	4
		2006-18-15			
( )HC-( )( )(x,v)	--	85-14-10	R2	Bk	2
(All HC models with x or v shank blades)					
( )HC-( )(2,3)(X,V)( )-( ) Series	--	97-18-02	R1	Bk	3
			(see Bk 4 for paper copy)		
BHC-A2VF-1	P24EA	2003-13-17		Bk	4
BHC-92 Series		2005-18-12		BW	05-19
BHC-B3W		2005-18-12		BW	05-19
HA-A2V20-1B Series	P59GL	97-18-02	R1	Bk	3
			(see Bk 4 for paper copy)		
HA-B3Z		2005-18-12		BW	05-19
HC-A2V Series	P24EA	2003-13-17		Bk	4
HC-B3M Series	P9EA	96-18-14		Bk	4
			(See Bk 4 for paper copy)		
		2005-14-12		BW	05-15
HC-B3T Series	P15EA	83-08-01	R2	BW	05-08
		86-05-12		Bk	2
		88-24-15		Bk	2
		96-15-04		Bk	3
		96-18-14		Bk	4
			(See Bk 4 for paper copy)		
		2003-04-23		Bk	4
		2005-04-08		BW	05-05
		2005-14-12		BW	05-15
HC-A3V Series	P6EA	96-18-14		Bk	4
			(See Bk 4 for paper copy)		
		2003-13-17		Bk	4
()HC-()2Y()-()	P-920	2003-01-03		Bk	4
HC-( )3Y( )-( ) Series	P25EA	94-17-13		Bk	3
	P31EA				
	P33EA				
HC-B4 Series	P40EA	94-03-11		Bk	3
	P56GL				

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
HC-B4T Series	P40EA	83-08-01	R2	BW	05-08
		87-15-05	R1	Bk	2
		95-01-02		Bk	3
		95-03-03		Bk	3
		96-18-14		Bk	4
		2003-13-17		Bk	4
			(See Bk 4 for paper copy)		
		2005-14-12		BW	05-15
HC-B4M Series	P56GL	83-08-01	R2	BW	05-08
		87-15-04		Bk	2
		96-18-14		Bk	4
			(See Bk 4 for paper copy)		
		2005-14-12		BW	05-15
HC-B5M Series	P44GL	83-08-01	R1	Bk	2
		96-15-04		Bk	3
		96-18-14		Bk	4
			(See Bk 4 for paper copy)		
		2005-14-12		BW	05-15
		2006-22-12			
HC-B3Z Series	P-907	61-03-03		Bk	1
		63-13-03		Bk	1
		67-06-04		Bk	1
BHC-C2Y Series	P-920	2003-13-17		Bk	4
HC-C2Y	P-920	64-20-01		Bk	1
		2003-03-20		Bk	4
		2003-06-02		Bk	4
		2003-13-17		Bk	4
HC-E2Y Series	P9EA	64-20-01		Bk	1
		71-21-09		Bk	1
		2003-13-17		Bk	4
HC-F2Y Series	P27EA	2003-13-17		Bk	4
HC-F3Y Series	P31EA	2003-13-17		Bk	4
HC-M2Y Series	P43GL	2003-13-17		Bk	4
HC-12V20 Series	P46GL	2003-13-17		Bk	4
HC-12MV Series	-	2003-13-17		Bk	4
HC-12X20 Series	P-845	56-17-03		Bk	1
		58-07-01		Bk	1
		59-01-03		Bk	1
		59-26-01		Bk	1
		64-28-01		Bk	1
		65-21-04		Bk	1
HC-13X20 Series	P-888	58-07-01		Bk	1
		59-01-03		Bk	1
HC-82V Series	-	2003-13-17		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER *	BOOK	NO.
HC-82X	P-878	53-15-03	Bk	1
		58-06-02	Bk	1
		58-07-01	Bk	1
		58-09-02	Bk	1
		59-01-03	Bk	1
		59-09-03	Bk	1
		60-16-04	Bk	1
HC-B3W Series	P2EA	67-06-04	Bk	1
HC-B3T Series	P15EA	2003-13-17	Bk	4
HC-Y2R Series	-	2003-13-17	Bk	4
HC-82V Series	-	2003-13-17	Bk	4
HC-83V Series	-	2003-13-17	Bk	4
HC-83X Series	P-884	57-08-04	Bk	1
		58-07-01	Bk	1
		59-01-03	Bk	1
HC-92VF Series	-	2003-13-17	Bk	4
HC-92WK-( )	P16EA	95-11-08	Bk	3
HC-92W Series		2005-18-12	BW	05-19
HC-92Z Series	P-892	60-16-04	Bk	1
		95-11-08	Bk	3
		2003-13-17	Bk	4
		2005-18-12	BW	05-19
HC-93Z Series	P-891	57-08-04	Bk	1
		58-04-02	Bk	1
		61-03-03	Bk	1
		63-13-03	Bk	1
		67-06-04	Bk	1
HC-B3 Series		2005-18-12	BW	05-19
HC-B3R Series	P28EA	2003-13-17	Bk	4
		2005-18-12	BW	05-19
HC-C3Y Series	P25EA	2003-13-17	Bk	4
HC-E3Y Series	P33EA	2003-13-17	Bk	4
HC-D4N	P10NE	96-15-04	Bk	3
HC-E4A	P10NE	94-10-01	Bk	3
		96-15-04	Bk	3
		98-02-07	Bk	3
		98-17-04	Bk	3
EHC-G3Y Series	P55GL	2003-13-17	Bk	4
PHC-A3V Series	P6EA	2003-13-17	Bk	4
PHC-C3Y Series	P25EA	2003-13-17	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER *	BOOK	NO.
PHC-J3Y Series	P36EA	2003-13-17	Bk	4
PHC-L3Y Series	P41EA	2003-13-17	Bk	4
T10176 Blades	- -	70-05-06	Bk	1
		72-08-04	Bk	1
T10176H Blades	- -	70-05-06	Bk	1
		74-14-01	Bk	1
T10173 Blades	- -	72-08-04	Bk	1
T10173H Blades	- -	74-14-01	Bk	1
T10178H Blades	- -	74-14-01	Bk	1
T10282H Blades	- -	74-14-01	Bk	1
HOFFMANN GmbH & CO. KG				
HO27( ) Series	P3EU	2000-04-10	Bk	4
HO4/27 Series	P6NE	2000-04-10	Bk	4
HO-V343	P12BO	2004-18-01	Bk	4
		2005-13-01	BW 05-13	
HO-V343K	---	2004-18-01	Bk	4
		2005-13-01	BW 05-13	
KOPPER AEROMATIC PROPS				
(See UNIVAIR AIRCRAFT)				
McCAULEY INDUSTRIAL CORP.				
()2()()3()C()()()–(): All constant speed two-bladed propeller models. ()3()()3()C()()()–(): All constant speed three-bladed propeller models. 1()()()()/(): All metal propeller models.		2005-14-11	BW 05-15	
41D5926 Hubs	Group 3-4	54-12-02	Bk	1
		2003-13-17	Bk	4
D1093 Hubs	TC 815	54-12-02	Bk	1
1A170	P-857	82-27-01	Bk	2
		2003-13-17	Bk	4
1A175	P-857	2003-13-17	Bk	4
1A100	P-918	2003-13-17	Bk	4
1A101	P-918	2003-13-17	Bk	4
1A102	P-918	2003-13-17	Bk	4
1A103	P50GL	89-26-10	Bk	2
		2003-12-05	Bk	4
		2003-13-17	Bk	4
1C160/CTM Series	P-910	2003-13-17	Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
1C160/DTM Series	P-910	2003-13-17		Bk	4
1C172/EM Series	P-910	2003-13-17		Bk	4
1C172/MDM	P-910	2003-13-17		Bk	4
1C172/MTM Series	P-910	2003-13-17		Bk	4
1C172/SBTM Series	P-910	2003-13-17		Bk	4
1C172/TM Series	P-910	2003-13-17		Bk	4
1C235 Series	P12EA	2003-13-17		Bk	4
1B90 Series	P-842	2003-13-17		Bk	4
2AF36C Series	P-911	63-10-04		Bk	1
		2003-13-17		Bk	4
2A36 Series	P-880	64-24-04		Bk	1
		68-08-01		Bk	1
		77-16-01		Bk	1
2A36C	P-880	83-24-11	R1	Bk	2
		98-25-13		Bk	3
		2003-13-17		Bk	4
B2A36 Series	P-880	64-24-04		Bk	1
		68-08-01		Bk	1
C2A36 Series	P-880	64-24-04		Bk	1
		68-08-01		Bk	1
D2A36 Series	P-880	64-24-04		Bk	1
		68-08-01		Bk	1
		77-16-01		Bk	1
2D36 Series	P-901	64-24-04		Bk	1
		70-04-01		Bk	1
		77-16-01		Bk	1
2A37C223/90RB	P3EA	95-09-08		Bk	3
D2A34C Series	P3EA	68-08-01		Bk	1
		68-10-03		Bk	1
		77-13-17		Bk	1
		77-16-01		Bk	1
		91-15-04		Bk	3
		2003-13-17		Bk	4
		2005-24-09		BW 05-25	
2A34C Series	P3EA	68-08-01		Bk	1
		77-13-17		Bk	1
		77-16-01		Bk	1
		82-27-02	R1	Bk	2
		83-24-11	R1	Bk	2
		91-15-04		Bk	3
		2003-13-17		Bk	4
C2A34C	P3EA	82-27-02	R1	Bk	2
		91-15-04		Bk	3
		2003-13-17		Bk	4

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
E2A34C Series	P3EA	68-08-01		Bk	1
		72-25-07		Bk	1
		77-16-01		Bk	1
		83-24-11	R1		2
		91-15-04		Bk	3
F2A34C Series	P3EA	77-16-01		Bk	1
		91-15-04		Bk	3
D2AF34C Series	P5EA	68-10-03		Bk	1
		75-24-13		Bk	1
		77-13-17		Bk	1
		78-01-13		Bk	1
		82-27-02	R1	Bk	2
		91-15-04		Bk	3
		2003-13-17		Bk	4
D2AF36C Series	P-911	2003-13-17		Bk	4
2AF34C Series	P5EA	68-10-03		Bk	1
		71-18-02		Bk	1
		77-13-17		Bk	1
		91-15-04		Bk	3
		2003-13-17		Bk	4
2D34C Series	P7EA	68-08-01		Bk	1
		70-04-01		Bk	1
		77-16-01		Bk	1
		91-15-04		Bk	3
		2003-13-17		Bk	4
		2005-24-09		BW	05-25
B2D34C Series	P7EA	70-04-01		Bk	1
		82-27-02	R1	Bk	2
		91-15-04		Bk	3
		2003-13-17		Bk	4
B2D37C Series	P7EA	2003-13-17		Bk	4
B3D32C Series	P58GL	2003-13-17		Bk	4
C3D36C Series	P58GL	2003-13-17		Bk	4
3A32C Series	P21EA	68-08-01		Bk	1
		2003-13-17		Bk	4
D3A32C Series	P21EA	68-08-01		Bk	1
		71-17-03		Bk	1
		77-13-17		Bk	1
		85-08-08		Bk	2
		2003-13-17		Bk	4
		2005-24-09		BW	05-25
3AF32C	P22EA	77-13-17		Bk	1
		83-13-06		Bk	2
		95-24-05	R1	Bk	3
		2003-13-17		Bk	4
		2005-24-09		BW	05-25
D3AF32C	P22EA	77-13-17		Bk	1
		95-24-05	R1	Bk	3
		2005-24-09		BW	05-25

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
3AF34C	P22EA	77-13-17		Bk	1
		95-24-05	R1	Bk	3
		2003-13-17		Bk	4
		2005-24-09		BW 05-25	
D3A34C	P47GL	77-26-03		Bk	1
		82-27-02	R1	Bk	2
		2003-13-17		Bk	4
3FF32C	P45GL	78-06-02		Bk	1
		2003-13-17		Bk	4
4HFR34C	P3NE	2000-15-10		Bk	4
L106FA-0	-	2000-15-10		Bk	4
B2334C53-0	-	2003-13-17		Bk	4
3PF32C501-A	-	2003-13-17		Bk	4
MT-PROPELLER ENTWICKLUNG GmbH & CO. KG					
MT	P19BO	2006-05-05		BW 06-06	
MTV-1	P25BO	2006-05-05		BW 06-06	
MTV-3	TP4BO	97-21-01	R1	Bk	3
		2002-23-09		Bk	4
		2006-05-05		BW 06-06	
MTV-6	P19NE	2006-05-05		BW 06-06	
MTV-7	P20BO	2006-05-05		BW 06-06	
MTV-9	P24NE	2002-23-09		Bk	4
		2006-05-05		BW 06-06	
MTV-12	P25NE	2006-05-05		BW 06-06	
MTV-14	P3BO	2006-05-05		BW 06-06	
MTV-15	P23BO	2006-05-05		BW 06-06	
MTV-18	P13BO	2006-05-05		BW 06-06	
MTV-21	P16BO	2006-05-05		BW 06-06	
MTV-25	P14BO	2006-05-05		BW 06-06	
RATIER-FIGEAC					
FH 76 Series	P11N	67-14-08		Bk	1
		67-24-04		Bk	1
RAYTHEON AIRCRAFT COMPANY					
(Formerly Beech Aircraft Corporation)					
(See Beech for ADs in Book 1 and 2)					
214	P-877	76-10-12		Bk	1
278	P-882	62-17-01		Bk	1
		77-11-03		Bk	1
		2003-13-17		Bk	4
B200	P-867	76-10-12		Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

SMALL PROPELLER MAKE & MODEL	TC NO.	AD NUMBER	*	BOOK	NO.
R201, R202, R203	P-807	76-10-12		Bk	1
SENSENICH CORP.					
All metal propeller models		2005-14-11		BW 05-15	
All fixed pitch metal propellers		66-23-02		Bk	1
M76A Series	1P2	54-05-02		Bk	1
M74D Series	P-886	60-11-08		Bk	1
		2003-13-17		Bk	4
76AM6 Series	1P2	2003-13-17		Bk	4
69CK Series	P-904	2003-13-17		Bk	4
M69CK Series	-	2003-13-17		Bk	4
M76EM Series	-	69-09-93	R3	Bk	1
72CK Serise	P-904	2003-13-17		Bk	4
76EM8 Series	P4EA	69-09-03	R3	Bk	1
		2003-13-17		Bk	4
74DM Series	P-886	2003-13-17		Bk	4
M74DM Series	-	2003-13-17		Bk	4
C-2F Series	TC 841	63-19-04		Bk	1
C-3F Series	TC 836	63-19-04		Bk	1
CS-2F Series	P-861	63-19-04		Bk	1
CS-3F Series	P-869	63-19-04		Bk	1
SOUTH 80 AVIATION					
(Formerly UNIVERSAL, KOPPERS)					
(See Kent Tarver)					
TARVER, KENT					
(Formerly Universal, Koppers, South 80 Avia.)					
TARVER PROPELLERS, LLC					
(Formerly Tarver, Kent, Formerly Universal, Koppers, South 80 Avia.)					
(See South 80 Avn for ADs in Bk 1)					
F200 Series	P-820	47-50-13		Bk	1
		50-34-01		Bk	1
		73-20-08		Bk	1
220 Series	P-833	73-20-08		Bk	1
TRW HARTZELL					
(See HARTZELL)					
UNIVAIR AIRCRAFT CORPORATION					
(See SOUTH 80 AVIATION)					
(Formerly FLOTTORP MANUFACTURING CO.)					
(For ADs in Bk 1 see Flottorp)					
F12 Series	P-902	64-07-03		Bk	1

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.

UNIVERSAL AIRCRAFT INDUSTRIES
(See UNIVAIR)

* T - telegraphic, L - letter, E - emergency, R(1) - indicating revision number since issue.